
HUMPHREY HEATING & ROOFING, INC. 2423 N. Marine Blvd. JACKSONVILLE, NORTH CAROLINA 28540-6999

OPERATION & MAINTENANCE REPLACE A/C UNITS, VARIOUS BUILDINGS MARINE CORPS AIR STATION, NEW RIVER JACKSONVILLE, NORTH CAROLINA N62470-86-C-5548

OPERATION & MAINTENANCE MANUAL

REPLACE A/C UNITS, VARIOUS BUILDINGS
MARINE CORPS AIR STATION, NEW RIVER
JACKSONVILLE, NORTH CAROLINA
N62470-86-C-5548



REPLACE A/C UNITS, VARIOUS BUILDINGS MARINE CORPS AIR STATION, NEW RIVER JACKSONVILLE, NORTH CAROLINA N62470-86-C-5548

PRIME CONTRACTOR:

Humphrey Heating & Roofing, Inc. 2423 North Marine Boulevard Jacksonville, NC 28540 - 6999

Phone: (919) 455-3555

SUB-CONTRACTOR:

Asbestos Removal

Waco, Incorporated Post Office Box 7160 Jacksonville, NC 28540

Phone: (919) 353-7574

SUB-CONTRACTOR:

Electrical

Big John's Electric Company Route 2, Box 260 - A

Jacksonville, NC 28540

Phone: (919) 455-2480

SUB-CONTRACTOR:

Acoustical Systems

Acoustics East, Inc. Post Office Box 3217 New Bern, NC 28560

Phone: (919) 638-8158

SUB-CONTRACTOR:

Insulation

Eastern Insulation Service of New Bern, Incorporated Post Office Box 3217 New Bern, NC 28560


Phone: (919) 638-8158

SUB-CONTRACTOR:

Controls

Triangle Controls 2716 Discovery Drive Raleigh, NC 27604 - 1850

Phone: (919) 878-8015



EQUIPMENT SUPPLIERS FOR:

REPLACE A/C UNITS, VARIOUS BUILDINGS MARINE CORPS AIR STATION, NEW RIVER JACKSONVILLE, NORTH CAROLINA N62470-86-C-5548

The Trane Company 5214 Western Blvd. Raleigh, NC 27606

Phone: (919) 851-4131

Central Station draw thru Air Handling Units; Condensing Units; Air Conditioners; Split System Condensing Units; Central Cooling Package System; Air Conditioner; Roof Top Accessories; Fresh Air Dampers; Time Delay Relay; Quick Attach Coupling Kit; Split System Condensing Units

Weeks - Williams - Devore 7000 Six Forks Road Raleigh, NC 27609 Phone: (919) 848-8367 Burnham Steel Boiler

Chet Adams Company Post Office Box 5218 Cary, NC 27511

Phone: (919) 851-6331

Exhaust Fans

Heat Transfer Sales 1305 Millbrook Road Building C, Suite #24 Raleigh, NC 27609

Phone: (919) 876-3846


Air Control System; Pumps; Heat Exchanger; Expansion Tanks; Tank Drainer

Trion, Incorporated Post Office Box 760 Sanford, NC 27330

Phone: (919) 775-2201 Electronic Air Cleaner

Governair Corporation 4840 North Sewell Street Oklahoma City, OK 73118

Phone: (405) 525-6546 Air Handling Equipment



Mec-Tric Controls Company 4110 Monroe Road Charlotte, NC 28222 Phone: (919) 376-8555 Farris Safety Valves

Frischkorn-Carolina, Inc. Post Office Box 10430 Wilmington, NC 28405

Phone: (919) 821-6150

Valves, Gauges, Thermometers, Traps, Circuit Setters, Strainers

Ihrie Supply Company, Inc. Post Office Box 1587 Morehead City, NC 28557

Phone: (919) 682-0033

Valves; Backflow Preventors

CC Dickson & Company 115 Moosehart Avenue Jacksonville, NC 28540

Phone: (919) 455-4996

Sight Glass; Filter Dryer

Industrial Maintenance Corp. 3520 Tryclan Drive Charlotte, NC 28210


Phone: (704) 525-6967

Chemical Feeder

Triangle Controls 2716 Discovery Drive Raleigh, NC 27604 - 1850

Phone: (919) 878-8015


Temperature Control System



REPLACE A/C UNITS, VARIOUS BUILDINGS MARINE CORPS AIR STATION, NEW RIVER JACKSONVILLE, NORTH CAROLINA N62470-86-C-5548

TABLE OF CONTENTS

- 1. <u>Central Station draw thru Air Handling Units</u> Maintenance and Installation Instructions.
- Condensing Units Installers Guide.
- Air Conditioning Units Reddie Facts.
- 4. Split System Condensing Units Installation, Operation & Maintenance Instructions and Service Facts.
- 5. <u>Central Cooling Package System</u> Installation, Operation and Maintenance Instructions.
- 6. Air Conditioners Service Facts.
- 7. Roof Top Accessories Installers Guide.
- 8. Fresh Air Dampers Installers Guide.
- 9. <u>Time Delay Relay</u> Installers Guide.
- 10. Quick Attach Coupling Kit Installers Guide.
- 11. Split System Condensing Units Installation, Operation and Maintenance Supplementary.
- 12. Burnham Steel Boiler Start-up, Operation, Maintenance Shut down and Repair Instructions.
- 13. Exhaust Fans Maintenance and Operating Instructions
 General Instructions, Terms & Conditions.
- 14. <u>Air Control System</u> General Information.
- 15. Pumps General Information.
- 16. <u>Heat Exchangers</u> General Information.
- 17. Expansion Tanks General Information.
- 18. <u>Tank Drainer</u> Features and Operation Instructions.
- 19. Electronic Air Cleaner Design, Installation, Operation Illustration & Drawings, Sequence of Operation and Control Schematic.




REPLACE A/C UNITS VARIOUS BUILDINGS

N62470-86-C-5548

TABLE OF CONTENTS (continued)

- 20. Air Handling Equipment Installation, Operation and Maintenance Instructions, Replacement Parts Guide, Troubleshooters Guide.
- 21. Farris Safety Valve User and Installation Manual, General Information.
- 22. Valves General Information.
- 23. Gauges General Information.
- 24. Thermometers General Information.
- 25. Traps General Information.
- 26. Circuit Setters General Information.
- 27. Strainers General Information.
- 28. Valves General Information.
- 29. Backflow Preventors Performance, Application, Construction, Warranty, Installation & Maintenance Instructions.
- 30. Sight Glass General Information.
- 31. Filter Dryer General Information.
- 32. Chemical Feeders Installation Figures.
- 33. <u>Temperature Control System</u> Sequence of Operation, Equipment Schedule, General Instructions.



EQUIPMENT LIST

REPLACE AIR CONDITIONING UNITS, VARIOUS BUILDINGS MARINE CORPS AIR STATION, NEW RIVER JACKSONVILLE, NORTH CAROLINA N62470-85-C-5548

BUILDING AS-236

Air Handler #1	Trane	Serial # K88B06604	5 Ton
		Model # CCDBOANBH	
Condensing Unit #1	Trane	Serial # C09298968	
		Model # TTA060A300A0	
Air Handler #2	Trane	Serial # K88B06605	4 Ton
		Model # CCDB06ANBH	
Condensing Unit #2	Trane	Serial # CC9298926	
		Model # TTA060A300A0	
Air Handler #3	Trane	Serial # K88C08421	1 ½ Ton
		Model # CCDB03BNBH	
Condensing Unit #3	Trane	Serial # C09276394	
		Model # TTB718A100A1	
Air Handler #4	Trane	Serial # K88B06606	15 Ton
		Model # CCDB14A3AG	
Condensing Unit #4	Trane	Serial # B15143825D	
		Model # BTA180F300AB	
Air Handler #5	Trane	Serial # K88C08422	5 Ton
		Model # CCDB03BNBH	
Condensing Unit #5	Trane	Serial # C09276210	
		Model # TTB718A100A1	
Air Handler #6	Trane	Serial # K88B06607	1 ½ Ton
		Model # CCDB03ANBH	
Condensing Unit #6	Trane	Serial # C11204558	
		Model # TTA048A300A0	
Hot Water Circulatin		Marie Control	
Pump	TACO	Serial # 7A88	
		Model # P56N4T10C2	
Electronic Filter	Trion	Serial # MOD71V-88-00006	
		Model # 71-206-D2	



EQUIPMENT LIST

REPLACE AIR CONDITIONING UNITS, VARIOUS BUILDINGS MARINE CORPS AIR STATION, NEW RIVER JACKSONVILLE, NORTH CAROLINA N62470-86-C-5548

BUILDING AS-3502

Air Handler Trane Serial # K88B06608 50 Ton
Model # CCDB31BNAG
Condensing Unit Trane Serial # J88B80443
Model # RAUBC506AE03

BUILDING AS-202

Air Handler Trane Serial # K88B06609 5 Ton

Model # CCDB03AB0H

Condensing Unit Trane Serial # B46295287

Model # TTA06DA300AD

BUILDING AS-502

Roof Mount A/C Unit Trane Serial # C10188896 10 Ton Model # BTC120F300HB

BUILDING AS-205

Air Handler	Govern	nair	Serial	#	25998	40	Ton
			Model	#	RSA-02		
Condensing Un	it Govern	nair	Serial	#	25997		
			Model	#	ACU-302		
Exhaust Fan #	1		Model	#	PV 83		
Exhaust Fan #	2		Model	#	PV 83		
Exhaust Fan #	3		Model	#	PV 83		
Hot Water Cir	culating						
Pump	TACO		Serial	#	YBM		
			Model	#	5K47PG1822AT		

EQUIPMENT LIST

REPLACE AIR CONDITIONING UNITS, VARIOUS BUILDINGS MARINE CORPS AIR STATION, NEW RIVER JACKSONVILLE, NORTH CAROLINA N62470-86-C-5548

BUILDING AS - 3504


Boiler

Hot Water Circulating Pump Serial # 18175

Model # 4FW-63-SPL-LB

Serial #FJ87

Model # M316P350




REPLACE AIR CONDITIONING UNITS MARINE CORPS AIR STATION, NEW RIVER JACKSONVILLE, NORTH CAROLINA N62470-86-C-5548

VALVE TAG LIST

BUILDING AS-3504

VALVE TAG	SIZE	TYPE	DESCRIPTION
301	2"	Gate	HWS Behind Pump
302	2"	Gate	HWR Before Pump
303	1"	Cut off Valve	Secondary Low Water Cut off
304	1"	Gate	Air Blender Valve
305	2"	Gate	HWR To Boiler
306	3/4"	Gate	Before Chemical Feeder Tank
307	3/4"	Gate	After Chemical Feeder Tank
308	3/4"	Gate	Drain
309	1"	Water Cut off	Primary Low Water Cut off
310	1"	Ball Valve	Drain
311	1/2"	Sight Glass	Boiler Sight Glass
312	1½"	Gate	Boiler Drain
313	3/8"	Gate	FOS
314	3/8"	Check	FOS
315	3/8"	Gate	FOS
316	1/2"	Gate	Drain
317	1/2"	FillaTank	Make up Water
318	3/4"	Check	Make up Water
319	3/4"	Gate	Make up Water
320	3/4"	PRV	Make up By pass
321	3/4"	Globe	Make up By pass
322	3/4"	Strainer with Blowdown Gate	Make up By pass
323	3/4"	Gate	Make up By pass
324	3/4"	Backflow Preventer	Make up By pass
325	3/4"	Relief Valve	Boiler
326	1/4"	Pet Cock	Chemical Feeder Tank



TAB PLACEMENT HERE

DE	SCRIPTION:
	Central Station
	Air Handling unit
	Tab page did not contain hand written information
Ďĺ	Tab page contained hand written information *Scanned as next image



Bldgs. 202 1286 13562

Installation


CLCH-IN-3A

Library	Service Literature
Product Section	Air Handling
Product	Central Station Air Handlers
Model	Climate Changers
Literature Type	Installation
Sequence	3A
Date	August 1986
File No.	SV-AH-CLCH-CLCH-IN-3A-886
Supersedes	CLCH-IN-3 (186)


CLIMATE CHANGER® CENTRAL STATION AIR HANDLERS

DRAW-THRU, BLOW-THRU SPRAYED COIL AND HIGH PRESSURE UNITS

B DEVELOPMENT SEQUENCE



DRAW-THRU



BLOW-THRU

X39640290-02

TABLE OF CONTENTS

ITEM	PAGE
GENERAL INFORMATION	2
RECEIVING AND HANDLING	
INSTALLATION	
Unit Location Recommendations	5
Mounting	6
Accessories	17
Fan Motor Assembly	
Dampers	
Inlet Vanes	
Ductwork	25
Piping	
Wiring	
INSTALLATION CHECKLIST	
START-UP	
Final Check/Procedures	38
Sheave Alignment	
Setscrews	38
Wheel Clamps	
Belt Tension	

Literature Change History:

CLCH-IM-10 (June 81)

Introduce infinity variable fin series. Change design sequence to "C".

CLCH-IN-2 (August 84)

Change bearing type (opposite drive side) on unit sizes 17 thru 31 w/stub shaft. Include weights for units with wide coils. Specific instructions for units shipping with optional coilless. Convert CLCH-IM-10C into separate Installation and Maintenance Manuals (CLCH-IN-2 & CLCH-M-1). Change design sequence to "D".

CLCH-IN-3 (January 1986)

Added level coils and Delta-Flo coils to units. Added cradle dimensions for wide coil unit sizes 3 thru 31. Added and updated Tables (4, 8A and 12). Change design sequence to "E".

CLCH-IN-3A (August 1986)

Corrected Figure 49.

GENERAL INFORMATION

Central Station Climate Changers® are air handlers designed to provide complete heating, cooling and dehumidifying by means of a wide variety of unit sizes, coils, fans and efficiency capabilities. This manual will cover all vertical and horizontal, draw-thru, blow-thru, sprayed coil and high pressure units.

NOTE: All dimensions and weights given in this manual are approximate and will vary for special units. Refer to submittal data for exact dimensional information.

An Installation Checklist is given at the end of the Installation section of this manual to be used by the installing contractor to verify proper installation procedures. These checklists should not be substituted for the detailed information and procedures contained in appropriate sections of the manual.

RECEIVING AND HANDLING

SHIPPING

Central Station Climate Changers® are shipped either assembled or in sections, depending on unit size and accessories. All units or sections of units are attached securely to skids. Nuts, bolts and washers necessary for unit assembly are attached to one of the skids. Motors ship separately when their size or location on the unit prevents safe transit. Access section is shipped unassembled.

To protect against loss from in-transit damage, complete the following upon receipt of the unit:

- Inspect individual pieces of the shipment before accepting it. Check for rattles, bent corners on cartons or other visible indications of shipping damage.
- If a carton or unit has apparent damage, open it immediately and inspect the contents before accepting the unit. Do not

- refuse the shipment. Make specific notations concerning the damage on the freight bill.
- Inspect the unit for concealed damage before it is stored and as soon as possible after delivery. Refer to the checklist given in step 8 for internal inspections. Concealed damage must be reported within 15 days.
- Do not move damaged material from the receiving location if possible. It is the receiver's responsibility to provide reasonable evidence that concealed damage was not incurred after delivery.
- If concealed damage is discovered, stop unpacking the shipment. Retain all internal packing, cartons and crates. Take photos of the damaged material if possible.
- Notify the carrier's terminal of the damage immediately by phone and mail. Request an immediate joint inspection of the damage by the carrier and consignee.
- 7. Notify the Trane sales representative of the damage and ar-

range for repair. Do not repair the unit, however, until damage is inspected by the carrier's representative. Trane is not responsible for shipping damage.

- 8. Complete the following inspections before installing the unit:
 - Verify that the correct unit has been received by comparing nameplate and model number information with submittal data.
 - Rotate the fan manually to be sure that it is free to operate. Inspect the fan housing for obstructions which may have entered the unit during shipment.
 - Check all dampers in the unit and accessories to be sure they are free to move and have not been damaged in transit.
 - Make sure the inlet vanes operate freely. Check that all sets of vanes operate together when opening and closing.

Refer to the Unit Location Recommendations in this manual before setting the unit in place. It is recommended that units are left on their skids for protection and ease of handling until set in place. For proper rigging and hoisting procedures, refer to the Rigging section of this manual and the instruction label on the unit.

RIGGING

Before preparing the unit or component for lifting, estimate the approximate center of gravity for lifting safety. Because of placement of internal components, the unit weight may be unevenly distributed, with more weight in the coil area. Approximate unit weights are given in Tables 1, 2 and 3.

Before hoisting the unit, be sure that the proper method of rigging is used, with straps or slings and spreader bars for protection during lifting. See Figure 1. Refer to the unit label for recommended rigging procedures. Always test-lift the unit to determine exact unit balance and stability before hoisting it to the installation location.

WARNING: DO NOT LIFT THE UNIT WITHOUT TEST-LIFTING FOR BALANCE AND RIGGING. DO NOT LIFT THE UNIT IN WINDY CONDITIONS OR ABOVE PERSONNEL. DO NOT LIFT THE UNIT BY ATTACHING A CLEVIS, HOOKS, PINS OR BOLTS TO THE CASING, CASING HARDWARE, CORNER LUGS, ANGLES, TABS OR FLANGES. FAILURE TO OBSERVE THESE WARNINGS MAY RESULT IN PERSONAL INJURY OR DEATH OR EQUIPMENT DAMAGE.




FIGURE 1 - Recommended Rigging Procedure

TABLE 1 - Climate Changer Unit Operating Weights In Pounds (Less Motors)

						UI	NIT SIZE									
	3	6	8	10	12	14	17	21	25	31	35	41	50	63	73	8
					Dra	w-Thru	Climate	Change	rs	-	1		1 00	1	1 /3	1 0
Casing Only	205	275	400	460	700	750	1,015	1,225	7	1 455	10.400	10540	T . ==	T		
2 Row	291	424		677	978	1,060		1,639			2,100	100000000000000000000000000000000000000	ALC: NO PERSONS AND ADDRESS OF THE PERSONS AND ADDRESS AN	1000		
4 Row	328		657	785	1,108	1,213		-	A STATE OF THE STA		2,832		100	THE CONTRACTOR		
6 Row	368	1000		891	1,243	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1		1,876			3,198	1477	4,260	COC \$5 459 \$150 C.	6,710	7,4
8 Row	406				LABOR TO SAME	1,369	1,807	2,018		2,813	3,616	Control of the Contro	4,794	6,929	7,560	8,4
	1 400	1 010	020	988	1,373	1,520	1,981	2,321	2,643	3,143	3,984	4,699	5,330	7,611	8,320	9,3
Cooling Only	1	T	1		raw-Thr		e Chang	er w/W	ide Coil							
Casing Only	225	295	425		100 BACK	780	1045	1260	1415	1505	2190	2715	2950	4845	4850	51
With 2 Row	365	495	665	779	1089	1166	1535	1738	1951	2262	3041	3959	4121		6157	669
With 4 Row	426	579	788	922	1257	1357	1759	2005	2372	2647	3467	4251	4796	6578	7142	785
With 6 Row	491	666	908	1063	1431	1552	1982	2246	2557	3058	3953	4818	5448	7401	8117	1
With 8 Row	553	754	1030	1192	1599	1740	2188	2526	2856	3436	4381	5354	6103	8190	8988	944
					Blov	v-Thru (limate (Changer	8		,	1 000 1	1 0.00	1 0130	0300	998
Casing Only		605	765	810	880	1,095	1,260	1,425	1,600	1,810	2 250	2 050	14005	14500	T =	T = =
2 Row	_	754	935	1,027	1,158	1,405	1,614	1,839			3,250	3,650	4,025	200	1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 -	5,50
4 Row	aly - 15 Page	817	1,022	1,135	1,288	1,558	1,803	A CONTRACTOR OF THE PARTY OF TH	2,070	2,472	3,982	4,463	4,983	5,839	16.	7,14
6 Row	10 E	882	1,107	1,241	1,423	100 700 300		2,070	2,339	2,808	4,348	4,907	5,535	6,528	7,240	8,11
8 Row	1	948	1,193	and the second	MINISTER STREET, NO.	1,714	1,992	2,298	2,609	3,168	4,766	5,367	6,069	7,239	8,018	9,04
	411	340	1,193	1,338	1,553	1,865	2,166	2,521	2,863	3,498	5,134	5,809	6,605	7.921	8,824	9.99
Cooles Only				OF THE SECTION OF SECTION SECT	ngle-Zor		Thru Cli	nate Ch	angers							
Casing Only		386	544	631	760	900	1,080	1,235	1,370	1,560	2,780	3,115	3,435	4,425	4,870	5,28
2 Row	-	535	714	848	1,038	1,210	1,434	1,629	1,840	2,222	3,512	3,928	4,393	5,684	6,276	6,89
4 Row	-	598	801	956	1,168	1,363	1,623	1,860	2,109	2,558	3,878	4,372	4,945	6,373	7,080	1000
6 Row	_	663	886	1,062	1,303	1,519	1,812	2,088	2,379	2,918	4,296	4,832	5,479	7,084	100000000000000000000000000000000000000	7,86
8 Row	-	729	972	1,159	1,473	1,670	1,986	2,311	2,673	3,248	4,664	5,274	6,015	7,766	7,858	8,79
					Spray	***************************************	Climate			0,2.10	4,004	0,214	0,013	1,700	8,664	9,74
Casing Only	690	915	1,105	1,270	1,880	2,130	3,100	3,285		0.405	4.050			Τ		
4 Row	815	1,125	1,360	1,595	2,290	2,595	1000		3,305	3,485	4,950	5,700	6,230	9,050	10,485	,
6 Row	855	1,190	1,445	1,700	2,425		3,745	4,125	4,145	4,485	6,050	6,950	7,740	10,100	11,700	13,78
8 Row	890	1,260	1,535			2,750	3,925	4,285	4,305	4,855	6,465	7,420	8,275	11,710	13,560	15,98
	030	1,200	1,535	1,800	2,555	2,900	4,195	4,550	4,570	5,175	6,835	7,860	8,810	12,390	14,355	16,91
Casina Only	т-	1	T		Pressure			ilmate (Changer	8						
Casing Only	- Teles	-	1,590	2,130	2,500	2,670	3,210	3,840	4,350	5,100	5,350	6,000	7,200	9,400	12,250	14,91
4 Row	_	-	1,845	2,455	2,910	3,135	3,755	4,485	5,190	6,100	6,450	7,250	8,710	11,350	Late Control of the Control	
6 Row	-	-	1,930	2,560	3,045	3,290	3,940	4,665	5,350	6,460	6,865	7,720	9,245	12,060	15,100	18,32
8 Row	_	-	2,020	2,660	3,175	3,440	4,115	4,935	5,615	8,790	7,235	8,160	9,780			
				High	Pressu	e Draw	Thru Cli	mate Cl	hangers					,.	10,000	10,21
an Section Only	_	_	610	770	920	1,060	1,290	1,580	1,870	2,060	2,200	2,330	2,580	2,950	4 000	E 400
an and Coil Section	-	-	1,250	1,800	2,150	2,250	2,650	3,400	3,950	4,250	4,600	5,250	5,650	6,850	4,090	5,400
4 Row	-	_	1,590	2,170	2,440	2,765	3,210	4,010	4,795	5,055	5,535	CVC ACCOMMON	0.00	Control of the control of	8,260	10,40
6 Row	-	_	1,720	2,310	2,690	3,030	211111111111111111111111111111111111111	4,180	4,930	5,445	5,935	6,335	7,180	8,600	10,260	12,79
8 Row	_	-	1,850	2,450	2,740	3,095	ASSESSMENT OF THE PARTY OF THE	1000	5,325	5,835	A CONTRACTOR OF THE PARTY OF TH	6,785	7,930	9,350	Supplied to the second	13,81
					Pressur					3,033	6,335	7,235	8,680	10,000	11,960	14,700
an Section Only			610	770		CONTRACTOR STATEMENT OF				20200						
an and Coil Section	A CHAPT		1,650		920	1,060	- TASK - THE COLUMN	The state of the s			2,200		2,580	2,950	4,090	5,400
4 Row		A LIN	100	2,250			4 22 3	U. 3355 S. S.	- 0 (B-20) He		6,000	6,850	7,300	9,300	12,140	14,900
6 Row	4		1,990	2,620			PERSONAL PROPERTY.	and the Control of						11,050	14,140	17,290
B Row	-			2,760						6,595	7,335	and the second second	9,580	11,800	14,990	18,310
O FIOW			2,250	2,900			4,180			6,985			10,180	12,450	15,840	19,200
				Thr	ee Deck	Multizo	ne Clima	te Char	ngers							
asing Only	-	725	885	930	1,000	1,255				2,060	3,350	4,000	4,385	4,950		
Row	-	874	1,055	1,147		10 March 1987	100000000000000000000000000000000000000	ALCOHOLD TO	AND THE COLUMN TO THE PARTY.	Section to the	N. 100 Carlotte 100	OF LEADING OF		TOTAL STATE OF	100	100
Row	-	937								Application of the second			5,343	6,219	-	-
Row	-	1,002	1,227		100				A Company of the Park		C 1. 50s. 1. 125.00 E50	NAME OF TAXABLE PARTY.	5,895	6,908	(c) T	-
Row	1000	1,068	, , , ,	.,	. 10 10	.,0,7	-,202	-,700	2,009	3,418	4,866	5,721	6,429	7,609	_	_

NOTE: Inlet vane weights will vary from 38 to 93 pounds per fan.

NOTE: Units with Delta-Flo coils will weigh approximately 10% lighter than standard coil weights.

Motor Horsepower		1/3	1/2		11/2		3	5	71/2	10	15	20	25	30	40	50	60	75
Motor Weight (Lbs.)	20	20	25	33	44	44	71	82	127	144	187	214	263	300	409	460	560	660

Standard Open Ball Bearing T-Frame Motor.

ABLE 3 - Accessory Weight UNIT SIZES	3	6	7	8	9	10	12	14	17	21	25	31	35	41	50	63	73	86
Flat Filter Box		1	3 8 4				T.	3 1	laj-								000	457
Throwaway	28	38	42	45	54	68	73	76	92	113	120	135	170	180	210	335 426	388 494	457 582
Low Velocity Permanent	33	47	52	56	67	84	91	97	117	145	155	183	222	234	284 365	582	674	794
High Velocity Permanent	51	63	69	75	91	108	120	131	156	193	207	257	306	338	300	502	0/4	134
Medium Filter Box													1			565	655	775
Throwaway	76	101	131	144	167	171	178	228	247	303	324	355	370	456	520	695	805	950
Low Velocity Permanent	84	117	149	162	191	195	204	260	284	348	373	413	429	546	631 799	935	1,085	1,275
High Velocity Permanent	96	141	181	190	227	231	248	312	347	428	456	513	557	706	799	933	1,005	1,2/5
High Capacity Box		dress		1.0					40.0				470		590	680	788	928
Throwaway	111	148	155	170	180	192	229	260	278	330	398	425	470	535	735	865	1,002	1,180
Low Velocity Permanent	120	166	184	194	208	223	261	305	324	393	468 576	512 648	574 742	660 852	950	1,160	1,344	1,583
High Velocity Permanent	136	198	217	230	257	271	317	360	396	489					-	750	870	1,025
Roll Filter	80	114	_	142	-	158	187	204	219	250	290	363	430	475	500	750	8/0	1,025
Comb. Filt./Mix Box				ols					1			F.				4 400	4 040	
Throwaway	115	168	200	248	255	286	300	215	358	400	490	620	710	790	885	1,133	1,310	,550 1,730
Low Velocity Permanent	122	184	217	266	279	310	324	345	393	441	540	686	780	874	997	1,165	1,465	2,060
High Velocity Permanent	134	208	249	298	315	346	368	397	456	521	635	786	906	1,035	1,265	1,505	1,740	2,000
Deluxe Comb. Filter/Mix Box					1	110			1000			1						
Throwaway	193	240	263	352	369	376	407	474	501	586	604	732	986					
Low Velocity Permanent	200	256	280	370	393	400	431	504	536	627	654	798	1,056	_	_		5.0	
High Velocity Permanent	212	280	312	402	429	436	475	556	600	707	739	898	1,182	NO.		-	-	1 105
Mixing Box	82	118	122	169	175	182	256	270	319	340	380	437	519	623	750	869	1,010	1,185
High Efficiency Bag Filter		. *							8	100	9.4	16	XTABLE		740	754		
Filter Sections	-	-	-	191	-	227	249	319	329	403	454	592	606	682	718	751	The state of	
Bag Filters	-	-	-	11	-	14	18	23	25	30	41	50	64	64	75	100		1
Prefilters	-	-	-	2	_	3	4	5	5	6	9	11	13	13	17	22 357	T-86	LIM
*Diffuser Section	-	-	_	55	-	79	84	88	107	130	138	153	191	202				-
External Face and Bypass	40	58	79	96	100	112	154	161	170	216	292	417	457	470	618	925	1,070	1,265
Internal Face and Bypass	30	53	74	77	92	100	109	113	124	184	223	327	334	363	441	535	620	730
Face Dampers	39	55	65	91	102	106	111	115	142	225	232	297	312	370	446	543	630	742
Straight Thru Discharge Plenum	50	65	90	100	130	110	130	150	170	180	200	300	400	400	_	. —	-	-

^{*}Weight given is sum of diffuser section, duct extension and canvas duct.

INSTALLATION

UNIT LOCATION RECOMMENDATIONS

When selecting and preparing the unit operating site, consider the following:

- 1. Consider the weight of the unit. Tables 1, 2 and 3 list operating weights.
- 2. Allow sufficient space for the recommended clearances, access panel removal, and maintenance access. Refer to Figure 2. Zero clearance to combustible materials is approved for units with or without steam or hot water heating coils.
 - NOTE: For units with optional wide coil, always maintain a 2-foot clearance from coil section end panel to permanent wall or obstruction.
- 3. The foundation or mounting platform must be large enough to include unit and accessory dimensions, given in specific sales submittals.
- Rubber-in-shear or spring isolators are recommended. For floor-mounted units, anchor the unit to the floor or foundation to prevent strains on the piping and ductwork.

- 5. Installer must provide suspension or support frame for ceiling-mounted units size 35 and larger. Use the weights given in Tables 1, 2 and 3.
- 6. Prepare the floor or foundation so that it is level. The unit must be mounted level to ensure proper hydronic coil drainage and condensate flow.
- 7. Coil piping and condensate drain requirements must be considered. For units with Type F cooling coils, the installer must provide and install a condensing unit and piping. Allow room for proper ductwork and electrical connections. Support all piping and ductwork independently of unit to prevent excess noise and vibration.
- 8. Optional coilless horizontal draw-thru unit sizes 3, 6, 8, 10, 14 and 21 require the contractor to field install coil in unit per COIL INSTALLATION INSTRUCTIONS given in the installation manual (included with coil shipment). On ceiling-mounted unit applications it is recommended to install coil in unit before hoisting unit to operating position.




FIGURE 2 - Recommended Clearances

*NOTE FOR WIDE COIL UNITS: Always maintain a 2-foot clearance from coil section end panel to permanent wall or obstruction.

MOUNTING VIBRATION ISOLATORS

Vibration isolators and isolator mounting legs, when supplied, are shipped with the unit and attached to the shipping skid. Locate the mounting legs at all corners of the unit or component section or at appropriate support sites. Fasten the isolators to the floor securely before mounting the unit. See Figure 3.

NOTE: If mounting the unit on a raised platform or foundation, be sure to allow room for the mounting legs and isolators, which extend beyond the unit dimensions.

Level the unit after installation by adjusting the isolator levelling bolts. For ceiling-mounted units, use threaded rods or adjustable isolators to level the unit.

Be sure to consider the additional unit height if isolators are used when making duct, piping and electrical connections. For large Draw-Thru and Sprayed Coil units, the coil section must be mounted on a higher base than the fan section in order to compensate for the height of the fan section isolators.

NOTE: Non-Trane isolators must be properly sized to ensure adequate support of the unit. Allow at least 20 percent weight addition when sizing isolators.

If using spring-type isolators, the isolator levelling bolt must be adjusted to provide adequate isolation, as unit weight may cause the upper isolator housing to rest on the lower housing. See Figure 4. Clearance B must be between 1/4-inch and 1/2-inch under full unit weight. To increase the clearance, lift the unit off the mountings and turn the levelling bolt clockwise. Recheck the unit level and shim as necessary under the isolators.

After the isolator height is adjusted correctly, adjust the horizontal snubber bolt to minimize any horizontal movements.




FIGURE 3 - Anchoring the Unit




FIGURE 4 - Spring-Type Isolator Adjustment

MOUNTING — CLIMATE CHANGER AIR HANDLERS DRAW-THRU UNITS

NOTE: No draw-thru units and or accessories have factory gasketed panels or drain pan gasketing unless specified on the order.

WARNING: DO NOT LIFT THE UNIT WITHOUT TEST LIFTING FOR BALANCE AND RIGGING. DO NOT LIFT THE UNIT IN WINDY CONDITIONS OR ABOVE PERSONNEL, DO NOT LIFT THE UNIT BY ATTACHING A CLEVIS, HOOKS, PINS OR BOLTS TO THE CASING, CASING HARDWARE, CORNER LUGS, ANGLES, TABS OR FLANGES. FAILURE TO OBSERVE THESE WARNINGS MAY RESULT IN PERSONAL INJURY OR DEATH OR EQUIPMENT DAMAGE.

NOTE: On certain horizontal draw-thru units that ship from the factory in sections, a splash angle must be field installed connecting the coil section to the fan section. See Figure 9. The following units apply,

- Horizontal D. T. Unit size 50 (with back vertical

discharge).

- Horizontal D. T. Unit Size 63 (with front or back vertical discharge).

- Horizontal D. T. Unit size 63 (with extra length casing).

NOTE: Check the bearing and sheave setscrews for proper torque settings. Refer to applicable section in this manual.

Floor-Mounted — Horizontal Unit Sizes 3-50 and Vertical Unit Sizes 3-31. Ship from factory as one assembly (Fan Section, Coil Section and Drain Pan).

NOTE: For optional coilless horizontal draw-thru units (size 3, 6, 8, 10, 14 and 21) refer to COIL INSTALLATION INSTRUCTIONS given in the installation manual to properly install coil in unit.

- Remove the diagonal shipping angles which secure coil(s) if they interfere with the use of access doors.
- Attach accessories, if used. Gasketing not provided unless specified on sales order.
- Anchor the isolators to the floor and mount the unit on the isolators. See Figure 3. For some applications it may be necessary to shorten the isolator adjusting bolt to properly secure unit to isolator.
- Level the unit for proper coil drainage and condensate removal from the drain pan.
- 5. Connect the ductwork and necessary piping to the unit. Refer to applicable section in this manual.
- Attach the motor, drives and motor splash pan if provided. If the motor was factory installed, check the bolts to make sure they are tight. Refer to the "Start-Up" section of the maintenance manual.

Note: All constant speed units are balanced at the factory at design rpm. If unit is to operate at more than 5% of design rpm a balance check and/or field rebalance will be necessary. Refer to "Start-Up" section in this manual.

Floor-Mounted — Horizontal Unit Sizes 63-86 and Vertical Unit Sizes 35-50. Ship from factory in 2 sections, (fan section and coil section).

NOTE: On certain horizontal draw-thru units that ship from the factory in sections, a splash angle must be field installed connecting the coil section to the fan section. See Figure 9. The following units apply,

- Horizontal D. T. Unit size 50 (with back vertical

discharge).

- Horizontal D. T. Unit Size 63 (with front or back vertical discharge).

- Horizontal D. T. Unit size 63 (with extra length casing).

NOTE: Check the bearing and sheave setscrews for proper torque settings. Refer to applicable section in this manual.

- Remove the diagonal shipping angles which secure coil(s) if they interfere with the use of access doors.
- 2. Fasten isolators to floor.
- 3. Horizontal Units Size 63 To assemble multi-section horizontal units, remove the drain pan from the coil section discharge flange and set in place. Then set the fan and coil sections on the drain pan, as shown in Figure 5. Bolt the sections together, attach gasketing if supplied. Make sure that the coil section support channels are also attached to the fan section. Mount assembled unit on isolators and fasten unit to isolators.
- 4. Horizontal Units Size 73 and 86 To assemble unit, mount the fan section on the isolators and fasten. Attach flexible connector to the fan section. Then fasten the splash guard to the fan section. See Figure 8. Mount the coil section on the base with the required distance between fan and coil sections. See Figure 7. Each fan section and coil section have separate factory assembled drain pans. Each drain pan must be trapped separately.

NOTE: Coil section base is provided by the installer. Height of coil section base should be equal to working height of fan section isolators. Be sure the base is high enough to allow room for a piping trap. See Figure 7. Refer to drain trap sketches in piping section.

Attach flexible connection to the coil section.

Fasten splash guard to coil section. Panel removal may be necessary to attach splash guard to coil section on size 86 units.

- 5. Vertical Units Size 35-50 To assemble multi-section vertical discharge units, attach the fan section to the top of coil section. Removal of front panel on coil section is necessary to assemble fan section. Install gasketing if supplied. Drain pan is factory assembled to coil section. Mount assembled unit on isolators and fasten unit to isolators. See Figure 6.
- Attach accessories, if used. Gasketing not provided unless specified on sales order.
- Level the unit, fan and or coil sections to assure proper coil drainage and removal of condensate from the drain pan.

- Connect the ductwork and necessary piping to the unit. Refer to applicable section in this manual.
- Attach the motor, drives and motor splash pan if provided. If the motor was factory installed, check the bolts to make sure they are tight.

Floor-Mounted — Horizontal and Vertical Spray Coll Unit Sizes 3-31. Ship from factory as one assembly (Fan Section, Coil Section and Drain Pan).

WARNING: DO NOT LIFT THE UNIT WITHOUT TEST-LIFTING FOR BALANCE AND RIGGING. DO NOT LIFT THE UNIT IN WINDY CONDITIONS OR ABOVE PERSON-NEL. DO NOT LIFT THE UNIT BY ATTACHING A CLEVIS, HOOKS, PINS OR BOLTS TO THE CASING, CASING HARDWARE, CORNER LUGS, ANGLES, TABS OR FLANGES. FAILURE TO OBSERVE THESE WARNINGS MAY RESULT IN PERSONAL INJURY OR DEATH OR EQUIPMENT DAMAGE.

NOTE: The complete spray section is gasketed on all vertical and horizontal sizes. Also, the factory installs a gasket at the joint between the spray section and coil section.




FIGURE 5 - Exploded View of the Horizontal Draw-Thru Unit Size 63




FIGURE 6 - Exploded View of the Vertical Draw-Thru Unit Sizes 35 through 50

NOTE: Check the bearing, and sheave setscrews for proper torque settings. Refer to Applicable section in this manual.

- Remove the diagonal shipping angles which secure coil(s) if they interfere with the use of access doors.
- Attach accessories, if used. Gasketing not provided unless specified on sales order.
- Anchor the isolators to the floor and mount the unit on the isolators. See Figure 3. For some applications it may be necessary to shorten the adjusting bolt to properly secure unit to isolator.
- Level the unit for proper coil drainage and condensate removal from the drain pan. On horizontal units the drain pan empties back into the sump.
- Connect the ductwork and necessary piping to the unit. Refer to applicable section in this manual.
- Attach the motor, drives and motor splash pan if provided. If the motor was factory installed, check the bolts to make sure they are tight. Refer to the "Start-Up" section of this manual.




FIGURE 7 - Mounting Clearance Dimensions for Draw-Thru Units Sizes 73-86




FIGURE 8 - Splash Guard Installation




FIGURE 9 - Splash Angle Installation

Note: All constant speed units are balanced at the factory at design rpm. If unit is to operate at more than 5% of design rpm a balance check and or field rebalance will be necessary. Refer to "Start-Up" section in this manual.

Floor-Mounted — Vertical Spray Coil Unit Sizes 35-50 ship from factory in 2 sections (fan section, coil section). Horizontal Spray Coil Unit Sizes 35-63 ship from factory in 3 sections (coil section, fan section, fan drain pan section). Horizontal Spray Coil Unit Sizes 73-86 ship from factory in 2 sections (fan section, coil section).

Note: The complete spray section is gasketed on all vertical and horizontal sizes. Also, the factory installs a gasket at the joint between the spray section and coil section.

NOTE: Check the bearing and sheave setscrews for proper torque settings. Refer to applicable section in this manual.

WARNING: DO NOT LIFT THE UNIT WITHOUT TEST-LIFTING FOR BALANCE AND RIGGING. DO NOT LIFT THE UNIT IN WINDY CONDITIONS OR ABOVE PERSON-NEL. DO NOT LIFT THE UNIT BY ATTACHING A CLEVIS, HOOKS, PINS OR BOLTS TO THE CASING, CASING HARDWARE, CORNER LUGS, ANGLES, TABS OR FLANGES. FAILURE TO OBSERVE THESE WARNINGS MAY RESULT IN PERSONAL INJURY OR DEATH OR EQUIPMENT DAMAGE.

- Remove the diagonal shipping angles which secure coil(s) if they interfere with the use of access doors.
- 2. Fasten isolators to floor.
- 3. Horizontal Units Size 35-63 Attach the spray section to isolators. Fasten the two mounting legs to the fan section drain pan. Set the fan section on the drain pan and bolt in place. Attach the drain pan and fan section to the spray section. See Figure 10.

4. Horizontal Units Size 73 and 86 — To assemble unit, mount the fan section on the isolators and fasten. Attach flexible connector to the fan section. Mount the coil section on the base with the required distance between fan and coil sections. See Figure 7. Drain pan is factory assembled to each section.

NOTE: Coil section base is provided by the installer. Height of coil section base should be equal to working height of fan section isolators. Be sure the base is high enough to allow room for a piping trap. See Figure 7. Refer to drain trap sketches in piping section.

Attach flexible connection to the coil section.

5. Vertical Units Size 35-50 — Set the spray section over the isolators and bolt together. Place the fan section on top of the coil section and bolt together. Gasketing not provided between fan section and coil section unless specified on the sales order. Drain pan (sump assembly) is factory assembled to spray coil section.




FIGURE 10 - Typical Horizontal Sprayed Coil Climate Changer

- Attach accessories, if used. Gasketing not provided unless specified on sales order.
- Level the unit, fan and or coil sections to assure proper coil drainage and removal of condensate from the drain pan.
- 8. Connect the ductwork and necessary piping to the unit. Refer to applicable section in this manual.
- Attach the motor, drives and motor splash pan if provided. If the motor was factory installed, check the bolts to make sure they are tight.

Note: All constant speed units are balanced at the factory at design rpm. If unit is to operate at more than 5% of design rpm a balance check and or field rebalance will be necessary. Refer to "Start-Up" section in this manual.

DRAW-THRU UNITS

Ceiling-Mounted — Horizontal Unit Sizes 3-31. Ship from factory as one assembly (Fan Section, Coil Section and Drain Pan).

NOTE: For optional coilless horizontal draw-thru units (size 3, 6, 8, 10, 14 and 21) refer to COIL INSTALLATION INSTRUCTIONS given in CLCH-IN-1 to properly install coil in unit. On ceiling-mounted unit applications it is recommended to install coil in unit before hoisting unit to operating position.

NOTE: Check the bearing and sheave setscrews for proper torque settings. Refer to applicable section in this manual.

Note: All ceiling suspended units with wide coil application must use a cradle (angle iron). See Figure 11A for details.

Note: Because of their weight, unit sizes 3-31 (wide coil only) and 35-86 (wide coil and standard units) require suspension support frames, to be provided by the installer. Figures 11A, 12 and 13 give the configuration and dimension of these frames. Note that two frames are required for sizes 73 and 86. See Figure 13.

WARNING: DO NOT LIFT THE UNIT WITHOUT TEST-LIFTING FOR BALANCE AND RIGGING. DO NOT LIFT THE UNIT IN WINDY CONDITIONS OR ABOVE PERSON-NEL. DO NOT LIFT THE UNIT BY ATTACHING A CLEVIS, HOOKS, PINS OR BOLTS TO THE CASING, CASING HARDWARE, CORNER LUGS, ANGLES, TABS OR FLANGES. FAILURE TO OBSERVE THESE WARNINGS MAY RESULT IN PERSONAL INJURY OR DEATH OR EQUIPMENT DAMAGE.

- Determine the unit mounting hole dimensions. Prepare the hanger rod and isolator assemblies and install them in the selected area. Threaded rods are recommended for leveling the unit. Tables 1, 2 and 3 list approximate operating weights. See Figure 11.
- Attach accessories, if used. Gasketing not provided unless specified on sales order.
- Attach the motor, drives and motor splash pan if provided. If the motor was factory installed, check the bolts to make sure they are tight.

Note: All constant speed units are balanced at the factory at design rpm. If unit is to operate at more than 5% of design rpm a balance check and/or field rebalance will be necessary. Refer to "Start-Up" section in this manual.

NOTE: Check to determine that the motor is clean and dry prior to start-up.

- Hoist the unit to the hanger or suspension rods and attach. See Figure 11.
- Level the unit for proper coil drainage and condensate removal from the drain pan. Refer to drain trap sketches in piping section.
- Connect the ductwork and necessary piping to the unit. Refer to applicable section in this manual. Isolate piping separately.





FIGURE 11 - Suspension Method for Horizontal Units Up to Size 31



Vertical Dimensions (Inches) With Wide Coil

UNIT SIZE	A	В	С	F
3	237/8	54	34	10
6	237/8	75	55	10
8	287/8	66	46	10
10	287/8	75	55	10
12	327/8	81	61	10
14	327/8	90	70	10
17	327/8	111	91	10
21	367/8	129	109	10
25	427/8	135	115	10
31	427/8	135	115	10

Horizontal Dimensions (Inches) With Wide Coil

JNIT SIZE	Α	В	C	F	
3	323/4	54	34	10	
6	343/4	75	55	10	
8	443/4	66	46	10	
10	443/4	75	55	10	
12	483/4	81	61	10	
14	483/4	90	70	10	
17	483/4	111	91	10	
21	523/4	129	109	10	
25 Arr. 1 & 2	523/4	135	115	10	
25 Arr. 3 & 4	583/4	135	115	10	
31 Arr. 1 & 2	523/4	135	115	10	
31 Arr. 3 & 4	583/4	135	115	10	

Figure 11A — Ceiling Suspension Mounting Frame and Dimensions for Wide Coil Unit Sizes 3 thru 31.

CEILING-MOUNTED — Horizontal Unit Sizes 35-50 ship from factory as one assembly (fan section, coil section, and drain pan). Horizontal Unit Sizes 63-86 ship from factory in 2 sections (fan section and coil section).




FIGURE 12 - Ceiling Suspension Mounting Frame and Dimensions for Unit Sizes 35 to 63

NOTE: On certain horizontal draw-thru units that ship from the factory in sections, a splash angle must be field installed connecting the coil section to the fan section. See Figure 9. The following units apply,

- Horizontal D. T. Unit size 50 (with back vertical discharge).
- Horizontal D. T. Unit Size 63 (with front or back vertical discharge).
- Horizontal D. T. Unit size 63 (with extra length casing).

WARNING: DO NOT LIFT THE UNIT WITHOUT TEST LIFTING FOR BALANCE AND RIGGING. DO NOT LIFT THE UNIT IN WINDY CONDITIONS OR ABOVE PERSONNEL, DO NOT LIFT THE UNIT BY ATTACHING A CLEVIS, HOOKS, PINS OR BOLTS TO THE CASING, CASING HARDWARE, CORNER LUGS, ANGLES, TABS OR FLANGES. FAILURE TO OBSERVE THESE WARNINGS MAY RESULT IN PERSONAL INJURY OR DEATH OR EQUIPMENT DAMAGE.




FIGURE 13 - Ceiling Suspension Mounting Frame and Dimensions for Unit Sizes 73 and 86 (Two Frames are Required for Each Unit)

- Determine the unit mounting hole dimensions. Prepare the hanger rod and isolator assemblies and install them in the selected area. Threaded rods are recommended for leveling the unit. Tables 1, 2 and 3 list approximate operating weights.
- Remove the diagonal shipping angles which secure coil(s) if they interfere with the use of access doors.
- 3. Attach accessories, if used. Gasketing not provided unless specified on the sales order.
- 4. Attach the motor, drives and motor splash pan if provided. If the motor was factory installed, check the bolts to make sure they are tight. Refer to the "Start-Up" section of the maintenance manual.

Note: All constant speed units are balanced at the factory at design rpm. If unit is to operate at more than 5% of design rpm a balance check and/or field rebalance will be necessary. Refer to "Start-Up" section in this manual.

NOTE: Check to determine that the motor is clean and dry prior to start-up.

Horizontal Unit Sizes 3-50 — Attach the coil section support channels to the fan section base angles. Set the assembly on the prepared support frame. Reference Figures 11A and 12.

- 6. Horizontal Unit Size 63 To assemble multi-section units, remove the drain pan from the coil section discharge flange and set in place. Then set the coil and fan sections on the drain pan and bolt sections together, attach gasketing if supplied. Attach the coil section support channels to the fan section base angles. Set the assembly on the prepared support frame. See Figure 12.
- 7. Horizontal Unit Sizes 73-86 Set the coil and fan section on each of the prepared support frame. See Figure 13. Attach the splash guard and fasten the flexible connector to the fan section. See Figure 8. Panel removal may be necessary to attach splash guard.

Each fan section and coil section have separate factory assembled drain pans.

- 8. Hoist the assembled unit or separate pieces with support frames and attach the support frames (sizes 3-86) to the hanger or suspension rods. For size 73-86 units, the required distance between fan and coil sections must be as shown in Figure 7. Attach flexible connection to the coil section.
- Level the unit for proper coil drainage and condensate removal from the drain pan. Refer to drain trap sketches in piping section.
- Connect the ductwork and necessary piping to the unit. Refer to applicable section in this manual. Isolate piping separately.

BLOW-THRU UNITS

Floor-Mounted — Three-Deck Unit Sizes 6-25 and Multizone Unit Sizes 6-31 ship from factory as one assembly (fan section, coil section w/drain pan and zone damper section).

WARNING: DO NOT LIFT THE UNIT WITHOUT TEST-LIFTING FOR BALANCE AND RIGGING. DO NOT LIFT THE UNIT IN WINDY CONDITIONS OR ABOVE PERSON-NEL. DO NOT LIFT THE UNIT BY ATTACHING A CLEVIS, HOOKS, PINS OR BOLTS TO THE CASING, CASING HARDWARE, CORNER LUGS, ANGLES, TABS OR FLANGES. FAILURE TO OBSERVE THESE WARNINGS MAY RESULT IN PERSONAL INJURY OR DEATH OR EQUIPMENT DAMAGE.

NOTE: Check the bearing and sheave setscrews for proper torque settings. Refer to applicable section in this manual.

- 1. Fasten isolators to the floor.
- 2. Mount the unit on the isolators and fasten.
- 3. Install accessories.
- Level the unit for proper coil drainage and condensate removal from the drain pan.
- Connect the ductwork and necessary piping to the unit. Refer to applicable section in this manual.

NOTE: See Figure 30 for duct installation.

Attach the motor, drives and motor splash pan if provided. If the motor was factory installed, check the bolts to make sure they are tight.

Floor-Mounted — Multizone Blow-Thru Unit Sizes 35-41 and Three Deck Unit Sizes 31-35 ship from factory in 3 sections (coil section, fan section and zone damper section).

NOTE: Check the bearing and sheave setscrews for proper torque settings. Refer to applicable section in this manual.

WARNING: DO NOT LIFT THE UNIT WITHOUT TEST-LIFTING FOR BALANCE AND RIGGING. DO NOT LIFT THE UNIT IN WINDY CONDITIONS OR ABOVE PERSON-NEL. DO NOT LIFT THE UNIT BY ATTACHING A CLEVIS, HOOKS, PINS OR BOLTS TO THE CASING, CASING HARDWARE, CORNER LUGS, ANGLES, TABS OR FLANGES. FAILURE TO OBSERVE THESE WARNINGS MAY RESULT IN PERSONAL INJURY OR DEATH OR EQUIPMENT DAMAGE.

- 1. Fasten isolators to floor.
- If ordered, mount zone damper assembly to discharge opening of coil section. First remove shipping angle in discharge opening. Attach zone damper with gasketing factory provided. Attach splitter panel (dividing plate) to zone damper. Gasketing not provided for dividing plate.

CAUTION: When installing the damper assembly to the hot deck and bypass section, make sure it is mounted squarely, otherwise the damper blades may twist and fail to operate.

- 3. Remove the 90° cover panel.
- 4. Apply gasketing to the fan section mounting flange.
- Set the assembled coil and damper sections on the isolators and fasten in place.
- Gain access thru the 90° cover panel (removed previously) and bolt the fan section to the coil section through the gasketing. Be sure to bolt the fan section to the tie angle assembly, mounted on the coil section.

NOTE: Horizontal bolting across top and bottom of fan section to coil section require internal access through the 90° cover panel. Vertical bolting along side of fan section to coil section does not require internal access.

- 7. Apply gasketing to the 90° cover panel.
- 8. Attach the coil section 90° cover panel.
- 9. Install accessories.
- Level the unit for proper coil drainage and condensate removal from the drain pan.
- Connect the ductwork and necessary piping to the unit. Refer to applicable section in this manual.

NOTE: See Figure 30 for duct installation.

 Attach the motor, drives and motor splash pan if provided. If the motor was factory installed, check the bolts to make sure they are tight.

Note: All constant speed units are balanced at the factory at design rpm. If unit is to operate at more than 5% of design rpm a balance check and/or field rebalance will be necessary. Refer to "Start-Up" section in this manual.

Floor-Mounted — Multizone Blow-Thru Unit Sizes 50-63 ship from factory in 4 sections (fan section, cooling coil section, heating coil section and zone damper section). Refer to Figure 15.

NOTE: Check the bearing and sheave setscrews for proper torque settings. Refer to applicable section in this manual.

WARNING: DO NOT LIFT THE UNIT WITHOUT TEST-LIFTING FOR BALANCE AND RIGGING. DO NOT LIFT THE UNIT IN WINDY CONDITIONS OR ABOVE PERSON-NEL. DO NOT LIFT THE UNIT BY ATTACHING A CLEVIS, HOOKS, PINS OR BOLTS TO THE CASING, CASING HARDWARE, CORNER LUGS, ANGLES, TABS OR FLANGES. FAILURE TO OBSERVE THESE WARNINGS MAY RESULT IN PERSONAL INJURY OR DEATH OR EQUIPMENT DAMAGE.

- 1. Fasten isolators to floor.
- Remove the shipping angles attached to the front or top of the coil section.
- 3. Vertical Discharge Units: Place hot deck on top of cold deck and bolt in place with gasketing factory provided. The front panel of coil section ships attached across the discharge opening. It must be removed and installed with gasketing to the front of the coil section. (This does not apply to horizontal discharge units.) Next, bolt the splitter panel (dividing plate) to the panel over the cooling coil.
- 4. Horizontal Discharge Units: Place the hot deck on top of cold deck and bolt in place with gasketing factory provided. Next, bolt the splitter panel (dividing plate) to the panel over the cooling coil.
- Apply gasketing to the damper section or double-duct frame. Refer to Figure 14. Gasketing is not required at the center of the damper section where the dividing plate will be fastened.
- Assemble the damper or double duct frame to the coil section bolting through the gasketing.




FIGURE 14 - Installation of Gasketing on the Damper Section




FIGURE 15 - Multizone Blow-Thru Climate Changers




FIGURE 16 - Typical Three Deck Horizontal Discharge Climate Changer

CAUTION: When installing the damper assembly to the hot deck and bypass section, make sure it is mounted squarely, otherwise the dampers may twist and fail to operate.

- Bolt the hot and cold deck dividing plate to the center of the damper section.
- 8. Remove the 90° cover panel of the coil section.
- Apply gasketing to the fan section mounting flange. Set the assembled coil and damper sections on the isolators and fasten in place.
- 10. Gain access thru the 90° cover panel (removed previously) and bolt the fan section to the coil section through the gasketing. Be sure to bolt the fan section to the tie angle assembly mounted on the coil section.

Note: Horizontal bolting across top and bottom of fan section to coil section requires internal access through the 90° cover panel. Vertical bolting along side of fan section to coil section does not require internal access.

- 11. Apply the gasketing to the 90° cover panel.
- 12. Attach the coil section 90° cover panel.
- 13. Install accessories.
- Level the unit for proper coil drainage and condensate removal from the drain pan.
- Connect the ductwork and necessary piping to the unit. Refer to applicable section in this manual.
- 16. Attach the motor, drives and motor splash pan if provided. If the motor was factory installed, check the bolts to make sure they are tight. Refer to the "Start-Up" section of this manual.

Note: All constant speed units are balanced at the factory at design rpm. If unit is to operate at more than 5% of design rpm a balance check and or field rebalance will be necessary. Refer to "Start-Up" section in this manual.

Floor-Mounted — Three Deck Blow-Thru Unit Sizes 41-63 ship from factory in 4 sections (cooling coil section, fan section, vent and heating coil section, and zone damper section). See Figure 16 for assembly.

NOTE: Check the bearing and sheave setscrews for proper torque settings. Refer to applicable section in this manual.

WARNING: DO NOT LIFT THE UNIT WITHOUT TEST-LIFTING FOR BALANCE AND RIGGING. DO NOT LIFT THE UNIT IN WINDY CONDITIONS OR ABOVE PERSON-NEL. DO NOT LIFT THE UNIT BY ATTACHING A CLEVIS, HOOKS, PINS OR BOLTS TO THE CASING, CASING HARDWARE, CORNER LUGS, ANGLES, TABS OR FLANGES. FAILURE TO OBSERVE THESE WARNINGS MAY RESULT IN PERSONAL INJURY OR DEATH OR EQUIPMENT DAMAGE.

- 1. Fasten the isolators to the floor.
- 2. With gasketing applied to the top of the cooling coil section, mount the hot deck and bypass section to the

- cooling coil section. Bolt the bypass deck divider plate to the panel over the cooling coil.
- Remove the shipping angles used to support the hot deck and bypass zone divider plates.
- Vertical Discharge Units Apply gasketing to the mounting flange of the fill-in section and mount the fillin section to the cooling, bypass and hot deck section.
- Apply gasketing to the damper assembly. See Figure 14. Gasketing is not required at the center of the damper section where the divider plate will be fastened.
- Attach the damper section to the coil section, bolting through the gasketing.

CAUTION: When installing the damper assembly to the hot deck and bypass section, make sure it is mounted squarely, otherwise the damper blades may twist and fail to operate.

NOTE: Be sure control rods are in correct position.

- Bolt the hot deck and bypass zone divider plates to the center dividers of the damper assembly. These must be bolted from the hot deck and cold deck side only. Gasketing not required.
- 8. Remove the 90° cover panel of the coil section.
- Apply gasketing around the fan section mounting flange.
- Set the assembled coil and damper sections over the isolators. Fasten in place.
- 11. Gain access thru the 90° cover panel (removed previously) and bolt the fan section to the coil section through the gasketing. Be sure to bolt the fan section to the tie angle assembly mounted on the coil section.

NOTE: Horizontal bolting across top and bottom of fan section to coil section require internal access through the 90° cover panel. Vertical bolting along side of fan section to coil section does not require internal access.

- 12. Apply the gasketing to the 90° cover panel.
- 13. Attach the coil section 90° cover panel.
- 14. Attach any accessories.
- Level the unit for proper coil drainage and condensate removal from the drain pan.
- Connect the ductwork and necessary piping to the unit. Refer to applicable section in this manual.
- 17. Attach the motor, drives and motor splash pan if provided. If the motor was factory installed, check the bolts to make sure they are tight. Refer to the "Start-Up" section of this manual.

Floor-Mounted — Multizone Blow-Thru Unit Sizes 73-86 ship from factory in 6 sections (fan section, cooling coil section, heating coil section, canvas duct section, inlet panel (size 73), extended plenum (size 86), and either double duct frame section or zone damper section).

NOTE: Check the bearing and sheave setscrews for proper torque settings. Refer to applicable section in this manual.

WARNING: DO NOT LIFT THE UNIT WITHOUT TEST-LIFTING FOR BALANCE AND RIGGING. DO NOT LIFT THE UNIT IN WINDY CONDITIONS OR ABOVE PERSON-NEL. DO NOT LIFT THE UNIT BY ATTACHING A CLEVIS, HOOKS, PINS OR BOLTS TO THE CASING, CASING HARDWARE, CORNER LUGS, ANGLES, TABS OR FLANGES. FAILURE TO OBSERVE THESE WARNINGS MAY RESULT IN PERSONAL INJURY OR DEATH OR EQUIPMENT DAMAGE.

- 1. Fasten isolators to the floor.
- Remove the shipping angles attached to the front or top of the coil section.
- 3. Vertical Discharge Units: Place hot deck on top of cold deck and bolt in place with gasketing, factory provided. The front panel of coil section ships attached across the discharge opening. It must be removed and installed with gasketing to the front of the coil section. (This does not apply to horizontal discharge units.) Next, bolt the splitter panel (dividing plate) to the panel over the cooling coil.
- 4. Horizontal Discharge Units: Place the hot deck on top of cold deck and bolt in place with gasketing factory provided. Next, bolt the splitter panel (dividing plate) to the panel over the cooling coil.
- Apply gasketing to the damper section or double-duct frame. Refer to Figure 14. Gasketing is not required at the center of the damper section where the dividing plate will be fastened.
- Assemble the damper or double duct frame to the coil section bolting through the gasketing.

CAUTION: When installing the damper assembly to the hot deck and bypass section, make sure it is mounted squarely, otherwise the damper blades may twist and fail to operate.

- Bolt the hot and cold deck dividing plate to the center of the damper section.
- Attach inlet panel (size 73) or extended plenum (size 86) to coil section inlet with gasketing, factory provided. Bolting for these sections is accomplished from exterior of the unit. See Figure 17.
- Attach flex connector between fan section and coil section (size 73). Attach flex connector between fan section and extended plenum coil section (size 86). Refer to Figure 17 for dimensions.
- Level the unit, fan and/or coil sections to assure proper coil drainage and removal of condensate from the drain pan.
- Connect the ductwork and necessary piping to the unit. Refer to applicable section in this manual.
- Attach the motor, drives and motor splash pan if provided. If the motor was factory installed, check the bolts to make sure they are tight.

NOTE: All constant speed units are balanced at the factory at design rpm. If unit is to operate at more than 5% design rpm a balance check and/or field rebalance will be necessary. Refer to the "Start-Up" section.

HIGH PRESSURE CLIMATE CHANGER — ALL SIZES

NOTE: Check the bearing and sheave setscrews for proper torque settings. Refer to applicable section in this manual.

WARNING: DO NOT LIFT THE UNIT WITHOUT TEST-LIFTING FOR BALANCE AND RIGGING. DO NOT LIFT THE UNIT IN WINDY CONDITIONS OR ABOVE PERSON-NEL. DO NOT LIFT THE UNIT BY ATTACHING A CLEVIS, HOOKS, PINS OR BOLTS TO THE CASING, CASING HARDWARE, CORNER LUGS, ANGLES, TABS OR FLANGES. FAILURE TO OBSERVE THESE WARNINGS MAY RESULT IN PERSONAL INJURY OR DEATH OR EQUIPMENT DAMAGE.

- Attach the mounting legs (Spray Coil Units only) and spring isolators to the fan section, as illustrated in Figure 18.
- Set the fan section in place and fasten isolators to the floor.
- Blow-Thru Units Apply factory provided gasketing to the sections where canvas duct is to be attached.
- Set the coil section in place. Attach the flexible connection. Place the bottom flange of the flexible connection in the V channel of the coil section.
- Attach the splash guard to the bottom of the fan inlet opening, as in Figure 8.
- Attach flexible connection to the fan section. Place the bottom flange of the flexible connection in the V channel of the fan section. Tighten bolts from exterior of the unit.
- 7. Blow-Thru Units Attach horizontal tension restraints (installer-supplied) to the coil section. Span the flexible connection and anchor the restraints to the fan section. See Figure 17. These restraints will counteract reaction forces due to airflow and will relieve pressure from the flexible connection.
- 8. Install accessories.
- Level the unit, fan and/or coil sections to assure proper coil drainage and removal of condensate from the drain pan.
- Connect the ductwork and necessary piping to the unit. Refer to applicable section in this manual.
- Attach the motor, drives and motor splash pan if provided. If the motor was factory installed, check the bolts to make sure they are tight.

Note: All constant speed units are balanced at the factory at design rpm. If unit is to operate at more than 5% of design rpm a balance check and/or field rebalance will be necessary. Refer to "Start-Up" section in this manual.




FIGURE 17 - Fan and Coil Section Ductwork Connections for Blow-Thru High Pressure Units

ACCESSORIES

Matching bolt holes are provided on all accessories for attachment to the unit or to other accessories. Mounting hardware is shipped with each accessory. Mounting legs on filter boxes and mixing boxes are to be attached to isolators and fastened to the floor or suspension device.

HIGH EFFICIENCY BAG FILTER

Before installing the bag filter accessory, be sure adequate clearance is provided to open the filter box and remove filters. Four feet of clearance on the access side of the filter section is recommended. Table 3 lists filter, filter section and diffuser section weights.

The high efficiency bag filter can be used as a prefilter when placed on the inlet side of the fan, a final filter

when placed on the outlet of the fan, or as both when placed in both locations. When used as a prefilter, the canvas duct and diffuser sections are not used, but isolators should be installed by the contractor to ease vibration. When used as a final filter, the canvas duct and diffuser sections are used, but isolators are not required. Installation instructions for both applications follow.

NOTE: The high efficiency bag filters can be operated at up to 100 percent relative humidity, but must not make direct contact with water droplets. Care must be taken to ensure that these filters are not used as prefilters with Sprayed Coil Climate Changers and to avoid water carryover in standard units.




FIGURE 18 - Attaching the Mounting Leg and Spring Isolator to the High Pressure Sprayed Coil Unit

Final Filter Section

When the high efficiency bag filter is used as a final filter, it must be mounted on the outlet side of the fan with the canvas duct and diffuser sections, as shown in Figures 19 and 20. Complete the following to install the final filter section:

NOTE: The final filter and prefilter section on sizes 6-86 can be installed with a right side or left side access door by flipping the filter section to desired access door location. Proper air flow direction thru filter section must be maintained. See Figure 19. Note that on size 3 units the access door is predetermined according to sales order specifications and cannot be modified.

- Bolt the mounting legs to the diffuser and filter sections. Bolts are provided with the assemblies.
- Bolt the canvas discharge duct to the flange on the outlet side of the fan.

NOTE: Single-zone blow-thru units are shipped with the canvas discharge duct bolted to the fan flange.

- Bolt the flange on the canvas discharge duct to the diffuser flange, with gasketing properly installed.
- Bolt the diffuser section to the filter section, with gasketing properly installed.
- For U.L. listed units, the canvas discharge duct is not provided. Install a field-provided connector which meets the requirements of NFPA 90A Sect. 2.1.1 to 2.1.2.3.

6. Level the unit.

Prefilter Section

When the high efficiency bag filter is to be used as a prefilter, it must be mounted to the coil section of a draw-thru unit or to the inlet side of the fan on a blow-thru unit. See Figures 19 and 20. Field-supplied isolators should be used on the filter section mounting legs to control vibration. The bag filter is not designed to be used as a prefilter on Sprayed Coil Climate Changers. Complete the following to install a prefilter section:

NOTE: The final filter and prefilter section on sizes 6-86 can be installed with a right side or left side access door by flipping the filter section to desired access door location. Proper air flow direction thru filter section must be maintained. See Figure 19. Note that on size 3 units the access door is predetermined according to sales order specifications and cannot be modified.

- Bolt the mounting legs to the filter box section and attach isolators. Bolts are provided with the assemblies.
- Bolt the filter box section to the coil section on drawthru units, or to the fan inlet with gasketing installed on blow-thru units.
- 3. Level the unit.




FIGURE 19 - High Efficiency Bag Filter Installation with Draw-Thru Unit (Used as Pre-Filter and Final Filter)




FIGURE 20 - High Efficiency Bag Filter Installation with Single-Zone Blow-Thru Unit (Used as Pre-Filter and Final Filter)




FIGURE 21 - Filter Mounting Track Location (Top View)

Filter Installation

Trane recommends the use of disposable prefilters with high efficiency bag filters. Prefilters slide into mounting tracks just ahead of the bag filter. Bag filter and prefilter size and quantity requirements are the same. See Figure 21 for filter arrangement and complete the following:

Ensure power is disconnected. Open filter section access door.

WARNING: DISCONNECT POWER SOURCE BEFORE OPENING FILTER SECTION ACCESS DOOR. FAILURE TO DO SO MAY RESULT IN INJURY OR DEATH FROM ELECTRICAL SHOCK, HIGH PRESSURE OR MOVING PARTS.

- 2. Remove adjustable blockoff from filter track.
- Slide bag filters and flat prefilters into the appropriate filter tracks. Bag filters must be installed with pleats vertical to airflow.
- 4. Slide adjustable blockoff into filter track.
- Close the access door. If door can be closed without compressing the filters, adjust the blockoff by loos-

ening its adjusting screws, moving the blockoff and tightening the screws. The door should squeeze the blockoff against the filters, compressing them.

NOTE: Filters must have an airtight seal to prevent air bypass. If using other filters, apply foam gasketing to the vertical edges of the filter-holding frame to ensure a tight fit.

For roll filter installation and operation checks, refer to RF-IM-1.

MANOMETER INSTALLATION

A manometer should be used with each bag filter accessory to monitor filter loading and is available from Trane. It should be located to read the pressure drop between the inlet and outlet of the filters. A 1-inch wg pressure difference indicates clogged filters.

WARNING: BAG FILTER FINAL RESISTANCE IS 1 INCH WATER GAUGE. FAILURE TO CHANGE BAG FILTERS AT THIS POINT MAY CAUSE PERSONAL INJURY, DEATH OR EQUIPMENT DAMAGE AS FILTERS WITH DUST MAY BE COMBUSTIBLE.

Five feet of double-column plastic tubing is provided with the gauge along with adapters for connection to 1/8" NPT fittings. To install the manometer, complete the following:

- Mount the manometer in the two 27/64-inch diameter holes drilled in top or side wall of the filter box, using the self-tapping screws provided. Turn the screws down snug, but not tight.
- Adjust the gauge until the bubble is centered in the spirit level. Tighten the mounting screws and check to be sure that the gauge remained level.
- Turn the zero adjust knob counterclockwise until it stops. Then turn it clockwise approximately three full turns so that there is room for adjustment in either direction.
- 4. Remove the fill plug and pour in the provided gauge fluid until the fluid level is visible in the vicinity of zero on the scale. Adjust for exact zero setting with the zero knob and replace the fill plug.
- 5. Install a tubing adapter on each side of the filter.
- Connect the coded red striped tube to the high pressure connection at the top of the gauge (left side) and insert the other end into the field-drilled port and adapter upstream of the bag filters.
- Connect the uncoded tube to the low side connection at the top of the gauge (right side) and insert the other end into the field-drilled port and adapter downstream of the filter bags.




FIGURE 22 - Exhaust Air Economizer Installation

EXHAUST AIR ECONOMIZER

The Exhaust Air Economizer system consists of the economizer section and a Cabinet Fan. The accessory is attached to a Climate Changer with a standard or combination mixing box accessory, as shown in Figure 22. Cabinet Fan size should be identical to Climate Changer size, except as noted below.

NOTE: Unit sizes 35 to 63 can use either the same size Cabinet Fan or a size 31 Cabinet Fan.

The economizer section contains a single damper set, similar to a face damper, which is used to prevent back-wheeling of the exhaust fan when it is shut off. Low leak and Ultra-low leak dampers can be used on the damper assembly. Refer to the Dampers section of this manual for operating torques.

CAUTION: To avoid equipment damage, the pressure differential across the damper must not exceed 3 inches during operation.

To install the Exhaust Air Economizer, complete the following:

- Bolt the Exhaust Air Economizer to the Cabinet Fan with the bolts and gasketing provided.
- If the unit is floor-mounted, fasten the isolators to the floor and mount the accessory on the isolators. If the unit is ceiling-mounted, follow proper safety precautions and hoist the accessory into position, attaching it to the hanger rods.
- Attach the contractor supplied canvas duct to the mixing box flange with sheet metal screws (not provided).
- Screw the canvas duct flange onto the economizer section flange from inside the economizer with sheet metal screws (not provided).
- 5. Attach the return air intake to the economizer section.
- 6. Level the unit. Secure all fasteners.

FAN MOTOR ASSEMBLY

On units that ship motors separately, the fan shafts, sheaves and drive assembly must be checked and aligned before unit operation. Complete the following:

WARNING: DISCONNECT ELECTRICAL POWER BEFORE INSPECTING FAN MOTOR ASSEMBLY. FAILURE TO DO SO MAY RESULT IN INJURY OR DEATH FROM ELECTRICAL SHOCK OR MOVING PARTS.

- Check that the fan shafts fully penetrate the bore of sheaves or sheave bushings. Bushed sheaves should have the bushing flange outboard of the sheave.
- Use a level to check that fan and motor shafts are level and parallel.
- Position the fan sheaves as closely to the drive side bearing as possible.
- Check that the fan sheave keys fully penetrate the bushing or sheave bore.
- Position the motor sheaves on the motor shaft as closely as possible to the motor housing. All sheave setscrews must make full contact with the motor shaft or shaft key.

NOTE: In some cases, motor shafts may not fully penetrate the sheave bore, but the sheave width must never exceed the recommended maximum per NEMA (MG1-14.43 a) for the respective motor size.

- Align sheaves with a straightedge or string. For multigroove sheaves, align center lines.
- Check belt tension. Detailed instructions are given in the Maintenance section of this manual.
- When properly aligned and tensioned, check that no point on the belt nearest the drive bearing is within 1/ 2-inch of unit flanges or structural supports.
- After drive components have been positioned correctly, tighten all sheave setscrews to the torque values given Table 4.

Table 4 - Torques for Tightening Locking Screws, Bearings and Sheaves

TORC	SETSCE		NING			OR TIGHT		
SET SCREW	HEX SIZE	10000	OM.			HEX SIZE	JC2-37738	OM.
DIA.	ACROSS FLATS	INCH LBS.	FOOT LBS.	COL- LAR	SCREW DIA.	ACROSS FLATS	INCH LBS.	FOOT LBS.
1/4"	1/8"	66	5.5	2-015B	8-32	1/8"	70	5.8
5/16"	5/32"	126	10.5	2-13B	8-32	1/8"	70	5.8
3/8"	3/16"	228	19.0	2-17B	10-24	9/64"	90	7.5
7/16"	7/32"	348	29.0	4	2.00			
1/2"	1/4"	504	42.0				2.1	
5/8"	5/16"	1,104	92.0		100 th 111	esplay and	G	- 41.5

NOTE: Tighten bearing setscrews to the torque shown before running unit. Setscrews can loosen in shipment.

DAMPERS

DRIVE ROD ASSEMBLY — BLOW-THRU MULTIZONE UNITS

On all Blow-Thru Multizone units, the zone damper drive rods are recessed to prevent damage during shipment. Before attaching ductwork, complete the following steps and then set the damper zones as instructed after this list. Refer to Figures 23 to 24B.

- Loosen the damper rod clip screws and extend each drive rod 2-1/2 inches beyond the edge of the damper assembly flange. See Figure 23.
- Check each set of damper blades to make sure that they are at 90-degree angles to each other. Move the dampers to be sure they are not binding.
- 3. Tighten all damper rod clip screws.
- 4. Under certain operating conditions, condensate may form on the cold deck portion of the damper section. To prevent this, insulate around the damper rods. Be sure that the insulation does not affect damper operation.

SETTING THE DAMPERS

Dampers on all units must be adjusted to ensure proper operation. Complete the instructions for each damper section. See Figure 24A.

 Select the number of damper segments required for the first zone. Loosen the damper lever set screws and turn all of the damper blades within the zone to the same position.

- 2. Tighten the damper lever set screws for this zone.
- Cut the damper linkage bar at the last lever. Figure 24A illustrates an example that uses two damper segments.
- Set all other zones with the same procedure given above.

NOTE: Damper operators must be connected to damper drive rods on the linkage side of the zone damper section.

DAMPER OPERATORS

Damper operators, levers and linkages, if not factory provided, are to be provided and installed by the contractor. Tables 5 through 8 list approximate values of damper torques to size the damper operators. When two motors are required, use synchronous motors. See Table 8A for actuator torques used with Multizone and 3-Deck Multizone damper units.

To install the operators, connect the motor to the damper drive rods on the linkage side of the zone damper section. Mount damper levers as close to the side of the unit as possible.

High-efficiency mixing box damper torques, given in Table 8, will vary with blade position (percent open), damper arrangement (top/back or top/bottom), pressure differential, cfm conditions and installation. The values given in Table 8 represent the maximums for all of the above conditions up to 0.4 inches of pressure difference and at a blade setting of 25 to 75 percent open. Greater pressure differences or incorrect adjustment will not be compensated for.

When low leak and ultra-low leak dampers are installed, operators should be sized according to operating torques given in Tables 5 through 7. Since low leak and ultra-low




FIGURE 23 - Zone Damper Blade Assembly




FIGURE 24A - Setting the Zone Damper Rods and Damper Linkage

leak damper operating torques are much higher than those for standard dampers, care must be taken to choose a properly sized operator. Stroke distance from full-closed to full-open is 90 degrees.

Low leak dampers with blade seal material, should not be installed in positions where temperatures might exceed 150 F.




FIGURE 24B - Proper Three-Deck Multizone Damper Blade Configuration

TABLE 5 - External Face and Bypass Low Leak Damper Torques (In./Lbs.)

UNIT .	STANDARD		LOW LEA	K DAMPER			ULTRA-LOW I	EAK DAMPER	
SIZE	DAMPER	1" ΔΡ	2" AP	3" AP	4" AP	1" ΔΡ	2" AP	3" AP	4" ΔΡ
3	30	36	37	39	41	39	41	43	44
6	33	43	47	50	53	50	54	57	60
7	33	43	47	50	52	49	53	56	59
8	35	47	52	56	59	55	60	64	67
9	36	47	51	55	58	54	58	62	65
10	36	52	58	63	67	62	68	73	77
12	38	67	65	71	76	70	77	83	88
14	40	63	71	79	85	77	86	94	100
17	42	68	78	87	93	85	95	103	110
21	77	108	120	131	139	128	141	151	159
25	84	121	136	149	159	146	161	173	183
31	93	142	161	177	190	174	193	210	222
35	100	159	182	202	217	198	221	241	256
41	110	190	216	239	256	234	261	283	300
50	124	214	250	280	304	273	310	339	363
63	145	259	305	343	373	335	381	419	449

NOTE:

On larger units with external face and bypass dampers it may be necessary to use two opposed damper operators to avoid excessive bending of damper shaft linkage.

TABLE 6 - Internal Face and Bypass Low Leak Damper Torques (In./Lbs.)

UNIT	STANDARD		LOW LEAK DAMPER				ULTRA-LOW I	LEAK DAMPER	
SIZE	DAMPER	1" ΔP	2" ΔΡ	3" AP	4" ΔP	1" ΔΡ	2" ΔΡ	3" AP	4" ΔΡ
3	30	33	35	36	37	35	37	38	39
6	33	40	43	45	47	44	47	49	51
7	33	39	42	44	46	44	46	48	50
8	35	45	48	52	54	51	55	58	60
9	36	44	46	49	51	48	51	54	56
10	36	48	53	57	60	56	61	65	68
12	38	52	57	62	65	61	66	71	74
14	40	56	63	68	72	67	73	78	83
17	42	62	70	77	82	76	84	90	96
21	77	101	111	119	125	118	127	135	142
25	84	111	122	130	138	129	139	148	155
31	93	129	143	154	164	152	166	178	187
35	100	143	160	174	186	171	188	203	214
41	110	159	179	195	208	192	212	228	241
50	124	183	206	226	242	222	245	265	281
63	145	219	249	274	293	269	298	323	343

NOTE:

On larger units with internal and external face and bypass dampers it may be necessary to use two opposed damper operators to avoid excessive bending of damper shaft linkage.

TABLE 7 - Mixing Box, Combination Filter Mixing Box Low Leak Damper Torques (In./Lbs.)

UNIT	STANDARD		LOW LEA	CDAMPER		ULTRA-LOW LEAK DAMPER				
SIZE	DAMPER	1" ΔΡ	2" ΔΡ	3" AP	4" ΔΡ	1" AP	2" ΔΡ	3" AP	4" ΔP	
3	7	11	13	14	15	14	15	17	18	
6	9	16	18	20	22	20	23	25	27	
7	10	17	20	23	25	22	25	27	29	
8	11	20	23	26	28	25	29	32	34	
9	12	20	23	25	27	25	28	30	32	
10	13	24	28	32	35	31	35	39	42	
12	14	27	32	37	40	35	41	45	48	
14	16	31	38	43	47	42	48	53	57	
17	18	36	44	50	54	48	56	62	67	
21	40	62	71	78	84	77	85	93	98	
25	47	73	83	91	98	90	100	108	115	
31	57	87	99	109	117	107	119	129	137	
35	64	99	112	124	133	122	135	147	156	
41	74	114	130	144	154	141	157	170	181	
50	89	139	158	174	188	171	191	207	221	
63	110	169	192	212	227	208	231	251	266	

NOTE:
On larger units with internal and external face and bypass dampers it may be necessary to use two opposed damper operators to avoid excessive bending of damper shaft linkage.

TABLE 8 - High Efficiency Mixing Box Damper Torque

UNIT SIZE	TORQUE (FTLBS.) AT 0.4" ΔP 25 TO 75% OPEN
3	0.65
6	1.10
8	1.50
10	1.85
12	2.25
14	2.70
17	3.15
21	3.75
25	4.50
31	5.30
35	6.20
41	7.20
50	9.10
63	10.75

INDLE ON -	MINITIZON	c and imi	O DOOR	IAIMICITOI	C LUIIC D	ampo.		sidnes free						
UNIT SIZE	3	6	8	10	12	14	17	21	25	31	35	• 41	50	63
Torque (In./Lbs)	27	29	31	32	33	34	36	38	41	45	48	51	57	66

VARIABLE INLET GUIDE VANES

Inlet vanes are used to regulate fan capacity and to reduce horsepower at lower system requirements.


Inlet guide vane operator motors, if not factory provided, are to be provided and installed by the contractor, according to the operating torques given in Tables 9, 10, and 11. Control lever stroke and radius is given in Figure 25.

Before operation, check the vanes and assembly for freedom of movement. If resistance above the torques given in Tables 9, 10 and 11 is encountered, check for vane damage or linkage misalignment. **Do not force the vanes.** See Figure 25 for typical inlet vane operation. Figures 26 and 27 illustrate FC and AF inlet vanes.

TABLE 9 - Torque and Force Required to Operate Inlet Vanes -AF Fans - Unit Sizes 35-86

		FAI	N OUTLET	VELOCITY	
	TO OPEN	2,000 F	PM	3,000 F	PM
UNIT	OR CLOSE	TORQUE	FORCE	TORQUE	FORCE
SIZE	INLET VANES	(INLBS.)	(LBS.)	(INLBS.)	(LBS.)
35	Open	70.0	7.7	158.0	16.7
	Close	17.0	1.9	39.0	4.3
41	Open	94.0	10.3	214.0	23.5
	Close	23.0	2.6	53.0	5.9
50	Open	128.0	14.1	287.0	31.5
	Close	31.0	3.4	71.0	7.8
63	Open	172.0	18.9	388.0	42.6
	Close	42.0	4.6	96.0	10.6
73	Open	172.0	18.9	388.0	42.6
	Close	42.0	4.6	96.0	10.6
86	Open	172.0	18.9	388.0	42.6
	Close	42.0	4.6	96.0	10.6

When automatic vane control is used, adjustment must be made to avoid forcing the vanes past either the full-open or full-closed positions. A locking lever is furnished if the inlet vanes are to be used with manual control.



NOTES:

- 1. Lever is furnished with the inlet vanes.
- To open the inlet vanes, rotate the control lever clockwise for left-hand mount and counterclockwise for right-hand mount.

FIGURE 25 - Inlet Vane Operation

IABLE 10 -	· rorque and	rorce to	Operate	inlet vane	s - FC Fans	- Unit Sizes 6-3	1
DOLONO CONTRACTOR CONT		M: 000000000000000000000000000000000000	**********************	\$0000000000000000000000000000000000000	*******************************	***************************************	

			FAN OUTLET	VELOCITY	
NO. OF FANS	TO OPEN	-2,0	00 FPM	3,0	00 FPM
AND FAN	OR CLOSE	TORQUE	FORCE (LBS.)	TORQUE	FORCE (LBS.)
SIZE	INLET VANES	(INLBS.)	4" ARM	(INLBS.)	4" ARM
1-101/2	Open	5.7	2.2	19.6	5.1
	Close	2.9	0.8	6.5	1.9
1-121/4	Open	10.0	2.5	22.5	5.7
	Close	3.5	0.9	7.8	2.1
1-131/2	Open	10.9	2.8	24.5	6.2
	Close	3.9	1.0	8.7	2.3
1-15	Open	14.1	3.6	31.9	8.0
	Close	5.0	1.3	11.4	3.0
1-161/2	Open	18.0	4.5	40.5	10.3
	Close	6.4	1.6	14.4	3.7
1-181⁄4	Open	23.1	5.8	52.2	13.3
	Close	8.3	2.1	18.6	4.8
1-20	Open	24.0	6.0	54.0	13.7
	Close	9.0	2.3	19.5	5.1
1-22	Open	25.0	6.3	56.0	14.2
	Close	9.5	2.4	21.0	5.3
1-25	Open	26.5	6.7	59.7	15.1
	Close	10.0	2.5	22.5	5.6
2-131/2	Open	21.8	5.5	49.1	12.4
	Close	7.8	2.0	17.5	4.6
2-15	Open	28.3	7.1	63.9	16.0
	Close	10.1	2.6	22.8	5.7
2-161/2	Open	36.0	9.0	81.1	20.3
	Close	12.8	3.2	28.9	7.3
2-181/4	Open	46.3	11.6	104.4	26.3
	Close	16.5	4.2	37.3	9.4
2-20	Open	48.0	12.0	108	27.2
	Close	18.0	4.5	39.0	9.9

TABLE 11 - Torque and Force Required to Operate Inlet Vanes — FC Fans — Unit Sizes 35-63

	•	d Force nequired to	FAN OUTLET VELOCITY								
		TO OPEN	2000 F	PM	3000 F	РМ	4000 F	PM			
UNIT	FAN SIZE	OR CLOSE INLET VANES	TORQUE (INLBS.)	FORCE* (LBS.)	TORQUE (INLBS.)	FORCE* (LBS.)	TORQUE (INLBS.)	FORCE (LBS.)			
35	25	Open Close	26.5 10.0	6.7 2.5	59.7 22.5	15.1 5.6		r tot _g			
	27	Open Close	115 40	29 10	190 90	48 23	240 140	60 35			
41	27	Open Close	115 40	29 10	190 90	48 23	240 140	60 35			
	30	Open Close	120 50	30 13	200 100	50 25	260 150	65 38			
50	30	Open Close	120 50	30 13	200 100	50 25	260 150	65 38			
63	30	Open Close	120 50	30 13	200 100	50 25	260 150	65 38			

*NOTE: Force is calculated using a 4" lever arm.




FIGURE 26 - Forward Curved Inlet Vanes




FIGURE 27 - Airfoil Inlet Vanes

DUCT CONNECTIONS

All air ducts should be installed in accordance with the standards of the National Fire Protection Association for the Installation of Air Conditioning and Ventilating Systems Other than Residence Type (NFPA 90A), and Residence Type Warm Air Heating and Air Conditioning Systems 90B).

NOTE: Installations that have supply ductwork without return ductwork may be restricted by local codes to serve a space exceeding 25,000 cubic feet in volume.

All inlet and discharge air duct connections to the unit should be made with a flexible material. Typically, about three inches is needed for this connection to rigid ductwork. Do not draw the flexible material tight; leave it sufficiently loose to prevent the transmission of any noise or vibration to the ductwork.

Duct turns and transitions must be made carefully to minimize air friction losses. Avoid sharp turns and use splitters or turning vanes when elbows are necessary, as shown in Figure 28. Make turns in the same direction of rotation as the fan. Discharge ductwork should run in a straight line, unchanged in size or direction, for at least a distance of 1-1/2 fan diameters. See Figure 28.




FIGURE 28 - Discharge Ductwork Recommendations

On two-fan units, both fan discharge openings should be jointed to a common duct after the recommended length of straight run. Figure 29 illustrates a proper duct run that will prevent unequal handling of air by the fans. Maximum duct transition should be 30 degrees. The included angle between joining ducts should not exceed 60 degrees. If necessary, split the duct at any point beyond the common connection.

For multizone units, zone duct clips are provided for attaching the ductwork to each zone. Refer to Figure 30. Inset the clips on the damper partitions as required for the number of zones. Approximately 7/16-inches of space will be left between each zone when the duct collar is placed in the duct clip.

NOTE: When attaching the ductwork to multizone units,

ensure that the duct connection does not interfere with damper blade travel. If necessary, attach the ductwork to the outside of the fan discharge in order to leave the damper clear of obstructions. A clearance of one inch (minimum) is required between ductwork and low leak dampers for proper damper operation.




FIGURE 29 - Discharge Ductwork Recommendations for Two-Fan Units




FIGURE 30 - Zone Duct Clip Installation

PIPING

CONDENSATE DRAIN CONNECTIONS

CAUTION: Failure to provide adequate condensate piping may result in water damage to the equipment or building.

Threaded condensate drain connections are provided on both sides of the coil section drain pan. Pitch the line downward toward an open drain and install a plugged tee to facilitate cleaning. Make sure the drain pan connection openings are unobstructed. Trap the drain line as shown in Figure 31 for draw-thru units and Figure 32 for blow-thru units. Draw-thru units size 73 and 86 have additional drain connections on both sides of the fan section. Run these drain connections into the coil section drain line or to a separate open drain.

Drain connection size on unit sizes 3 through 31 is 1-1/4-inch NPT (external). Drain connections on units size 35 to 86 is 1-1/2-inch NPT (internal). Install pipe caps or plugs on all unused unit drain connections.

Note: For units with optional wide coil, the contractor will need to extend the drain pan nipples under the extended drain pan before connecting the drain trap. Nipple length extension is determined by unit size. For size 3-31 units, add an additional 7½-inches in length. Size 41-50 units, add an additional 12-inches in length. Size 35, 63, 73 and 86 units, add an additional 8½-inches in length.




FIGURE 31 - Drain Trap for Draw-Thru Units




FIGURE 32 - Drain Trap for Blow-Thru Units

SPRAY SECTION PIPING — SPRAYED COIL CLIMATE CHANGER

Sprayed coil units require the following piping to the spray section:

- 1. Make-up water to the float line. See Figure 33A.
- Water line from overflow connection to a trapped drain.
- 3. Shutoff valve and piping to an open or trapped drain.
- 4. Water line to the quick-fill connection.
- Insulation of external piping around the spray pump to prevent condensate runoff.
- 6. Fill the spray tank.
- 7. Adjust the float valve to maintain a level 1/2-inch below the overflow outlet.

NOTE: Air must be purged from the system and spray pump vavle must be adjusted for proper water flow. Instructions are given in the Start-Up section of the CLCH maintenance manual.

CAUTION: Water treatment is required for Sprayed Coil Climate Changers if the supply water is scale forming or corrosive. If neccessary, engage the services of a qualified water treatment specialist. The object of water treatment is to prevent the fouling of the coll surfaces or undue metal damage. THE TRANE COMPANY CAN ASSUME NO RESPONSIBILITY FOR EQUIPMENT FAIL-URES WHICH ARE THE RESULT OF UNTREATED OR IMPROPERLY TREATED WATER.




FIGURE 33A - Sprayed Coil Unit Tank Connections

GENERAL COIL PIPING RECOMMENDATIONS

- Proper installation, piping and trapping is necessary to insure satisfactory coil operation and to prevent operational damage.
- When selecting coil location, allow sufficient space for access to the coil for routine maintenance and service.
- 3. Support all piping independently of the coils.
- Provide swing joints or flexible fittings in all connections that are adjacent to heating coils in order to absorb thermal expansion and contraction strains.
- 5. The Trane Company recommends that a short pipe nipple be used on coil headers prior to making up any welded flange or welded elbow type connections. This allows the use of a back-up pipe wrench when it is necessary to further rotate the welded flange or elbow when lining up bolt holes on the prefabricated piping.

NOTE: Use a "Back-Up Wrench" when attaching piping to coils with copper headers. Do not use brass fittings or brass pipe connectors. Brass distorts easily and causes connection leaks.

Delta-Flo coils have copper headers which extend outside the unit casing so that back-up pipe wrenches can be used.

- 6. When attaching the piping to the coil header, make the connection only tight enough to prevent leaks. Maximum recommended torque is 200 foot-pounds. Use pipe sealer on all threaded connections. The use of Teflon tape or paste is not recommended by Trane.
- After completing the piping connections, seal the gap between the pipe and casing with tape or mastic before insulating the pipes.
- To connect supply and return coil piping, outer coil panels must be removed. If not ordered, drain and vent access holes must be drilled. See Item 9.
- Provisions must be made to drain those coils that are not in use when subjected to freezing temperatures.

CAUTION: Failure to properly drain and vent coils when not in use during freezing temperatures may result in coil freeze-up damage.

Coil types N, NS and A may be adequately drained in their pitched position in the unit. In coilless units, the coil, after field installation, is not pitched (unless special pitching coil support channel is ordered for steam coils) and may be adequately drained in their position in the unit.

(Type N is drainable through the return connection.) The installer must provide appropriate piping for adequate drainage.

Type WL coils are not drainable in either pitched or level position. To drain these coils remove the vent and drain plugs and blow the coils out as completely as possible with compressed air. The coils should then be filled and drained several times with full strength ethylene gylcol so that it will mix thoroughly with the water retained in the coil. Drain the coil out as completely as possible.

Coil types D, DD, and K, plus W, P2, P4, P8, DL and LL are drainable in their factory-installed level position. Coil types D, DD, DL and LL also have Trane factory-installed drain and vent connections. Figures 34 through 39 illustrate coil drain and vent connections.

Drainable coils installed in units containing coil types DL or LL will also have factory-installed drain and vent connections.

NOTE: On units with stacked coils, there is a condensate follower located at each end of the coil connection. Figure 33B illustrates the condensate follower provided at the end of the stacked coils.




FIGURE 33B - Draw-Thru Unit Coil Section Details with View of Condensate Follower




FIGURE 34 - Coil Connections With Drain and Vent Locations (Type WC 24" and Type WS 30" and 33" Headers)




FIGURE 35 - Coil Type P2 Connections with Drain and Vent Locations (18", 24" and 30" Headers)




FIGURE 36 - Coil Type P4 Connections with Drain and Vent Locations (18", 24", and 30" Headers)




FIGURE 37 - Coll Type P8 Connections with Drain and Vent Locations (18", 24", and 30" Headers)




FIGURE 38 - Coll Type W Connections With Drain and Vent Locations (18", 24", 30", and 33" Headers)




FIGURE 39 - Right Hand Coil Type WD Connections with Drain and Vent Locations (6, 8, 10, and 12 Rows)

STEAM COIL PIPING

Refer to Figures 40 to 45 for typical steam coil piping.

CAUTION: Condensate must flow freely from the coil at all times in order to prevent coil damage from water hammer, unequal thermal stresses, freeze-up and corrosion. Complete the following recommendations to prevent coil damage.

CAUTION: Failure to properly drain and vent coils when not in use during freezing temperatures may result in coil freeze-up damage.

- Check that the coil is installed correctly, with airflow in the same direction as indicated on the nameplate coil casing.
- Install a 1/2-inch, 15-degree swing-check vacuum breaker in the unused condensate return tapping as close as possible to the coil.

TABLE 12 — Cooling and Heating Coil — Connection Sizes (Inches NPT)

COIL TYPE	HEADER HEIGHT	SUPPLY	RETURN	VENT	DRAIN
w	18, 24, 30, 33	2.5	2.5	0.5	0.5
D	18, 24, 30, 33	2.5	2.5	0.5	0.5
DD	18, 24, 30, 33	2.5	2.5	0.5	0.5
WD	18, 24, 30, 33	2.5	2.5	0.5	0.5
K	18, 24, 30, 33	2.5	2.5	0.5	0.5
P2	18, 24, 30	0.75	0.75	0.5	0.5
P4	18, 24, 30	1.0	1.0	0.5	0.5
P8	18, 24, 30	1.25	1.25	0.5	0.5
wc	18 24 30, 33	1.0 1.25 2.5	1.0 1.25 1.5	0.5 0.5 0.5	0.5 0.5 0.5
WA	18, 24, 30, 33	2.5	2.5	0.5	0.5
N, NS	18 24 30, 33	2.0 2.5 3.0	1.0 1.25 1.25	NA NA NA	NA NA NA
A, AA	18 24, 30, 33	2.5 2.5	1.0 1.25	NA NA	NA NA
П	18, 24, 30, 33	0.75	0.75	NA	NA
DL	18, 24, 30, 33	1.5	2.0	0.375	0.375
WL	18, 24, 30, 33	1.5	2.0	0.375	0.375
LL	18, 24, 30, 33	2.5	2.5	0.375	0.375

Notes:

- 1. Connections are NPT internal.
- 2. Coil Type NS drains through supply connections.
- Vent the vacuum breaker line to the atmosphere or connect it to the return main at the discharge side of the steam trap.
 - **NOTE:** Vacuum breaker relief is mandatory when the coil is controlled by a modulating steam supply or a two-position (ON-OFF) automatic steam supply valve.
- 4. Run the return pipe at the full size of the steam trap connection except for the short nipple screwed directly into the coil condensate connection. Do not bush or reduce the coil return tapping size.
- 5. With automatic controls, or where the possibility of low pressure supply steam exists, use float and thermostatic traps with atmospheric pressure gravity drain and continuous discharge operation. Locate the steam trap discharge at least 12 inches below the condensate return tapping. Use bucket traps only when supply steam is unmodulated and pressure is 25 psig or higher.
- When coils are installed in a series, size the steam traps for each coil using the capacity of the first coil in airflow direction.
- Always trap each coil separately to prevent holdup in one or more coils.
- Always install strainers as close as possible to the inlet side of the trap.
- Use a V-port modulating valve to obtain gradual modulating action.
- Control each coil bank separately when installing coils for series airflow with automatic steam control valves.

CAUTION: Always open the steam supply control valve slowly to prevent possible coil damage.

 Do not modulate systems with overhead or pressurized returns unless the condensate is drained by gravity to

TABLE 13 - Refrigerant Coil (Type F) Piping Sizes (Inches)

HEADER	NO. OF	CONNECTION	SIZE (INCHES
HEIGHT	CIRCUITS	LIQUID	SUCTION
	2	7/8	13/8
18	3	7/8	1%
	6	11/8	21/8
	12	1%	21/8
- treatment	2	7/8	15/8
24	4	7/8	1%
	8	11/8	21/8
	16	(2)11/8	(2)21/8
	2	7/8	13/8
	4	7/8	15/8
30	5	7/8	21/8
	10	13/8	21/8
	20	(2)1%	(2)21/8
Acres to the	3	7/8	15/8
33	7	11/8	21/8
	11	13/8	21/8
	22	(2)1%	(2)21/8

NOTE: Connections are piping OD.

- a receiver (vented to the atmosphere) and returned to the main by a condensate pump.
- 12. At start-up on units with fresh air dampers, slowly turn the steam on full for at least 10 minutes before opening the fresh air intake.
- 13. Pitch all supply and return steam piping down a minimum of 1 inch per 10 feet in the direction of flow.
- 14. Do not drain the steam mains or take-offs through the coils. Drain the mains ahead of the coils through a steam trap to the return line.
- Overhead returns require 1 psig of pressure at the steam trap discharge for each 2-foot elevation to assure continuous condensate removal.




FIGURE 40 - Typical Piping for Type NS Steam Coils and Horizontal Tubes for Horizontal Airflow




FIGURE 41 - Typical Piping for Type NS Steam Coils and Vertical Tubes for Vertical Airflow




FIGURE 42 - Typical Piping for Type A Steam Coils, High Pressure, Horizontal Tubes for Horizontal Airflow




FIGURE 43 - Typical Piping for Type A Steam Colls, High Pressure, Vertical Tubes for Horizontal Airflow




FIGURE 44 - Typical Piping for Type A or N Steam Coils, Horizontal Tubes for Horizontal Airflow




FIGURE 45 - Typical Piping for Type A or N Steam Coils, Vertical Tubes for Horizontal Airflow

HOT WATER COIL PIPING

Refer to Figures 46 to 48 for typical hot water coil piping.

- Check that the coil is installed correctly, with airflow in the same direction as indicated on the nameplate or coil casing.
 - Type W, WL, DL, and WC hot water coils are self-venting only if the water velocity exceeds 1.5 feet per second. If it is below this rate, vent the coils by either of the following methods:
 - Install an air vent in the top pipe plug tapping of the return header.
 - Vent from the top of the return header horizontally to the return piping if the return line rises and is above the top of the coil.

CAUTION: Do not throttle or modulate the water flow for coils that are exposed to freezing air. Coil damage may result from freeze-up.




FIGURE 46 - Typical Piping for Type WC Water Coil




FIGURE 47 - Typical Piping for Type W, Two-Row Water Coil




FIGURE 48 - Typical Piping for Type W or WA, 1-Row Water Coil

WATER COOLING COIL PIPING

Refer to Figures 49, 50 and 50A for typical water cooling coil piping.

- 1. Check that the coil is installed correctly, with airflow in the same direction as indicated on the nameplate or coil casing.
- 2. Vent both supply and return lines.
- 3. Install a strainer ahead of the control valve, if used.
- Install a drain line and shutoff valve in the supply line near the coil.
- 5. Check for coil fin damage and straighten if necessary.
- 6. Type W, D, K, DL, WL and LL water coils are self-venting only if the water velocity exceeds 1.5 fps. Type DD and WD coils are self-venting only if the water velocity exceeds 2.5 fps. If water velocity is below these minimum values, vent by one of the following methods.
 - Install an air vent in the top pipe plug tapping of the return header, or;
 - b. When the return line rises above the top of the coil, vent from the top of the return header horizontally to the return piping.




Figure 49 - Typical Piping for Type D, W or K Water Cooling Coils with End Connections.




Figure 50 - Typical Piping for Type DD Water Cooling Coil with Center Connections.




Figure 50A - Typical Piping for 2-Row, Type WL and DL Water Coil with Drain and Vent Locations.




FIGURE 51 - Type F Refrigerant Coil

REFRIGERANT COIL PIPING

NOTE: This coil has been dehydrated and charged with a holding charge. To prevent leaks and system contamination, do not break the seals until the coil is installed.

Check that the coil is installed correctly, with airflow in the same direction as indicated on the coil nameplate or casing. The suction connection must be at the bottom of the suction header.

Follow accepted refrigeration piping practices and safety precautions. See Figure 51 for typical refrigerant coil piping. General refrigerant piping recommendations for component selection and line sizing follow. Specific recommendations should be provided with the high-side components, including instructions for pressure testing, evacuation, and system charging.

Leak-test the entire refrigeration system after piping is complete. Charge the unit according to approximate weight requirements and operating pressures. Measure superheat and adjust the thermal expansion valve setting if necessary.

GENERAL REFRIGERANT PIPING RECOMMENDATIONS

Liquid Line Components

Trane recommends the use of a properly sized liquid line filterdrier, installed upstream from the expansion valve and as close to the evaporator coil as possible. Filter-drier selection should be based on a maximum pressure drop of 2 psi at the design condition.

In addition, a moisture indicator/sight glass should be installed between the expansion valve and filter-drier. The moisture indicator/sight glass must be sized to match the size of the liquid line at the thermal expansion valve.

A liquid line shutoff valve with access port should be sized with the selected liquid line OD, and installed close to the condenser.

Other valves, tube bends, and reducers should be minimized, since these items tend to increase pressure drop and reduce subcooling at the expansion valve.

The Thermal Expansion Valve (TEV) must be selected for proper size and capacity. A slightly oversized valve will allow the unit to operate satisfactorily at low-load conditions. The use of a hot gas bypass valve should be taken into account when sizing the TEV.

Liquid line receivers, other than those factory-installed, are **not** recommended.

Suction Line Components

A suction line pressure tap should be installed on the leaving side of the evaporator coil near the TEV sensing bulb location. Accurate superheat measurement and thermal expansion valve adjustment demands that suction pressure be measured near the evaporator coil.

Suction line filter-driers are usually only necessary on systems that have experienced a severe compressor motor burn-out or other failure which results in extremely high refrigerant temperatures. This filter-drier should not be left in the suction line permanently.

Liquid Line Sizing

All compressors have a Refrigerant Charge Limit (RCL) that must not be exceeded. Since the RCL and pressure drop are in direct inflict with each other, Trane recommends that the liquid line be zed as small as possible, while maintaining a low enough pressure drop to ensure 5 degrees F of subcooling at the expansion valve.

Suction Line Sizing

Suction line tubes must be sized to maintain refrigerant vapor velocities that are high enough to ensure oil entrainment under all operating conditions.

Although not harmful, it is not necessary to pitch horizontal suction lines toward the compressor when the refrigerant coil is used with Trane condensing units, which are designed with a gas trap in the suction line just prior to the compressor. This gas trap helps the crankcase heater to stop temperature-induced migration during the off cycle. However, it also eliminates gravity flow to the compressor sump.

WIRING

WARNING: DISCONNECT ELECTRICAL POWER SOURCE BEFORE SERVICING THE UNIT OR CONNECTING ELEC- TRICAL WIRES. FAILURE TO DO SO MAY RESULT IN PER-SONAL INJURY OR DEATH FROM ELECTRICAL SHOCK OR ENTANGLEMENT IN MOVING PARTS.

Wiring to the unit fan motor and the spray pump motor (sprayed coil units only) must be provided by the installer and must comply with all national and local electrical codes. The installer must also furnish a fused disconnect switch in compliance with national and local electrical codes.

CAUTION: Use copper conductors only for terminal connections. Use of aluminum or other type of wiring may result in galvanized corrosion or overheating and resultant equipment damage.

Fan motors require motor overload protective devices that are rated or selected in compliance with the National Electric Code. Specific unit and motor connection diagrams are provided on the unit. If wiring directly to the motor, provide a flexible connection at the motor to permit fan belt adjustment. Fractional-horse-power motors may be factory-connected to a terminal box on the unit. If this construction is provided, complete field wiring to this connection box.

NSTALLATION CHECKLIST

Complete this checklist as the unit is being installed to verify that all recommended installation procedures are accomplished before the unit is started. This checklist does not replace the detailed instructions given in appropriate places in the Installation section of this manual. Read the entire section carefully to become familiar with the installation before installing the unit.

WARNING: DISCONNECT ELECTRICAL POWER BEFORE SERVICING OR INSPECTING THE UNIT. FAILURE TO DO SO MAY RESULT IN PERSONAL INJURY OR DEATH FROM ELECTRICAL SHOCK OR ENTANGLEMENT IN MOVING PARTS.

RECEIVING AND HANDLING

	1. Unit and accessories are inspected for shipping damage or material shortage. Report any claims immediately.
	2. Unit nameplate data agrees with submittal and ordering information.
LIF	TING
	Center of gravity is approximated.
	2. Proper rigging devices are installed, including slings and spreader bars.
	3. Unit is hoisted to its approximate location.
UN	IT LOCATION
	1. Floor or foundation is prepared to support unit weight and to be level.
	2 Sufficient access is provided for unit size clearances and maintenance access

3. Foundation or mounting platform is sized for unit, accessories and mounting legs.

For ceiling-mounted units, suspension frame is selected and prepared.

MOUNTING	
 1. Vibration isolators are installed and fastened to the floor. 	
☐ 2. Shipping angles are removed.	The second s
3. Multi-section units are assembled.	
NOTE: Some units require further assembly after part of the unit is mounted.	
4. Support frame are constructed and attached for ceiling-mounted units.	
5. Assembled units are mounted on isolators or ceiling supports.	
☐ 6. Unit assembly is complete.	
7. Mutti-section units are joined with flexible connection material.	
8. Tension restraints are installed on high-pressure units.	
9. Splash guards are installed where necessary.	
☐ 10. Unit is fastened to isolators.	
☐ 11. Unit is level.	
ACCESSORIES	
1. Bag filter section is installed.	
2. Filters are installed.	
 3. Manometers, if necessary, are installed. 	
4. Exhaust Air Economizer is installed.	
☐ 5. All accessories are installed.	
FAN MOTOR ASSEMBLY	
1. Shafts are properly installed in bearings.	
2. Sheaves are properly located on shafts.	
☐ 3. Shafts are level and parallel.	
4. Sheaves are aligned.	
☐ 5. Belt tension is correct.	
☐ 6. Belt is at least 1/2-inch from unit flanges or structural supports.	
7. All sheave and bearing set screws are tightened to the correct torques	sa glaggim pilat i jarradis amapati jarra 19. – 19. – 19. – 19. Maradis ama
8. Belt guard is installed.	
DAMPERS	
☐ 1. Blow-Thru Mutlizone units — Drive rod assembly is adjusted.	
2. Cold deck damper rods are insulated (if necessary).	
☐ 3. Dampers are set for each zone.	
☐ 4. Damper operators (furnished by the installer) are installed and adjusted.	
INLET VANES	
1. Vanes and rod assemblies move freely. Lubricate if necessary.	
2. Operators and linkage (furnished by the installer) are installed and adjusted.	de transfer a Maria de Maria de Caraca

DUCTWORK

- 1. Intake and discharge connections are made with flexible connection.
 - 2. Discharge ductwork is unchanged in size or direction for at least 1-1/2 fan diameters in length.
 - 3. Adequate clearance is allowed between duct connections and dampers.

PIPING

- 1. Condensate drain lines are trapped, installed and connected to the coil drain pan.
 2. Unused drain connections are plugged.
 3. Spray section piping is complete for sprayed-coil units.
 4. Provisions are made for properly draining and venting all coils.
- 5. Supply and return coil connections are made.
- 6. Supply and return piping is complete.

WIRING

- 1. Supply power is connected to fan motor.
- 2. Wiring direct to fan motor is flexible connection.
- 3. If terminal box is provided, field-wiring to terminal box is complete.
- 4. Supply power is connected to spray pump motor (sprayed-coil units only).
- 5. Fused disconnect switch is installed within sight of unit.
- 6. Motor overload protective devices are installed.

START-UP

WARNING: DISCONNECT ELECTRICAL POWER AND ALLOW ALL ROTATING PARTS TO STOP COMPLETELY BEFORE SERVICING OR INSPECTING THE UNIT. FAILURE TO DO SO MAY RESULT IN PERSONAL INJURY OR DEATH FROM ELECTRICAL SHOCK, ENTANGLEMENT IN MOVING PARTS OR PRESSURE DIFFERENTIAL WITHIN THE UNIT.

PREPARATION

Perform the following checks and inspections before operating the unit:

- With the system de-energized, check that the electrical connections are complete and tight at the terminals.
- 2. Make sure the belt guard is in place.
- Inspect the fan wheels. They should turn freely in the proper direction of rotation.
- As mentioned previously in the Installation section, check the bearing and sheave setscrews for proper torque settings.
 Refer to applicable section in this manual.
- i. Inspect fan belt tension and sheave setscrews. Belt tension, sheave alignment and setscrew torques for the motor assembly are given in this manual.

- Check the piping and valves for leaks. Open or close the valves, depending on their function in the system. Drain lines should be open. If a refrigerant coil is used, the system must be evacuated, leak-tested with dry nitrogen, and charged with refrigerant.
- Check that the air filters are in place and that all dampers are set properly.
- Remove all foreign material from the drain pan. Check the drain pan and condensate line to make sure they are not obstructed.
- All unit access panels must be in place. All screws, nuts and bolts must be tightened to their proper torques.
- On high-pressure units, the coil piping hole gaskets must be installed properly.
- 11. If the unit includes fan paralleling control, open it fully.
- 12. Inspect fan motor and bearing lubrication.

CAUTION: To prevent fan motor or bearing failures, it is necessary that they are lubricated properly. This must be checked before the unit is started for the first time. See the label on the side of the unit, the tag attached to the motor and the Climate Changer Maintenance Manual.

START-UP PROCEDURES

After completing all the items uner "Pre-Start-Up," the unit may be started and the following checks and adjustments performed:

NOTE: High Pressure units with self-locking collar fan bearings. During start-up check rotation of fan shaft to determine if fan motor is wired correctly. Incorrect rotation of fan may cause premature bearing and shaft failure.

- Measure the motor voltage and amps on all phases to insure proper operation. Compare these readings with the motor nameplate.
- If the unit includes a spray pump, open the spray pump air valve and purge air from the system. Adjust the spray pump valve until the spray pattern diameter equals the finned height of the top cooling coil. The resulting gauge pressure should be between 7 and 10 psig.
- 3. If the unit includes fan paralleling control (two-fan, blow-thru units only), adjustment may be required. An indication of an incorrect setting is paralleling of the fan (pulsating operation) and erratic fan motor amperage readings. Adjust the fan paralleling control until fan operation is smooth and the amperage reading is steady.

The fan paralleling control should be closed only far enough to eliminate erratic operation. Rarely should adjustment exceed two inches on either fan. If the devices are closed too far, unit capacity will be reduced.

Each fan paralleling control device has two rods per fan extending upward through the top of the blow-thru fan section. To adjust fan operation for a smooth airflow condition, the following should be done:

- Loosen the locking nut on one rod, lower the rod ½-inch and retighten. Repeat for the other rod on the fan.
- b. If the unstable condition still exists, repeat Step A.
- If the unstable condition still exists, relocate the fan paralleling control to the original position and perform Steps A and B on the other fan.
- d. If the unstable condition still exists, lower both fan paralleling devices to 1-inch from the original position. Repeat Steps A, B, and C, using 1-inch as a base reference.
- 4. Measure voltage at all three wires. Maximum allowable voltage imbalance is two percent. Voltage imbalance is defined as 100 times the sum of the deviation of the three voltages from the average, divided by twice the average voltage. For example, if the three measured voltages are 221, 230 and 227, the average voltage would be 226 volts. The percent of voltage imbalance is then calculated:

$$\frac{100 \times \{ [226-221] + [230-226] + [227-226] \}}{2 \times 226}$$
2.2% (Unacceptable)

In this example, 2.2 percent imbalance is not acceptable and the power company should be notified to correct it.

If the fan speed is changed more than 5% from the original designed rpm, or if parts such as shafts, fan wheels,

bearings, or other drive components are replaced, the unit vibration should be checked.

The unit vibration, measured horizontally and vertically directly on the fan shaft bearing (perpendicular to the shaft centerline), should not exceed 0.2 in/sec. or 3.0 mils, whichever is the lower displacement at the unit operating speed.

SHEAVE ALIGNMENT

To prevent interference of the fan frame with the belt, make sure that the belt edge closest to the motor has the proper clearance from the fan frame, as shown in Figure 52.

Align the fan and motor sheaves by using a straightedge as shown in Figure 53. The straightedge must be long enough to span the distance between the outside edges of the sheaves. When the sheaves are aligned, the straightedge will touch both sheaves at points A through D. A string, drawn tight, may be used in the same manner. For uneven width sheaves, place a string in the center groove of both sheaves and pull tight. Adjust sheaves and tighten the sheave set-screws to the proper torques, given in Table 4.

Parallel operation of the fan and motor shafts is necessary to prolong belt life. Place a level on the shafts to check horizontal alignment. Shim if necessary.




Figure 52 - Minimum Allowable Distance Between Frame Work and Fan Sheave.

FAN ASSEMBLY SETSCREWS

Check and adjust fan wheel, bearing and sheave setscrews whenever a component is removed or an adjustment is made. Refer to Table 4 for recommended Torques.




Figure 53 - Sheave Alignment

FAN WHEEL CLAMPS

The clamps that hold the fan hub on the shaft must be properly esitioned and tightened to ensure safe fan operation.

MOTE: On fans that are 20 inches or smaller, the clamps should be replaced whenever the wheel or shaft is replaced.

On fans that are 20 inches or smaller, locate the two-piece clamp over the hub so that the hub tabs go through the clamp slots. Finger-tighten the two bolts evenly, then torque down both bolts evenly in small increments to 25 foot-pounds. The clamp flanges should meet at both bolt locations before 25 foot-pounds is reached.

On fans that are larger than 20 inches, finger-tighten the three bolts evenly, then torque down all three bolts evenly, in small increments, to 35 to 40 foot-pounds. Visually check the spacing between the three clamp flanges to make sure they are consistently tightened.

FAN BELT TENSION

NOTE: Fan belt tension should be checked at least twice during the first days of operation, since there is a rapid decrease in tension until belts are run in.

WARNING: DISCONNECT ELECTRICAL POWER SOURCE AND ALLOW ALL ROTATING EQUIPMENT TO STOP COM-PLETELY BEFORE INSPECTING OR SERVICING THE UNIT. FAILURE TO DO SO MAY RESULT IN PERSONAL INJURY OR EATH FROM ELECTRICAL SHOCK OR MOVING PARTS. Proper belt tension is required to ensure maximum bearing and drive component life and is based on fan brake horsepower requirement. Use Chart 1 to find the proper tension and refer to the inset for an example. To use the chart, you must know:

- 1. Fan design bhp per belt (not motor hp)
- 2. Fan rpm
- 3. Fan sheave pitch diameter (Figure 54 found by measuring where the middle of the belt rides in the sheave).
- 4. Type of belt cross-section (stamped on the belt)




Figure 54 - Fan Sheave Pitch Diameter

As shown in the example of Chart 1, the correction tension (pounds force) is 9.6 pounds, at ½-inch deflection. Deflection is determined by dividing the belt span distance by 64, as shown in Figure 55.




Figure 55 - Belt Tension Measurement

Table 14 — Values for K Factor (Belt Cross-Section Types)

BELT TYPE															
"K" FACTOR	8	13	40	80	95	6	6	6	6	12	25	11	18	54	101

To measure belt tension, use a belt tensioner as shown in Figure 56. Determine actual deflection by depressing one belt with the belt tensioner and measuring the deflection relative to the other belts or to belt line. Adjust the belt tension the correct pounds force and tighten all setscrews to the proper torques.




Figure 56 - Belt Tensioner

For belt cross-section types not given in Chart 1, refer to Table 14 and use the following equations to calculate correct belt tension:

$$F = \frac{T + K}{16}$$

where F = force measured in pounds at specific deflection

K = constant determined by belt cross-section type (See Table 14).

$$T = 24,750 \times \frac{\text{(fan hp per belt)}}{\text{(belt speed)}}$$

Belt speed =
$$\frac{\text{(fan pitch diameter)}}{12} \times (\pi) \times \text{fan rpm (ft/min)}$$

For example, given the following:

Motor sheave pitch diameter: 16.8 inches, eight groove Fan sheave pitch diameter: 19.8 inches, eight groove

Fan horsepower: 262.4 bhp

Fan rpm: 983 rpm Belt type: 8V

Sheave span: 60.9 inches

Belt speed =
$$\frac{19.8}{12}$$
 x 3.14 x 983 = 5092

$$T = 24,750 \times \frac{(262.4 \text{ bhp/8 belts})}{5092} = \frac{24,750 \times 32.8}{5092} = 159.4 \text{ lbs}$$

$$F = \frac{159.4 + 25}{16} = 11.5 \text{ lbs}$$

Also, D =
$$\frac{\text{Belt span (inches)}}{64} = \frac{60.9}{64} = .95 =$$

approximately 15/16 inches


Therefore, the belt tensioner should read 11.5 pounds force at 15/16-inch deflection. This will yield 159.4 pounds force belt tension.


Belt tensions determined by using Chart 1 and Table 14 are minimum values. The correct operating tension for a V-belt drive is the lowest tension at which the belts will not slip under start-up or peak load conditions. It may be necessary, however, to increase the tension of some drives to reduce excessive belt flopping.


CAUTION: Do not over-tension the belts. Excessive tension will reduce fan and motor bearing life, accelerate belt wear and possibly cause shaft failure.

Remove the belt guard and clean the sheaves and belts with a dry cloth. Oil and gease should be kept away from the belts because they can cause deterioration and slippage. The use of belt dressing is **not** recommended.

For further information on this product or other Trane products, refer to the "Trane Service Literature Catalog", ordering number IDX-IOM-1. This catalog contains listings and prices for all service literature sold by Trane. The catalog may be ordered by sending a \$20.00 check to: The Trane Company, Service Literature Sales, 3600 Pammel Creek Road, La Crosse, WI 54801.










Bldgo AS-202 AS-236 AS-3502 Maintenance CLCH-M-2


Library	Service Literature		
Product Section	Air Handling		
Product	Central Station Air Handlers		
Model	Climate Changers		
Literature Type	Maintenance		
Sequence	2		
Date	January 1986		
File No.	SV-AH-CLCH-CLCH-M-2-186		
Supersedes			

CLIMATE CHANGER® CENTRAL STATION AIR HANDLERS

DRAW-THRU, BLOW-THRU SPRAYED COIL AND HIGH PRESSURE UNITS B DEVELOPMENT SEQUENCE



DRAW-THRU



X39640291-01

BLOW-THRU

Since The Trane Company has a policy of continuous product improvement, it reserves the right to change specifications and design without notice. The installation and servicing of the equipment referred to in this booklet should be done by qualified, experienced technicians.

LITERATURE HISTORY CHANGE:

Delta—Flow Coils added to units, changing design sequence to 'E'.

TABLE OF CONTENTS

SUBJECT		PAGE
GENERAL INFORMATION		2
START-UP		3
MAINTENANCE		4
Periodic Maintenance Checklist		4
Maintenance Procedures		1
Filters		4
Bearings		
Fan Motors		7
Sheave Alignment		/
Setscrews	٠	8
Whool Clamps	٠	8
Wheel Clamps	٠	8
Belt Tension		9
Coil Cleaning		11
Coil Winterization		11
Spray Humidifier Nozzle		12
Manometer Calibration		12
Sprayed Coil Water System	1	12
Thermal Expansion Valve Adjustment		13
TROUBLE ANALYSIS		14
System Check		14
System Analysis Charts		14

GENERAL INFORMATION

Central Station Climate Changers® are air handlers designed to provide complete heating, cooling and dehumidifying by means of wide variety of unit sizes, coils, fans and efficiency capabilities. This manual will cover all vertical and horizontal, draw-thru, blowthru, sprayed coil and high pressure units. A Periodic Mainte-

nance Checklist at the beginning of the Maintenance section provides the suggested routine maintenance schedule. This checklist should not be substituted for the detailed information and procedures contained in appropriate sections of the manual.

START-UP

WARNING: DISCONNECT ELECTRICAL POWER AND ALLOW ALL ROTATING PARTS TO STOP COMPLETELY BEFORE SERVICING OR INSPECTING THE UNIT. FAILURE TO DO SO MAY RESULT IN PERSONAL INJURY OR DEATH FROM ELECTRICAL SHOCK, ENTANGLEMENT IN MOVING PARTS OR PRESSURE DIFFERENTIAL WITHIN THE UNIT.

PREPARATION

Perform the following checks and inspections before operating the unit:

- With the system de-energized, check that the electrical connections are complete and tight at the terminals.
- 2. Make sure the belt guard is in place.
- 3. Inspect the fan wheels. They should turn freely.
- As mentioned previously in the Installation Manual, check the bearing and sheave setscrews for proper torque settings. Refer to applicable section in this manual.
- Inspect fan belt tension. Belt tension, sheave alignment and setscrew torque information is given in the applicable section of this manual.
- Check the piping and valves for leaks. Open or close the valves, depending on their function in the system. If a refrigerant coil is used, the system must be evacuated, leak-tested with dry nitrogen and charged with refrigerant.
- Remove any foreign material from the drain pan. Check the drain pan and condensate line to make sure they are not obstructed.
- All unit access panels must be in place. All screws, nuts and bolts must be tight.
- If the unit includes fan paralleling controls, open them fully.
- 12. Inspect fan motor and bearing lubrication.

CAUTION: To prevent fan motor or bearing failures, it is necessary that they are lubricated properly. This must be checked before the unit is started for the first time. See the label on the side of the unit, the tag attached to the motor, and the Maintenance section of this manual.

START-UP PROCEDURES

After completing all the items uner "Pre-Start-Up," the unit may be started and the following checks and adjustments performed:

NOTE: High Pressure units with self-locking collar fan bearings. During start-up check rotation of fan shaft to determine if fan motor is wired correctly. Incorrect rotation of fan may cause premature bearing and shaft failure. Refer to bearing section in this manual.

 Measure the motor voltage and amps on all phases to insure proper operation. Compare these readings with the motor nameplate.

- If the unit includes a spray pump, open the spray pump air valve and purge air from the system. Adjust the spray pump valve until the spray pattern diameter equals the finned height of the top cooling coil. The resulting gauge pressure should be between 7 and 10 psig.
- If the unit includes fan paralleling control (two-fan, blow-thru
 units only), adjustment may be required. An indication of an
 incorrect setting is paralleling of the fan (pulsating operation)
 and erratic fan motor amperage readings. Adjust the fan paralleling control until fan operation is smooth and the amperage reading is steady.

The fan paralleling control should be closed only far enough to eliminate erratic operation. Rarely should adjustment exceed two inches on either fan. If the devices are closed too far, unit capacity will be reduced.

Each fan paralleling control device has two rods per fan extending upward through the top of the blow-thru fan section. To adjust fan operation for a smooth airflow condition, the following should be done:

- a. Loosen the locking nut on one rod, lower the rod ½-inch and retighten. Repeat for the other rod on the fan.
- b. If the unstable condition still exists, repeat Step A.
- If the unstable condition still exists, relocate the fan paralleling control to the original position and perform Steps A and B on the other fan.
- d. If the unstable condition still exists, lower both fan paralleling devices to 1-inch from the original position. Repeat Steps A, B, and C, using 1-inch as a base reference.
- 4. Measure voltage at all three wires. Maximum allowable voltage imbalance is two percent. Voltage imbalance is defined as 100 times the sum of the deviation of the three voltages from the average, divided by twice the average voltage. For example, if the three measured voltages are 221, 230 and 227, the average voltage would be 226 volts. The percent of voltage imbalance is then calculated:

$$\frac{100 \times \{ [226-221] + [230-226] + [227-226] \}}{2 \times 226}$$
2.2% (Unacceptable)

In this example, 2.2 percent imbalance is not acceptable and the power company should be notified to correct it.

If the fan speed is changed more than 5% from the original designed rpm, or if parts such as shafts, fan wheels, bearings, or other drive components are replaced, the unit vibration should be checked.

The unit vibration, measured horizontally and vertically directly on the fan shaft bearing (perpendicular to the shaft centerline), should not exceed 0.2 in/sec. or 3.0 mils, whichever is the lower displacement at the unit operating speed.

MAINTENANCE

PERIODIC MAINTENANCE CHECKLIST

WARNING: DISCONNECT ELECTRICAL POWER AND ALLOW ROTATING PARTS TO STOP BEFORE SERVICING THE UNIT OR REMOVING THE FAN BELT GUARD. FAILURE TO DO SO MAY RESULT IN PERSONAL INJURY OR DEATH FROM ELECTRICAL SHOCK OR ENTANGLEMENT IN MOVING PARTS.

The following checklist describes the suggested maintenance schedule to maintain proper operation of the unit. Detailed procedures for owner-operator maintenance checks are given after this checklist. For more information on the unit, refer to the Service Guide or contact a local Trane Service Company.

EVERY MONTH

- 1. Inspect air filters. Clean or replace if clogged.
- 2. Inspect air filter manometer for bag filters or roll filters with manual controls. Change bag filters when manometer reading is 1 inch wg. Change roll filters when manometer reading is ½ inch wg.
- Check sump water concentration in Sprayed Coil units to make sure that no corrosive or scaling conditions have been created by poorly treated water.

EVERY THREE TO SIX MONTHS

NOTE: The procedures listed in this section should be completed every three to six months. The frequency of their completion will depend on load and ambient conditions. Detailed procedures following this Maintenance Checklist will give more information on suggested conditions and schedules.

- Check that fan bearing grease lines are tight to the bearings so no grease leaks at the connection.
- 2. Lubricate fan bearings.
- 3. Check bearing locking setscrews and other setscrews for proper tightness. All bearing races must be secure.
- 4. Lubricate fan motors.
- 5. Check sheave alignment and level of shafts.
- Check fan belt tension. Adjust if belts slip. Replace worn or frayed belts with a new matched set.
- Inspect coils for frost or dirt built-up. Clean fins if airflow is clogged.
 - Inspect spray humidifier for lime deposits in the spray nozzle. Clean if flow is clogged.
- 9. Inspect steam grid humidifier wrapping. Replace if flow is clogged.

EVERY YEAR

- Inspect electrical wiring for condition. Tighten all connections.
- Inspect the unit casing and accessories for chipping or corrosion. If damage is found, clean and repaint with a good grade of rust resistant zinc chromate paint.

- Inspect the drain pan for sludge or other foreign material. Clear the drain openings and drain line to ensure adequate flow.
- Check damper linkages, setscrews and blade adjustment for proper tightness and operation. Do not lubricate nylon damper rod bushings.
- 5. Check inlet vane linkages, setscrews and vane adjustment for proper tightness, operation, and alignment.
- 6. Recalibrate the filter manometer.
- 7. Clean and check the water system on Sprayed Coil Climate Changers.

MAINTENANCE PROCEDURES

FILTERS

Table 1 lists air filter sizes and quantities required for all filter boxes. Replace with UL Class 2 approved filters only. Always install filters with directional arrows pointing in direction of airflow.

To clean permanent filters, wash under a stream of hot water to remove dirt and lint. Follow with a wash of mild alkali solution to remove old filter oil. Rinse thoroughly and let dry. Recoat both sides of the filter with Air Maze filter oil or an equivalent and let dry. Replace filter element in the unit.

Bag filters should be replaced when pressure differential across the filter is 1 inch wg. A manometer should have been installed for surveillance of pressure drop across the filter.




FIGURE 1 - Filter Mounting Track Location (Top View)

TABLE 1 - Filter Sizes and Quantities Per Set

UNIT	2-INCH FLAT FILTER BOX	COMBINATION & MEDIUM FILTER BOX	HIGH CAPACITY BOX	BAG FILTER AND PREFILTER (HXW)	4-INCH PLEATED FILTER BOX
3	1-20x25	2-16x25	2-20x25	<u>-</u>	
6	2-20x25	4-16x25	4-20x25		
8	4-16x20	4-20x25	6-20x20	1-24x12 1-24x24	4-16x20
10	4-16x25	6-16x25	6-20x25	2-24x24	4-16x25
12	2-20x20 2-16x25 1-16x20	4-20x25 2-16x25	6-16x20 3-20x25	2-24x12 2-20x20	1-16x20 2-16x25 2-20x20
14	4-16x20 2-20x25	8-16x25	6-20x20 3-20x25	2-24x12 3-20x20	4-16x20 2-20x25
17	6-16x20 2-16x25	8-20x25	3-20x25 9-20x20	1-24x12 3-24x24	6-16x20 2-16x25
21	8-16x20 2-16x25	10-20x25	3-20x25 12-20x20	5-24x20	8-16x20 2-16x25
25	12-16x20	6-20x25 6-16x25	6-20x25 9-20x20	4-24x12 5-20x20	12-16x20
31	7-16x20 7-16x25	8-16x25 12-16x20	8-20x25 12-20x20	10-20x20	7-16x20 7-16x25
35	14-16x25	16-20x25	28-16x25	2-24x12 8-24x24	14-16x25
41	6-16x20 12-20x20	20-20x25	32-16x25	2-24x12 8-24x24	6-16x20 12-20x20
50	7-16x20	28-16x25 14-16x25	35-16x25	15-20x20	7-16x20 14-16x25
63	10-16x25 12-20-25	30-20x25	49-16x25	20-20x20	10-16x25 12-20x25
73	6-20x20 18-20x25	36-20x25	42-20x25		
86	21-20x25 7-20x20	42-20x25	49-20x25	7	

WARNING: MAXIMUM BAG FILTER PRESSURE DROP IS 1 INCH WG. OPERATION OF THE UNIT AT A PRESSURE DIF-FERENTIAL GREATER THAN THIS MAY CAUSE PERSONAL INJURY OR EQUIPMENT DAMAGE FROM COMBUSTION.

Trane recommends the use of optional disposable prefilters with high efficiency bag filters. Prefilters slide into mounting tracks just ahead of the bag filter and serve to prolong the life of bag filters. Figure 1 illustrates bag filter and prefilter installation. Complete the following to install high efficiency bag filters:

 Ensure power is disconnected. Open filter section access door.

WARNING: DISCONNECT POWER SOURCE BEFORE OPENING FILTER SECTION ACCESS DOOR. FAILURE TO DO SO MAY RESULT IN PERSONAL INJURY OR DEATH FROM ELECTRICAL SHOCK, HIGH PRESSURES OR MOVING PARTS.

- Slide bag filters and flat prefilters into the appropriate filter tracks. Bag filters must be installed with pleats vertical to airflow.
- 3. Slide adjustable blockoff into filter track.
- Close access door. If door can be closed without compressing the filters, adjust the blockoff by loosening its screws and sliding it towards the door. The door should

squeeze the blockoff against the filters, compressing them together. Tighten the adjusting screws.

NOTE: Filters must have an airtight seal to prevent air bypass. If using other than recommended filters, apply foam gasketing to the vertical edges of the filter holding frame for a tight seal.



FIGURE 2 - Flange Type Bearing with Grease Fitting and Squeezeloc Tightener

TABLE 2 - Recommendations for Grease Lubricated Fan Bearings

	GREASING INTERVALS					
OPERATING CONDITIONS	-20 F To 140 F	140 F To 200 F				
Clean, Dry	3-6 Months	1-3 Months				
Dirty, Dry	1-3 Months	1-4 Weeks				
Dirty, Wet, High Humidity	1-4 Weeks	1-14 Days				
	RECOMMENDED OPERATING RANGE					
RECOMMENDED GREASES						
Texaco-Multi Fak #2	-20 F to 250 F					
Shell Alvania #2	-20 F to 250 F					
Mobil Mobilux #2	-20 F to 250 F -20 F to 250 F -20 F to 250 F -20 F to 250 F -65 F to 250 F -40 F to 225 F					
Exxon Unirex #2						
Texaco Premium RB						
Mobil 532						
Exxon Beacon						
Keystone Keystone 84 H						

NOTE: Greases used should conform to NLGI No. 2 penetration.

FAN BEARING LUBRICATION

Fan bearings (see Figure 2) with grease fittings or with grease line extensions should be lubricated with a lithium base grease which conforms to NLGI Number 2 for consistency and which is free of chemical impurities. See Table 2 for recommended lubricants. Improper lubrication can result in early bearing failure.

To lubricate the fan bearings, complete the following:

- Bearings are to be lubricated while unit is not running, disconnect main power switch.
- 2. Connect a manual grease gun to the grease line or fitting.
- While turning the fan wheel manually, add grease, preferably when bearing is warm, until a light bead of grease appears at the bearing grease seal.

NOTE: On sizes 35 thru 86 CLCH or other size units with internal opposite drive side bearings, it will be necessary to remove unused bearing plate for observation of bearing grease seal.

CAUTION: Do not over-lubricate bearings. Excessive pressure caused by overlubrication can displace bearing grease seals or cause grease to overheat the bearing, resulting in premature bearing failure.

WARNING: DISCONNECT ELECTRICAL POWER SOURCE BEFORE SERVICING THE UNIT. IF UNIT MUST BE ON FOR MAINTENANCE PROCEDURES, EXERCISE EXTREME CAU-TION. FAILURE TO DO SO MAY RESULT IN PERSONAL INJURY OR DEATH FROM ELECTRICAL SHOCK OR ENTAN-GLEMENT IN MOVING PARTS.

FAN BEARING TIGHTENING INSTRUCTIONS (DOUBLE LOCK SETSCREW)

The pillow block bearing with double setscrew locking arrangement requires specific tightening instructions. See Figure 3. Complete the following.

- Rotate the shaft until the double lock bearing setscrews are in the vertically up position as shown in Figure 4.
- Without V-Belt tension, snug (hand tight) all four setscrews of the double lock bearing in the numerical sequence as shown in Figure 4.




FIGURE 3 - Pillow Block Type Bearing with Grease Fitting and Double Lock Setscrew Arrangement

Torque each setscrew of the double lock bearing in the numerical sequence to 66 inch-pounds. See Figure 4.

FAN BEARING SELF-LOCKING COLLAR INSTALLATION

The pillow block bearing with self-locking collar arrangement is used on size 8-35 High Pressure Climate Changer Units. See Figure 5.

NOTE: At or before start-up check the wiring of the three phase fan motor to assure proper shaft rotation. Incorrect fan rotation may loosen the locking collar resulting in pre-mature bearing failure.

Complete the following recommended steps for bearing replacement.

- Slip the shaft through the pillow block. Be certain the bearing is aligned in position along the shaft to eliminate any possibility of cramping loads.
- Fasten the unit securely to the base using the proper bolt size.




FIGURE 4 - Instruction Sketch for Pillow Block Bearing with Double Lock Setscrew

- Manually rotate fan shaft several times to assure bearing alignment.
- 4. Place the self-locking collar on the shaft with its cam adjacent to the cam on the end of bearing's inner ring. Turn the collar in the direction of shaft rotation. The eccentric recessed cam will drop over and engage the corresponding cam on the bearing inner ring.
- Using a light-weight hammer and drift pin inserted in the drift pin hole strike in the direction of shaft rotation to positively engage the collar. The wide inner ring is now locked to the shaft.
- 6. Tighten the setscrew to recommended torque. See Table 5.




FIGURE 5 - Pillow Block Type Bearing with Grease Fitting and Self-Locking Collar Arrangement

FAN MOTORS

Inspect periodically for excessive vibration or temperature. Operating conditions will vary the frequency of inspection and lubrication. Table 3 lists recommended motor greasing intervals. Motor lubrication instructions are found on the motor tag or nameplate. If not available contact the motor manufacturer for instructions.

To relubricate the motor, complete the following:

WARNING: DISCONNECT POWER SOURCE FOR MOTOR LU-BRICATION. FAILURE TO DO SO MAY RESULT IN INJURY OR DEATH FROM ELECTRICAL SHOCK OR MOVING PARTS.

- 1. Turn the motor off. Make sure it cannot accidentally restart.
- 2. Remove the relief plug and clean out any hardened grease.
- Add fresh grease through the fitting with a low pressure grease gun.
- Run the motor for a few minutes to expel any excess grease through the relief vent.
- 5. Stop the motor and replace the relief plug.

NOTE: If excessive grease is plugged at the motor shaft, use less grease and/or extend the greasing interval.

Refer to Table 4 for minimum torques of motor mounting and bearing bolts.

TABLE 3 - Motor Greasing Intervals

TYPE OF SERVICE	UP TO 7.5 HP MOTORS	10-40 HP MOTORS	50-150 HP MOTORS
8-16 Hrs., Clean, Dry	5 Years	3 Years	1 Year
12-24 Hrs., Moderate Dirt Or Moisture	2 Years	1 Year	6 Months
Severe - Very Dirty, High Temperature	6 Months	3 Months	2 Months

TABLE 4 - Minimum Hex Head Bolt Torques

	TORQUE - FOOT/POUNDS				
BOLT SIZE	GRADE 2	GRADE 5			
1/4" - 20 UNC	4	6			
1/4" - 28 UNF	4	7			
7/16" - 18 UNC	8	14			
7/16" - 24 UNF	9	16			
3/8" - 16 UNC	14	24			
3/8" - 24 UNF	16	28			
/ ₁₆ " - 14 UNC	30	42			
//16" - 20 UNF	35	45			
1/2" - 13 UNC	40	69			
1/2" - 20 UNF	47	83			
9/16" - 12 UNC	57	99			
9/16" - 18 UNF	68	118			
%" - 11 UNC	86	150			
%" - 18 UNF	101	176			
3/4" - 10 UNC	146	254			
3/4" - 16 UNF	173	301			
7/8" - 9 UNC	206	358			
7/8" - 14 UNF	244	422			
1" - 8 UNC	289	500			
1" - 14 UNF	347	602			

NOTE: Grade 2 bolts have no markings on the capscrew. Grade 5 bolts have 3 radial dashes, 120 degrees apart.

TABLE 5 - Torques for Tightening Locking Screws, Bearings and Sheaves

TORC		FOR TIGHTENING TORQUE FOR TIGHTENING SEALMASTER LOCKING COLLAR						AR
SET	HEX SIZE	RECOM. TORQUE				HEX SIZE		OM.
DIA.	ACROSS FLATS	INCH LBS.	FOOT LBS.	COL- LAR	SCREW DIA.	ACROSS FLATS	INCH LBS.	FOOT
1/4"	1/8"	66	5.5	2-015B	8-32	1/8"	70	5.8
5/16"	5/32"	126	10.5	2-13B	8-32	1/8"	70	5.8
3/8"	3/16"	228	19.0	2-17B	10-24	9/64"	90	7.5
7/16"	7/32"	348	29.0					
1/2"	1/4"	504	42.0				The great	200
5/8"	5/16"	1,104	92.0	110			2.00	

NOTE: Tighten bearing setscrews to the torque shown before running unit. Setscrews can loosen in shipment.

Fan motors should be stored indoors in a clean and dry atmosphere and on solid ground. The motor shaft should be turned occasionally to prevent brinelling of the bearings. If motors must be stored outdoors in varying, humid climate, use space heaters and cover the motors as completely as possible to keep them dry. If space heaters have not been installed and motors have been subjected to the elements for several months, the following steps are recommended before operating the motors:

- Inspect bearings for moisture and rust. Replace bearings if necessary and repack with new grease.
- Check motor winding. An acceptable reading is from 6 megohms to infinity. If reading is less than 5 megohms, windings should be dried out in an oven or by a blower.

- 3. Inspect the entire motor for rust and corrosion.
- Lubricate the motor as instructed in this Maintenance manual, or as indicated by the maintenance tag on the motor.

SHEAVE ALIGNMENT

To prevent interference of the fan frame with the belt, make sure that the belt edge closest to the motor has the proper clearance from the fan frame, as shown in Figure 6.

Align the fan and motor sheaves by using a straightedge as shown in Figure 7. The straightedge must be long enough to span the distance between the outside edges of the sheaves. When the sheaves are aligned, the straightedge will touch both sheaves at points A through D. A string, drawn tight, may be used in the same manner. For uneven width sheaves, place a string in the center groove of both sheaves and pull tight. Adjust sheaves and tighten the sheave setscrews to the proper torques, given in Table 5.

Parallel operation of the fan and motor shafts is necessary to prolong belt life. Place a level on the shafts to check horizontal alignment. Shim if necessary.




FIGURE 6 - Minimum Allowable Distance Between Frame Work and Fan Sheave




FIGURE 7 - Sheave Alignment

FAN ASSEMBLY SETSCREWS

Check and adjust fan wheel, bearing and sheave setscrews whenever a component is removed or an adjustment is made. Refer to Table 5 for recommended torques.

FAN WHEEL CLAMPS

The clamps that hold the fan hub on the shaft must be properly positioned and tightened to ensure safe fan operation.

NOTE: On fans that are 20 inches or smaller, the clamps should be replaced whenever the wheel or shaft is replaced.

On fans that are 20 inches or smaller, locate the two-piece clamp over the hub so that the hub tabs go through the clamp slots. Finger-tighten the two bolts evenly, then torque down both bolts evenly in small increments to 25 foot-pounds. The clamp flanges should meet at both bolt locations before 25 foot-pounds is reached.

On fans that are larger than 20 inches, finger-tighten the three bolts evenly, then torque down all three bolts evenly, in small increments, to 35 to 40 foot-pounds. Visually check the spacing between the three clamp flanges to make sure they are consistently tightened.

TABLE 6 - Values for K Factor (Belt Cross-Section Types)

BELT TYPE	A	В	С	D	Е	3L	4L	5L	3V	5V	8V	AX	ВХ	CX	DX
"K" FACTOR															

FAN BELT TENSION

NOTE: Fan belt tension should be checked at least twice during the first days of operation, since there is a rapid decrease in tension until belts are run in.

WARNING: DISCONNECT ELECTRICAL POWER SOURCE AND ALLOW ALL ROTATING EQUIPMENT TO STOP COM-PLETELY BEFORE INSPECTING OR SERVICING THE UNIT. FAILURE TO DO SO MAY RESULT IN PERSONAL INJURY OR DEATH FROM ELECTRICAL SHOCK OR MOVING PARTS.

Proper belt tension is required to ensure maximum bearing and drive component life and is based on fan brake horsepower requirement. Use Chart 1 to find the proper tension and refer to the inset for an example. To use the chart, you must know:

- 1. Fan design bhp per belt (not motor hp)
- 2. Fan rpm
- 3. Fan sheave pitch diameter (Figure 8 found by measuring where the middle of the belt rides in the sheave)
- 4. Type of belt cross-section (stamped on the belt)




FIGURE 8 - Fan Sheave Pitch Diameter

As shown in the example of Chart 1, the correction tension (pounds force) is 9.6 pounds, at $\frac{1}{2}$ -inch deflection. Deflection is determined by dividing the belt span distance by 64, as shown in Figure 9.




FIGURE 9 - Belt Tension Measurement

To measure belt tension, use a belt tensioner as shown in Figure 10. Determine actual deflection by depressing one belt with the belt tensioner and measuring the deflection relative to the other belts or to belt line. Adjust the belt tension to the correct pounds force and tighten all setscrews to the proper torques.





FIGURE 10 - Belt Tensioner

CHART 1 - Belt Tension

10



For belt cross-section types not given in Chart 1, refer to Table 6 and use the following equations to calculate correct belt tension:

$$F = \frac{T + K}{16}$$

where F = force measured in pounds at specific deflection

K = constant determined by belt cross-section type (See Table 6)

$$T = 24,750 x \frac{\text{(fan hp per belt)}}{\text{(belt speed)}}$$

Belt speed =
$$\frac{\text{(fan pitch diameter)}}{12} x(\pi) x \text{ fan rpm (ft/min)}$$

For example, given the following:

Motor sheave pitch diameter: 16.8 inches, eight groove Fan sheave pitch diameter: 19.8 inches, eight groove

Fan horsepower: 262.4 bhp

Fan rpm: 983 rpm Belt type: 8V

Sheave span: 60.9 inches

Belt speed =
$$\frac{19.8}{12}$$
 x 3.14 x 983 = 5092

$$T = 24,750 \text{ x} \frac{(262.4 \text{ bhp/8 belts})}{5092} = \frac{24,750 \text{ x } 32.8}{5092} = 159.4 \text{ lbs}$$

$$F = \frac{159.4 + 25}{16} = 11.5 \text{ lbs}$$

Also, D =
$$\frac{\text{Belt span (inches)}}{64} = \frac{60.9}{64} = .95 =$$

approximately 15/16 inches

Therefore, the belt tensioner should read 11.5 pounds force at 15/16-inch deflection. This will yield 159.4 pounds force belt tension.

Belt tensions determined by using Chart 1 and Table 6 are minimum values. The correct operating tension for a V-belt drive is the lowest tension at which the belts will not slip under start-up or peak load conditions. It may be necessary, however, to increase the tension of some drives to reduce excessive belt flopping.

CAUTION: Do not over-tension the belts. Excessive tension will reduce fan and motor bearing life, accelerate belt wear and possibly cause shaft failure.

Remove the belt guard and clean the sheaves and belts with a dry cloth. Oil and grease should be kept away from the belts because they can cause deterioration and slippage. The use of belt dressing is **not** recommended.

COIL CLEANING

Coils should be kept clean to maintain maximum performance. If fins become dirty, they should be cleaned. Clean steam, hot water and water cooling coils with steam and detergent, hot water spray and detergent, or one of the commercially available chemical coil cleaners. Clean refrigerant coils with cold water and detergent or one of the commercially available chemical coil cleaners. Rinse coils thoroughly after cleaning.

WARNING: DO NOT USE STEAM OR HOT WATER TO CLEAN A REFRIGERANT COIL. IMPROPER APPLICATION OF HEAT MAY RESULT IN PERSONAL INJURY, DEATH OR EQUIPMENT DAMAGE DUE TO HIGH PRESSURE AND EXPLOSION.

COIL WINTERIZATION

Provisions must be made to drain those coils that are not in use when subjected to freezing temperatures.

CAUTION: Failure to properly drain and vent coils when not in use during freezing temperatures may result in coil freeze-up damage.

Coil types N, NS, and A, may be adequately drained in their pitched position in the unit. In coilless units, the coil, after field installation, is not pitched (unless special pitching coil support channel is ordered for steam coils) and may be adequately drained in their position in the unit.

(Type N is drainable through the return connection.) The installer should have provided appropriate piping for adequate drainage.

Type WL coils are not drainable in either pitched or level position. To drain these coils remove the vent and drain plugs and blow the coils out as completely as possible with compressed air. The coils should then be filled and drained several times with full strength glycol so that it will mix thoroughly with the water retained in the coil. Drain the coil out as completely as possible.

Coil types D, DD and K, plus W, P2, P4, P8, DL and LL are drainable in their factory-installed level position. Coil types D, DD, DL and LL also have Trane factory-installed drain and vent connections. See the Installation Manual for illustrated drain and vent connection locations.

Drainable coils installed in units containing coil types DL or LL will also have factory-installed drain and vent connections.

NOTE: On units with stacked coils, there is a condensate follower located at the end of each coil connection. Figure 11 illustrates the location of the condensate follower provided at the end of the stacked coils.

NOTE: Coil type TT is drainable through its supply connection.




FIGURE 11 - Draw-Thru Coil Section Details with View of Condensate Follower

SPRAY HUMIDIFIER NOZZLE

If lime deposits have developed, clean by soaking the nozzle in an industrial cleaning solution intended for that purpose. Rinse thoroughly with water. Follow the application, safety and cleaning instructions of the industrial cleaner.

MANOMETER CALIBRATION

To check and adjust the calibration of the bag filter or roll filter manometer, complete the following:

 Make sure the manometer is properly installed on the unit wall within three feet of the filter section. Drain oil from the gauge. Disconnect top tube.

- Adjust the gauge until the bubble is centered in the spirit level. Tighten the mounting screws and check to be sure that the gauge remained level.
- Turn the zero-adjust knob counterclockwise until it stops. Then turn it clockwise approximately three full turns so that there is room for adjustment in either direction.
- 4. Remove the fill plug and pour in needed gauge fluid until the fluid level is visible in the vicinity of zero on the scale. Adjust for exact zero setting with the zero knob and replace the fill plug.

CAUTION: Use Dwyer red or blue oil only. Other fluids may damage the gauge.

Clean the gauge with a soft cloth and soap and water. Rinse carefully.

SPRAYED COIL WATER SYSTEM

To complete the yearly cleaning and check for sprayed coil spray systems, complete the following:

- Clean the spray tank and the spray pump return line strainer.
 See Figure 12.
- Check the spray float valve and pump pressure. Adjust the float so that the water level is 1/2-inch below the overflow pipe.
- Check that the copper pipe is properly located in the overflow drain and is free of dirt, so that the spray tank water is continually being changed.
- Clean spray nozzles, if necessary, and check for corrosion. Replace damaged nozzles.




FIGURE 12 - Sprayed Coil Unit Tank Connections

THERMAL EXPANSION VALVE ADJUSTMENT

The importance of proper suction gas superheat cannot be over-emphasized. Accurate superheat measurements should be taken with other trouble analysis procedures to monitor refrigerant flow, coil efficiency and compressor protection. Refer to compressor or condensing unit service literature for recommended superheat setting.

Instruments

Because of the importance and sensitivity of superheat measurement and adjustment, the gauges used to measure suction pressure should be of the best quality available. Gauges that are permanently installed on the equipment should not be used. Trane recommends a good quality gauge on a standard refrigerant manifold set. To measure suction temperature, an electronic temperature tester is sufficient.

Measurement

In order to determine suction gas superheat, the pressure at the evaporator outlet must be measured and converted to saturated vapor temperature. Use a Refrigerant-22 pressure temperature conversion chart as given in Table 7 to convert pressure (psig) to temperature (degrees F). The computed saturated vapor temperature is then subtracted from the actual suction temperature, which is also measured on the suction line at the expansion valve sensing bulb location. The difference between these two temperature readings is the suction gas superheat reading.

NOTE: If a pressure tap is not provided at the thermal expansion valve sensing bulb location, suction pressure may be measured at the compressor, if suction line pressure is added to the compressor pressure reading. Suction pressure at the compressor plus estimated suction line pressure loss equals an estimate of suction pressure at the thermal expansion valve sensing bulb location.

To determine actual superheat, complete the following:

- Cut the suction line insulation to gain access to the suction line at the sensing bulb. If Armaflex insulation is used, slit the insulation for the length of the temperature sensor.
- Clean the line carefully and attach the electronic temperature sensor. Make sure the sensor is making good contact with the tube. Black electrical tape may be used to prevent sensor contact with ambient air.

NOTE: For accurate measurement, the temperature sensor must be properly installed and insulated. Make sure that the insulation covers the sensor completely and seal all connections to the pipe to keep ambient air from affecting the temperature readings.

- Install the pressure gauge to monitor suction pressure at the expansion valve sensing bulb location. If no pressure tap is provided, install the pressure gauge at the compressor and estimate the suction line pressure loss between the compressor and sensing bulb.
- Operate the system for approximately 10 to 15 minutes in order for the expansion valve to stabilize.

5. To calculate superheat from pressure and temperature readings, compare the actual vapor temperature of the refrigerant as converted from the suction pressure reading (plus suction line pressure loss, if applicable) to the suction temperature measured by the electronic tester. See the examples given below.

EXAMPLE 1:

SUCTION PRESSURE = 66.0 psig (measured at expansion valve sensing bulb)
SUCTION TEMPERATURE = 52 F
SUCTION PRESSURE CONVERTED TO SATURATED
VAPOR TEMPERATURE = 38 F
SUCTION SUPERHEAT = 52-38 = 14 F

EXAMPLE 2:

SUCTION PRESSURE = 65.0 psig (measured at the compressor)

ESTIMATED SUCTION LINE PRESSURE LOSS = 3 psi TOTAL ESTIMATED SUCTION PRESSURE = 68 psig (at the sensing bulb)

SUCTION TEMPERATURE = 52 F
SUCTION PRESSURE CONVERTED TO SATURATED
VAPOR TEMPERATURE = 40 F
SUCTION SUPERHEAT = 52-40 = 12 F

Adjustment

To increase the superheat reading, turn the adjusting stem of the expansion valve to close the valve and to limit the amount of refrigerant flowing into the evaporator. Adjustment should be made at one-half turn at a time. To

TABLE 7 - Refrigerant-22 Pressure/Temperature Conversion Chart

TEMPERATURE (DEGREES F)	SUCTION PRESSURE (PSIG)
26	49.9
27	51.2
28	52.4
29	53.6
30	54.9
31	56.2
32	57.5
33	58.8
34	60.1
35	61.5
36	62.8
37	64.2
38	65.6
39	67.1
40	68.5
41	70.0
42	71.4
43	73.0
44	74.5
45	76.0
46	77.6
47	79.2
48	80.8
49	82.4
50	84.0

decrease the superheat reading, increase refrigerant flow to the evaporator. Continue with tests and adjustments, onehalf turn at a time, until an acceptable reading is obtained. Allow the system to re-stabilize for 10 minutes after each adjustment. CAUTION: Incorrect superheat readings may be due to plugged filters or blocked refrigerant flow. Before making major adjustments to the expansion valve, check refrigerant level and filter/driers to ensure proper flow. Blocked filters may cause floodback to the compressor, damaging internal components.

TROUBLE ANALYSIS

SYSTEM CHECK

Before repairing or replacing any Climate Changer unit or component, complete the following simple checks. A trouble analysis chart follows this checklist. For more detailed information on the unit, refer to the Service Guide available through your local Trane Sales Office.

WARNING: DISCONNECT ELECTRICAL POWER BEFORE SERVICING OR INSPECTING THE UNIT. DISCONNECT POWER BEFORE REMOVING OR CONNECTING ELECTRICAL WIRES. ALLOW ALL ROTATING EQUIPMENT TO STOP BEFORE SERVICING THE UNIT. FAILURE TO DO SO MAY RESULT IN PERSONAL INJURY OR DEATH FROM ELECTRICAL SHOCK OR ENTANGLEMENT IN MOVING PARTS.

1. Electrical	power is	available	to unit.
---------------------------------	----------	-----------	----------

2.	11	nit	ic	tur	hon	on
6.	U	HIL	13	LUI	nea	OH.

3.	Electrical	routing	and	connections	are	correct.	Refer
	to specific	wiring o	diagra	ams provided	on t	he unit.	

- 4. Filters are clean and properly positioned.
- ☐ 5. Fan belt is not broken or slipping.
- ☐ 6. Fan sheaves are properly aligned.
- 7. Fan is not hitting housing or inlet cone.
- 8. Dampers are not stuck open or closed.
 - 9. Ductwork connections are secure and airtight.
- ☐ 10. Piping has no leaks.
- ☐ 11. Coils are not clogged or frozen.

TROUBLE ANALYSIS CHARTS

Use the tables in this section to assist in identifying the cause or causes of a malfunction in Climate Changer® operation. The column headed RECOMMENDED ACTION will suggest repair procedures.

NOTE: These tables are intended as a diagnostic aid only. For detailed repair procedures, contact your local Trane Service Company.

WARNING: DISCONNECT ELECTRICAL POWER BEFORE INSPECTING OR SERVICING THE UNIT AND ALLOW ALL ROTATING EQUIPMENT TO STOP COMPLETELY. FAILURE TO DO SO MAY RESULT IN PERSONAL INJURY OR DEATH FROM ELECTRICAL SHOCK OR MOVING PARTS.

CLIMATE CHANGER® TROUBLE ANALYSIS

SYMPTOM	POSSIBLE CAUSE	RECOMMENDED ACTION		
Motor fails to start.	Blown fuse or open circuit breaker.	Replace fuse or reset circuit breaker.		
	Overload trip.	Check and reset overload.		
	Improper wiring or connections.	Check wiring with diagram supplied on unit.		
	Improper current supply.	Compare actual supply power wit motor nameplate recommendations Contact power company fo adjustments.		
	Mechanical failure.	Determine that motor and drive turn freely. Check bearings and lubrication.		
	Short-circuited stator.	Indicated by blown fuses. Motor must be rewound.		
	One phase of a three-phase motor is open.	Check line for open phase.		
	Overloaded motor.	Reduce load or replace with larger motor.		

SYMPTOM	POSSIBLE CAUSE	RECOMMENDED ACTION	
Motor stalls.	Low line voltage.	Check across AC line. Correct voltage if possible.	
	Overloaded motor.	Reduce load or replace with a larger motor.	
Motor runs and then dies down.	Partial loss of line voltage.	Check for loose connections. Determine adequacy of main power supply.	
	Stator shorts when motor warms up.	Replace stator.	
Motor does not come up to speed.	Low voltage at motor terminals.	Check across AC line and correct voltage loss if possible.	
	Line wiring to motor too small.	Replace with larger sized wiring.	
	60 cycle motor connected to 50 cycle supply.	Replace with a 50 cycle motor.	
Motor overheats.	Overloaded motor.	Reduce load or replace with a larger motor.	
	Motor fan is clogged with dirt, preventing proper ventilation.	Remove fan cover, clean fan and re- place cover.	
	Three-phase motor has one phase open.	Check wiring. Secure al connections.	
	Improper line voltage.	Check across AC line. Consult power company. Step transformer may be necessary.	
	Worn bearings.	Replace bearings and seals.	
Excessive motor noise.	Motor mounting bolts loose.	Tighten motor mounting bolts.	
	Rigid coupling connections.	Replace with flexible connections.	
	Worn motor bearings.	Replace bearings and seals.	
	Fan rubbing on fan cover.	Remove interference in fan housing	
Rapid motor bearing wear.	Excessive overhung load due to over-tensioned drive.	Check belt tension and overhung load.	
	Excessive overhung load due to a small diameter motor sheave.	Replace sheave with larger one.	
Loose fan belt.	Motor is poorly positioned.	Adjust tension.	
	Worn or damaged belt.	Replace belt or belt set. Check sheave alignment.	
4.5	Worn sheaves.	Replace sheaves.	
Short belt life.	Worn sheaves.	Replace sheaves.	
	Misaligned belt.	Realign drive with MVP sheave set at mean pitch diameter.	
	Grease or oil on belts.	Check for leaky bearings. Clean belts and sheaves.	
	Belt slipping.	Adjust tension.	
	Belts rubbing.	Remove obstruction or realign drive for clearance.	
	High ambient temperature.	Provide ventilation. Shield belts. Use gripnotch belts.	

SYMPTOM	POSSIBLE CAUSE	RECOMMENDED ACTION
Low coil capacity. (CHILLED WATER)	Air is bypassing coil.	Prevent bypass with blockoffs.
	Coil tubes are blocked.	Clean and unblock tubes.
	Incorrect airflow.	Check fan operating conditions.
	Incorrect gpm.	Check water pumps, valves and lines for obstructions.
	Incorrect water temperature.	Provide proper water temperature.
Low coil capacity. (REFRIGERANT)	Air is bypassing coil.	Prevent bypass with blockoffs.
	Coil tubes are blocked.	Clean and unblock tubes.
	Incorrect airflow.	Check fan operating conditions.
	Expansion valve not operating.	Check sensing bulb location and TEV operation.
	Poor refrigerant distribution.	Check for blockage in distributor and tubes.
Low coil capacity. (STEAM)	Air is bypassing coil.	Prevent bypass with blockoffs.
	Tubes are blocked.	Clean and unblock tubes.
	Incorrect airflow.	Check fan operating conditions.
	Incorrect steam pressure.	Adjust pressure supply.
Fan does not operate.	Electrical.	Check fuses, electrical on-off switch, overload protector and voltage output.
	Mechanical.	Look for broken belts or loose pul- leys. Make sure the fan blades are not stopped or obstructed by the fan housing.
Noisy fan.	Fan hitting inlet cone, cutoff, or housing.	Center fan in inlet cone. Secure cutoff in housing. Secure fan on shaft. Repair or replace damaged parts.
	Drive belts not operating properly.	Adjust belt tension. Check for matched set. Replace worn or broken belts and clean oily or dirty belts.
Bearing is excessively hot.	First start after relubrication. (grease distribution)	Allow machine to cool down and restart.
	Over-lubrication.	Clean surface of grease and purge.
	No lubricant.	Apply lubricant. Check bearings for damage.
	Excessive load or speed.	Replace with a larger bearing.
	Misaligned bearing.	Correct alignment. Check shaft level.

For further information on this product or other Trane products, refer to the "Trane Service Literature Catalog", ordering number IDX-IOM-1. This catalog contains listings and prices for all service literature sold by Trane. The catalog may be ordered by sending a \$20.00 check to: The Trane Company, Service Literature Sales, 3600 Pammel Creek Road, La Crosse, WI 54601.



INSTALLER'S GUIDE

BLDC A5-202 18-AC33D1 A5-236 1st Printing, 1984

BTA-IN-3

BTA—B or D CONDENSING UNITS (36.000 - 72.000 BTUH)

ALL phases of this installation must comply with NATIONAL, STATE AND LOCAL CODES.

These instructions do not cover all variations in systems nor provide for every possible contingency to be met in connection with installation. Should further information be desired or should particular problems arise which are not covered sufficiently for the purchaser's purposes, the matter should be referred to The Trane Company, Dealer Products Group.

A. GENERAL

Check for transportation damage after unit is uncrated. Report promptly to the carrier, any damage found to the unit.

To determine the electrical power requirements of the unit, refer to the nameplate of the unit. The electrical power available must agree with that listed on the nameplate.

B. LOCATION & PREPARATION OF THE UNIT

- 1. The unit should be set on a level, reinforced concrete pad 2" larger than the unit on all sides. (Approximate pad size is 35" x 35".) (See Figure 1.)
- 2. The concrete pad must NOT be in direct contact with any structure. Unit must be positioned a minimum of 12" from any wall or surrounding shrubbery to insure adequate airflow. Clearance must be provided in front of control box (access panels) and other sides requiring service access in accordance with National and Local Codes. Also, the unit location must be far enough away from any structure to prevent roof run-off water from pouring directly on the unit.
- 3. The top discharge area must be unrestricted for at least five (5) feet above the unit.
- 4. Mount the unit on mounting pads (shipped with condensing unit) and install in accordance with instruction included with mounting pads.
- 5. When the outdoor unit is mounted on a roof, be sure the roof will support the unit's weight. Vibration isolation is recommended to prevent transmission to the building struc-
- 6. The maximum length of refrigerant lines from outdoor to indoor unit should NOT exceed eighty (80) feet.
- 7. If outdoor unit is mounted above the air handler, maximum lift should not exceed 80 feet (suction line). If air handler is mounted above condensing unit, maximum lift should not exceed 60 feet (liquid line).

NOTE: Refer to "Refrigerant Piping Guide" Pub. No. 22-3040 Tab 16 in "APPLICATION MANUAL."

8. Locate and install indoor coil or air handler in accordance with instruction included with that unit.

C. REFRIGERANT LINES


All "000" series condensing units have provisions for Field Fabricated lines. The indoor section may have Quik-Attach Couplings.

All "700" series condensing units are equipped with "Quik-Attach" line connectors. The use of precharged "Quik-Attach Lines" is recommended.

Standard tire-valve type pressure taps are provided on the precharged lines for installation and service use.

The indoor end of recommended refrigerant lines may be straight or with a 90 degree bend, depending upon situation requirements. This should be thoroughly checked out before ordering refrigerant lines.


The suction (gas) line must always be insulated.



C. INSTALLING REFRIGERANT LINES (Cont.)

The units are factory charged with the system charge required when using 10 feet of connecting line. The precharged lines are provided with the proper charge to accommodate their length. Unit nameplate charge is the total system charge with 25 feet of interconnecting lines.

If refrigerant charge adjustment is considered necessary, use the Charge Charts (Operating Instructions) accompanying the outdoor unit.



- 1. Determine the most practical way to run the lines.
- 2. Consider types of bends to be made and space limitations. NOTE: Large diameter tubing will be very difficult to rebend once it has been shaped.
- 3. Determine the best starting point for routing the refrigerant tubing INSIDE OR OUTSIDE THE STRUCTURE.
- 4. Provide a pull-through hole of sufficient size to allow both liquid and suction (gas) lines plus fittings to clear. The location of this hole (if practical) should be just above the wall plate which is resting on the foundation.
- 5. Be sure the tubing is of sufficient length.
- 6. Uncoil the tubing do not kink or dent. The Quik-Attach fittings with pressure tap connect to the outdoor unit.

DO NOT REMOVE DUST PLUGS FROM COUPLINGS BEFORE ROUTING COPPER TUBING.

7. Route the tubing making all required bends and properly secure the tubing before making Quik-Attach connections.

NOTE: Lines must be isolated from structure and pull-through hole must be sealed weather-tight after installation.

ATTACHING COUPLING QUIK-ATTACH

- 1. Remove the protective plugs from all fittings.
- 2. Oil the face and threads of the couplings with clean refrigerant oil before mating. Make sure that no dirt, water or other foreign material is permitted to adhere to the mating surfaces of the couplings before the halves are connected.
- 3. Engage the fittings by hand tightening the union nut until snug.

CAUTION: The male and female Quik-Attach fittings must be properly aligned to prevent cross threading.

- 4. Continue tightening with a wrench until the coupling halves bottom. A firm metal to metal contact will be felt.
- 5. Advance the union nut another 1/4 turn. This final turn is necessary to insure a proper metal seal of the coupling halves, forming a leak-proof joint. Do NOT continue to tighten the coupling as distortion of the coupling nut will result in a leak.

CAUTION: Correct tightening of the coupling is very important. Undertightening or overtightening will result in a coupling leak.

NOTE: For attaching the indoor connection, follow the instructions packaged with the indoor unit. See Figure 2 as a reference to the appearance of completed indoor Quik-Attach coupling installation.

D. FIELD FABRICATED REFRIGERANT LINES

The routing of the field fabricated lines is done making the same observations as for the precharged lines.

- 1. Minimize the use of sharp 90° bends.
- 2. Cut and fit tubing, then braze using accepted good brazing techniques.
- 3. Use a dry nitrogen purge and brazing alloy without flux for brazing.
- 4. Insulate the entire suction (gas) line and its fittings.
- 5. Do NOT allow uninsulated lines to come into contact with each other.

Upon completion of installation, evacuate, and/or purge the refrigerant lines before connecting to the outdoor unit. If purging with R-22 refrigerant, connect the indoor fittings and purge from the liquid line through the indoor coil and out the suction (gas) line pressure tap.

- 6. Using a manifold gauge, connect an external supply of R-22 to the gauge port tap on the liquid line valve. Position R-22 supply container so only the gas is used in purging.
- 7. Charge connecting lines and indoor coil to the gas pressure of R-22 supply.
- 8. Leak check brazed line connections using soap bubbles or halogen leak detector. Repair leaks (if any) after relieving pressure.
- 9. Close manifold gauge valve, depress valve stem in gauge port on suction (gas) line valve and bleed-off gas pressure in connecting lines and indoor coil down to 2 PSIG.
- 10. Repeat this purging described in steps 7 and 9 two additional times.

NOTE: When the outdoor temperature is below 60°F. and above 40°F., purge the connecting lines and indoor coil four times. When the outdoor temperature is below 40°F., purge the connecting line and indoor coil five times.

If refrigerant lines are to be field fabricated or if precharged lines have been altered in length, it will be necessary to adjust refrigerant, to the system upon completion of installation. Use the following table for recommended amount.

Tubing	g Sizes		Additional
Suction	Liquid	Tubing Length	Refrigerant
1-1/8"	3/8"	15'	5 oz.
1-1/8"	3/8"	25'	12 oz.
1-1/8"	3/8"	32'	18 oz.
1-1/8"	3/8"	40'	24 oz.
7/8"	3/8"	15'	4 oz.
7/8"	3/8"	25'	11 oz.
7/8"	3/8"	32'	16 oz.
7/8"	3/8"	40'	22 oz.
7/8"	5/16"	15'	3 oz.
7/8"	5/16"	25'	8 oz.
7/8"	5/16"	32'	11 oz.
7/8"	5/16"	40'	15 oz.
3/4"	5/16"	15'	2 oz.
3/4"	5/16"	25'	7 oz.
3/4"	5/16"	32'	10 oz.
3/4"	5/16"	40'	13 oz.
5/8"	1/4"	15'	-3 oz.
5/8"	1/4"	25'	0 oz.
5/8"	1/4"	32'	+2 oz.
5/8"	1/4"	40'	+4 oz.

Tubing lengths in excess of forty (40) feet use the following amount:

1-1/8" and 3/8" uses 3 oz. per each 4 ft.

7/8" and 5/16" uses 5 oz. per each 10 ft.

7/8" and 3/8" uses 7 oz. per each 10 ft.

3/4" and 5/16" uses 4 oz. per each 9 ft.

5/8" and 1/4" uses 1 oz. per each 4 ft.

E. LEAK CHECK

Check for leaks with an electronic leak detector or liquid soap. If no leaks are present, insulate the suction (gas) line fittings and exposed tubing to prevent sweating.

F. ELECTRICAL CONNECTIONS

WARNING: When installing or servicing this equipment, ALWAYS exercise basic safety precautions to avoid the possibility of electric shock.

- 1. All electrical lines, sizing, protection, and grounding must be in accordance with national and local electrical codes.
 - 2. Install a separate disconnect switch at the outdoor unit.
- 3. Isolate conduit whenever vibration transmission may cause a noise problem within the building structure.
- 4. Be sure all connections are made tight and no wires exposed.
- 5. All electrical accessories must be installed and wired according to the instructions packaged with that accessory, (see typical Hook-Up diagrams on pages 4, 5 & 6).
- 6. Use color coded, low voltage, multi-wire cable to simplify low voltage connections between outdoor unit, indoor unit and room thermostat for easy identification.

G. ELECTRIC HEATERS

Electric heaters, if used, are to be installed in the air handling device according to the instructions accompanying the air handler and the heaters.

H. OPERATIONAL AND CHECKOUT PROCEDURES

Final phases of this installation are the unit Operational and Checkout Procedure which are found on pages 7 & 8 of this instruction.


I. COMPRESSOR SUMP HEAT

After all electrical wiring is complete, SET THE THER-MOSTAT SYSTEM SWITCH IN THE OFF POSITION SO COMPRESSOR WILL NOT RUN, and apply power by closing the system main disconnect switch. This will activate the compressor sump heat. Do not change the Thermostat System Switch until power has been applied long enough to evaporate any liquid R-22 in the compressor (30 minutes for each pound of R-22 in the system as shown on the name-plate). Following this procedure will prevent compressor damage at the initial startup.

Record the "POWER APPLIED DATA" on the designated lines below:


Time	A.M./P.M. Date	
Ву		
25	(Electrician)	Man while it is

FIELD WIRING DIAGRAM FOR BTA WITH FURNACE (TRANSFORMER IN FURNACE)



From Dwg. 21B308116 Rev. 0

FIELD WIRING DIAGRAM FOR BTA WITH BWV,BWH BWE-C AIR HANDLERS, NO SUPPLEMENTARY HEAT



TO POWER SUPPLY PER LOCAL CODES & AS DEFINED IN FIELD WIRING TABLE

SUPPL. HTR. CONTROL BOX

SEE NOTE 6

SEE NOTE 5

AIR HANDLER

13 PH

R Y2 O

YI

W1 W2 W3 B

FIELD WIRING DIAGRAM FOR BTA WITH BWV,BWH-A or P AIR HANDLERS

ADDED

JUMPER

ROOM THERMOSTAT AY28X092 OR AY28X105

1 2 W G Y R

INTER-COMPONENT WIRING

24 V. FACTORY WIRING

24 V. FIELD WIRING

SET "HA" PER CURRENT

NOTES: 1. POWER WIRING AND GROUNDING OF EQUIPMENT MUST COMPLY WITH LOCAL CODES. 2. BE SURE POWER SUPPLY AGREES WITH EQUIPMENT NAMEPLATE. 3. LOW VOLTAGE WIRING TO BE NO. 18 A.W.G. MINIMUM CONDUCTOR. 4. USE COPPER CONDUCTORS ONLY. 5. POLARIZED PLUG SECTIONS PM-A AND PF-B ATTACHED TO HEATER CONTROL BOX. SECTIONS 1-PF AND 2-PM FACTORY WIRED INTO AIR HANDLER. 6. IF ODT IS NOT USED, THEN CONNECT APPROPRIATE O. D. SECTION R NOTE 7 JUMPERS FROM W1 TO W2 AND W3 ON LVTB _Y_A 7. TO USE LOW AMBIENT COOLING KIT BAY28X123B ON 3 PHASE MODELS, "R" LEAD MUST BE B - A CONNECTED TO "Y" LEAD IN ORDER TO SUPPLY CONTROL VOLTAGE FOR KIT.


TO POWER SUPPLY

PER LOCAL CODES

From Dwg. 21B131067 Rev. 1

FIELD WIRING DIAGRAM FOR BTA WITH BWV,BWH-P AIR HANDLERS AND SUPPLEMENTARY HEATERS (OVER 48 AMPS)


00T-1



FIELD WIRING DIAGRAM FOR BTA WITH BWE-C1 AIR HANDLERS AND SUPPLEMENTARY HEATERS

NOTES

- 1. POWER WIRING AND GROUNDING OF EQUIPMENT MUST COMPLY WITH LOCAL CODES.
- 2. BE SURE POWER SUPPLY AGREES WITH EQUIPMENT NAMEPLATE.
- 3. LOW VOLTAGE WIRING TO BE NO. 18 A.W.G. MINIMUM CONDUCTOR.
- 4. USE COPPER CONDUCTORS ONLY.
- 5. POLARIZED PLUG SECTIONS PM-A AND PF-B ATTACHED TO HEATER CONTROL BOX. SECTIONS PE-A AND PM-R FACTORY WIRED INTO AIR HANDLER
- 6. IF ODT IS OMITTED, THEN CONNECT APPROPRIATE JUMPERS FROM W1 TO W2 AND W3 ON LVTB
- 7. TO USE LOW AMBIENT COOLING KIT BAY28X123B ON 3 PHASE MODELS, "R" LEAD MUST BE CONNECTED ON "Y" LEAD IN ORDER TO SUPPLY CONTROL VOLTAGE FOR KIT



From Dwg. 21C126746 Rev. 2

FIELD WIRING DIAGRAM FOR BTA WITH BWE-C4 AIR HANDLERS AND SUPPLEMENTARY HEATERS

NOTES:


- 1. POWER WIRING AND GROUNDING OF EQUIPMENT MUST COMPLY WITH LOCAL CODES.
- 2. BE SURE POWER SUPPLY AGREES WITH EQUIPMENT NAMEPLATE.
- 3. LOW VOLTAGE WIRING TO BE NO. 18 A.W.G. MINIMUM CONDUCTOR.
- 4. USE COPPER CONDUCTORS ONLY.

TO POWER SUPPLY

- 5. POLARIZED PLUG SECTIONS PM-A AND PF-B ATTACHED TO HEATER CONTROL BOX. SECTIONS PF-A AND PM-B FACTORY WIRED INTO AIR HANDLER.
- 6. IF ODT IS OMITTED, THEN CONNECT APPROPRIATE JUMPERS FROM W1 TO W2 AND W3 ON LVTB.
- 7. IF AIR HANDLER DOES NOT HAVE EDC, THEN CONNECT THIS LEAD TO TERMINAL "Y" ON LVTB.

O. D. SECTION

(3 PH ONLY)



From Dwg. 21C126783 Rev. 1

CHECKOUT PROCEDURE WITH MAIN POWER DISCONNECTS CLOSED (ON)

		Indoor Thermostat				Component Operation					
Step No.	To Check	Switch Set			witch	Indoor Outdoor Compress. Runs		Comp. Sump	Furnace Heat Comes		
		Off	Cool	Heat①	Auto	On	Runs	Runs	Runs		Heat
1	Sump Heat	X			X					X	
2	Indoor Fan Operation	X				X	X		Harris &	X	
3	Cooling Operation		X		X		X	X	X	X	1
4	Check Performance & Charge		X		U:	SE CHAI	X RTS ATTA	X CHED TO (X D.D. UNIT—	Х	
5	Heating ②	2007		X	X		X ①			X	X
6	Inform owner on how to	operate sy	stem an	d what t	o expect	of it. At	the same ti	me deliver	Owner's Use	and Care	Booklet.

① Also set thermostat dial to call for cooling or heating as necessary.

³ Check only necessary if heating unit is used for indoor section and wiring has been disturbed during installation of cooling equipment.

³ Allow time for furnace bonnet switch to heat and close.

CHECKOUT PROCEDURE

After installation has been	completed,	it is recommende	d that the	entire	system	be	checked
against the following list;							

1.	Refrigerant Line, Leak checked []
2.	Suction Lines and Fittings properly insulated []
3.	Have all Refrigerant Lines been secured and isolated properly? []
4.	Have passages through masonry been sealed? if mortar is used,
	prevent mortar from coming into direct contact with copper tubing []
5.	Indoor coil drain line drains freely. Pour water into drain pan []
6.	Supply registers and return grilles open and unobstructed []
7.	Return air filter installed
8.	Thermostat thermometer accuracy. Check against a
	reliable thermometer. Adjust per instructions with thermostat []
9.	Is correct speed tap being used? (Indoor blower motor) []

SYSTEM OPERATIONAL CHECK

IMPORTANT: To prevent compressor damage which may result from the presence of LIQUID refrigerant in the crankcase these procedures should be followed at initial Start-Up and at anytime the power has been off for 12 hours or more.

1. Before proceeding with this "Operational Check", go to "Electrical Section" of this instruction to determine the time compressor heat has been "ON", and make entry on the designated lines, in Step 2.

2. Start-Up Time _____ A.M./P.M. Power Applied Time _____ A.M./P.M. Time Lapse _____ Hours ____ Minutes.

- 3. If Steps 1 and 2 cannot be used, then place thermostat's system switch in the "OFF" position and apply power by closing system disconnect switch. This energizes compressor heat and evaporates the liquid in the crankcase. TO EVAPORATE LIQUID ALLOW AT LEAST ONE-HALF HOUR PER POUND (R-22), AS SHOWN ON UNIT NAMEPLATE.
- 4. Except as required for safety while servicing: DO NOT OPEN SYSTEM DISCONNECT SWITCH.
- 5. After completing above procedures, turn to page 7 for Operational checkout of system(s).

TAB PLACEMENT HERE

DESCRIPTION: CONDENSING ONITS Tab page did not contain hand written information Tab page contained hand written information *Scanned as next image

Confidential Records Management, Inc. New Bern, NC 1-888-622-4425 9/08



INSTALLER'S GUIDE

BLDG AS-236

18-AC30D5 1st Printing, 1987 TTB-IN-2

XE 800 TTB CONDENSING UNITS (12,000 — 24,000 NOMINAL BTUH)

All phases of this installation must comply with NATIONAL, STATE AND LOCAL CODES.

These instructions do not cover all variations in systems nor provide for every possible contingency to be met in connection with installation. Should further information be desired or should particular problems arise which are not covered sufficiently for the purchaser's purposes, the matter should be referred to The Trane Company, Dealer Products Group, Tyler, Texas.

A. GENERAL

The following instructions cover the TTB712-724 Condensing Units.

Check for transportation damage after unit is uncrated. Report promptly, to the carrier, any damage found to the unit.

B. LOCATION & PREPARATION OF THE UNIT

- 1. The unit should be set on a level, concrete pad at least as large as the unit base pan or larger.
- 2. The concrete pad must NOT be in direct contact with any structure. Unit must be positioned a minimum of 12" from any wall or surrounding shrubbery to insure adequate airflow. Clearance must be provided in front of control box (access panels) and any other side requiring service access to meet National and Local Codes. Also, the unit location must be far enough away from any structure to prevent roof run-off water from pouring directly on the unit.
- 3. The top discharge area must be unrestricted for at least five (5) feet above the unit.
- 4. Mount the unit on mounting pads (shipped with condensing unit).
- 5. When the outdoor unit is mounted on a roof, be sure the roof will support the unit's weight. Vibration isolation is recommended to prevent transmission to the building structure.
- 6. The maximum length of refrigerant lines from outdoor to indoor unit should NOT exceed eighty (80) feet.
- 7. If outdoor unit is mounted above the air handler, maximum lift should not exceed eighty (80) feet (suction line). If air handler is mounted above condensing unit, maximum lift should not exceed sixty (60) feet (liquid line).

NOTE: Refer to "Refrigerant Piping Guide" Pub. No. 22-3040 Tab 18 in "APPLICATION MANUAL."

8. Locate and install indoor coil or air handler in accordance with instruction included with that unit.


C. INSTALLING REFRIGERANT LINES

The following steps are to be considered when installing the refrigerant lines (steps apply to both "Precharged Quik-Attach Lines" & "Field Fabricated Lines").

Standard tire-valve type pressure taps are provided on the precharged lines for installation and service use.

There is a 90 degree bend on one end of recommended refrigerant line. Bent end to be installed either inside or outside depending on situation requirements. This should be thoroughly checked out before beginning installation.

The gas line must always be insulated.



The units are factory charged with the system charge required when using 10 feet of connecting line. The precharged lines are provided with the proper charge to accommodate their length. Unit nameplate charge is the total system charge with 25 feet of interconnecting lines.

If refrigerant charge adjustment is considered necessary, use the Charge Charts accompanying the outdoor unit.

- 1. Determine the most practical way to run the lines.
- 2. Consider types of bends to be made and space limitations.

NOTE: Large diameter tubing will be very difficult to rebend once it has been shaped.

3. Determine the best starting point for routing the refrigerant tubing — INSIDE OR OUTSIDE THE STRUCTURE.

C. INSTALLING REFRIGERANT LINES (Cont.)

- 4. Provide a pull-through hole of sufficient size to allow both liquid and gas lines plus fittings to clear. The location of this hole (if practical) should be just above the wall plate which is resting on the foundation.
- 5. Be sure the tubing is of sufficient length.
- 6. Uncoil the tubing do not kink or dent. The Quik-Attach fittings with pressure tap connect to the outdoor unit.

DO NOT REMOVE DUST PLUGS FROM COUPLINGS BEFORE ROUTING COPPER TUBING.

7. Route the tubing making all required bends and properly secure the tubing before making Quik-Attach connections.


NOTE: Lines must be isolated from structure and pull-through hole must be sealed weather-tight after installation.

ATTACHING COUPLING QUIK-ATTACH

- 1. Remove the protective plugs from all fittings.
- 2. Oil the face and threads of the couplings with clean refrigerant oil before mating. Make sure that no dirt, water or other foreign material is permitted to adhere to the mating surfaces of the couplings before the halves are connected.
- 3. Engage the fittings by hand tightening the union nut until snug.

CAUTION: The male and female Quik-Attach fittings must be properly aligned to prevent cross threading.

4. Continue tightening with a wrench until the coupling halves bottom. A firm metal to metal contact will be felt, (See Figure 2).



5. Advance the union nut another 1/4 turn. This final turn is necessary to insure a proper metal seal of the coupling halves, forming a leak-proof joint. Do NOT continue to tighten the coupling as distortion of the coupling nut will result in a leak.

CAUTION: Correct tightening of the coupling is very important. Undertightening or overtightening will result in a coupling leak.

NOTE: For attaching the indoor connection, follow the instructions packaged with the indoor unit. See Figure 2 as a reference to the appearance of completed indoor Quik-Attach coupling installation.

D. FIELD FABRICATED REFRIGERANT LINES

The routing of the field fabricated lines is done making the same observations as for the precharged lines.

- 1. Minimize the use of sharp 90° bends.
- 2. Cut and fit tubing, then braze using accepted good brazing techniques.
- 3. Use a dry nitrogen purge and silver brazing alloy without flux for brazing.
- 4. Insulate the entire gas line and its fittings.
- 5. Do NOT allow uninsulated lines to come into contact with each other.
- 6. Upon completion of installation, evacuate the refrigerant lines and indoor coil before connecting to the outdoor unit:
- a. Attach appropriate hoses from manifold gauge to suction and liquid line pressure taps.
- b. Attach center hose of manifold gauges to vacuum pump.

NOTE: Unnecessary switching of hoses and complete evacuation of all lines leading to sealed system can be accomplished by placing a "T" in manifold center hose and connecting branch hose to cylinder of R-22.

- 7. Evacuate until the micron gauge reads 350 microns.
- 8. Close off valve to vacuum pump and observe the micron gauge. If gauge pressure rises above 500 microns in one (1) minute, then evacuation is incomplete or system is leaking.
- 9. If vacuum gauge does not rise above 500 microns in one (1) minute the evacuation should be complete.
- 10. With vacuum pump and micron gauge blanked off, open valve on R-22 cylinder and charge refrigerant lines and indoor coil to tank pressure of R-22 supply.
- 11. Close valve on R-22 supply cylinder. Close valves on manifold gauge set and remove refrigerant charging hoses.

If refrigerant lines are to be field fabricated or if precharged lines have been altered in length, it will be necessary to adjust refrigerant, to the system upon completion of installation. Use the following table for recommended amount.

Suction	Liquid	Tubing Lengths	Refrigerant
5/8"	1/4"	15'	2 oz.
5/8"	1/4"	25'	5 oz.
5/8"	1/4"	32'	7 oz.
5/8"	1/4"	40'	9 oz.
3/4"	5/16"	15'	2 oz.
3/4"	5/16"	25'	7 oz.
3/4"	5/16"	32'	10 oz.
3/4"	5/16"	40'	13 oz.

NOTE: The refrigerant charge shown on the condensing unit nameplate is the correct charge with up to twenty-five (25) feet of recommended precharged lines connecting the outdoor and indoor units.

E. ELECTRICAL CONNECTIONS

3/4" and 5/16" uses 4 oz. per each 9 ft.

WARNING: When installing or servicing this equipment, ALWAYS exercise basic safety precautions to avoid the possibility of electric shock.

- 1. Power wiring and grounding of equipment must comply with local codes.
- 2. Power supply conductors to the outdoor unit must be in weatherproof insulation or conduit and must conform to local codes.
- 3. Install a separate disconnect switch at the outdoor unit.
- 4. Provide flexible electrical conduit whenever vibration transmisson may create a noise problem within the structure.
- 5. The use of color coded low voltage wire (24V. 18 AWG minimum) is recommended to simplify connections between the outdoor unit, the thermostat and the indoor unit.
- 6. Mount the indoor thermostat in accordance with instruction included with the thermostat. Wire per appropriate Field Wiring diagram (included in these instructions).
- 7. If there is no fan relay in indoor unit, install one inside control compartment and wire per Field Wiring diagram.
- 8. The diagrams on page 3 & 4 represent typical Field Wiring of Matched Systems (for addition of supplementary electric heaters see Product Data).

F. COMPRESSOR SUMP HEAT

This unit is supplied from the factory with the optional compressor heat activated. The Seasonal Energy Efficiency Rating (SEER) is obtained WITHOUT the compressor heat energized. Compressor heat IS NOT required where connecting refrigerant lines are 25 feet or less in length. Disconnect the CRA capacitor as shown on the wiring diagrams to de-energize compressor heat.

Where connecting refrigerant line lengths exceed 25 feet activate the compressor heat per wiring diagram inside the unit control box.

Set the Thermostat System Switch in the off position so compressor will not run, and apply power by closing the main disconnect switch. This will activate the compressor sump heat. Do not change the Thermostat System Switch until power has been applied long enough to evaporate any liquid R-22 in the compressor (30 minutes for each pound of R-22 in the system as shown on the nameplate). Following this procedure will prevent compressor damage at initial start-up.

Record the "POWER APPLIED DATA" on the designated lines below:

Time ______ A.M./P.M. Date _____ By

Electrician

G. OPERATIONAL AND CHECKOUT PROCEDURES

Final phases of this installation are the unit Operational and Checkout Procedure which are found on pages 5 & 6 of this instruction.


H. ELECTRIC HEATERS


Electric heaters, if used, are to be installed in the air handling device according to the instructions accompanying the air handler and the heaters.

I. START CONTROL KIT

Provision is made on these units for a field installed BAY41X228 accessory quick start kit, as required. The kit is to be installed outside the cabinet of the unit.


CAUTION: These units require installation of a start kit if indoor unit is equipped with a non-equalizing expansion valve.





From Dwg. 21B308116 Rev. 5

TTB712-724 OUTLINE DRAWING



CHECKOUT PROCEDURE WITH MAIN POWER DISCONNECTS CLOSED (ON)

		Indoor Thermostat Switch Setting					Com	Component Operation					
	To Check					Indoor	Outdoor	Compress.	Comp.	Furnace			
Step No.		System Switch		Fan S	witch	Blower	Fan	Runs	Sump	Heat			
IVO.		Off	Cool①	Heat①	Auto	On	Runs	Runs		Heat	Comes On		
1	Sump Heat 4	X		10%	X	76				X			
2	Indoor Fan Operation	X		1		X	X			X			
3	Cooling Operation		X		X		X	X	X				
4	Check Performance & Charge	4	X		U	SE CHAI	X RTS ATTA	CHED TO	D.D. UNIT—				
5	Heating ②			X	X		X3			X	X		
6	Inform owner on how to	operate sy	ystem an	d what t	o expect	of it. At	the same t	ime deliver	Owner's Use	and Care	Booklet.		

- ①Also set thermostat dial to call for cooling or heating as necessary.
- ②Check only necessary if heating unit is used for indoor section and wiring has been disturbed during installation of cooling equipment.
- (3) Allow time for furnace bonnet switch to heat and close.
- (4) Unit is supplied with optional sump heat activated. If refrigerant lines exceed 25 feet, do not deactivate sump heat.

CHECKOUT PROCEDURE

Afte	er installation has been completed, it is recommended that the entire system be checked against the following list;
1.	Refrigerant Line, Leak checked
2.	Suction Lines and Fittings properly insulated
	Have all Refrigerant Lines been secured and isolated properly? [
	Have passages through masonry been sealed? If mortar is used, prevent mortar from coming into direct contact with copper tubing
5.	Indoor coil drain line drains freely. Pour water into drain pan
	Supply registers and return grilles open and unobstructed
	Return air filter installed
	Thermostat thermometer accuracy. Check against a reliable thermometer. Adjust per instructions with thermostat
9.	Is correct speed tap being used? (Indoor blower motor)
	SYSTEM OPERATIONAL CHECK
efri	ORTANT: To prevent compressor damage which may result from the presence of LIQUID gerant in the crankcase, these procedures should be followed at initial Start-Up and at time the power has been off for 12 hours or more.
1.	Before proceeding with this "Operational Check," go to "Compressor Sump Heat Section" of this instruction to determine the time compressor has been "ON," and make entry on the designated lines, in Step 2.
2.	Start-Up Time A.M./P.M. Power Applied Time A.M./P.M. Time Lapse Hours Minutes.
	If Steps 1 and 2 cannot be used, then place thermostat's system switch in the "OFF" position and apply power by closing system disconnect switch. This energizes compressor heat and evaporates the liquid in the crankcase. TO EVAPORATE LIQUID ALLOW AT LEAST ONE-HALF HOUR PER POUND (R-22), AS SHOWN ON UNIT NAMEPLATE.
	Except as required for safety while servicing: DO NOT OPEN SYSTEM DISCONNECT SWITCH.

5. After completing above procedures, turn to page 5 for Operational checkout of

Library	Service Literature
Product Section	Unitary
Product	Split Systems A/C - Condensing Units
Model	TTB
Literature Type	Installer's Guide
Sequence	2
Date	June 1987
File No.	SV-UN-S/S-TTB-IN-2 6/87
Supersedes	
Ordering No.	

The Trane Company
Dealer Products Group
Troup Highway
Tyler, TX 75711
© American Standard Inc. 1987

system(s).



REDDI FACTS

Air Conditioner Model: BTA048D300A0

IMPORTANT — This document is customer property and is to remain with this unit. Please return to service information pack upon completion of work.

PRODUCT SPECIFICATIONS

OUTDOOR UNIT	BTA048D300A
POWER CONNS. — V/Ph/Hz Min, Brch. Cir Ampacity® Br. Cir. — Max. (Amps) Prot. Rtg. (Amps) Noise Rating No.®	200/230/3/60 23.2 35 35 8.6
COMPRESSOR No. Used — No. Speeds /olts/Ph/Hz R.L. Amps — L.R. Amps Brch. Cir. Selec. Cur. Amps	Climatuff™ 1 — 1 200/230/3/60 16.3 — 117 16.3
OUTDOOR FAN — Type Dia. (in.) — No. Used Type Drive / No. Speeds CFM @ 0.0 in. w.g. No. Motors — HP Motor Speed R.P.M. Volts/Ph/Hz F.L. Amps — L.R. Amps	Propeller 22 — 1 Direct — 1 4600 1 — 0.50 1075 200/230/1/60 2.8 — 8.4
OUTDOOR COIL — Type Rows — F.P.I. Face Area (sq. ft.) Tube Size (in.)	Spine Fin [™] 1 — 20 19.5 1/2
REFRIGERANT Lbs. — R-22 (0.D. Unit)® Factory Supplied Line Size — in. 0.D. Gas® Line Size — in. 0.D. Liq.®	10 lb. 8 oz. Yes 1.12 0.38
DIMENSIONS Outdoor Unit — Crated (in.)	H x W x D 39-3/16 x 32-7/16 x 34-3/16
WEIGHT Shipping (lbs.) Net (lbs.)	265 257

① Rated in accordance with A.R.I. Standard 210. ② Rated in accordance with A.R.I. Standard 270.







SAFETY NOTICE

THIS INFORMATION IS INTENDED FOR USE BY INDIVIDUALS POSSESSING ADEQUATE BACKGROUNDS OF ELECTRICAL AND MECHANICAL EXPERI-ENCE. ANY ATTEMPT TO REPAIR A CENTRAL AIR CONDITIONING PRODUCT MAY RESULT IN PERSONAL INJURY AND OR PROPERTY DAMAGE. THE MAN-UFACTURER OR SELLER CANNOT BE RESPONSIBLE FOR THE INTERPRETATION OF THIS INFORMATION, NOR CAN IT ASSUME ANY LIABILITY IN CONNECTION WITH ITS USE.

Library Service Literature **Product Section** Unitary Split System A/C Product Model BTA Service Facts Literature Type Sequence 13AA Date March 1987 File No. SV-UN-S/S-BTA-SF-13AA 3/87 Supersedes Ordering No.

OPTIONAL EQUIPMENT

OPTIONAL EQUIPMENT FOR OUTDOOR UNITS

Indoor Thermostats —
Horizontal, Heat/Cool Only w/ Manual
Switchover
Vertical, Cool Only w/Fan Switch AY28X104
Vertical, Heat/Cool w/Manual Switchover AY28X105
Horizontal, Heat/Cool BAY28X182
Outdoor Thermostat Kit
Includes Thermostat AY28X125 and Mtg.
Brkt., for 46°F. to -10°F. (Adjustable) BAY28X125A
Evaporator Defrost Control Kit Needed for
Cooling Operation Between 55° and 40° AY28X79
Head Pressure Control Kit BAY28X123B
Head Pressure Control Kit BAY28X123C
Coupling Kit — 7/8" Tube (90° Bend),
-11 Coupling, 3/8" Tube -6 Coupling BAY71X103
Coupling Kit — 7/8" Tube -11 Coupling,
3/8" Tube -6 Coupling
Coupling Kit — 1-1/8" Tube (90° Bend),
-11 Coupling, 3/8" Tube -6 Coupling BAY71X105
Coupling Kit — 1-1/8" Tube -11 Coupling,
3/8" Tube -6 Coupling

TUBING INFORMATION

Tubing	Sizes		Additional		
Suction	Liquid	Tubing Length	Refrigerant		
1-1/8"	3/8"	15'	5 oz.		
1-1/8"	3/8"	25′	12 oz.		
1-1/8"	3/8"	32'	18 oz.		
1-1/8"	3/8"	40'	24 oz.		

- ③ Calculated in accordance with National Electric Code. Suitable for use with HACR circuit breakers or fuses.
- Standard Air Dry Coil Outdoor. ® This value approximate. For more precise value see unit nameplate and service instruction
- ® Max. linear length 80 ft; Max. lift Suction 60 ft; Max lift Liquid 60 ft. Max. length of precharged tubing 40 ft. For greater length refer to Refrigerant Piping Manual Pub. No. 22-3040.
- Rated in accordance with D.O.E. test procedure.

RECONNECT ALL GROUNDING DEVICES

ALL PARTS OF THIS PRODUCT CAPABLE OF CONDUCT-ING ELECTRICAL CURRENT ARE GROUNDED. IF GROUNDING WIRES, SCREWS, STRAPS, CLIPS, NUTS OR WASHERS USED TO COMPLETE A PATH TO GROUND ARE REMOVED FOR SERVICE, THEY MUST BE RETURNED TO THEIR ORIGINAL POSITION AND PROP-ERLY FASTENED.

DISCONNECT POWER BEFORE SERVICING

The Trane Company

P.I. 3/87 © American Standard Inc. 1987

Dealer Products Group • Troup Highway • Tyler, TX 75711

Dwg. No. 21A136821 P01 Page C-64

LEGEND

REDDI PARTS

COMPONENT	QTY.	DESCRIPTION	CATALOG #
Capacitor (CF)	1	5 MFD, 370V	WG20X26
Coil, Outdoor	1	Replacement	WW88X230
Compressor Internal Line Break (IOL) Internal Press. Relief (IPR)	1	CT50HK3A: FLA 20.0 LRA 117.0, Wind. res. @ 77°F. = .624 Ohms Opens on rise in winding temp Resets in 30-90 min. Open on 350# diff. between high & low side pressure	Order by unit model #
Contactor (MS)	1	Type DPST, Contacts 240V, FLA 25.0, LRA 125.0, Coil 24V, .95 A.In., .53 A.Hld., #3ARR8FE4	WW24X138
Drier	1	Suc. Line w/Sweat Fit., 30 Cu. In., 1%"x1%"	WW22X70
Drier	. 1	Liq. Line w/Sweat Fit., 8 Cu. In., 1/2" X 1/2"	WW22X101
Fan •	1	4 Blade, 22" Dia., 1/2" Bore, 30° CW * Hub Up	WW73X79
Motor		208/230V, 60 Hz., 1 Ph., Closed Shell, CCW, 1125 RPM, 1/2 HP, 1-Speed, FLA 3.0, LRA 12.0, Ball Bearings, Winding resistance — Ohms @ 77°F: Blk. to White 6.15/5.29 Brn. to Blk. 72.7/62.5	WW94X316
Relay, Sump Heater * (SR)	1	Type SPDT, Contacts 230V, FLA 5.0, LRA 15.0, Coil 230V., 177 A.In., 2.0 A. HLD., #KU1885	WW24X158
Slinger	1	1/2" Dia. Bore	WW72X67
Sump Heater	1	230V, 65 W., Res. Heater, Cart. Type	WW08X65
Switch, Low Pressure 1 Cut-Out (LPCO)		Cut-Out Pressure: Opens @ 8 ± 4 PSIG, Resets 25 ± 7 PSIG, #20PS100BE025G008D, T.I.	WW26X90
Thermostat	1 1 1 1	AY28X92, Heat/Cool, Manual, Horizontal AY28X104, Cool only, w/Fan Switch, Vertical AY28X105, Heat/Cool, Manual, Vertical BAY28X182, Single Stage, Heat/Cool	WY28X92 WY28X104 WY28X105 WW28X182

*New Part - Set Up Within The Last 18 Months


Parts List For Optional Head Pressure Control Kit

BAY28X123B&C

Auto Transformer	1	Carson #6131; @ 230V, Red 116.0 VAC, Orange 134.5 VAC, Yellow 200.0 VAC, @ 460V, Red 232.0 VAC, Orange 273.0 VAC, Yellow 400.0 VAC	WW32X57
Fuse (Used only on BAY28X123C)	1	5 Amp, 600 Volt	WW23X195
Pressure Switch (HPCO)	1	#20PS104DF280K160R, Opens @ 280 ± 10 PSIG, Closes @ 160 ± 10 PSIG	WW26X79
Relay, (ODFA)	1	Type SPDT, Contacts 240/480V, FLA 6/3, LRA 35/18, Coil 24V, .53/.61 A.In., .26/.31 A.Hld., #R8222B-1158	WW24X70
Relay (ODFB)	1	Type DPDT, Contacts 240V, 180 LRA, 30 FLA, Coil 24V, .615 A.In., .41 A.Hld., 50-60 Hz, P&B #PRD11AG1-24V	WW24X137
Thermostat (OFTA)	1	#20606L42-4111, Opens @ 55° ± 6°F., Closes @ 45° ± 6°F.	WW28X119
Thermostat (OFTB)	1	#20606L42-802, Opens @ 35° ± 6°F., Closes @ 25° ± 6°F.	WW28X120

SCHEMATIC DIAGRAM

* THERMALLY PROTECTED INTERNALLY



BTA048D300A0

NOTES: 1. LOW VOLTAGE (24 V.) FIELD WIRING MUST BE NO. 18 AWG 2. USE COPPER CONDUCTORS. IF ALUMINUM OR COPPER-CLAD ALUMINUM POWER WIRING IS USED, CONNECTORS WHICH MEET ALL APPLICABLE CODES AND ARE ACCEPTABLE TO THE INSPECTION AUTHORITY HAVING

3. TO USE WITH APPROVED SUPPLEMENTARY HEATERS, SEE WIRING DIAGRAM ON SUPPLEMENTARY HEATER CONTROL BOX.

JURISDICTION SHALL BE USED.


4. RELAY ACCESSORY BAY24X042




THREE PHASE MOTOR IS) FACTOR SUPPLIED IN THIS EQUIPMENT, PROTECTED UNDER PRIMARY SINGLE-PHASING CONDITIONS

From Dwg. 21D135817 P01

WIRING DIAGRAM



TROUBLESHOOTING CHART — WHAT TO CHECK



P Primary Causes S Secondary Causes


REFRIGERANT CIRCUIT FIELD INSTALLED INTER-CONNECTING OUTDOOR SECTION INDOOR UTDOOR From Dwg. 21C134403 Rev. 0 BRAZE CONN.

SERVICE TIPS

On this and other cooling only machines high side pressure is taken downstream of the condenser and liquid line drier. In the event of a restriction of either of these two components, charge can be added to cause the high side press to agree with the performance chart. However, discharge pressure becomes significantly higher, possibly causing the IPR to trip.

PERFORMANCE CURVES — BTA048D300A0 with Indoor Unit BXA048D300A; BXA748P3HPA. All data at Indoor CFM 1600. (With Interconnecting Lines of 1-1/8" O.D. Suction and 3/8" O.D. Liquid)

BXA748P3HPA



COOLING PERFORMANCE TO BE CHECKED WHEN OUTDOOR TEMPERATURE IS ABOVE 65°F. AFTER OPERATING PRESSURES HAVE STABILIZED: MEASURE INDOOR WET BULB TEMP - OUTDOOR TEMP - LIQUID & SUCTION PRESSURES. LOCATE OUTDOOR TEMP ① LOCATE INDOOR WET BULB ② FIND INTERSECTION OF OD TEMP & ID W.B. ③ READ LIQUID OR SUCTION PRESSURE IN LEFT HAND COLUMN ④

ACTUAL LIQUID PRESSURE SHOULD BE ± 10 PSIG OF CHART SUCTION PRESSURE SHOULD BE ± 3 PSIG OF CHART

BXA048D300A

EXAMPLE: ① OUTDOOR TEMP 85°F., ② INDOOR WET BULB 67°F., ③ LIQUID PRESSURE @ 1600 CFM = 240 PSIG ② ③ SUCTION PRESSURE @ 1600 CFM = 72 PSIG ④

ALTERNATE INDOOR UNITS

COOLING WITH CAPILLARY TUBES

		CORR	PRESS.
INDOOR UNIT	CFM	S	L
*BXA048A200A	1600	0	0
BXF048A200A	1600	0	0
BWH748A100A	1600	+3	+10
BWV748A100A	1600	+3	+10

COOLING WITH THERMAL EXPANSION VALVE

INERMALE	AFARO	IOIS AVE	
*BXA748P3HPA	1600	0	0
BXA742P3HPA	1575	-3	0
BXF748P3HPA	1600	0	0
BXA060A300A	1800	+3	0
BXA060P3HPA	1800	+6	0
BXH060P3HPA	1800	+6	0
BXF060A300A	1800	0	0
BWE060C100F	1800	+6	0
BWE060C300F	1800	+6	0
BWH742P100A	1575	0	0
BWV742P100A	1575	0	0
BWH748P100A	1600	0	0
BWV748P100A	1600	0	0
BWH760P100A	1800	+6	0
BWH754P100A	1800	+6	0
BWV760P100A	1800	+6	0
BWV754P100A	1800	+6	0

*BASE INDOOR UNIT FOR CURVES ON DRAWING 21D136932 Rev. 0 S - Suction L - Liquid

From Dwg. 21A136932 Rev. 0



REDDI FACTS

Library

AS- 236

Air Conditioner Model: TTA060A300A0

IMPORTANT — This document is customer property and is to remain with this unit. Please return to service information pack upon completion of work.

PRODUCT SPECIFICATIONS

OUTDOOR UNIT	TTA060A300A0	
PWR. CONNS. — V/Ph/Hz Min. Brch. Cir. Ampacity® Fuse Size — Max. (Amps) Fuse Size — Recmd. (Amps)	200-230/3/80 25.2 40 40	
COMPRESSOR No. Used — No. Speeds Volts/Ph/Hz R.L. Amps — L.R. Amps Brch. Cir. Selec. Cur. Amps	Climatuff™ 1 — 1 200-230/3/60 18.6 — 118 18.6	
OUTDOOR FAN — Type Dia. (in.) — No. Used Type Drive — No. Speeds CFM @ O.D in. w.g. No. Motors — HP Motor Speed R.P.M. Volts/Ph/Hz F.L. Amps — L.R. Amps	Propeller 26 — 1 Direct — 1 4030 1 — 1/4 825 200-230/1/60 1.9 — 3.3	
OUTDOOR COIL — Type Rows — F.P.I. Face Area (sq. ft.) Tube Size (in.)	Spine Fin™ 1 — 20 26.92 .38	
REFRIGERANT Lbs. — R-22 (O.D. Unit)® Factory Supplied Line Size — in. O.D. Gas® Line Size — in. O.D. Liq.®	10 Yes 1-1/8 3/8	
DIMENSIONS — Cratd (in.) H x W x D	37.5 x 40 x 38	
WEIGHT Shipping (lbs.) Net (lbs.)	332 314	

Product Section	Unitary
Product	Air Conditioners - Split System
Model	TTA
Literature Type	Service Facts
Sequence	4
Date	June 1987
File No.	SV-UN-S/S-TTA-SF-4 6/87
Supersedes	
OPTION	AL EQUIPMENT

Service Literature

OPTIONAL EQUIPMENT FOR CONDENSING UNITS	
Indoor Thermostats —	
Horizontal, Heat/Cool only w/Manual Switchover	AY28X92
Horizontal, Heat/Cool w/Manual Switchover	AY28X97A
Horizontal, 2-Stage Heat/Cool w/Manual	
Switchover :	AY28X98A
Vertical, Cool only w/Fan Switch	AY28X104
Vertical, Heat/Cool w/Manual Switchover	AV28X105
Horizontal, Heat/Cool	.DA1201102
Evaporator Defrost Control Kit Needed for	*******
cooling operation between 55° and 40°	AY28X/9
Outdoor Thermostat Kit	
Includes Thermostat AY28X125 and Mtg.	
Brkt. — for 46°F. to -10°F. (Adjustable)	BAY28X125A
Hot Water Bank	BHW009A
Muffler for Hot Water Bank	BAY41X219
Coupling Kit - 7/8" Tube (90° Rend) -11	
Coupling, 3/8" Tube -6 Coupling	BAY71Y003
Coupling Kit — 7/8" Tube —11 Coupling, 3/8" Tube —6 Coupling	DAVTIVOOA
3/8" Tube —6 Coupling	.BAT/1X004
Coupling Kit — 1-1/8" Tube (90° Bend), -11	
Coupling, 3/8" Tube -6 Coupling	.BAY71X005
Coupling Kit — 1-1/8" Tube —11 Coupling,	
3/8" Tube -6 Coupling	.BAY71X006
3/8" Tube -6 Coupling	AYLOAM100A

TUBING INFORMATION

Suction	Sizes Liquid	Tubing Longth	Additional Refrigerant	
Suction	ridaa	land rendra	nannyaram	
1-1/8"	3/8"	15'	5 oz.	
1-1/8"	3/8"	25'	12 oz.	
1-1/8"	3/8"	32'	18 oz.	
1-1/8"	3/8"	40'	24 oz.	

①Rated in accordance with A.R.I. Standard 210.

②Rated in accordance with A.R.I. Standard 270.

Calculated in accordance with currently prevailing National Electric Code.

Standard Air — Dry Coil — Outdoor.

This value approximate. For more precise value see unit nameplate and service instruction.

@Max. linear length 80 ft; Max. lift - Suction 60 ft; Max. lift - Liquid 60 ft. Max length of precharged tubing 40 ft. For greater length refer to Refrigerant Piping Manual Pub. No. 22-3040.

Rated in accordance with D.O.E. test procedure. HSPF is at the minimum design requirement for Region IV.

Power supply voltage limits (a) I.D. Airflow between 400 & 450 CFM/ Max O.D. Temp. **Voltage Limits** Max I.D. Temp. TON. Low High DB/HTG DB/WB CLG DB HTG DB CLG (b) I.D. Airflow between 400 & 450 CFM/ TON. Start kit required. 95/71 207 - 25475 115 80 196 - 207(a)95/71 75 105 (c) Capacity reduction for unit operation at

208 volts vs. 230 volts is 1% 187 - 196(b) 95/71 approximately.

RECONNECT ALL GROUNDING DEVICES ALL PARTS OF THIS PRODUCT CAPABLE OF CONDUCT-

ING ELECTRICAL CURRENT ARE GROUNDED. IF GROUNDING WIRES, SCREWS, STRAPS, CLIPS, NUTS OR WASHERS USED TO COMPLETE A PATH TO GROUND ARE REMOVED FOR SERVICE, THEY MUST BE RETURNED TO THEIR ORIGINAL POSITION AND PROP-**ERLY FASTENED.**


THIS INFORMATION IS INTENDED FOR USE BY INDIVIDUALS POSSESSING ADEQUATE BACKGROUNDS OF ELECTRICAL AND MECHANICAL EXPERI-ENCE. ANY ATTEMPT TO REPAIR A CENTRAL AIR CONDITIONING PRODUCT MAY RESULT IN PERSONAL INJURY AND OR PROPERTY DAMAGE. THE MAN-UFACTURER OR SELLER CANNOT BE RESPONSIBLE FOR THE INTERPRETATION OF THIS INFORMATION, NOR CAN IT ASSUME ANY LIABILITY IN CONNECTION WITH ITS USE.

SAFETY NOTICE

DISCONNECT


The Trane Company

Dwg. No. 21A142231 P01




REDDI PARTS

COMPONENT	QTY.	DESCRIPTION	CAT. #
Capacitors (CF)	1	12.5 MFD, 370V	WG20X0029
Compressor Internal Line Break (IOL) Internal Press. Relief (IPR)	1	GP673-LM3-AA RLA 18.6 LRA 118, Wind. res. @ 77°F. = .565 Ohms Opens on rise in winding temp Resets in 30-90 min. Opens on 350# diff. between high & low side pressure	Order by
Contactor (MS)	l.	Type DPST, Contacts 240V, FLA 25.0, LRA 125.0, Coil 24V., .53 A. Hid., # 3ARR8C4	WW23X0138
Drier	1,		WW22X0070
Drier	1	The state of the s	WW22X0088
Fan			WW73X0102
Motor	1	200 1000 11 20 1	WW94X0488
Sump Heater	1		WW08X0065
Switch, Low Pressure Cut-Out (LPCO)	1/2		WW26X0090
Thermostat	1,	AY28X92, Heat/Cool, Horizontal AY28X104, Cool Only, w/Fan Switch, Vertical	WY28X0092 WY28X0104 WY28X0105





REFRIGERANT CIRCUIT




From Dwg. 21C141012 Rev. 0


TROUBLESHOOTING CHART - WHAT TO CHECK








TXC760P3HPA
Cooling with Thermal Expansion Valve
Indoor Unit



OUTDOOR TEMPERATURE (°F)



From Dwg. 21D139920 Rev. 1

ALTERNATE INDOOR UNITS

COOLING WITH THERMAL EXPANSION VALVE


		CORR. PRES	SURE
INDOOR UNIT	CFM	\$	
BWE060C100F	2000	-3 ()
BWH748P100A	1800	-3 ()
BWH754P100B	2000	0 ()
BWH760P100A	2000		1
BWV748P100A	1800	-3)
BWV754P100B	2000)
BWV760P100A	2000	0 (1
BXA060A300A	2000	-3 ()
BXA060P3HPA	2000	0 ()
BXA090A3HPA	2250	the court of the c)
BXA748P3HPA	1800	-3)
BXF060A300A	2000	-3 () -
BXF748P3HPA	1800	-3)
BXH060P3HPA	2000		1
TWH764P100A	2000	+3)
TWV764P100A	2000	+3)
TXC748P3HPA	1800	ALL STATES AND THE ST)bo
TXC760P3HPA*	2000)
TXC072P300A	2250	+3 ()

*BASE INDOOR UNIT FOR COOLING CURVES ON 21D139920

S - Suction L - Liquid

From Dwg. 21A139920 Rev. 0

COOLING PERFORMANCE TO BE CHECKED WHEN OUTDOOR TEMPERATURE IS ABOVE 65° F. AFTER OPERATING PRESSURES HAVE STABILIZED: MEASURE INDOOR WET BULB TEMP - OUTDOOR TEMP - LIQUID & SUCTION PRESSURES. LOCATE OUTDOOR TEMP \oplus LOCATE INDOOR WET BULB \oplus FIND INTERSECTION OF OD TEMP & ID W.B. \oplus READ LIQUID OR SUCTION PRESSURE IN LEFT HAND COLUMN \oplus ACTUAL LIQUID PRESSURE SHOULD BE \pm 10 PSIG OF CHART EXAMPLE: \oplus OUTDOOR TEMP 85°F., \oplus INDOOR WET BULB 67°F., SUCTION PRESSURE SHOULD BE \pm 3 PSIG OF CHART \oplus LIQUID PRESSURE \oplus 2000 CFM = 220 PSIG \oplus SUCTION PRESSURE \oplus 2000 CFM = 76 PSIG \oplus



TAB PLACEMENT HERE

DE	SCRIPTION:
	Air conditioning
	Unit
	Tab page did not contain hand written information
Ŋ	Tab page contained hand written information *Scanned as next image

Confidential Records Management, Inc. New Bern, NC 1-888-622-4425 9/08



REDDI FACTS

Indoor Thermostats —

Air Conditioner Model: TTB718A100A1

IMPORTANT — This document is customer property and is to remain with this unit. Please return to service information pack upon completion of work.

PRODUCT SPECIFICATIONS

OUTDOOR UNIT	TTB718A100A1
PWR. CONNS. — V/Ph/Hz Min. Brch. Cir. Ampacity® Fuse Size — Max. (Amps) Fuse Size — Recmd. (Amps)	200/230/1/60 13 20 20
COMPRESSOR No. Used — No. Speeds Volts/Ph/Hz R.L. Amps — L.R. Amps Brch. Cir. Selec. Cur. Amps	Climatuff™ 1 — 1 200/230/1/60 9.4 — 41 9.4
OUTDOOR FAN — Type Dia. (in.) — No. Used Type Drive — No. Speeds CFM @ 0.0 in. w.g. No. Motors — HP Motor Speed R.P.M. Volts/Ph/Hz F.L. Amps	Propeller 14 — 1 Direct — 1 1495 1—1/8 1650 230/1/60
OUTDOOR COIL — Type Rows — F.P.I. Face Area (sq. ft.) Tube Size (in.)	Spine Fin™ 1 — 20 6.14 3/8
REFRIGERANT Lbs. — R-22 (0.D. Unit)® Factory Supplied Line Size — in. 0.D. Gas® Line Size — in. 0.D. Liq.®	3 Yes 5/8 1/4
DIMENSIONS — Crated (in.) H x W x D Uncrated	24.5 x 19.5 x 21 See Outline Dwg.
WEIGHT Shipping (lbs.) Net (lbs.)	115 109

①Rated in accordance with A.R.I. Standard 210. 2 Rated in accordance with A.R.I. Standard 270.





Service Literature Library **Product Section** Split System - Air Conditioning Product TTB Model Literature Type Service Facts 2A Sequence July 1987 Date SV-UN-S/S-TTB-SF-2A 7/87 File No. Supersedes

OPTIONAL EQUIPMENT

Heat/Cool — Horizontal
Heat/Cool — Vertical
Evaporator Defrost Control Kit Needed for cooling operation
Between 55° and 40° AY28X79 Coupling Kit — 5/8" Tube (90° Bend)
Size -11 Coupling, 1/4" Tube - 6
Coupling BAY71X101 Coupling Kit — 5/8" Tube —11 Coupling,
1/4" Tube —6 Coupling BAY71X102 XT400 Electronic Thermostat BAYSTAT251
Remote Sensor BAYSTAT021 Start Kit BAY41X0228

TUBING INFORMATION

Tubing Sizes			Additional
Suction	Liquid	Tubing Length	Refrigerant
5/8"	1/4"	15'	−3 oz.
5/8"	1/4"	25′	'+'0 oz.
5/8"	1/4"	32'	+2 oz.
5/8"	1/4"	40'	+4 oz.

©Calculated in accordance with Natl. Electric Code. Suitable for use with HACR circuit breakers or fuses.

Standard Air — Dry Coil — Outdoor.

©This value approximate. For more precise value see unit nameplate and service instruction.

©Max. linear length 80 ft.; Max. lift - Suction 60 ft.; Max. lift - Liquid 60 ft. Max. length of precharged tubing 40 ft. For greater length refer to Refrigerant Piping Manual Pub. No. 22-3040.

Rated in accordance with D.O.E. test procedure.

SAFETY NOTICE

THIS INFORMATION IS INTENDED FOR USE BY INDIVIDUALS POSSESSING ADEQUATE BACKGROUNDS OF ELECTRICAL AND MECHANICAL EXPERI-ENCE. ANY ATTEMPT TO REPAIR A CENTRAL AIR CONDITIONING PRODUCT MAY RESULT IN PERSONAL INJURY AND OR PROPERTY DAMAGE. THE MAN-UFACTURER OR SELLER CANNOT BE RESPONSIBLE FOR THE INTERPRETATION OF THIS INFORMATION, NOR CAN IT ASSUME ANY LIABILITY IN CONNECTION WITH ITS USE.

RECONNECT ALL GROUNDING DEVICES

ALL PARTS OF THIS PRODUCT CAPABLE OF CONDUCT-ING ELECTRICAL CURRENT ARE GROUNDED. IF GROUNDING WIRES, SCREWS, STRAPS, CLIPS, NUTS OR WASHERS USED TO COMPLETE A PATH TO GROUND ARE REMOVED FOR SERVICE, THEY MUST BE RETURNED TO THEIR ORIGINAL POSITION AND PROP-ERLY FASTENED.

DISCONNECT POWER BEFORE SERVICING

P.I. 7/87 Dealer Products Group • Troup Highway • Tyler, TX 75711 © American Standard Inc. 1987

The Trane Company

Dwg No. 21A142767 P01 Page C-216



REDDI PARTS

COMPONENT	QTY.	DESCRIPTION	CAT. #
Capacitors (CRA) (CRB) (CF)	1 1 1	25 MFD, 440V 5 MFD, 370V 4 MFD, 370V	WW20X0129 WG20X0026 WG20X0025
Coil, OD •	1	Replacement	WW88X0388
Compressor Internal Line Break (IOL) Internal Press. Relief (IPR)	1	BH193-ABI-AA: FLA 9.4 LRA 41 Winding resistance @ 77°F.: Start 3.52 Ohms — Run 2.05 Ohms Opens on rise in winding temp. resets in 30-90 minutes Opens on 350# differential between high & low side pressure	Order by unit model #
Contactor (MS)	1	Type DPST, Contacts 240V, FLA 18/8, LRA 90/18, Coil 24V, .64 A.In., .32 A. Hid., #3ARR9FE14	WW24X0026
Drier	1	Suction Line, w/Sweat Fittings, 30 Cu. In., 5/8" x 5/8"	WW22X0077
Drier	1	Liquid Line w/Sweat Fittings, 8 Cu. In., 3/8" x 3/8"	WW22X0088
Fan	1	3 Blade, 14" Dia., 1/2" Bore, CW, 30°, Hub Up	WW73X0072
Motor •	1	230V, 60 Hz., 1 Ph., Closed Shell, CCW, 1650 RPM, 1/8 HP, 1 SPD., FLA .9, LRA 2.2, Sleeve Bearings, Winding Resistance — OHMS @ 77 °F. Blk to Pur 49.1/42.3, Blk to Brn 76.5/65.8	WW94X0412
Thermostat	1 1	AY28X92, Heat/Cool, Horizontal AY28X104, Cool only, w/fan Switch, Vertical AY28X105, Heat/Cool, Vertical	WY28X0092 WY28X0104 WY28X0105

*New Part - Set Up Within Last 18 Months


SCHEMATIC DIAGRAM TO 200-230 V., 60 HZ, I PH. POWER SUPPLY PER LOCAL CODES CSR-1 CSR - OR /BK MS-1 MS-2 CR-B THERMALLY CPR PROTECTED INTERNALLY GYWR HEATING-

COOLING THERMOSTAT

FAN

TO SEPARATE 24 V. N.E.C. CLASS

2 POWER SUPPLY (18 V.A. MIN.)



LEGEND Factory Wiring Line V 24 V. Field Wiring Line V. Field Installed **Factory Wiring** Ground Junction Wire Nut or Connector Coil -)-Capacitor Relay Contact (N.O.) Relay Contact (N.C.) o Internal Overload Protector o Motor Winding o Fuse Color of Wire Black Wire with Blue Marker Color of Marker Black Yellow Orange YL BL BR Green Brown WH White PR Fan Capacitor Run Capacitor CPR CS CRS

NOTES:

1. LOW VOLTAGE (24 V) FIELD WIRING MUST BE 18


Start Capacitor

Capacitor Switching Relay Internal Overload Protector Compressor Motor Contactor


- USE COPPER CONDUCTORS, IF ALUM, OR COPPER-CLAD ALUM, POWER WIRING IS USED, CONNECTORS WHICH MEET ALL APPLICABLE CODES AND ARE ACCEPTABLE TO THE INSPECTION AUTHORITY HAVING JURISDICTION SHALL BE
- 3. TO DISCONNECT OPTIONAL SUMP HEAT MOVE


more than 5° below chart value remove refrigerant
 if below 5° limit line, do not add refrigerant


REFRIGERANT CIRCUIT



TROUBLESHOOTING CHART — WHAT TO CHECK







COOLING PERFORMANCE TO BE CHECKED WHEN OUTDOOR TEMP. IS ABOVE 75°F. HEATING PERFORMANCE CAN BE CHECKED WHEN THE OUTDOOR TEMP. IS BELOW 60°F.

TO CHECK COOLING PERFORMANCE, ALLOW PRESSURES TO STABILIZE AND MEASURE INDOOR WET BULB TEMP. — OUTDOOR TEMP. — HEAD AND SUCTION PRESSURES. LOCATE OUTDOOR TEMP. ® LOCATE INDOOR WET BULB ® FIND INTERSECTION OF OD TEMP. & ID W.B. ® READ HEAD OR SUCTION PRESSURE IN LEFT HAND COLUMN ®

ACTUAL HEAD PRESSURE SHOULD BE \pm 10 PSIG OF CHART SUCTION PRESSURE SHOULD BE \pm 3 PSIG OF CHART

EXAMPLE: ① OUTDOOR TEMP 85°F., ② INDOOR WET BULB 67°F., ③ HEAD PRESSURE @ 600 CFM = 240 PSIG ④ ③ SUCTION PRESSURE @ 600 CFM = 75 PSIG④

ALTERNATE COOLING WI		UNITS		COOLING WIT	ГН			TWH024A140A TWH724A140A	675 675	3	6
CAPILLARY				TXC018A4HPA* TXC012A4HPA	600 450	_0 _9	0 -18	TWH030A140A TWH730A140A	675 675	5	10 10
INDOOR UNIT	CFM	CORR.	PRESS. L	TXC024A4HPA TXC025A4HPA	675 675	4	8	COOLING WI	тн		
BXA018A200A BXA718P2HPA BXA718D200A	600 600 600	0 0	0 0	TXA025A4HPA TXA725A4HPA TXC030A4HPA	675 675 675	4 4 5	8 8 10	BWH724P100A BWU024B10GB BWU030B10NA	675 675 675	0	0
BXA024A200A BXA724M2HPA BXA724D200A	675 675 675	2 2 2	4 4 4	TXA030A4HPA TXA730A4HPA TWV018A140A	675 675 600	5 5 2	10 10 4	BWV024P100E BWH030P100A BWV724P100E	675 675 675	0 3	0 6
BWU018A100B BWU024A100B BFW718A100A	600 675 450	0 2 -3	0 4 -6	TWV718A140A TWV024A140A TWV724A140A	600 675 675	3 3	6 6	BWV030P100E *BASE INDOOR UN CURVES ON DRAW	675 IT FOR	3 402 Pau 0	6
BFW724A100A BCW724A100A BWH718A100A	675 675 600	4 4 2	8 8 4	TWV025A140A TWV725A140A TWV030A140A	675 675 675	3 5 5	6 10	S - Suction L - Li		492 Nev. U	
BWV018A100E BWV718A100E BWV024A100E	600 600 675	2 2 3	4 4 6	TWV730A140A TWH018A140A TWH718A140A	675 600 600	2 2	10 4 4	From Dwg. 21	A141492	2 Rev. 0	




Bldgs As-202 As-236 BTA-IN-5

INSTALLER'S GUIDE

Split System Condensing Units

Models BTA120D-AB BTA150D-AB BTA180D-AB BTA180F-AB

Library	Service Literature
Product Section	Unitary
Product	Split System
Model	ВТА
Literature Type	Installation
Sequence	5
Date	December 1986
File No.	SV-UN-S/S-BTA-IN-5 12/86
Supersedes	New



Since The Trane Company has a policy of continuous product improvement, it reserves the right to change specifications and design without notice. The installation and servicing of the equipment referred to in this booklet should be done by qualified, experienced technicians.


Table of Contents

Subject	age
Unit Model Number Description	 . 2
General Information	 . 3
Installation	 . 3
Unit Installation	
Receiving	
Location and ClearancesFoundation	
Rigging	
Pre-Installation Leak Test	
Refrigerant Piping	
Recommended Line Sizes	 . 9
Refrigerant Piping Guidelines	
Suction Line Components	
Risers and Tube Routing	
Electrical Wiring	
Electrical Characteristics	
Thermostat Installation	
Start-Up	
Initial Start-Up	
Compressor Motor Checks	 . 21
Voltage Imbalance Check	
Start-Up Log	 . 23

Unit Model Number Description

Trane LCG products are identified by a multiple-character model number that precisely identifies a particular type of unit. An explanation of this multiple-character number is shown below. It will enable the owner or Service Engineer to define operation, components and applicable accessories for a specific unit.

LCG Unit Model Nomenclature



120 = 120 MBH 180 = 180 MBH 240 = 240 MBH

General Information

Model BTA Condensing Units are designed for outdoor mounting with a vertical air discharge. They are usually installed on concrete slabs at ground level, but can also be used on a flat roof or a sloping roof with a properly built-up platform (making a level installation possible). Each unit is leak tested and evacuated at the factory, and shipped with a holding charge of Refrigerant-22. An access panel on the

end of the unit provides access to the compressor section and access to the control box.

An Installation Checklist is provided at the end of this manual and should be completed after all installation procedures have been accomplished. This checklist should not be substituted for the detailed information given in appropriate sections of this manual.

Installation

Unit Installation

BTA unit dimensions, weights, and clearances are shown in Figures 1 through 3. Figure 4 illustrates various components of the split system condensing unit.

Receiving

When the unit is delivered to the jobsite, inspect all components for damage. Manually rotate the condenser fans to be sure they revolve freely. Report any damage or material shortage to the carrier and record this information on the bill of lading. File damage claims with the carrier, and notify the appropriate Trane sales office before installing a damaged unit. Any material shortages should also be reported directly to the Trane sales office.

Compare the electrical data on the unit nameplate with the ordering and shipping information to verify that the correct unit has been received.

Unit wiring diagrams and installation-operation-maintenance literature are shipped with the unit. Before unit start-up, read the provided literature to become familiar with the unit and its operation.

Location and Clearances

Select a location for the condensing unit where air will flow, without obstruction, upward through the coil and away from the fan discharge. Limit the length of refrigerant piping by locating the condensing unit as close to the evaporator as possible.

CAUTION: If the condensing unit must be placed under an overhang, take the necessary steps to avoid the recirculation of warm discharged air. Failure to do so will hinder the performance of the condensing unit and lead to unit damage.

Suggested air flow clearances and service clearances are given in Figures 1 through 3. If the unit is placed under an overhang, allow at least six feet of clearance above the unit to prevent recirculation of hot discharge air.

NOTE: Four feet of service clearance must always be provided on the compressor end of the unit.

Allow sufficient space to install a liquid line shutoff valve with an access port next to the condensing unit. The access port will be needed to measure subcooling, as discussed in the MAINTENANCE manual.

BTA-IN-5




Figure 1 - Dimensions, Weights, and Clearances for BTA120D Units




Figure 2 - Dimensions, Weights, and Clearances for BTA150D and 180D Units




Figure 3 · Dimensions, Weights, and Clearances for BTA180F Units




Figure 4 - BTA Component Identification

Foundation

If the unit is to be set on the ground, provide a four inch thick, level concrete slab for mounting. In rooftop applications, make sure the roof is strong enough to support the unit. Check with a roofing contractor for proper waterproofing installation practices to ensure that the roof does not develop leaks as a result of unit weight, vibration, and hot weather.

Rigging

Rig the unit using either belt or cable slings. The slings must be fastened to the unit at the four holes in the base rail of the unit, as

shown in Figure 6. Use spreaders to protect the top of the unit when it is lifted. The point where the slings meet at the lifting hook must be at least six feet above the unit. Refer to Figure 5 for center of gravity information, and to Figure 6 for proper rigging procedures.

WARNING: TO PREVENT OVERSTRESSING THE BASE RAILS, THE UNIT SHOULD BE RIGGED AS SHOWN IN FIGURE 6 AND LIFTED AS SMOOTHLY AS POSSIBLE. FAILURE TO DO SO COULD RESULT IN SERIOUS PERSONAL INJURY AND DAMAGE TO THE UNIT.




Figure 5 - Unit Center of Gravity Information

Pre-Installation Leak Test

Trane condensing units and evaporators are shipped with a holding charge of Refrigerant-22. Before installing these units, momentarily depress either the suction or discharge line access valve to verify that this holding charge has not been lost.

If no refrigerant escapes when depressing the access valve, the condensing unit should be leak tested to determine the source of refrigerant loss. Pressurize the unit to 100 psi with refrigerant, and use a halogen leak detector, halide torch, or soap bubbles to check for leaks. If a leak is found, release the test pressure and repair the leak. If no leak is found, use nitrogen to increase the test pressure to 150 psi and repeat the leak test. When repairing leaks, refer to "Brazing Procedures" in the MAINTENANCE PROCEDURES manual. Retest the unit to make sure the problem has been corrected.

NOTE: It may be difficult to pressurize the unit to 100 psi with refrigerant if the ambient temperature is below 60 F.

WARNING: DO NOT USE OXYGEN, ACETYLENE, OR AIR IN PLACE OF REFRIGERANT AND DRY NITROGEN FOR LEAK TESTING. A VIOLENT EXPLOSION WILL RESULT WHICH COULD CAUSE SERIOUS INJURY OR DEATH.




Figure 6 - Rigging the Unit

Refrigerant Piping

It is essential that refrigerant piping be properly sized and applied since these factors have a significant effect on system performance and reliability. On self-contained units, proper piping design is insured by the equipment manufacturer. However, split systems must operate with interconnecting lines which are selected and applied by the installer. If the interconnecting piping does not follow recommended guidelines, any system will be plagued by erratic performance, compressor failures, and other problems.

NOTE: The piping should be sized and laid out according to the job plans and specifications. This should have been completed when components were selected for the system.

Recommended Line Sizes

The interconnecting line sizes recommended by Trane are listed in Table 1. These tube sizes are within the velocity, pressure drop, and refrigerant charge limitations necessary for proper system operation. (The refrigerant charge limit is the maximum system charge recommended for a particular compressor, and is determined by the design of the compressor.) The line lengths in Table 1 are based on pressure drop and refrigerant charge limitations in the **liquid line**. Pressure drop limits assume that equivalent length equals two times the physical length. In most applications, this is a reasonable assumption. However, actual pressure

drop must be calculated if one or more of the following situations exists:

- LONG RISER: Installations with liquid line risers have an added pressure drop of 0.5 psi per foot of riser. If the riser is long, the system may require a larger diameter and/or shorter liquid line to ensure subcooling at the expansion valve.
- EXCESSIVE BENDS, REDUCERS, VALVES: A larger than normal number of tube bends, reducers, and/or valves may increase equivalent length and pressure drop above the assumption of two times the physical length. Actual pressure drop should be calculated for these situations.

Trane recommends sizing the liquid line diameter as small as possible, while maintaining pressure drop within acceptable limits. This will minimize system charge and, therefore, have the general effect of increasing compressor life.

Trane recommends the use of Type L (medium wall) refrigerant tubing. Only refrigeration grade copper tubing should be used since it is available cleaned, dehydrated, and capped to avoid contamination prior to installation. Copper tubing used for plumbing usually has oil, grease, or other contaminants on the interior wall, and these can cause serious operating problems if not removed prior to installation. Tube size recommendations in this manual are based on Type L (medium wall) tubing.

Table 1 - Interconnecting Line Sizes

	LENGT	H OF INT	ERCON	NECTING	LINES	(FEET)		
CONDENSING	0	-20	2	1-40	4	1-60	61	-80
UNIT LINE SIZE — O.D. (INCHES)								
UNIT	LIQ.	SUCT.	LIQ.	SUCT.	LIQ.	SUCT.	LIQ.	SUCT
BTA120D†	3/8	7/8	3/8	1-1/8	1/2	1-1/8	1/2	1-1/8
BTA150D†	3/8	7/8	3/8	1-1/8	1/2	1-1/8	1/2	1-3/8
BTA180D†	1/2	1-1/8	1/2	1-1/8	1/2	1-1/8	1/2	1-3/8
BTA180F	5/8	1-3/8	5/8	1-3/8	5/8	1-5/8		

NOTES:


Refrigerant Piping Guidelines

A. Maximum recommended line lengths:
Maximum linear length80 Ft.
(w/o accumulator)
Maximum suction line lift60 Ft.
Maximum liquid line lift
B. Maximum allowable pressure drops (R-22):
Suction line3 psi
Liquid line35 psi

Route refrigerant piping for minimum linear length, minimum number of bends and fittings (no reducers) and minimum amount of line exposed to outdoor ambients.

^{1.} For line lengths and risers greater than maximum recommended in table, refer to the Trane Refrigeration Manual

Use type L (medium wall) A.C.R. copper tubing. †2 line sets required.



10

Figure 7 - Diagram of Refrigerant Piping Components in Liquid Line

Liquid Line Components

A properly sized liquid line filter drier must be installed upstream from the expansion valve. In addition, a moisture indicator/sight glass should be installed between the expansion valve and filter drier. Both of these components should be installed at the evaporator close to the expansion valve, as shown in Figure 7.

A shut-off valve (with access port) should be sized with the liquid line O.D. selected, and installed close to the condenser. Other valves, tube bends, and reducers should be minimized since these items tend to increase pressure drop and reduce subcooling at the expansion valve.

Liquid line receivers are not recommended on 10 to 15 ton systems since they increase the refrigerant charge.

The following points should be considered when connecting the evaporator to the BTA180F condensing unit.

- It is recommended that the full evaporator coil be used during low speed compressor operation because of efficiency considerations.
- In some installations, insufficient moisture removal may result when the full evaporator coil is used with the compressor on low speed.
- In instances where the importance of moisture removal overrides efficiency considerations, one-half of the evaporator coil capacity can be shut off when the compressor switches to low speed.

4. If solenoid valves are required, they should be installed between the filter drier and sightglass in order to shutoff one-half of the evaporator coil capacity. On units where the solenoid valves are factory installed, the sightglass can be installed between the unit and filter drier. However, all of these components should be installed close to the expansion valve, and no more than one-half of the coil capacity should be shut off.

Suction Line Components

Trane does not recommend the use of suction line accumulators on 10 to 15 ton single compressor units because accumulators of sufficient size and quality are not available.

Suction line filter driers are not recommended as standard components when installing BTA condensing units. They may be necessary on systems that have experienced a compressor burn-out (refer to Trane Service Bulletin No. HCOM-SB-45).

On 10 to 15 ton systens, a suction line shut-off valve installed in the interconnecting tubing has little value, and is not recommended due to pressure drop considerations. Increased suction line pressure drop has a significant effect on system capacity and efficiency.

BTA-IN-5

Risers and Tube Routing

Liquid Line

Liquid line riser lengths are limited only by the additional pressure drop (0.5 psi/ft) which results from the liquid column. No limit exists on the length of liquid line drops, and no special line sloping considerations are necessary.

Normally it is not necessary or desirable to insulate liquid lines. In most applications, the ambient temperature is lower than the refrigerant temperature, and has the desirable effect of increasing subcooling at the expansion valve. However, liquid lines routed through extremely high ambient environments (such as a boiler room) may reduce subcooling below acceptable levels. To minimize this loss, liquid lines passing through extremely warm spaces should be insulated. Increasing the liquid line size only tends to aggravate this problem.

Suction Line

The suction line sizes recommended in Table 1 will result in sufficient refrigerant vapor velocity to ensure good oil entrainment. It is also important to utilize good tube routing practices in order to ensure proper oil return to the compressor.

It is recommended that horizontal suction lines be pitched toward the compressor.

Insulate the suction line with 1/2-inch thick, closed cell neoprene insulation such as armaflex or similar material.

Brazing and Leak Testing

For proper brazing techniques when installing refrigerant piping, refer to "Brazing Procedures" in the MAINTENANCE manual.

After completing the installation of all refrigerant piping, the system should be thoroughly checked for possible leaks. Refer to "Leak Testing" in the MAINTENANCE manual.

BTA-IN-5

Electrical Wiring

WARNING: OPEN THE ELECTRICAL POWER DISCONNECT SWITCH AND SECURE IN THAT POSITION BEFORE INSTALLING OR SERVICING THE UNIT. FAILURE TO DO SO MAY RESULT IN PERSONAL INJURY OR DEATH FROM ELECTRICAL SHOCK.

Install all field wiring, including the unit electrical ground, in accordance with the National Electrical Code and applicable local codes. Figure 8 provides a block diagram of the electrical connections to be made by the customer or installing contractor.

NOTE: When connecting wires at the terminal block, make sure that all lugs are tight. Also check the terminal block and compressor contactor lugs that were wired at the factory.

The unit wiring diagram is pasted on the back of the control box cover. Refer to Figures 1 and 2 for the locations of holes provided for electrical conduit entry on the unit. The locations of the electrical panel components are shown on the unit wiring diagram.

Table 2 lists the electrical characteristics for BTA120D to BTA180D, BTA180F units.




Figure 8 - Electrical Connections by Customer

Table 2 - Electrical Characteristics for BTA120D to BTA180D, BTA180F Units

		Unit Chara	cteristics				Compre	ssor Mo	tor	Co	ondense	r Fan Mo	otor
Model	7 Electrical Characteristics	Allowable Voltage	3.6 Min. Circuit Range	2.6 Max. Fuse Amp.	4.6 Recm'd Dual Element Fuse Size	No.	1 RLA (Ea)	1 LRA (Ea)	1.5 KW (Ea)	NO/ HP	1 FLA (Ea)	1 LRA (Ea)	1.5 KW (Ea)
BTA120D300	208-230/60/3	187-254	53	70	60	2 2 2	19.0	115	6.0	2/.75	5.0	11.0	0.77
BTA120D400	460/60/3	416-508	29	35	35		10.6	50	6.0	2/.75	2.7	5.5	0.77
BTA120DW00	575/60/3	520-536	23	30	25		8.5	45	6.0	2/.75	1.8	4.4	0.77
BTA150D300	208-230/60/3	187-254	65	80	80	2 2 2	23.6	142	7.3	3/.50	4.1	9.5	0.60
BTA150D400	460/60/3	416-508	30	40	35		10.7	71	7.3	3/.50	2.1	4.8	0.60
BTA150DW00	575/60/3	520-635	24	30	30		8.6	57	7.3	3/.50	1.6	3.8	0.60
BTA180D300	208-230/60/3	187-254	73	100	80	2 2 2	27.1	156	8.9	3/.50	4.1	9.5	0.62
BTA180D400	460/60/3	416-508	34	45	40		12.3	79	8.9	3/.50	2.1	4.8	0.62
BTA180DW00	575/60/3	520-635	27	35	30		9.9	63	8.9	3/.50	1.6	3.8	0.62
BTA180F300	208-230/60/3	187-254	83	125	100	1	56.4	248	17.8	3/.50	9.5	9.5	0.62
BTA180F400	460/60/3	416-508	42	60	50	1	28.2	124	17.8	3/.50	4.8	4.8	0.62
BTA180FW00	575/60/3	520-635	33	50	40	1	22.6	100	17.8	3/.50	3.8	3.8	0.62

NOTES

- 1. Electrical information is for each individual motor.
- 2. Maximum fuse size permitted by N.E.C. 440-22 is 225% of one compressor motor RLA plus the total RLA of the remaining motors in the circuit.
- 3. Minimum circuit ampacity is 125% of the RLA of one compressor motor plus the total RLA of the remaining motors in the circuit.
- 4. Recommended dual element fuse size is 150% of the RLA of one compressor motor plus the total RLA of the remaining motors in the circuit.
- 5. KW values are taken at conditions of 45 F saturated suction temperature at the compressor and 95 F ambient.
- 6. Local codes may take precedence.
- 7. Allowable range at unit terminal block.
- 8. Data given at high speed.

CAUTION: Use only copper conductors for supply power power wiring. Do not use aluminum conductors. Unit terminals are not designed to accept other than copper conductors.

NOTE: For 208 volt operation, reconnect the control power transformer as shown on the unit wiring diagram. Cap the unused transformer lead with a wire nut.

Fuses

Refer to the unit wiring diagram pasted on the inside of the control box cover for condenser fan and control circuit fuse specifications.

Thermostat Installation

Recommended wire sizes and lengths for installing the unit thermostat are provided in Table 3. The total resistance of these low voltage wires must not exceed one ohm. Any resistance in excess of one ohm may cause the control circuit to malfunction.

When selecting a thermostat location, be sure to choose a site in a frequently occupied area with good air circulation at an average temperature. The thermostat should be positioned approximately five feet above the floor and **must be level**.

Avoid mounting the thermostat in areas subject to the following:

- drafts or "dead" spots behind doors or in corners;
- hot or cold air from ducts:
- radiant heat from the sun, or from appliances;
- concealed pipes and chimneys;
- unheated or uncooled surfaces behind the thermostat, such as outside walls;
- in an area where the thermostat will be affected by a unit in another zone.

CAUTION: If an energy management device, time clock, or other power consuming device is used, a separate power supply must be provided for that device. Do not use the unit control circuitry, or damage to the unit may result.

Table 3 - Recommended Thermostat Wire Size

WIRE SIZE	MAXIMUM WIRE LENGTH
22 Gauge	30 Ft.
20 Gauge	50 Ft.
18 Gauge	75 Ft.
16 Gauge	125 Ft.
14 Gauge	200 Ft.

Table 4 - Air Handler Motor Electrical Data

Unit Model	Unit Electrical	No. of	Нр	Speed	FLA	V	LRA	
Number	Characteristics	Motors	(Ea.)	(Rpm)	200/230V	460V	200/230V	460V
BWE090C100E	200-230/60/1	1	1	3450	6.3	_	45.0	-
BWE090C400E	200-230 & 460/60/3	1	1	1725	3.8	1.9	21.2	10.6
BWE120C100E	200-230/60/1	1	2	3450	11.5		61.0	_
BWE120C400E	200-230 & 460/60/3	1	11/2	1725	5.0	2.5	37.4	18.7
BTE120C100E	200-230/60/1	1	2	3450	11.5		61.0	-
BTE120C400E	200-230 & 460/60/3	1	11/2	1725	5.0	2.5	37.4	18.7

Table 5 - BWH and BWV Unit Electrical Data

Unit Model Number	Unit Cha	racteristics				
	Electrical Characteristics	Voltage Utilization Range	No. Req'd.	Hp (Ea.)	Speed (Rpm)	FLA
BWH180B300C BWV180B300C	200-230/60/3	180-254	1	3	1725	9.0
BWH180B400C BWV180B400C	460/60/3	414-506	1	3	1725	4.4
BWH240B300C BWV240B300C	200-230/60/3	180-254	1	5	1725	15.2
BWH240B400C BWV240B400C	460/60/3	415-506	1	5	1725	6.6




Figure 9 - Field Wiring for BTA120D with BTE120B Air Handler No Electric Heat




Figure 10 · Field Wiring for BTA120D with BTE120B Air Handler With Electric Heat




Figure 11 - Field Wiring for BTA150D and BTA180D With Two (2) BWE090C Air Handlers With Electric Heat




Figure 12 - Field Wiring for BTA150D and BTA180D With Two (2) BWE090C Air Handlers




Figure 13 - Field Wiring for BTA150D and BTA180D With Two (2) BWE090C Air Handlers Without Electric Heat




Figure 14 - Field Wiring for BTA150D, BTA180D and BTA180F With the BWV180B, BWH180B Air Handlers Without Electric Heat




Figure 15 - Field Wiring for BTA150D, BTA180D and BTA180F With the BWV180B, BWH180B Air Handlers With Electric Heat




Figure 16 - Field Wiring for BTA120D With BTE120B Air Handler BTA-IN-5




Figure 17 - Field Wiring for BTA150D, BTA180D and BTA180F With the BWV180B, BWH180F Air Handlers

Installation Checklist-

Complete this checklist as the unit is installed to verify that all recommended installation procedures are accomplished before the unit is started. This checklist does not replace the detailed instructions provided in the INSTALLATION section of this manual. Read the entire section carefully to become familiar with the installation procedures before installing the unit.

	unit.
Re	ceiving
	Unit nameplate data corresponds with ordering information. Unit inspected for shipping damage and claim filed, if necessary. Unit checked for material shortage and any shortages reported.
Ur	nit Location
	Condenser air clearances over unit good. Service clearances around unit good. Unit secured in correct location.
Re	frigerant Piping
	Liquid line sized properly and within recommended maximum line length. Suction line sized properly. Thermostatic expansion valve properly sized and installed close to evaporator. Liquid line filter drier installed near expansion valve. Sight glass installed in liquid line between evaporator and filter drier. Liquid line access valve installed in liquid line close to condenser. Low ambient accessories installed, if necessary. Check all unit and piping connections for leaks.
Ele	ectrical Wiring
	Field installed wiring complies with all applicable codes. Compressor contactor and terminal block lugs checked for tightness. Thermostat properly mounted and wired. Any other accessories properly installed and wired. Grounding wires securely bonded to earth ground.
	Re O

20

BTA-IN-5

Start-Up

Pre-Start Checks

Before starting the unit, complete the procedures outlined below to make sure the unit is properly installed and ready for start-up.

WARNING: OPEN THE UNIT DISCONNECT SWITCH AND LOCK IT IN THAT POSITION TO PREVENT ACCIDENTAL START-UP. NEVER OPEN AN ACCESS PANEL TO INSPECT OR SERVICE THE UNIT WITHOUT FIRST OPENING THE DISCONNECT SWITCH. FAILURE TO DO SO MAY RESULT IN INJURY OR DEATH FROM ELECTRICAL SHOCK OR CONTACT WITH MOVING PARTS.

1.	Inspect all electrical connections to be sure that the wires
	are securely attached to their terminals. Make sure that all
	wires are clear of any rotating parts, such as fan blades.

- 2. Check the condenser and evaporator fans. Fan blades must be secure on the motor shafts and must rotate freely. Airflow must be unobstructed.
- 3. Make sure the evaporator air filters are clean.
- 4. Check the evaporator and condenser coils to ensure that they are clean, that the fins are straight, and that there are no obstructions to airflow.
- 5. Check the voltage at the line side of the disconnect switch.
 It should be within 10 percent of the unit nameplate voltage.

Evacuation

Infter completing the "Pre-Start Checks," use a vacuum pump to remove air, moisture, and contaminants from the system. The system should be evacuated to a pressure of 500 microns or less. Refer to "Evacuation Procedures" in the MAINTENANCE manual.

Refrigerant Charging

With the system properly evacuated, determine the required charge of Refrigerant-22 and charge the system as outlined under "Refrigerant Charging" in the MAINTENANCE manual.

Oil Charge

The compressors on BTA120D to BTA180D, BTA180F units ship with a sufficient oil charge for systems that stay within the maximum line lengths listed in Table 1. As long as the maximum line length is not exceeded, the compressor will have adequate oil.

Initial Start-Up

Normally it is not necessary to energize the crankcase heater prior to intital start-up. However, if more than 30 minutes passes between refrigerant charging and initial start-up, a significant amount of refrigerant could migrate to the compressor. When here is a time lapse between charging and start-up, the crankase heater should be energized for a minimum of eight hours before starting the unit.

CAUTION: Failure to energize the crankcase heater and wait eight hours before starting the unit may result in excessive foaming at start-up and possible damage to the compressor bearings.

Set the room thermostat as follows to start the unit:

- Turn the thermostat selector switch to either COOL or AUTO, depending on the thermostat;
- 2. Place the thermostat fan switch in the AUTO position;
- 3. Set the thermostat at a point below room temperature.

The unit will operate automatically in response to cooling needs, as determined by the thermostat setting.

Compressor Motor Checks

With the compressor operating, check the amp draw. The amperage should not exceed the "Maximum Allowable Amps" listed in Table 7. The amp draw may be less than the value listed in the table.

Voltage at the compressor terminals must be within the "Allowable Voltage Range" listed in Table 7. If not, check the voltage at the unit terminal block and at the disconnect switch to determine if voltage problems are being caused by feeder line, loose terminals, or defective unit wiring.

Table 7 - Maximum Allowable Amp Draw

NE PERSONAL PROPERTY OF THE PERSON NAMED IN COLUMN 1		Allowable**	Max. Allowable Amps	
Condensing	Electrical	Voltage	Matched	Oversized*
Unit	Characteristics	Range	Evap.	Evap.
BTA120D300	208-230/60/3	187-253	24	0 =
BTA120D400	460/60/3	416-506	11	
BTA120DW00	575/60/3	520-635	9	
BTA150D300	208-230/60/3	187-253	=======================================	30
BTA150D400	460/60/3	416-506		13
BTA150DW00	575/60/3	520-635		11
BTA180D300	208-230/60/3	187-253	31	36
BTA180D400	460/60/3	416-506	14	16
BTA180DW00	575/60/3	520-635	11	13
BTA180F300	208-230/60/3	187-254	66	67
BTA180F400	460/60/3	416-508	33	34
BTA180FW00	575/60/3	520-635	27	27

^{*}Evaporator one size larger than condensing unit

^{**}Allowable voltage range at the unit terminal block

^{***}Compressor operating at high speed.

Voltage Imbalance Check

Voltage imbalance on three phase systems can cause motor overheating and eventual failure. Maximum allowable imbalance is two percent, which must be measured at the compressor terminals. Voltage imbalance is defined as 100 times the maximum deviation of the three voltages from the average, without regard to sign, divided by the average voltage. For example, if the three measured voltages are 221, 230 and 227, the average voltage would be:

$$\frac{221 + 230 + 227}{3} = 226 \text{ volts}$$

and the percent voltage imbalance would be:

$$\frac{100 \times (226-221)}{226} = 2.2\%$$

In this example, 2.2 percent imbalance is not acceptable and could result in as much as 20 percent current imbalance. This will increase the motor winding temperature, and thus decrease the life of the motor.

If more than 2.0 percent imbalance exists, check the voltage readings at the disconnect switch to determine if the imbalance is present in the incoming power lines. If so, the power company should be notified to correct it. If the imbalance is due to problems within the unit, check the unit electrical wiring connections.

Operating Pressures

Install pressure gauges on the discharge and suction line access valves next to the compressor. When the unit reaches stabilized operation, suction and discharge pressures can be read. Refer to "Operating Pressures" in the MAINTENANCE manual to compare the measured pressures with the normal system operating pressures.

Start-Up Log

		DATE
NAMEPLATE INFORMATION		
Model No.		II No
Voltage	RLA	
. COMPRESSOR(S)		
A. VOLTAGE AT COMPRESSOR TERMINALS		
Comp. No. 1: T1	T2	T3
Comp. No. 2: T1	T2	T3
Voltage Imbalance: Comp. No. 1	3 3	Comp. No. 2
B. AMP DRAW		
Comp. No. 1: L1	L2	L3
Comp. No. 2: L1	. L2	L3
II. OPERATING CONDITIONS		
A. COMPRESSOR NO. 1		
Discharge Pressure	Suction Pressure —	
Liquid Line Pressure		
Liquid Line Temp.	Superheat	
Subcooling	Evap. Entering Air Temp. (DB/WB)	
Ambient Temp.	Evap. Discharge Air Temp. (DB/WB)	
B. COMPRESSOR NO. 2		
Discharge Pressure	Suct	ion Pressure ———
Liquid Line Pressure	Suction Line Temp.	
Liquid Line Temp.	Superheat	
Subcooling —	Evap. Entering Air Temp. (DB/WB)	
Ambient Temp.	Evap. Discharge Air Temp. (DB/WB)	
V. CONTROLS		
Fans Operating (Yes or No): Fan No. 1	No	No. 3
Crankcase Heater Operating (Yes or No): Comp	o. No. 1	Comp. No. 2
V. REFRIGERANT PIPING		
Evacuation Loyal	Custom (harma






Split System Condensing Units

Models BTA120D-AB BTA150D-AB BTA180D-AB BTA180F-AB

Library	Service Literature	
Product Section	Unitary	
Product	Split System	
Model	ВТА	
Literature Type	Operation/Maintenance	
Sequence	3	
Date	December 1986	
File No.	SV-UN-S/S-BTA-M-3 12/86	
Supersedes	New	



Since The Trane Company has a policy of continuous product improvement, it reserves the right to change specifications and design without notice. The installation and servicing of the equipment referred to in this booklet should be done by qualified, experienced technicians.


Table of Contents

Subject		Page
Unit Model Number Description		
General Information		
Operation Electrical Sequence of Operation Dual Compressor Operation Single Compressor, 2-Speed Operation		
Safety Controls		 9
Maintenance		10
Periodic Maintenance Once A Month Once A Year		10
Shutdown and Start-Up Maintenance Log		
Maintenance Procedures Coil Cleaning		
Control Testing		
Leak Testing		 14
Refrigerant Charging		16
Checking Refrigerant Charge		
Measuring Superheat		
Troubleshooting		

Unit Model Number Description

Trane LCG products are identified by a multiple-character model number that precisely identifies a particular type of unit. An explanation of this multiple-character number is shown below. It will enable the owner or Service Engineer to define operation, components and applicable accessories for a specific unit.

LCG Unit Model Nomenclature



120 = 120 MBH 180 = 180 MBH 240 = 240 MBH

General Information

Periodic Maintenance checklists are provided at the beginning of the MAINTENANCE manual for performing recommended maintenance. These checklists should not be substituted for the detailed information given in appropriate sections of this manual. A Maintenance Log at the end of the "Periodic Maintenance" section enables the operator/serviceman to maintain a record of system operating data.

Operation

Electrical Sequence of Operation

The typical wiring diagrams provided in Figures 1 and 2 should be used only as a reference for the following discussion. For the actual wiring of your specific unit, refer to the wiring diagram pasted on the inside of the unit's control box cover.

System operation is controlled by a two-stage thermostat, depending upon the number of compressors in the system. Closing the unit disconnect switch supplies power to the control power transformer (T1), the compressor crankcase heaters (CCH1 and CCH2), and the line side of all control contactors.

Depending on the thermostat selected, it may be possible to operate the evaporator fan independently of the compressors by placing the thermostat fan switch in the ON position. This energizes the evaporator fan contactor, starting the fan. If the thermostat has a separate fan switch, moving that switch to the AUTO position will cause the evaporator fan to start in conjunction with the compressor whenever the thermostat calls for cooling.

Dual Compressor Operation

Sensing a need for cooling, the first stage cooling contacts of the thermostat will close. This supplies power to the compressor contactor solenoid coil (CC1), provided that the high pressure control, low pressure control, and reset relay contacts are closed.

The contacts of the compressor contactor close, energizing the first stage compressor, provided that the compressor internal motor winding thermostats are closed.

The compressor has only two leads broken by the compressor contactor. The third leg of the contactor energizes the condenser fan motors. The outdoor temperature determines the number of condenser fans that will start. A fan limit control (FLT) is electrically positioned between both fans #1 and #2 and fans #2 and #3. Depending on the position of these controls, one or more fans may start.

As the cooling load increases, the second stage contacts of the thermostat will close. This supplies power to the solenoid coil of the second stage compressor contactor (CC2), staring the second compressor.

Single Compressor, 2-Speed Operation

Sensing a need for cooling, the first stage cooling contacts of the thermostat will close. Assuming that no safety controls have tripped, this supplies power to the low speed compressor contactor coil (CCS) and outdoor fan relay coil (ODR). Safety controls in this circuit include the high pressure control (HPC), low pressure control (LPC), reset relay (RR), and compressor motor protection module (CMPM).

NOTE: The compressor contactor cannot be re-energized on the BTA180F for four minutes after winding temperatures have returned to normal following cut-out on excessive temperature, current overload, or power interruption to Terminal T1 of the compressor motor protection module. This provides an antishort cycle feature on the standard unit. The compressor cannot be re-energized for four minutes following termination of the cooling cycle. This is an option on the dual compressor units.

Energizing the compressor contactor coil (CCS) closes the CCS contacts in the power circuit, and starts the compressor on low speed. Concurrently, outdoor fan relay coil ODR is energized. This starts the outdoor fan motor(s) by closing the ODR contact in the power circuit. The total number of condenser fans which will operate is dependent upon the outdoor ambient and the resulting position of the FLT switches (see Figure 2).

As the cooling load increases, the second stage contacts of the thermostat will close. This supplies power to the control relay coil (CR), which opens one set of contacts and closes the other on this single-pole, double-throw relay. This, in turn, deenergizes the low speed compressor contactor coil (CCS) and supplies power to the "tie point" compressor contactor coil (CCT) through normally closed auxiliary contacts CCS located in the control circuit. Auxiliary control circuit contacts CCT then close, and power is supplied to the high speed compressor contactor coil (CCF). After the low speed compressor contactor contacts (CCS) in the power circuit open, both the "tie point" and high speed compressor contactor contacts (CCT and CCF) close and the compressor motor switches from low to high speed.

It should be noted that the dual compressor contactor is both mechanically and electrically interlocked in order to protect the compressor motor from having both low and high speed windings energized at the same time. Electrically, this is accomplished with a normally closed auxiliary side switch (CCS) on the "tying" compressor contactor coil (CCT), and a double-pole, double-throw auxiliary side switch (CCT) on both the high and low speed compressor contactor coils (CCF and CCS). See Figures 3 and 4 for further details on this electrical connection.


Normally, the compressor will start and operate on low speed before switching to high speed. However, the compressor can start on high speed if the difference between the thermostat setting and the space temperature is great enough. This will be the case in a "pull-down" situation where the unit has been disconnected from normal thermostat control for an extended period of time. It will also occur if the thermostat setting is lowered substantially while the system is off.

NOTE: The compressor may not start in low speed when a differential pressure greater than 180 psig exists between the high and low side of the refrigerant circuit.

BTA compressors include two-pole/four-pole motor hookup capability for two speed operation. The compressor operates at approximately 3500 RPM on high speed (two-pole), and at 1750 RPM on low speed (four-pole).

To achieve two speed operation, the motor windings are switched between a parallel connected (high speed) and series connected (low speed) motor winding through the use of low speed, high speed, and tie point contacts on the compressor contactor. This is shown in Figure 3 (high speed) and Figure 4 (low speed).

CAUTION: Extreme care must be taken when making wiring connections in the compressor terminal box. Incorrect hookup can result in immediate compressor failure when power is applied.



	LEGEND	
COMP	COMPRESSOR	
CC	COMPRESSOR CONTACTOR	
ODFM	OUTDOOR FAN MOTOR	
TS	TERMINAL STRIP	
TI	TRANSFORMER	
F	FUSE	
CAP	CAPACITOR	
RR	RESET RELAY	
HPC	HIGH PRESSURE CONTROL	
ССН	CRANKCASE HEATER	
LPC	LOW PRESSURE CONTROL	
LATD	LOW AMBIENT TIME DELAY	
FLT	FAN LIMIT T-STAT	
DESCRIPTION OF THE PARTY OF THE		

TRANE FORM NO. 6-3563

(CONTINUED ON NEXT PAGE)

Figure 1 - Typical Unit Wiring Diagram (Dual Compressor Unit Shown)

DISCONNECT ELECTRICAL POWER SOURCE TO PREVENT INJURY OR DEATH FROM ELECTRICAL SHOCK

USE COPPER CONDUCTORS ONLY TO PREVENT EQUIPMENT DAMAGE






(CONTINUED FROM PREVIOUS PAGE)

OTE S

- I SEE NAMEPLATES OF ALL MOTORS FOR VOLTAGE BEFORE CONNECTING TO LINE
- 2. ALL COMPONENTS AND WIRES SHOWN DOTTED ARE SUPPLIED BY CUSTOMER
- 3. IF ANY OF THE ORIGINAL WIRES AS SUPPLIED WITH THIS UNIT MUST BE REPLACED, IT MUST BE REPLACED WITH APPLIANCE WIRING MATERIAL RATED 105°C OR EQUIVALENT
- 4. ALL CUSTOMER WIRING MUST BE IN ACCORDANCE WITH NATIONAL AND LOCAL ELECTRICAL CODES
- SALL 208-230 VOLT UNITS WILL BE FACTORY WIRED FOR 230 VOLT APPLICATIONS.
 FOR 208 VOLT APPLICATIONS MOVE LEAD 97 FROM THE 240 VOLT TRANSFORMER
 TERMINAL TO THE 208 VOLT TERMINAL.
- 6. THREE PHASE MOTORS ARE PROTECTED UNDER PRIMARY SINGLE PHASING CONDITIONS
- 7. EVAPORATOR APPLICATION TEMPERATURE RANGE +32°F TO +53.5°F
- B REPLACE F7 FUSE WITH BUSSMAN TYPE GLQ & GMQ 3 AMP 300V FUSES ONLY
- 9 REPLACE F5 AND F6 FUSES WITH 300 V.30 AMP TYPE SC FUSES ONLY
- IO RESET RELAY WILL RESET WHEN POWER IS INTERRUPTED



2306-3563




Figure 2 - Typical Unit Wiring Diagram (15 Ton Single Compressor Unit Shown)

- 7 HEPLACE F5 AND F6 FUSES WITH 300 VOLT, 30 AMP TYPE SC FUSES ONLY


- ALL 208-230 VOLT UNITS WILL BE FACTORY WIRED FOR 230 VOLT APPLICATION. FOR 200 VOLT APPLICATIONS MOVE LEAD 95 FROM THE 780 VOLT THANFOOMER TERMINAL (NS) TO THE 200 VOLT TERMINAL (NS).


 DIAMPM IS LOCATED IN THE COMPRESSOR JUNCTION BOX, TEXAS INSTRUMENT PRISA ALIOSA. COMPRESSOR CONTACTOR CANNOT BE HE-ENGIZED FING A MINUTES AFTER WINDING TEMPRATURES HAVE RETURNED TO MORMAL FOLLOWING CUT-OUT ON EXCESSIVE TEMPRATURE, CUARRENT OWERLOAD, OR POWER INTERRUPTION TO TERMINAL. 11.

 DEMOGRAPH OF APPLICATION TEMPERATURE AND 2° 7 TO 33.5° F
- (II) REPLACE ONLY WITH BUSSMAN GLQ OR GMQ SAMP SOOV FUSES.

(CONTINUED FROM PREVIOUS PAGE)







WARNING -**DISCONNECT ELECTRICAL POWER** SOURCE TO PREVENT INJURY OR **DEATH FROM ELECTRICAL SHOCK**


- CAUTION -**USE COPPER CONDUCTORS ONLY** TO PREVENT EQUIPMENT DAMAGE


IMPORTANT

ANTI-SHORT CYCLE FEATURE IS STANDARD ON THIS UNIT. COM-PRESSOR CANNOT BE RE-ENERGIZED FOR 4 MINUTES FOL LOWING TERMINATION OF COOLING CYCLE.

CAUTION

DO NOT ENERGIZE UNTIL UNIT CHECK-OUT AND START-UP PROCEDURE HAS BEEN COMPLETED









2306-3564




Figure 3 - High Speed Operation (Parallel Connected)




Figure 4 - Low Speed Operation (Series Connected)

Safety Controls

High Pressure Control

BTA150D, BTA180D and BTA180F units have an external high pressure control that prevents excessive compressor discharge pressures. This control opens the electrical control circuit, stopping compressor operation, if the condensing pressure becomes too high. Refer to Table 1 for control settings.

The compressors on BTA120D units are provided with an internal pressure relief valve which automatically vents hot gas onto the winding thermostat whenever condensing pressure becomes excessive. This heat causes the contacts of the winding thermostat to open, and compressor operation ceases until the thermostat cools enough for its contacts to close.

Low Pressure Control

All BTA120-180 units have an external low pressure control that stops compressor operation if the operating pressure is too low. Refer to Table 1 for control settings.

Reset Relay

Whenever the system is stopped by the high or low pressure control, the reset relay locks out the compressor contactor. This prevents the system from recycling until the condition causing the high or low pressure cut-out is corrected, and the relay is manually reset. To reset this relay, turn the room thermostat from COOL to OFF and then back to COOL, or open the unit disconnect switch and reclose it.

Fan Sequencing

Condenser fans are cycled on and off in response to ambient temperature in order to keep the capacity of the condenser relatively constant and to maintain proper system pressures. Figure 5 details the possible condenser fan operating modes.

Motor Overloads

All BTA120-180 units have internal compressor and condenser fan motor overloads. These overloads protect the motors from overheating and automatically reset as soon as they cool.

Condenser Fan Limit Control

The condenser fan limit control (FLT) is a temperature sensor that energizes and de-energizes the condenser fan in response to ambient temperature. As the ambient temperature decreases, the cooling capacity of the condenser increases. The cooling low ambient sensor turns off condenser fans to keep the capacity of the condenser constant and to maintain proper system pressures. Refer to Table 1 for control settings.

Table 1 - Control Settings

CONTROL	CUT-IN	CUT-OUT
High Pressure Control (All Units)	345 PSIG (20)	425 PSIG (+20)
Low Pressure Control (All Units)	48 PSIG (±7)	20 PSIG (±4)
FLT 10 Ton	75 F(±3)	65 F(±3)
FLT 12.5-15 Ton	75 F(±3)	65 F(±3)
FLT 12.5-15 Ton	65 F(±3)	55 F(±3)

FLT = Fan Limit Temperature Control




Figure 5 - Condenser Fan Operating Modes

Maintenance

Periodic Maintenance

Perform all of the indicated maintenance procedures at the intervals scheduled. This will prolong the life of the unit and reduce the possibility of costly equipment failure. A MAINTENANCE LOG is provided on page 12 of this manual for recording operating data on a regular basis.

Once a Month

Conduct the maintenance inspections outlined below on a monthly basis during the cooling season.

- 1. Inspect the evaporator coil air filters. Clean or replace if necessary.
- 2. Inspect the evaporator and condenser coils for dirt and foreign debris. If the coils appear dirty, clean them according to the instructions provided under "Coil Cleaning" in the MAINTENANCE PROCEDURES section of this manual.

Once a Year

The following maintenance practices must be performed at the beginning of each cooling season to ensure efficient unit operation.

WARNING: OPEN THE UNIT DISCONNECT SWITCH AND LOCK IT IN THAT POSITION TO PREVENT ACCIDENTAL START-UP. NEVER OPEN AN ACCESS PANEL TO INSPECT OR SERVICE THE UNIT WITHOUT FIRST OPENING THE DISCONNECT SWITCH. FAILURE TO DO SO MAY RESULT IN INJURY OR DEATH FROM ELECTRICAL SHOCK OR CONTACT WITH MOVING PARTS.

- 1. Inspect the evaporator coil air filters. Clean or replace if necessary. Depending on filter type and system application, filters may need to be serviced more frequently.
- 2. Clean both the evaporator and condenser coils. Follow the procedures outlined under "Coil Cleaning" in the MAINTE-NANCE PROCEDURES section of this manual.
- 3. With the unit disconnect switch open, check to see that each condenser and evaporator fan is securely fastened to its motor shaft. All fans should turn freely and airflow should be unobstructed.
- 4. Replace worn or frayed evaporator fan belts. Check the belt tension of the evaporator fans. A 1/2-inch deflection under light hand pressure is normal. Tighten if necessary.
- 5. Remove the condensing unit control box cover and inspect the panel wiring. All electrical connections should be secure. Inspect the compressor and condenser fan motor contactors. If the contacts appear severely burned or pitted, replace the contactor (refer to Figure 6). Do not clean the contacts. Inspect the condenser fan capacitors for visible damage.



Figure 6 - Compressor Contactor Replacement Guide

- 6. Remove any accumulation of dust and dirt from the condensing unit.
- 7. Clean and inspect the drain pan of the evaporator unit. Make sure the drain piping is clear.
- 8. Check the superheat and subcooling.
 - a. The condenser and evaporator coils must be clean before making the following checks.
 - Determine the superheat of the system. Refer to "Measuring Superheat" in the MAINTENANCE PROCEDURES section of this manual.
 - Adjust the superheat if necessary (instructions are provided in the "Measuring Superheat" section of this manual).
 - d. When the superheat setting is correct, check the subcooling. Refer to "Measuring Subcooling" in the MAIN-TENANCE PROCEDURES section of this manual.
 - e. If the subcooling is low, leak test the system to determine if there is a leak. Refer to "Leak Testing" in the MAINTENANCE PROCEDURES section of this manual.
 - f. Charge the system with refrigerant if necessary. Instructions are provided under "Checking Refrigerant Charge" in the MAINTENANCE PROCEDURES section of this manual.
 - g. Enter the operating pressures, superheat, and subcooling in the MAINTENANCE LOG provided on the following page.

Shutdown and Start-Up

Shutdown: Short Duration

The system can be shutdown for periods of short duration, such as over the weekend, by moving the thermostat selector switch to the OFF position and the fan switch to the AUTO position.

NOTE: The unit disconnect switch should remain closed. This will permit the crankcase heater to continue to function, preventing refrigerant from condensing in the compressor oil sump.

Start-Up: Short Duration

The system is returned to operation after a shutdown of short duration, such as over a weekend, by adjusting the thermostat setting to the desired temperature, placing the thermostat selector switch in the COOL or AUTO position, and setting the fan switch in either the AUTO or ON position.

Shutdown: Seasonal

For seasonal shutdown, open the unit electrical disconnect switch to prevent the unit from starting accidently.

Start-Up: Seasonal

To start the system after an extended period of shutdown, complete the following procedures.

- Perform all of the "Once A Year" checks listed in the PERI-ODIC MAINTENANCE section of this manual.
- 2. Move the thermostat selector switch to OFF.
- Close the electrical disconnect switch to the condensing unit.This will energize the compressor crankcase heater. If oper-

ating properly, the crankcase should be hot to the touch. Wait a minimum of eight hours before turning the room thermostat to the COOL position.

CAUTION: Failure to wait eight hours before turning the room thermostat to COOL may result in damage to the compressor bearings.

- 4. Start a dual compressor system by adjusting the thermostat setting to the desired temperature, placing the thermostat selector switch in the COOL or AUTO position, and placing the fan switch in either the AUTO or ON position.
- Adjust the thermostat setting on a single compressor unit so that the compressor will be operating at high speed. Place the thermostat selector switch in either the COOL or AUTO position, and the fan switch in either the AUTO or ON position.
- Place a clamp-on ammeter on each compressor lead and check the motor amperage. Amperage draw should not be greater than the "Maximum Allowable Amps" given in Table 9.
- 7. Place the clamp-on ammeter around either of the two leads from each outdoor fan motor run capacitor to determine if the run capacitor is open and must be replaced. The amp draw should not be greater than the nameplate rating for the condenser fan motors.
- 8. Lower the thermostat setting to the desired temperature.

Maintenance Procedures

This section of the manual describes specific maintenance procedures which must be performed as a part of the unit's maintenance program. Before performing any of these operations, however, be sure that power to the unit is disconnected unless otherwise instructed.

WARNING: WHEN MAINTENANCE CHECKS AND PROCEDURES MUST BE COMPLETED WITH THE ELECTRICAL POWER ON, CARE MUST BE TAKEN TO AVOID CONTACT WITH ENERGIZED COMPONENTS OR MOVING PARTS. FAILURE TO EXERCISE CAUTION WHEN WORKING WITH ELECTRICALLY-POWERED EQUIPMENT MAY RESULT IN SERIOUS INJURY OR DEATH.

Coil Cleaning

Condenser coils must be cleaned at least once each year, or more frequently if the unit is located in a "dirty" environment, to help maintain proper unit operating efficiency and reliability. The relationship between regular coil maintenance and efficient unit operation is outlined below:

- Clean condenser coils minimize compressor head pressure and amperage draw, and promote system efficiency.
- Clean evaporator coils minimize water carry-over and help eliminate frosting and/or compressor flood back problems.
- Clean coils minimize required fan brake horsepower and maximize efficiency by keeping coil static pressure loss at a minimum.

 Clean coils keep motor temperatures and system pressures within safe operating limits for good reliability.

Specific instructions for cleaning condenser coils are provided in the following paragraphs. Follow these instructions as closely as possible to avoid potential damage to the coils.

To clean refrigerant coils, the following equipment is required: a soft brush and either a garden pump-up sprayer or a high pressure sprayer. In addition, a high quality detergent must be used: suggested brands include SPREX A.C., OAKITE 161, OAKITE 166, and COILOX. Follow the manufacturer's recommendations for mixing to make sure the detergent is alkaline with a pH value less than 8.5.

1. Disconnect power to the unit.

WARNING: OPEN UNIT DISCONNECT SWITCH. FAILURE TO DISCONNECT UNIT FROM ELECTRICAL POWER SOURCE MAY RESULT IN SEVERE ELECTRICAL SHOCK, AND POSSIBLE INJURY OR DEATH.

- Remove enough panels from the unit to gain access to the coil.
- Protect all electrical devices such as motors and controllers from dust and water spray.
- 4. Straighten coil fins with a fin rake, if necessary.

MAINTENANCE LOG

DATE	AMBIENT TEMP. (F)	EVAPO	RATOR ING AIR		(HIGH SPEED)	NAME AND ADDRESS OF THE OWNER, WHEN PERSON NAMED IN			RHEAT	
DAIL	TEMP. (F)	DRY BULB	WET BULB	SUCTION PRESSURE	DISCHARGE PRESSURE	SUCTION PRESSURE	DISCHARGE PRESSURE	CIRCUIT NO. 1 (F)	CIRCUIT NO. 2 (F)	SUBCOOLING (I
										
									7 45	
								1		
										7.
									4	

- Use a soft brush to remove loose dirt and debris from both sides of the coil.
- Mix the detergent with water according to the manufacturer's instructions. The detergent-and-water solution may be heated to a maximum of 150 F to improve its cleansing ability.

WARNING: DO NOT HEAT THE DETERGENT-AND-WATER SOLUTION TO TEMPERATURES IN EXCESS OF 150 F. HIGH-TEMPERATURE LIQUIDS SPRAYED ON THE COIL EXTERIOR WILL RAISE THE PRESSURE WITHIN THE COIL AND MAY CAUSE IT TO BURST, RESULTING IN POSSIBLE INJURY TO SERVICE PERSONNEL AND EQUIPMENT DAMAGE.

- 7. Place the detergent-and-water solution in the sprayer. If a high-pressure sprayer is used, be sure to follow these guidelines:
 - Minimum nozzle spray angle is 15 degrees.
 - Spray the solution perpendicular (at a 90 degree angle) to the coil face.
 - Keep the sprayer nozzle at least six inches from the coil.
 - Sprayer pressure must not exceed 600 psi.

CAUTION: Do not spray motors or other electrical components. Moisture can cause component failure.

- Spray the leaving air side of the coil first, then spray the entering air side of the coil. Allow the detergent-and-water solution to stand on the coil for five minutes.
- 9. Rinse both sides of the coil with cool, clean water.
- Inspect the coil. If it still appears to be dirty, repeat Steps 7, 8 and 9.
- 11. Replace all unit panels and parts, and restore electrical power to the unit.
- 12. Remove the protective covers installed in Step 3.

Control Testing

The following procedures can be used to check the operation of the high and low pressure controls. To determine operating pressures, attach gauges to the compressor suction and discharge access valves.

High Pressure Control

- 1. Open the unit electrical disconnect switch.
- Disconnect the low voltage lead(s) from the condenser fan relay coil(s). This will de-energize the condenser fans.
- On BTA150D-BTA180D units only, disconnect Y2 on the control box terminal strip when checking the high pressure control for Compressor No. 1. This will prevent the second compressor from running while checking the control in the first compressor circuit.
- Close the unit disconnect switch and start the unit. On BTA180F units operate the compressor on high speed.

CAUTION: Be prepared to open the unit disconnect switch immediately if the compressor continues to run after the discharge pressure exceeds the high pressure control cut-out range. Failure to do so could damage the system.

- 5. Observe the rising discharge pressure. When the pressure reaches 425 psig (±20) as shown in Table 1, the compressor should shut off. If the pressure reaches 445 psig without the high pressure switch breaking, immediately open the unit disconnect switch. Check to make sure that the high pressure control attached to liquid line No. 1 is wired to low voltage circuit No. 1. Replace the faulty high pressure control.
- 6. On BTA150D-BTA180D units, repeat Steps 1 through 5 to test the high pressure control in the second compressor circuit. In place of Step 3, however, reconnect Y2 and disconnect Y1 on the control box terminal strip. This will prevent Compressor No. 1 from running while the control for the second compressor circuit is being tested.
- 7. Open the unit disconnect switch.
- 8. Reconnect the wires removed in Step 2 on single compressor units, on in Steps 2 and 6 on dual compressor units.
- Allow the discharge pressure(s) to drop below the cutin setting in Table 1, and close the unit disconnect switch. This will also close the reset relay that locked out the compressor contactor when the high pressure control tripped.
- The unit should start. If not, allow the discharge pressure to decrease further and repeat Step 9.

Low Pressure Control

- 1. Open the unit electrical disconnect switch.
- Disconnect the wire that goes to the indoor blower coil from either Terminal T or R on the control box terminal strip. This will de-energize the evaporator fans.
- On BTA120D-BTA180D units only, disconnect Y2 on the control box terminal strip when checking the low pressure control for Compressor No. 1. This will prevent the second compressor from running while checking the control in the first compressor circuit.
- Remove the wires from Terminal 2 on the low ambient time delay relay(s). Insulate the wire terminals with electrical tape.
- 5. Close the unit disconnect switch and start the unit.

CAUTION: Be prepared to open the unit disconnect switch immediately if the compressor continues to run after the suction pressure drops below the low pressure control cut-out range. Failure to do so could damage the compressor.

- 6. Observe the decreasing suction pressure. When the pressure drops to 20 psig (±4) as shown in Table 1, the compressor should shut off. If the pressure reaches 15 psig without the low pressure switch breaking, immediately open the unit disconnect switch. Replace the faulty low pressure control.
- 7. On BTA120D-BTA180D units, repeat Steps 1 through 6 to test the low pressure control in the second compressor circuit. In place of Step 3, however, reconnect Y2 and disconnect Y1 on the control box terminal strip. This will prevent Compressor No. 1 from running while the control for the second compressor circuit is being tested.

13

- 8. Open the unit disconnect switch.
- Reconnect the wires removed in Steps 2 and 4 on single compressor units, or in Steps 2, 4, and 7 on dual compressor units.
- 10. Allow the suction pressure(s) to rise above the cut-in setting in Table 1, and close the unit disconnect switch. This will also close the reset relay that locked out the compressor contactor when the low pressure control tripped.
- The unit should start. If not, allow the suction pressure to rise further and repeat Step 10.

Evacuation

For field evacuation, use a rotary-style vacuum pump capable of pulling a vacuum of 100 microns or less.

When hooking the vacuum pump to a refrigeration system, it is important to manifold the pump to both the high and low side of the system (liquid line access valve and compressor suction access valve). Follow the pump manufacturer's directions as to the proper methods of using the vacuum pump.

CAUTION: Do not, under any circumstances, use a megohm meter or apply power to the windings of a compressor while it is under a deep vacuum. In the rarified atmosphere of a vacuum, the motor windings can be damaged.

The lines used to connect the pump to the system should be copper and of the largest diameter that can practically be used. Using larger line sizes with minimum flow resistance can significantly reduce evacuation time. Rubber or synthetic hoses are not recommended for unit evacuation because they have moisture absorbing characteristics which result in excessive rates of outgassing and pressure rise during the standing vacuum test. This makes it impossible to determine if the unit has a leak, excessive residual moisture, or a continual or high rate of pressure increase due to the hoses.

An electronic micron vacuum gauge should be installed in the common line ahead of the vacuum pump shutoff valve, as shown in Figure 7. Close Valves B and C, and open Valve A. After several minutes, the gauge reading will indicate the minimum blank-off pressure the pump is capable of pulling. Rotary pumps should produce vacuums of less than 100 microns.

Open Valves B and C. Evacuate the system to a pressure of 500 microns or less. Once 500 microns or less is obtained, with Valve A closed, a time versus pressure rise should be performed. The maximum allowable rise over a 15 minute period is 200 microns. If the pressure rise is greater than 200 microns but levels off to a constant value, excessive moisture is present. If the pressure steadily continues to rise, a leak is indicated. Figure 8 illustrates three possible results of the time versus temperature rise check.




Figure 7 - Vacuum Pump Hook-Up

LEAK TESTING

When leak testing the unit, the following safety precautions must be observed:

WARNING: DO NOT WORK IN A CLOSED AREA WHERE REFRIGERANT OR NITROGEN MAY BE LEAKING. A SUFFICIENT QUANTITY OF VAPORS MAY BE PRESENT TO CAUSE PERSONAL INJURY. PROVIDE ADEQUATE VENTILATION.

WARNING: DO NOT USE OXYGEN, ACETYLENE, OR AIR IN PLACE OF REFRIGERANT AND DRY NITROGEN FOR LEAK TESTING. A VIOLENT EXPLOSION WILL RESULT WHICH COULD CAUSE SERIOUS INJURY OR DEATH.




Figure 8 - Time vs. Pressure Rise after Evacuation

WARNING: ALWAYS USE A PRESSURE REGULATOR, VALVES, AND GAUGES TO CONTROL DRUM AND LINE PRESSURES WHEN PRESSURE TESTING THE SYSTEM. EXCESSIVE PRESSURES MAY CAUSE LINE RUPTURES, EQUIPMENT DAMAGE, OR AN EXPLOSION WHICH COULD RESULT IN PERSONAL INJURY OR DEATH.

Leak test the liquid line, evaporator, and suction line at pressures dictated by local codes.

CAUTION: Do not exceed 200 psig when leak testing the system.

- Charge enough refrigerant into the system to raise the pressure to 100 psig.
- Use a halogen leak detector or halide torch to check for leaks. Be thorough in this test, checking the interconnecting piping joints, the evaporator unit, and the condensing unit.

- If a leak is found during the testing, release the test pressure, break the connection, and remake it as a new joint. Refer to the "Brazing Procedures" in this section of the manual for proper brazing techniques.
- 4. If no leak is found, use nitrogen to increase the test pressure to 150 psig, and repeat the leak test. Soap bubbles should be used to check for leaks when nitrogen is added. If a leak is found after increasing the pressure to 150 psig with nitrogen, release the test pressure and repair the leak.
- Retest the system to make sure the new connection is solid.
- If a leak is suspected after the system has been fully charged with refrigerant, use a halogen leak detector, halide torch, or soap bubbles to check for leaks.

Brazing Procedures

Proper brazing techniques are essential when installing refrigerant piping. The following factors should be kept in mind when forming sweat connections.

- When copper is heated in the presence of air, copper oxide forms. To prevent copper oxide from forming inside the tubing during brazing, sweep an inert gas, such as dry nitrogen, through the tubing. Nitrogen displaces air in the tubing and prevents oxidation of the interior surfaces. A nitrogen flow of one to three cubic feet per minute is sufficient to displace the air. Use a pressure regulating valve or flow meter to control the flow.
- Ensure that the tubing surfaces to be brazed are clean, and that the ends of the tubes have been carefully reamed to remove any burrs.
- 3. Make sure the inner and outer tubes of the joint are symmetrical and have a close clearance, providing an easy slip fit. If the joint is too loose, the tensile strength of the connection will be significantly reduced. The overlap distance should be equal to the diameter of the inner tube.
- 4. Wrap the body of each refrigerant line component with a wet cloth to keep it cool during brazing. Also move line insulation and tube grommets away from the joints. Excessive heat can damage these components.
- If flux is used, apply it sparingly to the joint. Excess flux will contaminate the refrigerant system.
- Apply heat evenly over the length and circumference of the joint. The entire joint should become hot enough to melt the brazing material.
- Begin brazing when the joint is hot enough to melt the brazing rod. The hot copper tubing, not the flame, should melt the rod.
- 8. Continue to apply heat around the circumference of the joint until the brazing material is drawn into the joint by capillary action, making a mechanically sound and gas-tight connection. Remove the brazing rod as soon as a complete fillet is formed to avoid possible restriction in the line.
- Visually inspect the connection after brazing to locate any pin holes or crevices in the joint. The use of a mirror may be required, depending on joint location.

Refrigerant Charging

Once the system is properly installed, leak tested and evacuated, refrigerant charging can begin. Liquid refrigerant must be charged into the system through the liquid line access valve, with the compressor shut off.

Refrigerant should be charged into the system by weight. Use an accurate scale or a charging cylinder to determine the exact weight of the refrigerant entering the system. Failure to use either a scale or charging cylinder can lead to under-charging or overcharging, resulting in unreliable operation.

The weights of refrigerant required for the evaporator unit and the condensing unit are given in Table 2. The weight of refrigerant required for the system piping can be determined by measuring the refrigerant lines and using the data in Table 3. The total system operating charge is calculated by adding the charge weight requirements of each part of the system. Refer to the following example.

EXAMPLE: The installation consists of a BTA180D condensing unit, a BWV180B evaporator unit, and 30 feet of 1/2 inch liquid line and 1-3/8 inch suction line.

BTA180D		163 oz./circuit
BWV180D	=	94 oz./circuit
Liquid Line (1.137 oz./ft.) x (30 ft.)	=	34 oz./circuit
Suction Line (.203 oz./ft.) x (30 ft.)	=	6 oz./circuit
Total Charge Per Circuit		255 oz./circuit

Since the 15 ton system has two circuits, the total system operating charge required is 510 oz.

Table 2 - Refrigerant charge Weights for Condensing and Evaporator Units

CONDENSING UNIT	CHARGE (IN OUNCES OF R-22)	EVAPORATOR UNIT	CHARGE (IN OUNCES OF R-22)
BTA120D	268 (134/circuit)	BTE120B	112 (56/circuit)
BTA150D	256 (128/circuit)	BWE090C (Two)	158 (79/circuit)
		BWV180B	188 (94/circuit)
BTA180D	326 (163/circuit)	BWE090C (Two)	158 (79/circuit)
		BWV180B	188 (94/circuit)
BTA180F	326	BWV180B	188 (94/circuit)

Table 3 - Refrigerant Line Charge Weights (Ounces/Foot)

TUBE O.D. (INCHES)	LIQUID LINE	SUCTION LINE
3/8	0.610	
1/2	1.137	
5/8	1.827	
3/4	2.738	0.056
7/8		0.078
11/8		0.133
13/8	Visit Million Charles for the Con-	0.203
15⁄8		0.288

WARNING: DO NOT APPLY FLAME TO A REFRIGERANT DRUM IN AN ATTEMPT TO INCREASE THE DRUM PRESSURE. UNCONTROLLED HEAT MAY CAUSE EXCESSIVE DRUM PRESSURES AND AN EXPLOSION MAY RESULT.

WARNING: SHOULD LIQUID REFRIGERANT COME IN CONTACT WITH THE SKIN, THE INJURY SHOULD BE TREATED AS IF THE SKIN HAS BEEN FROSTBITTEN OR FROZEN. SLOWLY WARM THE AFFECTED AREA WITH LUKEWARM WATER.

Proceed as follows to charge the system with refrigerant.

Charge liquid refrigerant into the liquid line of the No. 1 compressor circuit, using the liquid line access valve. The vacuum within the system will draw some of the required refrigerant into the system. If the pressure within the system equalizes with the pressure in the charging cylinder before the required charge has been drawn in, proceed to Step 2.

NOTE: On 10, 12.5, and 15 ton units, this charging process must be repeated for compressor circuit No. 2.

- If the system cannot be completely charged by liquid refrigerant entering the system liquid line as outlined in Step 1, complete the process by charging gaseous refrigerant into the suction line. However, at least part of the charge must be in the system prior to starting the compressor. Proceed as follows:
 - a. Close the liquid line valve on the manifold gauge set.
 - b. Connect the manifold gauge set to the suction and discharge access valves (shown in Figure 9). The manifold valves should be closed.
 - Turn the refrigerant drum upright so that gaseous refrigerant is drawn off the top.
 - Start the unit by following the procedures outlined in the INITIAL START-UP section of this manual.
 - e. With the condensing unit operating, slowly open the suction line valve on the manifold gauge set. The remainder of the refrigerant will be drawn into the system.

CAUTION: Do not allow liquid refrigerant to enter the suction line. Excessive liquid will damage the compressor.

Checking Refrigerant Charge

Before taking measurements to determine if the system is correctly charged with refrigerant, verify that all other aspects of the system operation are proper. The following conditions must be checked and satisfied.

- Check the evaporator and condenser fans to ensure that they are rotating in the proper direction, that the fan blades do not have dirt buildup, and that each fan is turning at the proper RPM. Make sure that the evaporator fan RPM is correct for the airflow desired and for the external static pressure being imposed by the duct system.
- 2. Make sure the evaporator air filters are clean.
- Check the evaporator and condenser coils to ensure that they are clean, that the fins are straight, and that there are no obstructions to airflow.
- 4. Measure the suction line superheat and adjust the expansion valve, if necessary. (Refer to "Measuring Superheat" in the MAINTENANCE PROCEDURES section of this manual.) The expansion valve superheat setting must be between 12 and 16 F.

Visually inspect the liquid line sight glass to see if clear liquid is present. Bubbles in the liquid line sight glass indicate either low refrigerant charge, excess liquid line pressure drop, or excess liquid line heat gain.

CAUTION: A clear sight glass does NOT necessarily mean the system has sufficient refrigerant.

After verifying that the system is operating properly, determine if the refrigerant charge is correct. This is accomplished by checking both system operating pressures **and** subcooling leaving the condensing unit.

CAUTION: It is not sufficient to check only operating pressures or only subcooling. Both must be in the acceptable range in order to establish correct system charge.

Operating Pressures:

Measure the suction and discharge line pressures and compare these readings with the normal operating pressures listed in Figures 10-13 and Tables 4-6. Refer to "Operating Pressures" in the MAINTENANCE PROCEDURES section of this manual.

Subcooling:

Determine the system subcooling. (Refer to "Measuring Subcooling" in the MAINTENANCE PROCEDURES section of this manual.) If the system is properly charged, subcooling at the liquid line access valve should be 14 to 19 F.

The system is low on refrigerant if: 1) the suction and discharge pressures are lower than the normal operating pressures as determined from Figures 10-13 and Tables 4-6 and 2) liquid subcooling is low (less than 14-19 F on Dual Compressor Units and less than 18-30 F on Single Compressor Units.

The system is overcharged with refrigerant if: 1) the suction and discharge pressures are higher than normal operating pressures and 2) liquid subcooling is high (greater than 14-19 F on Dual Compressor Units and greater than 18-50 F on Single Compressor Units.

CAUTION: If both the suction and discharge pressures are low but subcooling is in the acceptable range, the system has a problem other than a shortage of refrigerant. Do not add refrigerant. Refer to the TROUBLESHOOTING section of this manual.

Adding Refrigerant:

Use the suction line access valve to add refrigerant to a system with a low charge, making sure that only refrigerant vapor enters the suction line. Continue to add refrigerant until the subcooling is between 14 and 19 F. At this point, the operating pressures should be within the limits defined by Figures 10-13 and Tables 4-6.

Removing Refrigerant:

If the system is overcharged, some refrigerant must be removed to lower the subcooling to the 14-19 F range. Refrigerant should be discharged from the system slowly to keep oil loss at a minimum. The liquid line access valve can be depressed to remove refrigerant. However, refrigerant should not be discharged into the atmosphere.

WARNING: DO NOT ALLOW REFRIGERANT TO COME IN CONTACT WITH THE SKIN. IF THIS OCCURS, THE INJURY SHOULD BE TREATED AS IF THE SKIN HAS BEEN FROST-BITTEN OR FROZEN. SLOWLY WARM THE AFFECTED AREA WITH LUKEWARM WATER.




Figure 9 - Compressor Suction and Discharge Access Valves (Dual Compressor Unit Shown)

Operating Pressures

Operating pressure data can be used to determine if the system is operating properly. System malfunctions — such as low airflow, line restrictions, incorrect refrigerant charge, malfunctioning expansion valve, damaged compressor, and so on — will result in pressure variations which are outside the normal range. If the condensing unit and evaporator are checked individually, as described below, the operating pressures can be used to determine which side of the system (high side or low side) is malfunctioning. In addition, the relationship of suction vs. discharge pressure, as well as whether these pressures are higher or lower than expected, will provide valuable clues for determining the specific problem(s).

CAUTION: Operating pressure data, by itself, cannot be used to accurately charge a system. Charging by weight is preferred. If this is not feasible, a combination of operating pressures and subcooling measurement is necessary to properly charge the system. Refer to "Checking Refrigerant Charge" in the MAINTENANCE section of this manual.

Unfortunately, many application variables exist which affect operating pressures. These include indoor dry bulb and wet bulb temperature, outside dry bulb temperature, suction line pressure drop, and evaporator airflow. Since these variables can give misleading results, it is not recommended that operating pressures be used as the sole check of system operation. Further, the following conditions must be satisfied before checking system operating pressures.

- The outdoor ambient temperature must be between 65 and 105 F. At ambient temperatures outside of this range, meaningful operating pressures cannot be measured.
- The relative humidity of the air entering the evaporator must be above 40%. If it is less than 40%, meaningful operating pressures cannot be measured.
- All condenser fans must be operating. If necessary, jumper the low ambient fan switches. Be sure to remove the jumpers when the measurements are completed.
- 4. Do not take measurements if the system includes a low ambient damper and/or hot gas bypass.

Use the following procedure to check operating pressures.

Table 4 - Compressor Suction Pressures (psig)

1.	Condensing	Unit	Performance:
----	------------	------	--------------

- Measure pressures (psig) at the suction and discharge line access valves next to the compressor.
- Measure the dry bulb air temperature (F) entering the condenser coil.
- c. If the outside ambient is between 65 and 105 F, enter the appropriate graph in Figures 10-13 at the measured suction pressure and condenser ambient. Read the corresponding discharge pressure.
- d. The measured discharge pressure should be within ±7 psi of the graph pressure. If the difference is greater than ±7 psi, the **condensing unit** performance is unacceptable. Refer to the TROUBLESHOOTING section of this manual.

								COI	NDENS	SER AN	MBIEN	T, F		124			
			1	65			75			85			95			105	
CON-		EVAP.	WE	T BUL	B, F	WE	T BULI	B, F									
DENSING	EVAP-	AIRFLOW	57	65	72	57	65	72	57	65	72	57	65	72	57	65	72
UNIT	ORATOR	(SCFM)					COMP	RESSC	OR SUC	CTION	PRES	SURE	(PSIG)				
BTA120D	BTE120B	4000	59	69	79	60	7.1	81	62	72	83	63	74	84	65	76	86
BTA150D	(2) BWE090C BWV180B	5000 5000	59 61	69 71	79 82	61 62	71 73	81 84	62 64	73 75	83 85	64 66	75 77	85 87	66 68	77 79	87 90
BTA180D	(2) BWE090C BWV180B	6000 6000	58 60	68 70	78 80	60 61	70 72	80 82	61 63	72 74	82 84	63 65	74 76	84 86	65 66	76 77	86 88
BTA180F	BWV180B	6000	57	67	76	59	69	78	61	71	81	63	73	83	65	75	86

NOTES

1. Table only good for relative humidity of air entering evaporator greater than 40%.

2. Interpolation between wet bulb temperatures is allowable. Do not extrapolate outside range given.

2. Evaporator Performance:

- Measure the actual wet bulb temperature (F) of the air entering the evaporator. Be sure to measure the mixed air condition if outside air is being ducted in.
- b. Find the correct combination of condensing unit and evaporator in Table 4. Match the condenser entering air temperature (measured in Step 1b) with the evaporator wet bulb temperature (measured in Step 2a) to determine the correct suction pressure.
- Use Table 5 to correct the suction pressure (from Table 4) for the line sizes used in your installation.
- d. Use Table 6 to correct the suction pressure (from Step 2c) for the airflow of your evaporator.
- e. The measured suction pressure at the compressor should be within ±2 psi of the corrected pressure from Tables 4-6. If not, improper system operation is indicated. Refer to the TROUBLESHOOTING section of this manual.

CAUTION: Table 4 is not accurate if the relative humidity of evaporator entering air is less than 40%, or if an evaporator/condensing unit combination other than those listed is used.

Table 5 - Suction Pressure Correction for Line Size (PSI)

CONDENSING UNIT	7/8" 0*	O.D. SU 25	ICTION 50	LINE LE	NGTH, 1	FEET 125*
BTA120D	+0.4	-1.0	-2.4	-3.6	-4.7	-5.8
BTA150D	+0.6	-1.6	-3.6	-5.4	-6.9	-8.4
BTA180D	+0.3	-2.5	-5.0	-7.1	-8.9	-10.6
CONDENSING	1-1/8	' O.D. S	UCTION	LINE L	ENGTH,	FEET
UNIT	0*	25	50	75	100	125*
BTA120D	+0.4	0	-0.4	-0.8	-1.1	-1.5
BTA150D	+0.6	0	-0.6	-1.2	-1.8	-2.3
BTA180D	+0.3	-0.5	-1.3	-2.0	-2.7	-3.4
CONDENSING	1-3/8	" O.D. S	UCTION	LINE L	ENGTH,	FEET
UNIT	0*	25	50	75	100	125*
BTA120D	+0.4	+0.3	+0.1	0	-0.2	-0.3
BTA150D	+0.6	+0.4	+0.2	0	-0.3	-0.5
BTA180D	+0.3	0	-0.2	-0.5	-0.8	-1.1
BTA180F	-0.7	-1.7	-2.6	-3.4	-4.2	-4.9
CONDENSING	1-5/8	" O.D. S	UCTION	LINE L	ENGTH,	FEET
UNIT	0*	25	50	75	100	125*
BTA180F	+0.4	0	-0.4	-0.8	-1.2	-1.6

*0 and 125 feet provided for interpolation purposes only.

Table 6 - Suction Pressure Correction for Airflow (PSI)

COND.	PI	ERCEN	IT OF F	RATED	EVA	PORA	TOR A	IRFLO	W
UNIT	-20%	-15%	-10%	-5%	0%	+5%	+10%	+15%	+20%
BTA120D	-2.8	-2.0	-1.3	-0.6	0	+0.6	+1.1	+1.6	+2.1
BTA150D	-2.6	-1.9	-1.2	-0.6	0	+0.5	+1.0	+1.5	+1.9
BTA180D	-2.6	-1.9	-1.2	-0.6	0	+0.5	+1.0	+1.4	+1.9
BTA180F	-2.5	-1.8	-1.2	-0.6	0	+0.5	+1.0	+1.4	+1.8
						_			




Figure 10 · BTA120D Operating Pressures

BTA150D COMPRESSOR DISCHARGE PRESSURE (PSIG) 280 = COMPRESSOR SUCTION PRESSURE (PSIG) NOTE: PRESSURES GIVEN WITH ALL FANS OPERATING.

Figure 11 - BTA150D Operating Pressures




Figure 12 · BTA180D Operating Pressures




Figure 13 - BTA180F Operating Pressures

Measuring Superheat

The "safe" setting range for suction gas superheat on Trane equipment is 12 to 16 degrees at the evaporator. Settings within this range will allow for measurement error. Superheats below 12 degrees can cause refrigerant flood back which could lead to serious compressor damage. Superheat readings above the 16 degree measurement reduce system efficiency by reducing the effective evaporator surface.

To determine suction gas superheat, the pressure at the outlet of the evaporator must be measured and then converted to saturated vapor temperature by using a Refrigerant-22 pressure/temperature chart. The saturated vapor temperature can then be subtracted from the actual suction temperature, which is measured on the suction line close to the expansion valve bulb. The difference between the two temperatures is known as suction gas superheat. On most Trane fan/coil units an access valve has been provided close to the expansion valve bulb. To obtain an accurate reading, this access valve must be utilized when determining suction gas superheat.

Instruments to Use:

- The gauge used to measure suction pressure should be of the best quality available. Gauges permanently installed on the equipment should not be used. A good quality gauge on a standard refrigerant manifold set is recommended.
- To measure suction temperature, an electronic temperature tester will be sufficient. Testers manufactured by Robinnaire, Annie, and Thermal are among those available. Glass thermometers do not have sufficient contact area to give accurate readings.

Procedure:

In most cases it is desirable to use a single distributor evaporator with the BTA condensing unit, thereby utilizing one expansion valve. When the system has only one expansion valve, the following procedure should be used for measuring superheat.

- Cut the suction line insulation to gain access to the suction line. If armaflex is used, it is best to cut around the circumference of the tubing.
- Clean the line carefully and attach the electronic temperature sensor. Black electrical tape works well when securing the sensor of the temperature tester to the suction line. (Make sure the sensor is making good contact with the tube.)
- Rejoin the armaflex and seal with plastic tape to prevent sensor contact with ambient air.

NOTE: For measurement accuracy the temperature sensor **must** be installed and insulated properly. Make sure the armaflex extends at least six inches on both sides of the sensor location. Seal both ends of the armaflex to keep ambient air from getting under the insulation and affecting the temperature readings.

- 4. Install a pressure gauge to monitor suction pressure.
- Operate the system for approximately 10 to 15 minutes to be sure that the expansion valve has time to stabilize.

6. To measure superheat, compare the saturated vapor temperature of the refrigerant converted from the suction pressure reading (see Table 7) to the actual temperature measured at the line by the electronic tester. Proper suction superheat is 12 to 16 degrees.

EXAMPLE:

Suction Pressure = 66.0 psig

Suction Temperature = 52 F

Suction Pressure converted to Saturated Vapor Temperature (from Table 11) = 38 F

Suction Superheat = (Actual Line Temp.) - (Saturated Vapor

= (52 F) - (38 F)

= 14

If initial suction superheat readings fall below 12 degrees, the adjusting stem on the expansion valve should be adjusted clockwise to close the valve, limiting the flow of refrigerant to the evaporator and thus increasing superheat. Adjustment should be made a half turn at a time. Conversely, if the initial suction superheat reading is greater than 16 degrees, the adjusting stem on the expansion valve should be adjusted counterclockwise to open the valve, increasing the flow of refrigerant to the evaporator and thus decreasing superheat. Adjustments should be made until an acceptable reading is obtained. The system should be allowed to restabilize for 10 minutes after each adjustment.

Table 7 - Pressure/Temperature Conversions for Calculating Suction Line Superheat

SATURATED TEMPERATURE	PRESSURE USING REFRIGERANT-22
30	54.9
31	56.2
32	57.5
33	58.8
34	60.1
35	61.5
36	62.8
37	64.2
38	65.6
39	67.1
40	68.5
41	70.0
42	71.4
43	73.0
44	74.5
45	76.0
46	77.6
47	79.2
48	80.8
49	82.4
50	84.0

Measuring Subcooling

The following conditions must be satisfied before checking subcooling.

- The outdoor ambient temperature must be between 65 and 105 F. At ambient temperatures outside of this range, meaningful operating pressures cannot be measured.
- The relative humidity of the air entering the evaporator must be above 40%. If it is less than 40%, meaningful operating pressures cannot be measured.
- 3. The compressor must be operating on high speed.
- All condenser fans must be operating. If necessary, jumper the low ambient fan switches. Be sure to remove the jumpers when the measurements are completed.
- 5. Do not take measurements if the system includes a low ambient damper and/or hot gas bypass.

The proper setting range for liquid subcooling is 18 to 30 F on BTA180F units. Determine the system subcooling as follows:


- Measure the liquid line pressure at the liquid line access valve installed inside the condensing unit. Convert this pressure reading to saturated temperature by using a Refrigerant-22 pressure/temperature chart (refer to Table 8).
- 2. Measure the actual liquid line temperature on the liquid line close to the access valve. To ensure an accurate reading, clean the line thoroughly where the electronic temperature sensor will be attached. Glass thermometers do not have sufficient contact area to give accurate readings. After securing the sensor to the line, wrap the sensor and line with insulation to prevent contact with ambient air.
- Determine the system subcooling by subtracting the actual liquid line temperature (measured in Step 2) from the saturated liquid temperature (calculated in Step 1).
- If the system is properly charged, subcooling at the liquid line access valve should be 18-30 F on BTA180F units and 14-19 F on BTA120D-BTA180D units.

Troubleshooting

The Troubleshooting Chart on the following pages is provided to serve as an aid for identifying the cause of any system malfunctions that may occur. The chart is divided into three columns:

- the "SYMPTOM" column describes the behavior the unit is exhibiting;
- the "PROBABLE CAUSE" column identifies possible sources of malfunction;
- the "RECOMMENDED ACTION" column indicates the procedures required to correct the malfunction.

If operating difficulties are encountered, make the following preliminary checks before referring to the Troubleshooting Chart:



Verify that the unit is receiving	electrical	supply	power,	and
that the fuses are intact.			•	




Table 8 - Pressure/Temperature Conversion for Calculating
Liquid Line Subcooling

SATURATED TEMPERATURE	PRESSURE USING REFRIGERANT-22
70	121.4
75	132.2
80	143.6
85	155.7
90	168.4
95	181.8
100	195.9
105	210.8
110	226.4
115	242.7
120	259.9
125	277.9
130	296.8
135	316.6
140	337.2
145	358.9
150	381.5

Table 9 - Maximum Allowable Amps

		Allowable**	Max. Allo	wable Amps
Condensing	Electrical	Voltage	Matched	Oversized*
Unit	Characteristics	Range	Evap.	Evap.
BTA120D300	208-230/60/3	187-253	24	Ξ
BTA120D400	460/60/3	416-506	11	
BTA120DW00	575/60/3	520-635	9	
BTA150D300	208-230/60/3	187-253	Ξ	30
BTA150D400	460/60/3	416-506		13
BTA150DW00	575/60/3	520-635		11
BTA180D300	208-230/60/3	187-253	31	36
BTA180D400	460/60/3	416-506	14	16
BTA180DW00	575/60/3	520-635	11	13
BTA180F300	208-230/60/3	187-253	66	67
BTA180F400	460/60/3	416-506	33	34
BTA180FW00	575/60/3	520-635	27	27

^{*}Evaporator one size larger than condensing unit

After completing the checks listed above, inspect the system for other obvious causes of trouble such as broken fan belts, a clogged condenser coil, or restricted air ducts. If everything appears to be in order, but the unit still fails to operate properly, refer to the appropriate section of the Troubleshooting Chart.

NOTE: The Troubleshooting Chart which follows is provided solely as a guide for determining the cause of mechanical failure or malfunction. When mechanical problems do occur, Trane recommends that trained service personnel be contacted to help ensure proper diagnosis and repair of the unit.

WARNING: OPEN THE UNIT DISCONNECT SWITCH AND LOCK IT IN THAT POSITION TO PREVENT ACCIDENTAL START-UP. NEVER OPEN AN ACCESS PANEL TO INSPECT OR SERVICE THE UNIT WITHOUT FIRST OPENING THE DISCONNECT SWITCH. FAILURE TO DO SO MAY RESULT IN INJURY OR DEATH FROM ELECTRICAL SHOCK OR CONTACT WITH MOVING PARTS.

^{**}Allowable voltage range at the unit terminal block

TROUBLESHOOTING CHART


SYMPTOM	PROBABLE CAUSE	RECOMMENDED ACTION
Compressor does not start, and does not hum. Condenser fans do not operate.	No power to unit.	Check for the following:
		a. Disconnect switch open.
		b. Fuses blown.
	2. No call for cooling.	2. Check for the following:
		a. Defective thermostat.
		b. Broken or improper control wiring
		c. Blown control power fuse.
	Anti-recycle timer has not timed out (if installed).	Wait at least five minutes for the ant recycle timer to time out.
	Compressor motor protection module cut out.	 Check motor windings for open circuit after allowing cool-down time Refer to Symptom F, "Compressor motor protection module cut out".
	5. Unit locked out by reset relay.	5. Check for the following:
		 Excessive discharge pressure. Refer to Symptom L, "Discharge pressure too high".
	그 과장이 가장 있는 사람들이	b. Defective high pressure control.
		 c. Low suction pressure. Refer to Symptom I, "Suction pressure too low".
		d. Defective low pressure control.
		e. Defective reset relay contacts.
AA. Compressor does not start, and does not hum. Condenser fans operate.	Compressor contactor will not close.	Check for the following:
		a. Defective compressor contactor.
		b. Improper wiring.
	2. Defective compressor.	2. Replace faulty compressor.

SYMPTOM	PROBABLE CAUSE	RECOMMENDED ACTION
B. Compressor hums, but will not start.	Low voltage at the compressor.	Check for the following:
		a. A single blown fuse.
	Marian Company and Superior	b. Low line voltage.
	一 自己 医多种神经中央内侧	c. Defective compressor contactor.
		d. Loose wiring connections.
	2. Defective compressor.	2. Check for the following:
		a. Open motor winding.
		b. Excessive amp draw on all phases.
C. Compressor fails to switch to high speed.	No call for second stage of cooling.	Check for the following:
	La company of the second	a. Setpoint too low.
		b. Defective thermostat.
		c. Broken or improper control wiring
	Compressor contactor will not close.	2. Same as AA-1.
	Defective compressor.	3. Same as AA-2.
D. Compressor short cycles.	Intermittent contact in control circuit.	Check for the following:
		a. Defective relay contacts.
		b. Loose wiring connections.
	Poor thermostat placement.	 Refer to "Thermostat Installation" in the ELECTRICAL WIRING section of this manual.
	3. Defective anti-recycle timer.	Replace compressor motor protection module.

SYMPTOM	PROBABLE CAUSE	RECOMMENDED ACTION
E. Compressor runs continuously.	Unit undersized for load (cannot maintain space temperature).	Check for cause of excessive load.
	Compressor fails to switch to high speed.	2. Refer to Symptom C.
	Thermostat setpoint too low.	3. Readjust thermostat.
	Defective thermostat or control wiring, (conditioned space too cold).	 Replace thermostat. Replace or repair control wiring.
	Welded contacts on compressor contactor.	5. Repair or replace contactor.
	Leaky valves in compressor (indicated by operation at abnormally low discharge and high suction pressures).	Replace compressor.
	 Shortage of refrigerant (indicated by reduced capacity coupled with high superheat, low subcooling, and low suction pressure). 	 Find and repair refrigerant leak. Recharge system.
F. Compressor motor protection module cut out.	Excessive load on evaporator (indicated by high supply air temperature).	Check for the following: a. Excessive airflow. b. High return air temperature.
	Lack of motor cooling (indicated by excessive superheat).	Check for the following: a. Improper expansion valve setting
		b. Faulty expansion valve.
		c. Restriction in liquid line.
	Improper voltage at compressor.	3. Check for the following:
		a. Low or unbalanced line voltage.b. Loose power wiring.c. Defective compressor contactor.
	Internal parts of compressor damaged.	4. Replace compressor.
G. Compressor is noisy.	Internal parts of compressor damaged or broken (compressor knocks).	Replace compressor.
	Liquid floodback (indicated by abnormally cold suction line).	2. Check and adjust superheat.
	Liquid refrigerant in the compressor at start-up (indicated by an abnormally cold compressor shell).	3. Replace crankcase heater.

SYMPTOM	PROBABLE CAUSE	RECOMMENDED ACTION
H. System short of capacity.	Low refrigerant charge (indicated by low subcooling and high superheat).	1. Add refrigerant.
	Clogged filter drier (indicated by temperature change in refrigerant line through drier).	2. Replace filter drier or core of drier
	Incorrect thermostatic expansion valve setting.	3. Readjust expansion valve.
	Expansion valve stuck or obstructed (indicated by high superheat and high space temperature).	4. Repair or replace expansion valve
	5. Low evaporator airflow.	5. Check filters. Adjust airflow.
	Noncondensibles in system.	6. Evacuate and recharge system.
	7. Leaky valves in compressor (indicated by operation at abnormally low discharge and high suction pressures).	7. Replace compressor.
I. Suction pressure too low.	Shortage of refrigerant (indicated by high superheat and low subcooling).	Find and repair refrigerant leak. Recharge system.
	Thermostat set too low (indicated by low discharge pressure and low space temperature).	2. Readjust thermostat.
	3. Low airflow.	Check for clogged filters, incorrect fan speed, or high duct static pressure.
	Clogged filter drier.	Check for frosting on filter drier. Replace if necessary.
	Expansion valve power assembly has lost charge.	Repair or replace expansion valve power head assembly.
	Obstructed expansion valve (indicated by high superheat).	6. Clean or replace valve.
J. Suction pressure too high.	Excessive cooling load (indicated by high supply air temperatures).	See Symptom E, "Compressor runs continuously".
	Overfeeding of expansion valve (indicated by abnormally low superheat and liquid flooding to compressor).	Adjust superheat setting and check to see that remote bulb is properly attached to suction line.
	 Suction valves broken in open position (indicated by noisy compressor). 	3. Replace compressor.
	Compressor on low speed.	Refer to Symptom C.

SYMPTOM	PROBABLE CAUSE	RECOMMENDED ACTION
K. Discharge pressure too low.	Shortage of refrigerant (indicated by low subcooling and high superheat plus bubbles in sight glass).	Repair leak and recharge system.
	 Broken or leaky compressor discharge valves (indicated by suction and discharge pressures that equalize rapidly after shutdown). 	2. Replace compressor.
	 Condenser fan control stuck in closed position (contacts closed when temperature is below 60 F). 	3. Replace defective control.
	Unit running below minimum operating ambient.	 Provide adequate heat pressure controls or a unit ambient lockout switch.
	 Low ambient damper stuck open (indicated by low discharge pressure). 	5. Repair or replace damper operator
L. Discharge pressure too high.	Too little or too warm condenser air; restricted air flow.	Clean coil. Check fan and motors fo proper operation.
	Air or noncondensible gas in system (indicated by exceptionally hot condenser and excessive discharge pressure).	2. Evacuate and recharge system.
	Overcharge of refrigerant (indicated by high subcooling, low superheat, and high suction pressure).	3. Remove excess refrigerant.
	Excessive system load.	4. Reduce load.
	Defective condenser fan or fan control (indicated by one fan off and high condenser pressure).	5. Repair or replace fan or control.
	Defective or inoperative low ambient dampers.	6. Repair or replace defective parts.



ВТА-М-3



BIND AS-202 dAS-236 SERVICE FACTS

Since The Trane Company has a policy of continuous product improvement, it reserves the right to change specifications and design without notice. The installation and servicing of the equipment referred to in this booklet should be done by qualified, experienced technicians.

Split System Condensing Unit

Library	Service Literature
Product Section	Unitary
Product	Split System
Model	BTA
Literature Type	Service Facts
Sequence	26A
Date	December 1986
File No.	SV-UN-S/S-BTA-SF-26A 12/86
Supersedes	

Model BTA180D300AB

IMPORTANT - This document is customer property and is to remain with this unit. Please return to service information pack upon completion of work.

SAFETY NOTICE

THIS INFORMATION IS INTENDED FOR USE BY INDIVI-DUALS POSSESSING ADEQUATE BACKGROUNDS OF ELEC-TRICAL AND MECHANICAL EXPERIENCE, ANY ATTEMPT TO REPAIR A CENTRAL AIR CONDITIONING PRODUCT MAY RESULT IN PERSONAL INJURY AND/OR PROPERTY DAMAGE. THE MANUFACTURER OR SELLER CANNOT BE RESPONSIBLE FOR THE INTERPRETATION OF THIS INFOR-MATION, NOR CAN IT ASSUME ANY LIABILITY IN CONNEC-TION WITH ITS USE.

RECONNECT ALL GROUNDING DEVICES

ALL PARTS OF THIS PRODUCT CAPABLE OF CONDUCT-ING ELECTRICAL CURRENT ARE GROUNDED. IF GROUNDING WIRES, SCREWS, STRAPS, CLIPS, NUTS OR WASHERS USED TO COMPLETE A PATH TO GROUND ARE REMOVED FOR SERVICE, THEY MUST BE RETURNED TO THEIR ORIGINAL POSITION AND PROPERLY FASTENED.

DISCONNECT POWER BEFORE SERVICING

INDOOR THERMOSTAT

Thermostat	System Switch	Fan Switch	Cool Steps	Heat Steps
BAYSTAT010*	Auto	Auto	2	2
BAYSTAT011	Auto	N.A.	2	2
BAYSTAT012	Manual	Auto	2	1
BAYSTAT013	Manual	Auto	2	2
BAYSTAT015	Auto	Auto	2	None

^{*}BAYRLAY001 must be used in conjunction with this thermostat.

Night Setback: BAYSTAT003 Coil Guard: BAYGARD004 Isolators: BAYISLT001

BAYISLT002

Low Ambient Damper: BAYLOAM001A



SERVICE PARTS

COMPONENT	QTY	DESCRIPTION	DPG CAT.#	CSG PART #
Capacitors (CAP)	3	5.0 MFD, 440V	WW20X0108	
Compressors (COMP)	2	208-230/60/3, FLA 27.1, Trane CRHH-075J	WW77X0750	0
Contactors (compressor) (CC)	2	Type 3PST, Contacts: Ind. FLA 40, Res. Amps 50, LRA @ 240 = 240, LRA @ 480 = 200, Coil: 24V, Inrush V.A. 50, Sealed V.A. 6.5	WW30X116	#CTR-522
Drier	2	Liquid Line w/Sweat Fittings, 16 c.u. in., ½" x ½"	WW22X0096	DHY-152
Fan	3	3 Blade, 20" Dia., 1/2" Dia. Bore, CW	WW73X0077	FAN-661
Fuse (control) (F7)	2	Dual Element, 3 Amps, 300V	WG23X0070	FUS-200
Fuse (F5,F6) (outdoor fan)	2	Dual Element, 30 amps, 300V	WW23X0212	FUS-92
Condenser Motor (ODFM)	3	208/230V, 60 Hz., 1 Ph., Dripproof Shell, CCW, 1625 Rpm, ½ H.P., 1-speed, FLA 4.1, LRA 9.5, type PSC	WW94X620	##MOT-2360
Relay (reset) (RR)	2	Type SPDT, Contact Rating: Pilot Duty, Coil Voltage: 24 V.A.C.	WW24X0171	RLY-657
Slinger	3	½" Dia. Bore	WW72X0048	SLG-31
Control Switch High Pressure (HPC)	2	Cut-out Pressure: Opens @ 425 ± 20 PSIG, Resets @ 325 ± 20 PSIG	WW26X0068	CNT-510
Control Switch Low Pressure (LPC)	2	Cut-out Pressure: Opens @ 20 ± 4 PSIG, Resets @ 50 ± 5 PSIG	WW26X0095	CNT-542
Condenser Fan Limit Control (FLT)	1	Type SPST, Switch Opens @ 55 ± 3 F. Closes @ 65 ± 3 F, Rating @ 240 V = 10 Amps	WW28X238	CNT-959
Condenser Fan Limit Control (FLT)	1	Type SPST, Switch Opens @ 65 ± 3 F. Closes @ 75 ± 3 F, Rating @ 240 V = 10 Amps	WW28X0250	THT-500
Time Delay Relay (LATD)	2	Time Delay 240 Sec., Input Voltage 24V, Output Rating 1 Amp.	WW24X0116	RLY-858
Fransformer (T)	1	Primary 208/240V, Secondary 24V, Class II, Rating 60 V.A., Primary 60 Hz.	WW32X0066	TRR-398
Crankcase Heater CCH)	. 1	230V, 60W	WW08X0088	HTR-1225
SERVICE REPLACE	MENT	PARTS		AFFERTS
Orier, Liquid		Liquid line w/sweat fittings, 16 Cu. In., ½" x ½"	WW22X096	DHY-152
Prier, Suction		Suction line w/sweat fittings, 30 Cu. In., 11/8" x 11/8"	WW22X070	DHY-180

#Standardized Part. First time replacement requires Side Switch, SWT-528, includes Holding Coil, COL-3601. ##Standardized Part. First time replacement requires Capacitor, CPT-230.

NOTE:

CSG refers to the Commercial Systems Group and DPG refers to the Dealer Product Group of The Trane Company. The CSG and DPG part numbers shown side by side above are not necessarily interchangeable for applications other than documented in this bulletin. Both are approved for service of the product listed. Inventories to support your needs are available to you through both Trane divisions.

Operation

Electrical Sequence of Operation

The typical wiring diagrams provided in Figures 1 and 2 should be used only as a reference for the following discussion. For the actual wiring of your specific unit, refer to the wiring diagram pasted on the inside of the unit's control box cover.

System operation is controlled by a two-stage thermostat, depending upon the number of compressors in the system. Closing the unit disconnect switch supplies power to the control power transformer (T1), the compressor crankcase heaters (CCH1 and CCH2), and the line side of all control contactors.


Depending on the thermostat selected, it may be possible to operate the evaporator fan independently of the compressors by placing the thermostat fan switch in the ON position. This energizes the evaporator fan contactor, starting the fan. If the thermostat has a separate fan switch, moving that switch to the AUTO position will cause the evaporator fan to start in conjunction with the compressor whenever the thermostat calls for cooling.

Dual Compressor Operation

Sensing a need for cooling, the first stage cooling contacts of the thermostat will close. This supplies power to the compressor contactor solenoid coil (CC1), provided that the high pressure control, low pressure control, and reset relay contacts are closed.

The contacts of the compressor contactor close, energizing the first stage compressor, provided that the compressor internal motor winding thermostats are closed. The compressor has only two leads broken by the compressor contactor. The third leg of the contactor energizes the condenser fan motors. The outdoor temperature determines the number of condenser fans that will start. A fan limit control (FLT) is electrically positioned between both fans #1 and #2 and fans #2 and #3. Depending on the position of these controls, one or more fans may start.

As the cooling load increases, the second stage contacts of the thermostat will close. This supplies power to the solenoid coil of the second stage compressor contactor (CC2), starting the second compressor.



2306-3563

BTA-SF-26A

Normal Operating Pressures

To determine the proper head and suction pressure refer to Figure A.

- Determine that the system CFM is the same as listed in Figure A.
- 2. Determine the evaporator entering air dry and wet bulb temperatures by using a sling psychrometer.
- Determine the outdoor ambient at temperature entering the condensor.
- 4. Find the intersection of the outdoor ambient temperature and the evaporator DB and WB temperatures. From that point, go vertically to find the correct suction pressure and horizontally to find the correct head pressure.
- Refer to the troubleshooting section of the Operation/Maintenance Guide for additional information if the head pressure is more than ±10 PSIG and the suction pressure is more than ±3 PSIG.

BTA180D / BWV180B 100% Compressor Load 6000 CFM Evap. Airflow




Figure A

PRODUCT SPECIFICATIONS BTA180D


Outdoor Unit Indoor Unit	Rated w/208-230
Ratings Cooling MBH Indoor Airflow (CFM) Power Input (KW) EER Noise Rating No.	190.0 6000 23.5 8.2 8.8
Power Conns V/Ph/Hz Min. Brch. Cir. Ampacity Br. Cir - Max. (Amps) Recommended Dual Element (Amps)	208-230/3/60 73 100 80
Compressor No. Used - No. Speeds Volts/Ph/Hz R.L. Amps L.R. Amps	Model H/ CRHH-075J-AE 2/1 208-230/3/60 27.1/76
Outdoor Fan - Type No. Used/Dia. (In.) Type Drive/No. Speeds CFM @ O.O. in W.G. No. Motors - H.P. Motor Speed Rpm Volts/Ph/Hz F.L. Amps	Propeller 3/20 Direct/1 12131 3/.5 1625 208-230/1/60 4.1
Outdoor Coil - Type Rows/F.P.I. Face Area (Sq Ft) Tube Size	Plate Fin 3/13 26.0 3/8"
Refr. Line Size Suction Liquid	1.125 3/8"
Outdoor Unit Dimen. Crated	43 x 43 x 112
Shipping Weight (Lbs)	1020
Net Weight (Lbs)	840

TROUBLESHOOTING CHART — WHAT TO CHECK

SYSTEM FAULTS	TINGE WIN	COMPA	STAN CAPACITO	of Capacita	CONTRO! STAFF RECO	LOW NO. COMING	CONTROL TAGE WITTS	CONTRACTOR	TOM TOTOR CO	STUVENTAGE	REFECIENT COMPRESS	RESEARING COMPRESSION	CHOCHAN DERCHA	ENCESSIVE CHARGE	WANT THE PARTY OF	OF STRUCTED PRISABLE	00 MM 700 MM ES	THE CHOULD	SHOW OF	BESTALTES SUPERINE	CACAL O PART	BESTRE IV	
REFRIGERANT CIRCUIT	1	,	'		,			'			'	1	'										_
Liquid Pressure Too High															P		s	P	s				
Liquid Pressure Too Low													S	Р						S	s		1
Suction Pressure Too High													S		Р	Р			-0	S	P		r
Suction Pressure Too Low		44											,	S			1				S	P	
Liquid Refrig. Floodback TXV System																				S	S		r
Liquid Refrig. Floodback Cápillary Tube System	8									3					Р			S	S	3	S	P	
I.D. Coil Frosting			es.					1			243		100	Р			.cm			1	18	P	-
Compressor Runs Inadequate or No Cooling					-							19	S	P		P	S		7	8	S	Р	0,
ELECTRICAL		377																					
Compressor & O.D. Fan Do Not Start	P	P			4		GR.	S	P	Р	P												
Compressor Will Not Start But O.D. Fan Runs		Р	S	Р	Р	Р						S											
O.D. Fan Won't Start		Р		Р							-	Y		74					70.0				
Compressor Hums But Won't Start		Р		Р	Р	Р	S					S							C.E.	100	802	1	
Compressor Cycles on IOL		Р	S	P	P	P	S		-10-1			Р	S	Р	S	S		S			s		S
I.D. Blower Won't Start	Р	S						S	Р		Р			4	100							-	-

P Primary Causes S Secondary Causes

REFRIGERANT CIRCUIT — BTA180D300A




NOTE: ONLY ONE CIRCUIT SHOWN.

The Trane Company Light Commercial Group Guthrie Highway Clarksville, TN 37040 BTA-SF-26A

AN AMERICAN— STANDARD COMPANY

TAB PLACEMENT HERE

DESCRIPTION:



- ☐ Tab page did not contain hand written information
- Tab page contained hand written information
 *Scanned as next image

Confidential Records Management, Inc. New Bern, NC 1-888-622-4425 9/08




BLDG# AS-502 INSTALLER'S GUIDE

Cooling Unit Packed System-Downflow 7-1/2 - 10 Ton

Library Service Literature Unitary **Product Section Rooftop Air Conditioning Product** Model Literature Type Installer's Guide Sequence Date March 1986 SV-UN-RT-BTC-IN-3A 3/86 File No. BTC-IN-3 7/85 Supersedes

Models: BTC090, 120F-G BTC090, 120F-H



Since The Trane Company has a policy of continuous product improvement, it reserves the right to change specifications and design without notice. The installation and servicing of the equipment referred to in this booklet should be done by qualified, experienced technicians.

18-AB60D4 Dwg. No. A723591 P01

ALL phases of this installation must comply with NATIONAL, STATE & LOCAL CODES.

This booklet of instructions covers the BTC090 & 120F Single Package Cooling Units. The format of this booklet is designed to give the installer an easy reference to all phases of an installation. Whether the installation is done by one installer, or combination of tradesmen, the order of the instruction should be followed.

These instructions do not purport to cover all possible contingencies to be met in connection with installation. Should further information be desired or should particular problems arise which are not covered sufficiently for the purchaser's purposes, the matter should be referred to The Trane Company.

NOTE: Do not destroy or mutilate this booklet on completion of your phase of installation. Leave booklet at unit (weather protected) for remaining installation.


A. INSPECTION

1. Check for damage after unit is unloaded. Report promptly, to the carrier, any damage found to unit. Do not drop unit.

CAUTION: A set of "spreader bars" is required when hoisting the unit (prevents damage to sides and top). A 4" standard width steel channel is recommended.

- 2. Check unit nameplate to determine if unit is correct for application intended. Power supply must be adequate for the unit and all accessories such as heaters and damper motor, if installed.
- 3. Check to be sure the refrigerant charge has been retained during shipment. Access to 1/4" flare pressure taps may be gained by removing compressor compartment access panel.

B. LOCATIONS AND RECOMMENDATIONS



TYPICAL ROOFTOP INSTALLATION

The Roof Mounting Curb is (factory assembled BAYCURB015) (field assembled BAYCURB014), or a field fabricated curb must be assembled and in place before unit is hoisted to the roof.

Roof Mounting Curb (frame) must be installed on a flat, level section of the roof (max. of 1/4" per foot pitch), providing a level mounting surface for the unit. In addition, provide sufficient height above the roof to prevent water from entering unit.

1. Be sure the mounting curb spans structural members (trusses) of the roof, thereby providing sufficient support for weight of the unit, curb and duct(s) plus any accessories (factory or field installed). See illustrations on pages 2 and 3.

NOTE: If any internal accessories are to be added to the unit, it should be done at the shop if at all practical.


2. The space above the outdoor air discharge section of unit should be unrestricted, see outline drawing for clearance.

B. LOCATIONS AND RECOMMENDATIONS (Cont.)

- 3. There must be at least 36" service clearance on sides of the unit and at least 42" from outdoor coil side to walls or other restrictions to airflow.
- a. Unit should be positioned so Roof-Run-Off water does not pour directly on unit.
- 4. For "Roof Top Application," unit must be elevated above roof with a mounting Curb or Frame.
- 5. Exhaust vents or other sources of contaminated air should not be near unit air inlet, if outside air is to be introduced as make-up air or the economizer ventilation feature is to be used.
- 6. Check the handling facilities to insure the safety of personnel and the unit(s).
- 7. CAUTION MUST BE TAKEN AT ALL TIMES TO AVOID PERSONAL INJURIES AND/OR DAMAGE TO EQUIPMENT.

BTC090, 120F OUTLINE DRAWING

(All dimensions are in inches)





C. UNIT MOUNTING

IMPORTANT: The insulated deck for use with Roof Mounting Curb BAYCURB015 or BAYCURB014 is secured, at the factory, to the bottom of the unit, under the outdoor coil section and requires NO field assembly. See Installation Instruction shipped with Curb for proper installation of roof-top accesso-

- 1. When the Curb and air ducts have been properly installed, the unit is ready to be hoisted to the roof and set into position. (CAUTION: "Spreader Bars" must be used when hoisting unit.)
- 2. Apply a bead of architectural grade caulking (field supplied) at corners of curb to seal all voids, preventing water leaks.

3. Place 1-1/2" x 1/2" P.V.C. rubber gasket (supplied with unit) on mounting curb as illustrated and in the Installation Instruction shipped with curb for correct placement of P.V.C. gasket on mounting curb.





C. UNIT MOUNTING (Cont.)

IMPORTANT: The unit must be **lowered** into position. The P.V.C. rubber gasket on the curb flange permits the unit to be repositioned if required, without destroying the P.V.C. rubber gasket affixed to mounting curb.

4. PLACING UNIT ON MOUNTING CURB — There is a locating angle (bracket) on the bottom of the unit, located across the compressor end. This locating angle (bracket) is formed to fit the mounting curb at the compressor end. See illustration "A" on page 4.

With the unit side rails astraddle mounting curb, and locating angle (bracket) in contact with the end of the curb, and by maintaining contact at this point as unit is lowered, the unit will align itself on the curb.

- 5. The unit side rails at the indoor air end of the unit will be straddling the roof mounting curb an equal amount on each side of the curb.
- 6. Insert the four(4) $1/4-20 \times 1-1/2''$ long hold-down screws shipped with curb. See illustration "A" on page 4.

IMPORTANT: Remove and discard the two (2) Baffles from rear of unit, at the fork lift channel area.


7. After unit has been set in place and secured, proceed to Electrical Connections section of instructions.

D. ELECTRICAL CONNECTIONS

- 1. To determine the electrical power requirements of the unit, refer to the nameplate of the unit. The electrical power available must agree with that listed on the nameplate.
- 2. Provide an approved weatherproof disconnect either on side of unit or within close proximity.
- 3. The power supply lines must be run in weather-tight conduit to the disconnect, and into unit control box or Single Power Entry box. Provide strain relief for all conduit with suitable connectors.
- 4. Provide flexible conduit supports whenever vibration transmission may cause a noise problem within the building structure.
- 5. Be sure all connections are made tight and no naked wires are exposed.
- 6. Ground the unit internally as provided, see wiring diagram for location.
- 7. All electrical accessories must be installed and wired according to the instructions packaged with that accessory.
- 8. Factory option on (BTC090, 120F) downflow models with factory installed heaters (special order) "single circuit power entry." See illustration.

The above electrical installation instructions items 1 thru 6 should be followed when making electrical connection to power entry box terminal block on units with Single Branch Circuit Power Entry.

- 9. Use color coded, low voltage, multi-wire cable to simplify circuiting between unit and room thermostat.
- 10. Refer to the Field Wiring Diagrams on pages 9 and 10 for electrically connecting unit and room thermostat together.
- 11. After all electrical wiring is complete, SET THE THER-MOSTAT SYSTEM SWITCH IN THE OFF POSITION SO COMPRESSOR WILL NOT RUN, and apply power by closing



From Dwg. 21C716265 Rev. 0

the system main disconnect switch. This will activate the compressor sump heat. Do not change the Thermostat System Switch until power has been applied long enough to evaporate any liquid R-22 in the compressor oil (30 minutes for each pound of R-22 in the system as shown on the nameplate). Following this procedure will prevent compressor damage at the initial start-up.


Record the "POWER APPLIED DATA" on the designated lines below.

Ву	(Electric			104	
	PM				
Time	AM Date	# 7			

E. CONDENSATE DRAIN PIPING

Do not use reducing fittings in the drain lines. The condensate drain line must be:

- 1. Made of 3/4" pipe size.
- 2. Pitched -1/4" per foot to provide free drainage to convenient drain system.
- 3. Trapped a pipe tee and clean out plug should be installed.
- Must not be connected to closed drain system.



F. DRIVE BELT ADJUSTMENT

DANGER: For personal safety, fan and motor must not be rotating or energized.

- 1. Remove panels and place belt on motor and blower pulleys, (Unit shipped with belt attached to blower pulley only.)
- 2. Loosen motor hinge and adjustment bolt and lift motor pulley into belt. (See Figure 3.)
- 3. Adjust belt tension to a 1" depression midway between pulleys using one finger (about 10 lbs. force).
- 4. Tighten hinge bolt and adjusting bolt.


IF NECESSARY TO CHANGE AIRFLOW:

NOTE: Caution, consult airflow performance data in Data/ Submittal to prevent overloading indoor blower motor.

- 1. Remove belt.
- 2. Loosen set screw that secures adjustable section of pulley.
- 3. Turn adjustable section of pulley until it meets stationary section.
- 4. Turn adjustable section of pulley in a reverse direction until set screw is in line with nearest flat. This position is zero (0) turns open.
- 5. Adjust pulley section to the required turns open to provide required airflow. Tighten set screw to secure adjustable section.
- 6. Reinstall belt.
- 7. Check that fan and motor pulleys are properly aligned and check belt tension.

AIRFLOW TABLE

Unit Model No.	BTC090F	BTC120F				
Min. Airflow CFM (Electric Heat)	3000	4000				
Max. Airflow CFM (Cooling)	3375	4500				



INDOOR BLOWER AND DRIVE MOTOR

FIGURE 3

G. FILTER INSTALLATION

Shipped with each unit are four (4) 1" thick filters, located in the Filter Racks. Access to the filters is made by removing the filter access panel (see Figure 1) and sliding filter from rack.

NOTE: Units equipped with economizer damper section or 0-100% Fresh Air Damper section must be equipped with permanent cleanable filters.

- 1. ACCESS Place the System Switch of the Room Thermostat or Disconnect Switch in the "OFF" position and remove the filter section access panel.
- 2. Check that filters are clean.

NOTE: Do not operate unit without these filters in place.


H. AIR DUCTS

All conditioned air duct work must be insulated to minimize heating and cooling duct losses. Use a minimum of 2" of insulation with a vapor barrier. The outside duct work must be weatherproofed between the unit and the building and should be insulated with a minimum of 2" of insulating material.

I. CHECKOUT AND OPERATIONAL PROCEDURE

Final phases of this installation are the unit Operational and Checkout Procedures which are found on pages 11 and 12 of this instruction.

ENTHALPY CONTROL SELECTION CHART




ECONOMIZER CONTROL CHECK-OUT

- 1. Set minimum position potentiometer (if used) to allow outdoor air damper to go to FULLY closed position. Potentiometer located on top of damper drive motor. (OPEN & & VCLOSE).
- 2. The following check-out steps for the economizer can be performed only if the outdoor air conditions are to the left of shaded area on psychrometric chart. See Chart.
- 3. Set indoor thermostat to satisfied position and apply power to unit.
- 4. Set minimum position potentiometer (MPP) to full open position. Outdoor air damper should open approximately half way.
- 5. Set MPP to close position. Outdoor air damper should close.
- 6. Set indoor thermostat to call for cooling.

CAUTION: Compressor will start. Avoid rapid cycling of compressor during check-out of economizer dampers.

- 7. Set mixed air control to 10° below outdoor temperature (factory set at 55°F.) and turn the enthalpy control knob to the "A" setting (full clockwise). If the outdoor temperature is less than 75°, the compressor will stop and outdoor damper will move to full open. If outdoor temperature is too high for enthalpy control to switch, the wires to terminals 1 and 3 on the control can be switched to verify proper operation. See illustration on page 8 for location of enthalpy control knob.
- 8. Set indoor thermostat to satisfied position, stopping indoor blower. Fresh air damper will close and return air damper will open.

ECONOMIZER CONTROL SELECTION & PSYCHROMETRIC CHART



ECONOMIZER CONTROL CHECK-OUT (Cont.)

- 9. Set indoor thermostat to call for cooling. Allow time for fresh air damper to open completely. Turn enthalpy control knob counter-clockwise past "D" position. Fresh air damper will close completely.
- 10. Determine the supply air temperature required for your application and set the "mixed air control" to that tem-

perature. Normally it will be 55°F. to 65°F. (factory set at 55°F.). Set the enthalpy control per illustration below. If maximum combination of relative humidity and temperature is not known, set enthalpy control to the "B" setting.


11. Without a call for cooling, ADJUST the minimum position potentiometer, if used, to provide the minimum fresh air desired (fresh air ventilation).

ECONOMIZER/DAMPER SYSTEM

The economizer accessory is factory assembled and is composed of the following items: 0-100% fresh air damper, damper drive motor, pre-set damper linkage, enthalpy control, high and low voltage polarized plug for electrical connections. The barometric relief damper is a separate accessory.


The system is completely automatic. When outdoor air temperature is low enough, the economizer can be utilized for free cooling by its switching off the compressor and bringing in outdoor air on a call for cooling from the room thermostat.

The enthalpy control is a humidity biased, outdoor dry bulb temperature device to provide good comfort control to conditioned space. The damper motor operates on 200/230/460 volt power source. The polarized plug will match the voltage of the unit to the correct voltage tap in the damper motor. See illustration below which depicts airflow during the free cooling cycle.




From Dwg. 21C716385 Rev. 1

FIELD WIRING DIAGRAM FOR BTC090,120F WITH SUPPLEMENTARY HEATERS AND MANUAL THERMOSTAT



From Dwg. 21C756592 Rev. 0

FIELD WIRING DIAGRAM FOR BTC090,120F WITH SUPPLEMENTARY HEATERS AND AUTOMATIC THERMOSTAT



HEATER THERMOSTAT® HEATER AMPS/LINE® KW HA-2 280/240V 480V 10 .36 20.8/24 12 20 36 41.6/48 24 .36 .36 62.4/72 36 40 .36 48 50 12 .12 104/120 60 72 125/144

NOTES:

- 1. SEE HEATER WIRING DIAGRAM ON HEATER.
- 2. SEE HEATER INSTALLED NAMEPLATE ON UNIT.
- 3. HA SETTINGS NOT REQUIRED WITH HEAT PUMPS.

From Dwg. 21A724003 Rev. 0

NOTES:

- POWER WIRING AND GROUNDING OF EQUIPMENT MUST COMPLY WITH LOCAL CODES.
- 2. BE SURE POWER SUPPLIES AGREE WITH EQUIPMENT NAMEPLATES.
- 3. SEE PRODUCT MANUAL FOR SELECTION AND INSTALLATION OF SUPPLEMENTARY HEATERS.
- 4. LOW VOLTAGE (24V) FIELD WIRING MUST BE 18GA, AWG MINIMUM.
- 5. WIRING LEGEND:

LOW VOLTAGE - FIELD

LINE VOLTAGE - FIELD


LINE VOLTAGE - FIELD

LINE VOLTAGE - FACTORY

- IF OUTDOOR THERMOSTATS ARE USED, CONNECT IN ACCORDANCE WITH INSTRUCTIONS SUPPLIED ON HEATER WIRING DIAGRAM.
- 7. THIS POLARIZED PLUG HAVING BROWN AND WHITE LEADS IS ONLY ON HEATERS HAVING SUFFIX "A" OR "B" AFTER MODEL NO. LEAVE JUMPER BETWEEN TERMINALS 1 AND 3 FOR THIS APPLICATION.

From Dwg. 21C756626 Rev. 0

FIELD WIRING DIAGRAM FOR BTC090,120F WITH SINGLE BRANCH CIRCUIT POWER ENTRY AND FACTORY INSTALLED ELECTRIC HEATERS



ROOM THERMOSTAT BAY28XI83 WITH SUB BASE BAY28XI84 SET HA PER DWG. A724005

NOTES:

- 1. POWER WIRING AND GROUNDING OF EQUIPMENT MUST COMPLY WITH LOCAL CODES. SEE DWG. 21A724005 AND EQUIPMENT NAMEPLATE FOR MIN. CIRCUIT AMPACITY AND MAX. OVERCURRENT DEVICE VALUES.
- 2. BE SURE POWER SUPPLIES AGREE WITH EQUIPMENT NAMEPLATES.
- 3. LOW VOLTAGE (24V.) FIELD WIRING MUST BE 18 GA. MINIMUM.
- 4. WIRING LEGEND:
- LOW VOLTAGE FIELD ---- LOW VOLTAGE — FACTORY
 LINE VOLTAGE — FIELD
 LINE VOLTAGE — FACTORY

From Dwg. 21C756638 Rev. 0

UNIT MODEL	① HE	ATERS	® MIN. CIR.	® MAX. (RECM.)	
OHIT MODEL	KW	VOLTS	AMPACITY	FUSE SIZE	
BTC090C300	10	240	45	60	
BTC090F300	20	240	64	70	
	30	240	94	100	
	40	240	124	125	
	50	240	154	175	
r variable	60	240	184	200	
BTC090C3A0	10	240	46	60	
BTC090F3A0	20	240	67	70	
	30	240	97	100	
	40	240	127	150	
	50	240	157	175	
	60	240	187	200	
BTC090C400	10	480	22	30	
BTC090F400	20	480	32	35	
	30	480	47	50	
	40	480	62	70	
	50	480	77	80	
	60	480	92	100	
BTC090C4A0	10	480	23	30	
BTC090F4A0	20	480	33	35	
	30	480	48	50	
	40	480	63	70	
	50	480	78	80	
	60	480	93	100	

UNIT MODEL	① HE	ATERS	O MIN. CIR.	1 MAX. (RECM.)
	KW	VOLTS	AMPACITY	FUSE SIZE
BTC120C300	10	240	60	80
BTC120F300	20	240	66	80
ALC: No.	30	240	97	100
	40	240	127	150
	50	240	157	175
	60	240	187	200
BTC120C3A0	10	240	60	80
BTC120F3A0	20	240	67	80
	30	240	99	100
	40	240	129	150
	50	240	159	175
	60	240	189	200
BTC120C400	10	480	26	35
BTC120F400	20	480	33	40
	30	480	48	50
	40	480	63	70
	50	480	78	80
	60	480	93	100
BTC120C4A0	10	480	30	40
BTC120F4A0	20	480	34	40
	30	480	49	50
	40	480	64	70
	50	480	79	80
	60	480	94	100

^{1.} SEE HEATER NAMEPLATE AND HEATER INSTALLED NAMEPLATE FOR KW/VOLTS.

CHECKOUT PROCEDURE WITH MAIN POWER DISCONNECTS CLOSED (ON)

			Indoo	or Therr	nostat		Component Operation						
		Switch Setting				Indoor	Outdoor	Compressor		Comp.	Electric	Econi-	
Step		System Switch ①		Fan Switch		Blower	Fan	"A"	"B"	Sump	Heaters	mizer	
No.	To Check	Off	Cool	Heat	Auto	On	Runs	Runs	Runs	Runs	Heater	(Warm Supply Air)	
1	Sump Heat	X			X						X	W-10.6.5	
2	Indoor Fan Operation	X			100	Х	X	and the second	And the part		X		
3	Cooling (1st Stage)		Х		Х		X	Х	•		X		•
4	Cooling (2nd Stage)		X3	10	Х		X	Х	•	0	X		•
5	Check Performance & Charge		Х	*	х		X	х	X	х	X		
	Ciral go	-	4		USE C	HARTS	ATTACHE	D TO O.D. U	NIT-				
6	Heating @(1st Stage)			X	X		X	G 51			X	X	7
7	Heating (3(2nd Stage)			Х	Х	7,00	X	1.35			X	X	
8	Inform owner on how to Set thermostat to desired						t.						

- ① Also Set thermostat dial to call for cooling or heating as necessary.
- ① Check, only, if an Accessory Electric Heater has been installed.
- 3 Turn Temperature Selector lever down until 2nd compressor starts.
- ① If the unit is equipped with Economizer system either the compressor or the Economizer will operate. See page 10
- 3 Not applicable if 20 KW (or less) Accessory Electric Heater has been installed.

CHECKOUT PROCEDURE

After installation has been completed, it is recommended that the entire system be checked against the following list:	
1. Check for secure anchoring if it is Roof Top or Ground Level application	
properly grounded	
in accordance with local building codes	
instructions with thermostat	
in instructions)	
FINAL AND OPERATIONAL CHECK	
 IMPORTANT: To prevent compressor damage which may result from the presence of LIQUID refrigerant in the crankcase, these procedures should be followed at initial Start-Up and at any time the power has been off for 12 hours or more. 1. Before proceeding with this "Operational Check," go to "Electrical Section" of this instruction to determine the time sump heater has been "ON," and make entry on the designated lines, in Step 2. 2. Start-Up Time A.M./P.M. Power Applied Time A.M./P.M. Time Lapse Hours Minutes. 3. If Steps 1 and 2 cannot be used, then place thermostat's system switch in the "OFF" position and apply power by closing system disconnect switch. This energizes compressor heat and evaporates the liquid in the crankcase. TO EVAPORATE LIQUID ALLOW AT LEAST ONE-HALF HOUR PER POUND (R-22), AS SHOWN ON UNIT NAMEPLATE. 4. Except as required for safety while servicing: DO NOT OPEN SYSTEM DISCONNECT SWITCH. 5. After completing above procedures, turn to page 11 for Operational checkout of system(s). 	
SUPPLEMENTARY HEATERS CHECKOUT PROCEDURES, IF INSTALLED	
IS HEATER CIRCUITED ACCORDING TO "NEC" & LOCAL CODES?	
1. Be sure the disconnect switch is "OFF" and safety label (if any) is attached	
4 Check control box panel —— in place and secured	
NOTE: OPERATION OF HEATERS MUST BE CHECKED DURING THE OPERATION CHECK OF THE TOTAL SYSTEM.	




BLDG# AS-502 OPERATION/MAINTENANCE GUIDE

Central Cooling Package System 7½ to 10 Ton

Models: BTC090,120C or F-G BTC090,120C or F-H

Library	Service Literature
Product Section	Unitary
Product	Rooftop Air Conditioning
Model	BTC
Literature Type	Operation/Maintenance
Sequence	3A
Date	March 1986
File No.	SV-UN-RT-BTC-M-3A 3/86
Supersedes	BTC-M-3 7/85



Since The Trane Company has a policy of continuous product improvement, it reserves the right to change specifications and design without notice. The installation and servicing of the equipment referred to in this booklet should be done by qualified, experienced technicians.

A single package unit is designed primarily for cooling. Supplemental heat may be used to provide for heating loads. The sequence of operation is as follows:

COOLING

With the disconnect in the "ON" position, current is supplied to the sump heaters and control transformer. The sump heater supplies heat to the compressor to prevent liquid refrigerant from migrating to the compressor during the "OFF" cycle. The transformer steps down the voltage from 200, 230V and 460V to 24V on the low voltage control circuit.

The cooling cycle is energized on a call for cooling, the first stage mercury contact closes completing a circuit through the low voltage side of the transformer that is marked R on the schematic. With the system switch in the automatic position and the cooling contact closed, voltage is supplied to the Y terminal in the low voltage circuit and from the Y terminal to the main starter, provided the High Pressure Cutout, & the Evaporator Defrost Control contacts are closed. The circuit is completed to the other side of the transformer. When energized, the main starter will close the high voltage circuit to the outdoor fans & the compressor.

The indoor blower is picked up simultaneously through the G terminal of the thermostat, which provides a circuit through the thermostat to the fan relay closing F contacts in the blower motor circuit.

Provided all fuses are O.K. and overloads are not

tripped, the unit will operate and refrigerant will flow as a hot gas from the compressor to the outdoor coil where it is condensed into a liquid. From there it passes through a dryer to the evaporator Expansion Valve and on into the evaporator coil where it removes (absorbs) heat from the air that is being moved over the coil surface. The heated gas then returns to the compressor to repeat the cycle again.

These units have an evaporator defrost control which prevents ice build up on the indoor coil (which would reduce the capacity of the unit). This control cuts off the compressor when its temperature setting is reached and allows the indoor air to continue to pass through the coil thereby defrosting the coil. At the evaporator defrost control reset setting, the compressor will start again. This condition normally only exists at low outdoor ambients.

There is an outdoor fan thermostat in the inboard fan (A) circuit which will open if the outdoor temperature falls below its setting (50°F.), thereby stopping this fan and allowing the condensor temperature and pressure to build up to a more normal, efficient operating level. If the OD temperature increases above 60°F., the thermostat will again close and start the fan.

HEATING

Supplemental Electric Heaters may be installed as accessories for use with this unit. There are several models to choose from and the operation of the models may vary as follows: Some models operate off the heating contact of the thermostat which energizes a relay which closes the power circuit to the first bank of heaters. Subsequent banks are energized through the outdoor thermostats which have different ON temperature and separate relays.

Supplementary Heaters are installed at the outlet of the indoor blower. Depending on the size of electric heater used, they could be operated as either single or two stage heaters. A polarized plug is used to plug into the thermostat circuit; however, each bank of heaters has its own circuit fuses in the high voltage line circuit. On a call for heat, the first stage is energized through the (W1) terminal and the closing of the (TSH-1) thermostat heating contact. This circuit picks up (LA) lock-in relay, which in turn energizes both the AH and BH contactors. The wiring diagrams show an (ER) Electric Heat relay. This is only required when heaters are used on Heat Pump systems. On cooling only units it should be disregarded. Provided all limit switches are closed, the contacts of both

these contactors will close the high voltage circuit to the first two banks of heaters simultaneously; however, only the first bank of heaters will be energized. This is the first stage heating. If the room temperature should drop another degree the second stage thermostat contact (TSH-2) will close — picking up the second lock-in relay (LB) thereby energizing the second two contactors (CH) and (DH). Since the last (ODT) outdoor thermostat has been jumpered, the last bank of heaters will be energized so as to provide additional heat at ID temperatures above 45°F. As soon as the outdoor temperature drops to the settings of the ODT's still in the circuit, the other banks of heaters will be energized in turn.

It is important to note that the first and second stage lock-in relays are wired in series with the indoor fan relay contact. Therefore, if the fan relay has not been energized, the electric heaters will not function. There must be indoor airflow at all times when the electric heaters are energized. Should airflow be interrupted at any time, temperature would increase to the limit switch (TCO) or fuse setting cutting off the heaters until airflow can be restored.

FRESH AIR DAMPER DAMPER MOTOR CONTROL

To provide for fresh air and to take advantage of cool outdoor air either of two damper controls may have been added to the system along with both return air and fresh air dampers.

One of these controls consists of a damper motor which is operated by a potentiometer located on a wall in the conditioned space which is manually set at desired percent of fresh air. On still another, the control is automatic using an economizer control which operates the opening and closing of the dampers using a capillary tube thermostat which senses the temperature of the return air as it enters the cooling coil. It opens and closes the dampers to maintain a temperature setting selected on the control of the damper motor.

Both the condensing units and the Damper controls are picked up through the cooling contacts of the Thermostat; therefore, once the thermostat is satisfied, both will shut down and the dampers will return to the minimum open set position. Maximum operating economy with minimum equipment expenditure can be realized by operating the system in response to a signal from the thermostat. In heating, the economizer is automatically locked out and the dampers return to minimum air for ventilation. When the outdoor air temperature is below the changeover tem-

perature, the compressor is locked out. If the cooling contacts close, the dampers are modulated by the mixed air temperature controller. When the outdoor air temperature is above changeover temperature the outdoor air dampers are closed to their minimum position and the compressor is controlled by the thermostat.

The damper motor is proportional acting and will position the damper at any point between fully open and fully closed to the demands of the mixed air controller.

An enthalpy economizer switch is used to control the air dampers. It responds to both the dry bulb temperature and humidity, allowing the use of outdoor air at a higher temperature for free cooling when the humidity is low. It functions as the first stage of cooling. On a call for cooling and if the outdoor air is below set point of the enthalpy control, the dampers are operated by the controller and the outdoor air is allowed to enter and mix with the recirculated air. If the indoor temperature increases the second stage cooling contact will close and start the compressor. If the outdoor air enthalpy increases to the set point of the entalpy controller the dampers will return to minimum ventilation air position.

OPERATING INSTRUCTIONS

There are three basic types of thermostats used to control indoor temperature with a central air conditioner. (1) The COOLING ONLY thermostat controls the central air conditioner only. (2) COOLING ONLY with a fan system switch and (3) the HEATING/COOLING thermostat controls both the central air conditioner and heating system.

Identify your thermostat from the pictures on page

four (4). Note the location of the temperature selector dial, the ''fan switch'', the ''fan system switch'' and the ''system switch''. Also note that all thermostats have a ''temperature selector dial'', some thermostats have a ''fan switch'' and all HEAT/COOL thermostats included a ''system switch''. (All thermostats also include a thermometer to indicate room temperature.)

THERMOSTAT OPERATION

- TO SELECT COOLING Heat/Cool thermostat position "system switch" to COOL position. Cooling Only with system fan switch position switch to AUTO position. Note that on both types of thermostats when the switch is in the "OFF" position the cooling system is in-operative.
- TO SELECT THE DESIRED TEMPERATURE (all thermostats) — Simply position the temperature selector until the pointer indicates the desired temperature. If "COOLING" has been selected and the room temperature is above the temperature you have selected, your central air conditioner will begin to supply conditioned air

and will continue to do so until the selected temperature has been reached.

If "HEATING" has been selected and the room temperature is below the temperature you have selected, the heating system will operate and continue to operate until the selected temperature has been reached.

TO SELECT FAN OPERATION (thermostats with fan switch) — Position fan switch to "AUTO" for normal fan operation. With the fan switch in this position, the fan will operate as required by the cooling or heating system, automatically. Note that the fan switch has only two

THERMOSTAT OPERATION (CON'T)

positions, "ON" and "AUTO." The word "FAN" is used to identify the switch only. Best results are usually obtained with the fan switch in the "AUTO" position for both heating and cooling. However, if continuous fan operation is desired, position the fan switch to the "ON" position. (Note — thermostats which do not have the fan switch feature will operate the fan on "AUTO" only.)

System fan switch is the same as above when in "AUTO" position; for continuous fan operation set switch to "FAN" position.

After the System has been installed it is put through an "OPERATIONAL CHECK-OUT" procedure. However, there could be a significant time lapse prior to occupancy of the structure. During this time there may have been a power interruption, therefore, if the unit is not operating at the time of occupancy, read and follow instructions under COOLING; item b.

If these has been no discontinuance of power after the initial start-up, the unit will need only periodic maintenance, and manual changing of the room thermostat to "HEAT" or "COOL" as required.

When using the Automatic Thermostat, manually changing to "HEAT" or "COOL" is not required.

COOLING — The System (when in "Cooling") will begin removing heat and humidity immediately after it cycles on, but may require several hours to obtain desired conditions. In order to control both temperature and humidity, it is desirable to permit the equipment to operate automatically (controlled by thermostat).

Use exhaust fans and hoods in areas where excessive heat or humidity is generated.

CAUTION: Exhaust fans and/or heat producing equipment are normally taken into account when sizing System equipment. Any additional exhaust fans or heat producing equipment will require:

- 1. Additional cooling/heating equipment or
- Some means of controlling the loss of conditioned air from the space.

Do not block supply or return registers.

Let the thermostat control the System. The use of window shades, venetian blinds, awnings, etc. will keep out the direct rays of sunlight, and reduce the load on the unit.

To shut down the system for vacation:

- a. Position System Switch to the "OFF" position. Do not turn power off at main disconnects. The compressor utilizes crankcase heaters that operate on line voltage.
- b. If the power to the compressor has been off for more than four hours position the System Switch to the "OFF" position and do not put the system in operation until power has been restored to the compressor's (crankcase heaters) for at least 1/2 hour per pound of refrigerant in unit. (See unit nameplate.)




FIGURE 1




FIGURE 2





FIGURE 3

LOCKING COVER

The locking cover as shown below, is an optional accessory. It fits over your thermostat, and is locked with a key. It is designed to prevent any tampering or

accidental shifting of the exposed Selector Levers, Fan or System switches, once they have been properly set.



PROTECTIVE CONTROLS

NOTE: ALL OF THESE CONTROLS MAY NOT BE INSTALLED ON YOUR UNIT, CHECK ELECTRICAL SCHEMATIC

EVAPORATOR DEPROST CONTROL (EDC)

This control is located in the indoor section of the Package Unit, or in the Air Handler of Split Units. The control's sensing tube is imbedded vertically in the evaporator coil, near the center. This device will stop the compressor if the indoor coil temperature drops below its setting. The indoor air will still circulate across the coil, bringing the temperature of the coil back up to the cut-in temperature of the evaporator defrost control.

LOW PRESSURE CUT-OUT (LPCO)

This control's sensor is located in the suction (gas) line, near the compressor. This control will stop the compressor and the condenser fans if suction pressure drops below the Low Pressure Cut-Out setting. Once the suction pressure has returned to normal, the compressor and condenser fans will cycle back on.

INTERNAL PRESSURE RELIEF VALVE (IPR)

The compressor design incorporates an internal pressure relief valve. The valve operates on a pressure difference between the discharge and suction pressure to prevent compressor overloading, thereby prolonging the life of compressor.

EXTERNAL OVERLOAD PROTECTOR (XOL)

This thermal device is located in the compressor terminal box. It will shut off the compressor if the compressor current draw exceeds its setting.

INTERNAL OVERLOAD PROTECTOR (IOL)

This device is a current/thermal actuated warp switch, imbedded in the compressor motor windings. It will shut off the compressor if the temperature of the compressor motor windings exceeds its design trip temperature.

COMPRESSOR MOTOR THERMOSTAT (TM)

This device is a circuit breaker temperature switch imbedded in the compressor motor windings. It will shut off the compressor if the temperature of the compressor motor windings exceeds its design trip temperature.

NOTE: These safety devices (XOL, IOL, & TM) will put the compressor back in operation once the compressor motor heat has dropped below the trip setting; however, a check of the refrigerant and electrical systems should be made to determine the cause, and THEN COR-RECTED!!!

INSPECTIONS.

A routine of monthly and seasonal inspections should be established. On the page below is a chart to help in a thorough check of the unit and its operation.

CAUTION: For your personal safety be sure to turn the electric power off at the main disconnects for both SYSTEM and HEATER accessories before removing any access panels, or attempting any maintenance, inspection, or service operation.

CAUTION: These procedures should be performed by Trained Technicians only. Normal precautions should be observed in making each check.

SUGGESTED CHECKLIST FOR ROUTINE INSPECTION

COMPONENTS	CHECK
Thermostat Operation	 a. Anticipator Setting(s) may be found on the unit wiring/schematic diagram located on inside of control box cover. b. Proper Calibration
Loose, Worn or Misaligned Pulley	Visually check and replace or adjust as required.
3. Loose, Worn Fan Belt(s)	Visually check and replace or adjust as required.
Loose Electrical connections	Visually check and tighten or replace terminal leads if needed.
Wiring deterioration	Visually check and replace as required.
6. Refrigerant Oil Traces	Check for refrigerant leaks.
7. Torn Insulation	Visually check and replace as required.
8. Loose or lost Screws	Visually check and tighten or replace where needed.
Unusual Noise or Vibration	Determine cause and correct by adjustment or replacement of defective part.
10. Dirty or clogged Air Filters	Check for accumulated dirt and debris, clean or replace.
	Heater should be hot to the touch (if power is on). ailable to the sump heater continuously or for at least frefrigerant, prior to start-up of compressor.
12. Painted Surfaces	Visually check, clean and paint as required.
13. Roof Flashing and Caulking	Visually check, repair as necessary.
A suggested form for recording routine inspection will be found on page 13.	Fill in data when maintenance is performed

VENTILATION.

Too much ventilation may result in:

1. Excessive equipment loading.

2. Higher operating cost.

3. Loss of indoor temperature and humidity control.

Too little ventilation may result in:

- 1. Excessive smoke, fumes and odors.
- 2. Stale air.

1. AIR FILTER

Filters should be inspected each month and cleaned or replaced as required.

NOTE: If you have a clogged filter indicator light on your thermostat (ask your installing dealer), clean or replace filters when the light indicates.

Filters must be located in the return air system. If you are not sure of the location, ask your installing contractor or servicing dealer to show you where they are located and how to replace them.

Filter types and How to Clean:

- A. Plastic Foam Type Wash in warm water and reinstall.
- B. Glass Fiber (Throwaway) Replace as often as required.
- C. Aluminum (Coated Type) Wash in soap and water and allow to dry; spray with coating as per manufacturer's instruction

2. OILING OF MOTORS

A. INDOOR BLOWER MOTOR -

Some blower motors used for indoor airflow require oiling once each year. Use a good grade of SAE 20 nondetergent oil. Six (6) to ten (10) drops in each of the two bearings is usually sufficient. Most motors are permanently lubricated and require no oiling. (If your motor has oil holes or tubes, it should be oiled.)

B. OUTDOOR FAN MOTOR -

Outdoor motors having oil ports should be oiled by your servicer annually, using same grade and quantity of oil used for indoor motors.

NOTE: Ball bearing type motors are permanently lubricated and will not require oiling with normal usage.

C. COMPRESSOR MOTOR —

The compressor motor is part of the sealed system and requires no oiling.

3. BELT DRIVE BLOWERS

Check fan belt tension and examine the belt for cracks, breaks, or misalignment at least twice a year. (1/2 to 1" free movement midway between the pulleys is the proper tension). Replace any belt that shows damage or excessive wear. Check belt tension after two weeks of use as a new belt will stretch and may require adjusting.

Where multiple belts are used, all belts should be replaced when one or more shows excessive wear or defects. This assures equal tension on all belts. Buy matched sets for best performance.

4. CLEANING HEAT TRANSFER COILS

Check all refrigerant coils at least twice each year and clean as required.

Coils may be cleaned by use of:

- A. Steam (low pressure)
- B. Detergent and Water
- C. Compressed Air

CAUTION:

Care must be used when cleaning coils to avoid damage to fins. Be especially careful with Spine Fin™ coils.

5. CLEANING BLOWER WHEELS

Check blower wheels ever six months and clean as required. **Do not** attempt to clean blower wheel unless all power to unit is **OFF!**

Method of Cleaning:

- A. Vacuum Cleaner or brush
- B. Water and detergent
- C. Compressed air

6. CONDENSATE DRAIN LINE

The condensate drain system should be visually inspected each time the air filters are inspected (minimum of once each month). If there is any evidence of water overflow, drain lines should be cleaned and/or condensate pump checked for proper operation.

7. FRESH AIR DAMPERS

A. Fixed Dampers:

If fixed or preset dampers are used to introduce fresh air into the building, it may require seasonal adjustment to obtain proper airflow and maximum comfort in the conditioned space.

Dampers should be inspected periodically for obstruction to airflow.

B. Motorized — Automatic Dampers:

Dampers and linkage should be inspected and lubricated at least once each year.
Control circuit and motors should be checked

once each year for proper operation.

8. GENERAL INSPECTION

In addition to items 1 thru 7, it is a good maintenance practice to physically and visually check the following during routine or periodic inspection.

9. TORN OR DAMAGED INSULATION

Insulation should be secured to the metal surface at all times. If insulation has been torn it may be re-attached by using duct tape. If pieces are missing then the missing section must be replaced.

10. FLASHING OR CAULKING

Wherever it has been necessary to penetrate the exterior surface of the structure, some type of weather-proofing must be done to the cavity. Check to be sure these places are sealed against the weather.

SERVICE.

To service a unit efficiently the servicer must be able to diagnose the problem and its cause. Some of the causes and effects you should be aware of are listed on pages 8 and 9.

For proper procedures and replacing of parts it is recommended that "SERVICE MANUAL" 18-BB09E1, and "SERVICE PROCEDURES MANUAL" 18-HH03E1 be obtained through your Trane Sales and Distribution Centers.

DIAGNOSTIC CHART FOR COOLING

COOLING PROBLEMS	POSSIBLE CAUSE	WHAT TO CHECK
INDOOR AND OUTDOOR	1. Power off	Check disconnect, fuses or breakers
EQUIPMENT INOPERATIVE	Defective control voltage transformer or wiring	Check for control voltage. Repair or replace.
	Defective thermostat	Replace thermostat
INDOOR BLOWER MOTOR WILL NOT START — COMPRESSOR OPERATES	(a) Faulty unit wiring (b) Loose wiring connections	(a) Check wiring per wiring diagram (b) Tighten terminals and wiring connections
OPERATES	Defective fan relay, capacitor or contactor	Check control voltage. Replace defective component.
	3. Defective motor	Check current draw of motor.
INDOOR BLOWER MOTOR	Improper voltage	Check voltage at motor terminals
CYCLES ON INTERNAL	2. Defective motor	Check current draw of motor
PROTECTOR	3. Belts too tight	Loosen so belts can be depressed 3/4"
Market State of the Control of the C	4. Motor overloading	Adjust pulley - Replace with larger motor
LOW INDOOR AIRFLOW	1. Dirty filters	Clean or replace
	2. Dirty coils	Check visually - clean or replace
	Improper pulley adjustment.	Adjust for proper airflow
COMPRESSOR WILL NOT START	Incorrect thermostat setting	Adjust thermostat
BUT INDOOR BLOWER OPERATES	Compressor overloads or internal thermostat open	Check supply voltage, current draw each winding.
	High or low pressure which- cut out open ever used	Reset and check head or suction pressures
COMPRESSOR MOTOR HUMS BUT WILL NOT START	1. Low voltage	Check voltages at each compressor terminal when compressor trying to start
	Compressor motor has open or shorted windings	Make continuity check with a reliable ohmmeter. (make sure compressor has cooled enough to permit internal motor protectors to reset).
	Tight compressor. (mechanical stall)	Condemn and replace compressor only after all methods of starting compressor electrically have failed.
SHORT CYCLING OF	Defective thermostat	Replace thermostat
COMPRESSOR	Safety controls tripping.	Check controls
	Compressor overloads tripping.	Compressor amperage & overloads
COMPRESSOR OPERATES CONTINUOUSLY (INDOOR	Improperly adjusted or defective thermostat	Adjust or replace
TEMPERATURE BELOW THERMOSTAT SETTING)	2. Defective compressor contactor	Welded contacts

DIAGNOSTIC CHART FOR COOLING (CON'T)

COOLING PROBLEMS	POSSIBLE CAUSE	WHAT TO CHECK	
COMPRESSOR OPERATES	Low refrigerant charge	Check suction & head pressures	
CONTINUOUSLY (INDOOR	2. Low suction pressure	(See reasons for low pressure)	
TEMPERATURE ABOVE	3. High head pressure	(See reasons for high pressure)	
THERMOSTAT SETTING)	4. Improperly sized equipment	Check for capacity requirements	
	5. High return air temperatures	Check fresh air intake	
	6. Defective compressor	Check operating pressures & amperage	
LOW SUCTION PRESSURE	1. Dirty filters	Clean or replace	
	2. Insufficient air	Check dampers and registers Check pulley setting. Check for loose blower belts. Check for dirty coils	
	3. Low refrigerant charge	Check for leaks and repair	
	4. Faulty expansion valve	Replace defective valve or power element	
	5. Defective fan motor	Replace motor or repair	
K HIGH SUCTION PRESSURE	Excessive load on unit	Check for high indoor air flow Check for high return air temperature	
And the state of t	2. Defective compressor	Check for low head pressure Check for low amperage draw	
	3. High head pressure	Check for condensor air flow Check for excessive refrigerant	
	4. Faulty expansion valve	Replace defective valve or power element	
HIGH HEAD PRESSURE	Excessive load on unit	Check for high indoor air flow Check for high return air temperature	
	2. Condenser surface clogged or dirty	Clean	
	3. Defective condenser fan motor	Repair or replace	
	Overcharge of refrigerant	Check performance chart. Purge gas until conditions balance and correspond to chart	

DIAGNOSTIC CHART FOR HEATING

HEATING PROBLEMS	POSSIBLE CAUSE	WHAT TO CHECK
M INDOOR AIRFLOW PROBLEM	SEE A, B, C & D	COOLING PROBLEMS
ELECTRIC HEATERS	1. Power off	Check disconnects, fuses & breakers
INOPERATIVE	2. Heating element	Check voltage at heater terminals Check continuity of fuseable link and heating element. Replace defective component
ELECTRIC HEATERS INOPERATIVE	3. Relay	Check control voltage & replace relay if defective
	4. Temperature protective devices	Check airflow, replace TCO or fuseable link if defective
	5. Thermostat adjustment	Adjust or replace
	Defective control voltage transformer or wiring	Check for control voltage. Repair or replace
	7. Outdoor thermostat	Adjust or replace

TROUBLE SHOOTING

ERRATIC OPERATING PRESSURES

Causes:

Low suction presure is usually caused by:

- Low indoor airflow (dirty filters, coil, undersized duct, blower too slow, etc.)
- 2. Undercharge of refrigerant.
- 3. Defective expansion valve.
- 4. Low side restriction.
- 5. Plugged filter-drier
- Light indoor coil loading (low temperature air entering evaporator).

High suction pressure is usually caused by:

- 1. High indoor airflow.
- 2. Overcharge of refrigerant.
- 3. Expansion valve.
- 4. Non-condensables in system.
- Heavy indoor coil loading (high temperature air entering evaporator).
- Defective compressor valves.

Low head pressure is usually caused by:

- 1. Low refrigerant charge.
- Light evaporator and/or condenser loads (low indoor and/or outdoor temperatures).
- 3. Defective compressor valves.

High head pressure is usually caused by:

- 1. An overcharge of refrigerant.
- 2. Non-condensables in the system.
- Low condenser airflow (coil dirty or obstructed, fan too slow, etc.).
- Excessive evaporator loading (high temperature air entering evaporator).
- 5. High temperature air entering condenser.
- 6. Recirculation of condenser air.

CHECKING CONTROL CIRCUIT

- With the power off Using an ohmmeter or test light check for continuity through each control or protective device. (Be sure to remove the leads of the device before checking.) Open Circuit — Determine why the switch is open. Rarely is the device itself defective.
- Using a voltmeter caution with the power on check incoming voltage (Step 1). If OK, touch the leads to the terminals of each device. No voltage reading indicates an open switch or device. Determine why the switch is open. Rarely is the device itself defective.

AIRFLOW — INDOOR AND OUTDOOR

- GENERAL Insufficient or incorrect airflows account for a large portion of service calls. The largest contributors to airflow problems are:
 - a. dirty or plugged filters
 - b. dirty or plugged coils
 - c. broken, worn or loose fan belts
 - d. dirty blower wheels
 - e. insufficient supply or return ducts or grilles.

Most of the above are best prevented or eliminated by regular maintenance. Checks should become second nature to the serviceman and the customer. Check these items when making service or maintenance checks.

- CHECKING AIRFLOW The best indicator of airflow problems is the unit normal operating pressures. Failure of the pressures to equal the chart values usually indicates airflow problems. Examples: (a) Suction pressure low, head pressure normal — insufficient indoor airflow; (b) Suction pressure normal, head pressure high insufficient outdoor airflow.
- 3. CLEANING OF FOULED COILS As the unit is used, dust, dirt and various other foreign materials accumulate on the outdoor coils. Sooner or later this accumulation becomes so great that it affects the operation of the unit causing a reduction in airflow, insufficient cooling or heating complaints, reduction in capacity, tripping of the overload and possible eventual failure of the compressor. The time required for fouling to cause these problems varies according to the atmosphere in which the unit is installed and according to the application. For instance, the unit located in a heavy industrial area will foul up faster than one located in a strictly residential suburban area.

Fouled coils can only be corrected by cleaning. The fundamentals involved in cleaning are:

- Removing parts from the air conditioner to gain access to the condenser.
- Protection of electrical components from cleaning solution used.
- c. Cleaning by use of some solution.
- d. Reassembling.

Protection of Electrical Components — If the electrical components are not removed, they must be protected during the cleaning process by use of waterproof Pliofilm, rubber sheets, or some equivalent method.

Pressure Tank Cleaning — A pressure spray tank having a flexible rubber hose of adequate length for ease of manipulations can be used for condenser cleaning. Adjust spray head to a relatively fine spray and apply. Apply mixture liberally to all surfaces possible. Areas not wetted by the cleaner may not clean satisfactorily. Allow cleaner to soak in for a few minutes — shorter or longer depending upon the amount and kind of soil present. Rinse liberally with as high a water pressure as is obtainable on plate fin surface. For spine fin surface use reduced water pressure. It is recommended to use only the water pressure from the hose without the nozzle attached in order to prevent flattening of spines.

The detergents recommended for the pressure tank method are mild general purpose cleaners developed to wet a wide variety of soils and belong to a class introduced several years ago as "waterless cleaners." They have passed simple lab tests as being innocuous in so far as corrosion is concerned and are considered free rinsing. They are available in all major cities, or orders can be filled elsewhere in a matter of days. Kelite Spray White or Oakite Spray used in proportions of 1 part detergent to 4 parts water (preferably hot, but not required) are satisfactory.

Steam Cleaning — Steam cleaning equipment may be used to do the actual cleaning, rather than the pressure spray tank. Steam cleaning will do a better job and is more impressive to the customer. Steam cleaning equipment can be put on a trailer or installed in a truck as local conditions warrant. The detergents satisfactory for steam cleaning equipment are: Oakite 202 or Kelite Formula 89.

REFRIGERANT LEAKS

- 1. Equipment necessary for leak testing
 - a. Leak Detector.
 - b. Halide torch leak detector.
 - c. Soap solution.
- 2. To check for leaks
 - a. Connect a pressure gauge to the compressor low side purge fitting. If the gauge registers a positive pressure, proceed with the test. If the gauge indicates the system to be out of gas, add sufficient R-22 to pressurize the system, then proceed with the test.
 - Using the leak detector (follow the directions furnished with the detector) check all joints, pressure switch capillaries, etc., for leaks or;
 - Using a halide torch check all joints etc. A leak will show up as a change in color of the torch flame A green flame indicates small leak A rising brilliant blue flame indicates larger leak, or:
 - d. Using soap solution smear soap on joints, etc.
 A rising bubble pin points the leak.
 - e. Hints and Tips
 - The presence of oil on lines, fittings, etc., usually indicates a leak.
 - Very small leaks may be found by pressuring the system with 300# pressure of dry nitrogen. After the leak is located, bleed the refrigerant charge. Some units may be pumped down or disconnected. Repair the leak by, brazing or tightening, whichever is appropriate. Evacuate and recharge the system.

STATIC ELECTRICITY NOISE

Motor and blower assemblies are normally free of any static electricity discharge due to the care taken in design and manufacture. Regardless of how much care is taken, however, a problem of this type is still a possibility.

A ground wire is imbedded in the motor resilient mounting; grounding is completed through the frame of the equipment. The equipment, naturally, is grounded as a part of the electrical installation. Despite these precautions there may be cases where the rotating components of blower assemblies become static collectors. This can result in a static electricity discharge that may cause noise interference in radios, some television sets, hi-fidelity phonographs, etc.; this will be apparent only when the equipment is operating. The staccato noise of this static arc can become quite annoying; the only solution is additional grounding.

CHECKING CONTROL TRANSFORMER

- 1. Power off using a test light or ohmmeter
 - a. Disconnect transformer leads
 - b. Check continuity through primary windings open circuit replace transformer.
 - c. Check continuity through secondary windings
 open circuit replace fuse or transformer.
- 2. Power on using a voltmeter
 - a. Check primary input voltage
 - b. Check secondary output voltage no voltage replace fuse or transformer.

LIQUID LINE DRIER

Check the temperature drop across the drier — if there is a noticeable temperature drop, the drier is clogged and should be replaced.

Two types of driers, flare and brazed, have been used. To change from brazed to flare, adapters are available from your distributor or may be improvised by careful piping practices.

CHECKING FOR REFRIGERANT RESTRICTIONS

- Capillary tube or expansion valve A restricted capillary tube results in:
 - Low suction pressure (may trip out low pressure switch)
 - b. Icing or frosting of the cap tube
 - c. Loss of capacity
 - d. Insufficient temperature drop across evaporator
- 2. Liquid Line A restricted liquid line results in:
 - a. Low Suction pressure (may pump down completely)
 - b. Loss of capacity

Probable locations of restrictions are:

- a. Drier
- b. Liquid line shut off valve
- c. Kinked tubing
- d. Strainer

The location of the restrictions will be indicated by a definite temperature difference across the restriction.

- 3. Discharge line and condenser These restrictions result in:
 - a. High head pressure (may trip out high pressure switch)
 - b. Loss of capacity

MAINTENANCE & SERVICE LOG

Serial Number				_ Date Inst	alled		100.07	
				- 201				
OPERATIONAL CHECK	CHECK AIR FILTERS	OIL MOTORS	INSPECT BELTS	INSPECT INDOOR COILS	INSPECT OUTDOOR COILS	INSPECT BLOWER WHEELS	INSPECT CONDENSATE DRAINS	CHECK DAMPER SETTINGS
Date By								K ee
Date By								6.
Date By	3							
Date By								
Date By								
Date By								
Date By					2 170			
Date By								
Date By							40	
								that's
DATE OF FAILURE	TYPE OF FAILURE		DATE	F FAILURE	т	YPE OF FAILURE		

DATE OF FAILURE	TYPE OF FAILURE	DATE OF FAILURE	TYPE OF FAILURE
		Contraction of the Section of the Contraction of th	A STATE OF THE STA
	The second of th		
10 to April 22000			

The Trane Company Light Commercial Unitary Division Guthrie Highway Clarksville, TN 37040

TAB PLACEMENT HERE

DE	SCRIPTION:
	Air Conditioners
	Tab page did not contain hand written information
	Tab page contained hand written information *Scanned as next image

Confidential Records Management, Inc. New Bern, NC 1-888-622-4425 9/08

Library	Service Literature
Product Section	Unitary
Product	Rooftop Air Conditioning
Model	ВТС
Literature Type	Service Facts
Sequence	29B
Date	May 1986
File No.	SV-UN-RT-BTC-SF-29B 5/86
Supersedes	

SERVICE FACTS

product improvement, it reserves the right to change specifications and design without notice. The installation and servicing of the equipment referred to in this booklet should be done by qualified, experienced technicians

Air Conditioner Model: BTC120F300HB BTC120F3A0HB

IMPORTANT — This document is customer property and is to remain with this unit. Please return to service information pack upon completion of work.

PRODUCT SPECIFICATIONS

MODEL	BTC120F	MODEL	BTC120F
RATINGS (Cooling) ① BTUH Indoor Airflow (CFM) Power Input (Kw) EER ® Noise Rating No. ②	120000 4000 13.90 8.65 8.8	INDOOR FAN — Type Dia. x Width (in.) No. Used Drive / Speeds (No.) CFM vs. in. w.g. ® No. Motors — HP No. Motors — HP Hi Static Opt.	Centrifugal 15 x 15 1 Belt / Adjustable See Fan Perf. 1 — 1-1/2
POWER CONNS. — V/Ph/Hz Min. Brch. Cir Ampacity ③ Br. Cir. — Max. (Amps.) Prot. Rtg. — Recmd. (Amps)	200-230/3/60 60 80	Motor Speed R.P.M. Volts/Ph/Hz F.L. Amps	1 — 2 1725 230/3/60 5.0
COMPRESSOR No. Used — No. Speeds Volts/Ph/Hz R.L. Amps — L.R. Amps Brch. Cir. Selec. Cur. Amps	80 Climatuff™ 2 — 1 200-230/3/60 19 — 125 20.5	FILTER — Furnished? Type Recommended Lo Vel. (NoSize-Thk.) Hi Vel. (NoSize-Thk.)	1 in. Low Velocity 4-20x20 — 1 or 2 in.
OUTDOOR COIL — Type Rows /F.P.I.	Spine Fin 1 / 20	REFRIGERANT Charge (lbs. of R-22)	Left (11.0)/Right (10.1)
Face Area (sq. ft.) Tube Size (in.)	38.5 1/2	DIMENSIONS Crated (in.)	H x W x D 47.5 x 76 x 83
INDOOR COIL — Type Rows / F.P.I. Face Area (sq. ft.) Tube Size (in.) Refrigerant Control Drain Conn. Size (in.)	Plate Fin 4 / 13.5 9.5 1/2 Expansion Valve 3/4 NPT	WEIGHT Shipping (lbs.) — Net (lbs.)	1222 / 1190
OUTDOOR FAN — Type No. Used / Dia. (in.) Type Drive / No. Speeds CFM @ 0.0 in. w.g. @ No. Motors — HP Motor Speed R.P.M. Volts/Ph/Hz F.L. Amps	Propeller 2 / 22 Direct / 1 9000 2 — 1/2 1100 200-230/1/60 3.8		

OPTIONAL EQUIPMENT

Indoor Thermostats —	
Single-Stage Heat/Cool AY28X182	
Two-Stage Heat/Cool AY28X183	
Two-Stage Cooling AY28X186	
Sub-Bases —	
Automatic or Manual	
Seasonal Changeover	
(For use w/AY28X183) AY28X184	
Manual Changeover	
(For use w/AY28X182,	
183) AY28X185	
Auto Seasonal Changeover	
(For use w/AY28X182,	
183, 186) AY28X187	
Head Pressure Control BAY28X123C	
Fan Control Relay Kit BAY24X42	

①Rated in accordance with A.R.I. Standard 240. @Rated in accordance with A.R.I. Standard 270. 3 Calculated in accordance with Natl. Electric Code. Suitable for use

with HACR circuit breakers or fuses.

Standard Air — Dry Coil -Outdoor. @Standard Air — Wet Coil — Indoor. @Rated in accordance with D.O.E. test procedure.

[*] Power supply voltage limits

1% approximately.

voltage Lillits	Max I.D. Temp.	IVIAX U.D. IEMP.
Low High	DB/WB	DB
207 — 254	95/71	115
196 — 207 (a)	95/71	105
187 — 196 (b)	95/71	100

(a) O.D. Fan must be on high speed. Indoor airflow must not exceed 450 CFM/TON. (b) O.D. fan must be on high speed. Indoor airflow must not exceed

450 CFM/TON. Start kit must be used. (c) Capacity reduction for unit operation at 208 volts vs. 230 volts is









SAFETY NOTICE

THIS INFORMATION IS INTENDED FOR USE BY INDIVIDUALS POSSESSING ADEQUATE BACKGROUNDS OF ELECTRICAL AND MECHANICAL EXPERI-ENCE. ANY ATTEMPT TO REPAIR A CENTRAL AIR CONDITIONING PRODUCT MAY RESULT IN PERSONAL INJURY AND OR PROPERTY DAMAGE. THE MAN-UFACTURER OR SELLER CANNOT BE RESPONSIBLE FOR THE INTERPRETATION OF THIS INFORMATION, NOR CAN IT ASSUME ANY LIABILITY IN CONNECTION WITH ITS USE.

RECONNECT ALL GROUNDING DEVICES

ALL PARTS OF THIS PRODUCT CAPABLE OF CONDUCT-ING ELECTRICAL CURRENT ARE GROUNDED. IF GROUNDING WIRES, SCREWS, STRAPS, CLIPS, NUTS OR WASHERS USED TO COMPLETE A PATH TO GROUND ARE REMOVED FOR SERVICE, THEY MUST BE RETURNED TO THEIR ORIGINAL POSITION AND PROP-**ERLY FASTENED.**

DISCONNECT POWER BEFORE SERVICING

Dwg. No. A724331P01

SERVICE PARTS

COMPONENT	ату.	DESCRIPTION	DPG CAT. #	CSG MNEMONIC #
Blower Wheel	1	15" D x 15" W x 1" Bore, CW	WW74X74	WHL-320
Capacitors (CFA-CFB)	2	7.5 MFD, 440V	WW20X134	CPT-265
Compressor Internal Line Break (IOL) Internal Press. Relief (IPR)	2	CT56HL3AX1: FLA 21.8 LRA 125.0, Wind. res. @ 77°F. — .620 Ohms Open on rise in winding temp Resets in 30-90 min. Open on 350# diff. between high & low side pressure	Order by unit model #	COM-2309
Contactor (MS-1)	1	Type DPST, Contacts 230/460/600V, Amps Ind./ Res. 40/50, LRA 240/200/160, Coil 24V 3.2 A.In., .36 A.Hld.	WW30X93	CTR-576
Contactor (MS-2) *	1	Type DPST, Contacts 240/480V, FLA * 30, LRA 180/150, Coil 24V,	WW30X108	CTR-577
Distributor (ID/OD)	2	1/2" Inlet - 4 Outlets - 1/4"	WW51X156	DST-134
Drier	2	Suc. Line w/Sweat Fit., 30 Cu. In., 1-1/8" x 1-1/8"	WW22X70	DHY-185
Drier	2	Liq. Line w/Sweat Fit., 8 Cu. In., 3/8"x3/8"	WW22X88	DHY-144
Evaporator Defrost Control (EDC)	1	120/240V, 10/5 FLA, 60/30 LRA, In @ 60° ±2°F., Out @ 25°±2°F.	WW26X62	SWT-507
Expansion Valve	2	3/8" In, 1/2" Out, Sweat, 5 Ton, 30" Cap, Ext. Equal., 90°, Superheat 45 ± 2 PSIG	WW51X240	VAL-2470
Fan	2	3 Blade, 22" Dia., 1/2" Bore, Hub up, CW, 34°	WW73X69	FAN-1214
Fuse (FU)	1	Red Cap, Dual Element, 3.2 Amp,	WG23X70	FUS-273
Motor (ID)	1	230/460V, 60 Hz., 3 Ph., Open Shell, Rev., 1725 RPM, 1-1/2 HP, FLA 5.6/2.8, LRA 37.4/18.7, Ball Bearing, 1-Speed, Winding Resistance — Ohms @ 77°F.: Hi Voltage 11.1/9.5, Line To Line	WW94X214	M0T-2293
Motor (ODA/ODB) *	2	200/230V, 60 Hz., 1 Ph., Closed Shell, CCW, 1100 RPM, 1/2 HP, 1-speed, FLA 3.8/3.3, LRA 6.2, Winding Resistance — Ohms @ 77°F.: Blk. to Blu. 8.4/7.4; Blk. to Brn. 41.3/35.5	WW94X413	M0T-2578
Outdoor Fan Thermostat (OFT)	1	240 V.A.C., 5 FLA, 30 LRA, Contacts Open @ 50°±5°F., Reset @ 60°±5°F.	WW28X110	THT-413
Pulley, Motor	1	4.2" D, 5/8" Bore, Pitch Varies From, 3.9" to 2.9"	WW34X2	SHE-641
Pulley, Blower	1	8.93" D x 1.0" Bore, 9.0 Pitch, 6 Spokes	WW34X52	SHE-733
Relay, Aux. (AR)	1	Type SPDT, w/Add. N/O Contacts, Contacts 230V, FLA 5.0, LRA 15.0, Coil 24V, .153 A.In., .084 A.Hld.	WW24X99	RLY-918
Relay (F)			WW30X83	RLY-1005
Shaft			WW15X39	SHF-913
Slinger	2 1/2" Dia. Bore		WW72X67	SLG-53
Sub-Bases	1 1 1	AY28X184, Auto/Manual Changeover AY28X185, Manual Changeover AY28X187, Auto Changeover	WW28X184 WW28X185 WW28X187	BAS-398 BAS-399 BAS-400
Sump Heater	2	230V, 65 W., Res. Heater, Cart. Type	WW08X65	HTR-1221
Switch, Low Pressure Cut-Out (LPCO)	2	Cut-Out Pressure: Opens @ 8 ± 4 PSIG, Resets 25 ± 7 PSIG	WW26X90	SWT-506
Thermostat	1 1 1	BAY28X182, Single Stage, Heat/Cool BAY28X183, 2-Stage Heat/Cool BAY28X186, Two-Stage Cool	WW28X182 WW28X183 WW28X186	THT-457 THT-463 THT-465
Transformer (TNS)	1	24V, Class 2, Rating 75 VA, Pri. 60 Hz.	WG32X39	TRR-385

*New Part - Set Up Within The Last 18 Months.

SERVICE PARTS

PARTS LIST FOR OPTIONAL HEAD PRESSURE CONTROL KIT BAY28X123C

COMPONENT	ату.	DESCRIPTION	DPG CAT. #	CSG MNEMONIC #
Auto Transformer 1 @ 230V, Red 116.0 VAC, Orange 134.5 VAC, Yellow 200.0 VAC, @ 460V, Red 232.0 VAC, Orange 273.0 VAC, Yellow 400.0 VAC		WW32X57	TRR-440	
Fuse •	1	5 Amp, 600 Volt	WW23X195	FUS-272
Pressure Switch (HPCO)	1	Opens @ 280 ± 10 PSIG, Closes @ 160 ± 10 PSIG	WW26X79	SWT-593
Relay (ODFA)	1	Type PDT, Contacts 240/480V, FLA 6/3, LRA 35/18, Coil 24V, .53/.61 A.In., .26/.31 A.Hld., #R8222B-1158	WW24X70	RLY-886
Relay (ODFB) 1 Type DPDT, Contacts 240V, 180 LRA, 30 FLA, coil 24V, 615 A.In., .41 A.Hid., 50-60 Hz		WW24X137	RLY-1002	
Thermostat (OFTA)	at (OFTA) 1 Opens @ 55° ± 6°F., Closes @ 45° ± 6°F.		WW28X119	THT-458
Thermostat (OFTB)	1	Opens @ 35° ± 6°F., Closes @ 25° ± 6°F.	WW28X120	THT-459

*New Part - Set Up Within The Last 18 Months.

NOTE: USE THE FOLLOWING COMPONENTS AS CORRESPONDING PARTS WHEN ORDERING FOR HI-STATIC MODEL


BTC120F3AOHB


COMPONENT QTY.		DESCRIPTION	DPG CAT. #	CSG MNEMONIC #	
Motor (ID)	1	230/460V, 60 Hz., 3 Ph., Open Shell, Rev., 1725 RPM, 2 HP, FLA 6.6/3.3, LRA 48.2/24.1, Ball Bearing, 1-Speed, Winding Resistance — Ohns @ 77°F.: (Hi-Voltage) 1-2 7.79/6.93, 1-3 7.79/6.93, 2-3 7.79/6.93	WW94X230	M0T2705	
Pulley, Motor	1	4.75" D, 7/8" Bore, Var. Pitch 4.4-3.4 on 0-5 Turns, Browning #IVM-50/IVP-50	WW34X56	SHE-737	

*New Part - Set Up Within The Last 18 Months.

NOTE:
CSG refers to the Commercial Systems Group and DPG refers to the Dealer Product Group of The Trane Company. The CSG
and DPG part numbers shown side by side above are not necessarily interchangeable for applications other than documented
in this bulletin. Both are approved for service of the product listed. Inventories to support your needs are evailable to you
through both Trane divisions.


REFRIGERANT CIRCUIT





From Dwg. 21D756526 P01

```
LEGEND
             FACTORY WIRING
---- 24 V
              FIELD WIRING
 Ť
        GROUND
оно
        CONTACT NORMALLY OPEN
01/20
       CONTACT NORMALLY CLOSED
        CONTACTS-SPDT
910
        CAPACITOR
        WIRE NUT OR CONNECTOR
 £
 8
        INTERNAL OVERLOAD PROTECTOR
00
        FUSE
        MAGNETIC COIL
000
        MOTOR WINDING
        RESISTOR OR HEATING ELEMENT
00000
        TRANSFORMER
        TEMPERATURE SENSING SWITCH
000
        PRESSURE SENSING SWITCH
回百
        TERMINAL BOARD
  0
        TERMINAL
               POLARIZED PLUG
```




FEMALE

From Dwg. 21C756518 P01


AUXILIARY RELAY AR CF FAN MOTOR CAPACITORS CN WIRE CONNECTOR CPR COMPRESSOR EVAPORATOR DEFROST CONTROL EDC INDOOR FAN RELAY FAN TERMINAL BOARD FUSE FTB_ FU GND HTR HEATER HIGH VOLTAGE TERMINAL BOARD HVTB INTERNAL OVERLOAD PROTECTOR IOL LOW PRESSURE CUT OUT LOW VOLTAGE TERMINAL BOARD LPCO LVTB MS COMPRESSOR MOTOR CONTACTOR MOTOR MTR OUTDOOR FAN THERMOSTAT POLARIZED PLUG - FEMALE CONTACT POLARIZED PLUG - MALE CONTACT TRANS FORMER

NOTES:

WHEN AUTOMATIC SUBBASES BAY28X184 OR BAY28X187 ARE USED, RELAY KIT BAY24X042 MUST BE USED TO PROVIDE "G" SIGNAL FOR ELECTRIC HEATING OPERATION. SEE FIELD WIRING DIAGRAM.



PRESSURE CURVES — BTC120F



SU

PRE

80

COOLING PERFORMANCE TO BE CHECKED WHEN OUTDOOR TEMPERATURE IS ABOVE 55°F. AFTER OPERATING PRESSURES HAVE STABILIZED: MEASURE INDOOR WET BULB TEMP. — OUTDOOR TEMP. — HEAD & SUCTION PRESSURES. LOCATE OUTDOOR TEMP. © LOCATE INDOOR WET BULB © FIND INTERSECTION OF OD TEMP. & ID W.B. ®

BULB @ FIND INTERSECTION OF OD TEMP. & ID W.B. ® READ HEAD OR SUCTION PRESSURE IN LEFT HAND COLUMN ® (SELECT PROPER INDOOR CFM)

ACTUAL HEAD PRESSURE SHOULD BE \pm 10 PSIG OF CHART SUCTION PRESSURE SHOULD BE \pm 3 PSIG OF CHART

EXAMPLE: ① OUTDOOR TEMP 85°F., ② INDOOR WET BULB 67°F.,
③ HEAD PRESSURE @ 4000 CFM = 260 PSIG

③ SUCTION PRESSURE @ 4000 CFM = 74 PSIG ⑥

NOTE:

- FOR OPERATION WITH ONLY ONE OUTDOOR FAN: USE CHARTS AT OUTDOOR TEMPERATURE 25° HIGHER THAN ACTUAL TEMPERATURE.
- 2. FOR OPERATION WITH ONLY **ONE COMPRESSOR**: INCREASE HEAD PRESSURE 5 PSIG AND SUCTION PRESSURE 5 PSIG.

From Dwg. 21C723907 Rev. 0

55 65 75 85 95 105 OUTDOOR TEMPERATURE (°F)

PRESSURE DROP CHARACTERISTICS ELECTRIC HEATERS

		MBER OF RAC table at the ri				
	1	2	3			
AIRFLOW, CFM	AIR PRESSURE DROP, in. w.g.					
2000	0.01	0.02	0.03			
2200 2400 2600	Ξ	0.03	0.04 0.05			
2800	0.02	0.04	0.06			
3000 3200 3400	Ξ	0.05	0.07 0.08			
3600 3800	0.03	0.06 0.07	0.09 0.10			
4000 4200	0.04	0.08 0.09	0.12 0.13			
4400 4600	0.05	0.10 0.11	0.15 0.16			
4800	0.06	0.12	0.18			
5000	0.07	0.13	0.20			

HEATER MODEL NO.	NOMINAL RATING	NO. OF
BAY96X241A BAYHTRA310	10 KW	1
BAY96X242A BAYHTRA320	20 KW	1
BAY96X243A BAYHTRA330	30 KW	2
BAY96X244A BAYHTRA340	40 KW	2
BAY96X245B BAYHTRA350	50 KW	3
BAY96X246B BAYHTRA360	60 KW	3

From Dwg. 21A723873 Rev. 0

INDOOR FAN PERFORMANCE FOR BTC120F300HB

	100	MOT	OR PULLE	Y TURN	S OPEN (FACTOR	Y SETTIN	G, 2)& E	SLOWER S	PEED -	- RPM	200
	0 & 7	725	180	690	2 & (655	3&6	620	4 & !	585	5&5	550
		EX	TERNALS	STATIC	PRESSUR	E (in. w.	g.) AND B	RAKE H	IORSEPO	VER (BI	HP)①	
AIRFLOW, CFM	PRESS	ВНР	PRESS	ВНР	PRESS	внр	PRESS	ВНР	PRESS	ВНР	PRESS	ВНР
2600	0.91	.97	0.81	.89	0.71	.81	0.62	.75	0.52	.72	0.43	.70
2800	0.89	1.03	0.79	.95	0.69	.85	0.59	.78	0.49	.75	0.39	.72
3000	0.86	1.09	0.76	1.00	0.66	.90	0.55	.82	0.44	.79	0.34	.75
3200	0.83	1.16	0.72	1.06	0.61	.97	0.50	.87	0.39	.83	0.28	.79
3400	0.79	1.23	0.67	1.12	0.56	1.03	0.45	.92	0.33	.87	0.22	.83
3600	0.74	1.30	0.62	1.19	0.51	1.09	0.39	.99	0.27	.92	0.15	.87
3800	0.68	1.37	0.56	1.26	0.45	1.15	0.32	1.05	0.20	.98	0.07	.92
4000	0.62	1.45	0.50	1.33	0.38	1.22	0.25	1.11	0.12	1.04		
4200	0.55	1.53	0.43	1.41	0.30	1.29	0.17	1.18	0.04	1.10		-
4400	0.46	1.61	0.34	1.49	0.21	1.37	0.08	1.26	727474		_	-
4600@	0.36	1.69	0.24	1.57	0.11	1.45	_		R:	_	1	<u>-</u>
4800@	0.26	1.78	0.14	1.66	0.01	1.54				_	1	_
5000@	0.16	1.87	0.04	1.75	_	_	B 2 - 3				10 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	12

^{© 1-1/2} HP. motor limit, (class B insulation). 2450 Watts at 230V & 460V 2150 Watts at 200V © Water blow-off limit: 4600 CFM

From Dwg. 21A723878 Rev. 0

INDOOR FAN PERFORMANCE HIGH STATIC (BTC120F3A0HB)

	resident	мо	OR PULLI	EY TURI	WET COIL	L, 1" GLA (FACTO	ASS FIBER	R FILTER	RS LOWER S	PEED —	- RPM	
	0 & 9	960	1 & 9	915	2 & 1	870	3 & 1	825	4 &	780	5&7	735
	Carlo Santina	EXT	ERNAL ST	ATIC PE	RESSURE	(In. of W	ater) AND	BRAKE	HORSEP	OWER (BHP)*	W. 1915
AIRFLOW CFM	PRESS	внр	PRESS	ВНР	PRESS	ВНР	PRESS	ВНР	PRESS	ВНР	PRESS	ВНР
2600	1.66	1.50	1.52	1.41	1.38	1.31	1.23	1.21	1.07	1.12	0.92	1.03
2800	1.64	1.60	1.50	1.49	1.36	1.39	1.21	1.28	1.05	0.19	0.90	1.09
3000	1.62	1.69	1.48	1.58	1.33	1.47	1.19	1.37	1.02	1.26	0.87	1.15
3200	1.60	1.79	1.45	1.67	1.30	1.56	1.16	1.45	0.99	1.33	0.84	1.23
3400	1.57	1.90	1.42	1.77	1.27	1.65	1.12	1.54	0.96	1.42	0.80	1.30
3600	1.53	2.01	1.38	1.87	1.23	1.74	1.08	1.62	0.92	1.49	0.75	1.38
3800	1.49	2.13	1.34	1.98	1.19	1.84	1.04	1.70	0.87	1.58	0.69	1.45
4000	1.44	2.26	1.30	2.10	1.15	1.95	0.99	1.80	0.81	1.66	0.63	1.54
4200	1.38	2.38	1.24	2.21	1.09	2.05	0.92	1.90	0.74	1.76	0.56	1.62
4400	1.31	2.51	1.17	2.33	1.01	2.16	0.84	2.00	0.65	1.85	0.48	1.70
4600**	1.23	2.64	1.09	2.45	0.93	2.28	0.75	2.11	0.56	1.95	0.39	1.79
4800**	1.14	2.76	1.00	2.57	0.84	2.39	0.66	2.22	0.47	2.05	0.29	1.85
5000**	1.04	2.90	0.91	2.70	0.75	2.52	0.57	2.34	0.38	2.16	0.19	1.98

SUPPLEMENTARY HEATERS

Model Number	Power Supply V/O/HZ	KW Rating 208-240 V	Nominal BTU/H
BAY96X241A BAYHTRA310	208-240/3/60	7.48-9.96	25,500-34,000
BAY96X242A BAYHTRA320	208-240/3/60 14 96-19 9		51,000-68,000
BAY96X243A BAYHTRA330	208-240/3/60	22.44-29.88	76,600-102,000
BAY96X244A BAYHTRA340	208-240/3/60	29.92-39.84	102,100-136,000
BAY96X245B BAYHTRA350	208-240/3/60	37.40-49.80	127,600-170,000
BAY96X246B BAYHTRA360	208-240/3/60	44.88-59.76	153,200-204,000

From Dwg. 21A724006 Rev. 0

^{*2} Hp. Motor Limit, (Class B Insulation): 2800 Watts.

**Water Blow-Off Limit: 4600 CFM
NOTES:

1. Fan motor heat: MBh = 3.15 x fan bhp, also: Kw (Mechanical output) = hp x .7457
Kw (Electrical input) = (hp x .7457) Motor Efficiency
Motor Efficiency = 80%

TAB PLACEMENT HERE

DE	SCRIPTION:
	Roof top
	Accessories
	Tab page did not contain hand written information
	Tab page contained hand written information *Scanned as next image

Confidential Records Management, Inc. New Bern, NC 1-888-622-4425 9/08






BLDG# A5-502

INSTALLER'S GUIDE

Rooftop Accessories

Rooftop Accessories BYC,BTC,BWC090-120F For use with 7-1/2 and 10 Ton Single Package

Library	Service Literature
Product Section	Unitary
Product	Unitary Accessories
Model	Econ., Roof Curbs, Ducts, Diffusers
Literature Type	Installer's Guide
Sequence	8A
Date	March 1987
File No.	SV-UN-ACC-ACCSY-IN-8A 3/87
Supersedes	



Since The Trane Company has a policy of continuous product improvement, it reserves the right to change specifications and design without notice. The installation and servicing of the equipment referred to in this booklet should be done by qualified, experienced technicians.

This booklet covers the Rooftop accessories listed for the 7½ and 10 ton models only SINGLE PACKAGE UNITS.

These instructions are organized into four (4) stages for an easy step by step procedure.

The FIRST stage covers the: ROOF MOUNTING CURB (or Frame) BAYCURB014 or BAYCURB015 (BAYCURB014 is to be field assembled) (BAYCURB015 is factory assembled, with insulation on the inside of the side and end rails) on pages 4 thru 6.

The SECOND stage covers the: CONCENTRIC SUPPLY/RETURN DUCT BAYDUCT001 on page 7.

The THIRD stage covers the: FLUSH MOUNTED SQUARE DIFFUSER BAYDFSR001 on page 9.

The FOURTH stage covers the mounting of the following: BAYECON025-A Automatic Economizer Dampers, Drive Motor and Enthalpy Control (0-100% outdoor air); BAYECON024 Economizer Dampers, less Drive Motor and Control (0-100% outdoor air) (see pages 10-13); BAYBARM007 Barometric Relief Damper, to be used with BAYECON025-A, also BAYECON024 if required.

BAYDMPR018 Motorized Fresh Air Damper. See page 14-15. For instructions related to the Single Package Unit, refer to the instructions packaged with that unit.

These instructions do not purport to cover all variations in systems nor to provide for every possible contingency to be met in connection with installation. Should further information be desired or should particular problems arise which are not covered sufficiently for the purchaser's purposes, the matter should be referred to The Trane Company.

Check for transportation damage after accessory is uncrated. Report promptly, to the carrier, any damage found to the kit.

NOTE: The roof mounting curb (frame) not only provides a support for the unit, but permits an easy penetration of the roof for the connecting ductwork. The roof mounting curb provides for proper flashing and sealing by the roofing contractor as approved by National Roofing Contractors Association.

	NOTES	
	Company of the father	
terretoria de la compansión de la compan		
THE ALLERS AS THE		Strain out
The state of the s		
		The state of
		- 100
TO THE PARTY OF TH		
and the state of t		
100		

GENERAL — LOCATIONS AND RECOMMENDATIONS

- 1. Adequate support must be provided beneath the roof mounting curb for the entire length. The total weight of the unit, curb and duct plus any accessories must be considered when selecting and placing the curb on the roof.
- 2. Be sure location of the roof mounting curb will allow needed service clearance around unit when the unit is in place. (As illustrated.)

IMPORTANT: The illustrations below have dimensions on the concentric supply/return duct, to emphasize that the duct extends out past the end of curb below roof deck, when installed. Check for clearance for duct inside the structure.

3. Roof Mounting Curb (frame) must be installed on a flat, level section of the roof (maximum of 1/4" per foot

pitch), providing a level mounting surface for the unit, even though the roof is not level. If the pitch of the roof exceeds 1/4" per foot it will be necessary for the contractor to construct a sub-base on which to install the roof mounting curb level.


- 4. Do not locate the mounting curb near exhaust vents or other sources of contaminated air that could enter unit air inlets. Although unit is water proof, guard against water runoff from higher overhanging structures.
- 5. Field Fabricated Ductwork Secure all ducts to building structure. Use flexible duct connectors between unit and ducts.

Ducts passing thru unconditioned space must be insulated and covered with a vapor barrier.


REQUIRED CLEARANCE FOR UNIT INSTALLATION AND ROOF PENETRATION HOLE

CONCENTRIC SUPPLY & RETURN DUCT FROM ABOVE ROOF CENTER RAIL DIVIDER RAIL A2" CLEARANCE 42" CLEARANCE SIDE RAIL 46" SUPPLY AIR RETURN AIR SUPPLY AIR RETURN AIR SUPPLY AIR RETURN AIR SUPPLY AIR RETURN AIR SUPPLY AIR CLEARANCE FOR THE PROOF CLEARANCE

CONCENTRIC SUPPLY & RETURN DUCT FROM BELOW ROOF



CURB AND CONCENTRIC DUCT ASSEMBLED



FIRST STAGE INSTALLATION ROOF MOUNTING CURB ROOF PENETRATION HOLE SIZE REQUIRED


CAUTION: The opening must be covered temporarily to prevent anyone or anything from falling thru the opening. Follow this safety precaution when working in other areas of installation, and leaving the job site overnight or for any extended period of time.

1. When installing the Concentric Supply Return Duct (BAYDUCT001) from below or above the mounting curb, a hole size of 59" W. x 46" L. must be provided in the roof to insert and secure the flanges of the duct to the mounting curb as illustrated on page 2 and below. When installing Field Fabricated ducts from below or above the mounting curb, a hole size of 59" W. x 40" is recommended to insert and secure the flanges of the duct to the mounting curb as illustrated on page

2 and below. When field fabricated ducts are used, the dimensions may be reduced to accommodate ducts and installation clearance needed. See the Supply and Return Air Openings as illustrated below.


- 2. The Field Fabricated supply and return Ducts are: Supply air duct $29-7/16'' \times 23-9/16''$ with 3/4'' flanges. Return air duct $20-5/16'' \times 33-7/16''$ with 3/4'' flanges. See shaded area of illustration below.
- 3. All duct work must be installed in accordance with the National Fire Protection Association Standards No. 90A and 90B.
- 4. The BAYCURB015 Roof Mounting Curb is factory assembled, with insulation on the inside perimeter of curb.

BAYCURB015 ROOF MOUNTING CURB OUTLINE



BAYCURB014 ROOF MOUNTING CURB ASSEMBLY

- 1. Remove the components of the mounting curb from carton and separate pieces from each other.
- 2. Layout, separate pieces on flat surface close to area where it will be used. See illustrations to determine proper placement of parts. Assemble by snapping clips on End Rails, Side Rails and Center Rail into the slots provided on the mating parts of mounting curb.
- 3. Secure these parts by driving $(1/4 20 \times 1/2'')$ long type "B") thread forming screws thru holes provided in mating part.
- 4. There are four (4) 1" x 1", three (3) 1" x 2" Duct Support Flanges and one (1) 2" x 2" Divider Rail with a flange for return air duct. All of the above can be placed and secured to the Side Rails, End Rail, Center Rail and each other (indoor section) by driving sheet metal screws through holes provided.



BAYCURB014 ROOF MOUNTING CURB

The BAYCURB014 Roof Mounting Curb is shipped disassembled with the components to be assembled on the job site as illustrated. This assembly includes the following components (check list before starting job). Note: The Insulated Deck is secured to the bottom of the 7-1/2, 10 ton "F-A" units at the factory and requires no field assembling.

CONTENTS

- 2-End Rails
- 2-Side Rails
- 1—Center Rail (Hood Support)
- 4—1" x 1" Duct Support Flanges
- 3—1" x 2" Duct Support Flanges
- 1—Divider Rail with a Flange for Return Air Duct.
- 1—Bag of Bolts & Screws
- 4—Wood Nailers (Attached)
- 4—¼-20 x 1½" long Hold Down Screws (Not Shown)
- 3—Rolls 1½ x ½ P.V.C. Rubber Gasket (shipped with unit)

ROOF MOUNTING CURB (Cont.)

NOTE: Remove and discard one (1) 1" x 1" and three (3) 1" x 2" Duct Support Flanges in the supply air section if concentric duct (BAYDUCT001) is to be installed from below the curb. There are three (3) 1" x 1" Duct Support Flanges shipped with and attached to the flange of the concentric duct (BAYDUCT001). Secure each 1" x 1" Duct Support Flange to the roof mounting curb in their respective location as shipped. Screws are provided to secure duct support flanges to curb.

IMPORTANT: The BAYCURB014 does not have insulation on inside perimeter of curb. To prevent condensation from forming on inside of curb, insulate and seal the outside surface of curb as illustrated in cross section view of curb and roof (item 8).


- 5. Secure Divider Baffle and all Duct Support Flanges if Field Fabricated Ducts are to be used.
- 6. Place Mounting Curb assembly over hole cut in roof. Square the Curb by measuring from one corner diagonally to the opposite corner. Repeat this measurement of opposite corners and adjust the Curb until the measurements are the same.

NOTE: The top of the End Rails, Center Rail, Divider Rail (and Supply Air 1" x 2" Duct Flanges if used) must be flush with the top of the Curb to insure a good water and air seal against the bottom of the unit.

7. Secure Mounting Curb assembly to roof by welding or bolting.

8. Install flashing and roofing as illustrated in accordance with local codes. A typical section of insulation, roof and mounting curb is shown at right.

9. Leave the four (4) 1/4-20 x 11/2 long Hold Down Screws attached to the curb temporarily as they will not be




*ITEMS AVAILABLE FROM THE TRANE COMPANY

needed until after the unit has been placed on the curb. See illustration below.

NOTE: If unit is not ready to be set into position at this time, stop work on mounting curb at this point. When unit is ready to set into position, and just prior to setting unit, complete steps 10 thru 14.

- 10. If the Concentric Transition Duct BAYDUCT001 is to be installed from above mounting curb, it should be done at this time. See page 7 and 8 for installation instructions.
- 11. If Field Fabricated Ducts are to be installed from above mounting curb, they should be installed at this time. See page 8 for installation instructions.
- 12. Apply a bead of architectural grade caulking (field supplied) at corners of curb to seal all voids, preventing water leaks.
- 13. Place 1-1/2 x 1/2 P.V.C. rubber tape (gasket) on mounting curb as illustrated below P.V.C. gasket to be applied to curb as shown just prior to setting unit on mounting curb.
- 14. All P.V.C. rubber gasket (supplied with unit) must be applied in continuous strips or overlapped 1" minimum for complete watertight seal.

P.V.C. RUBBER GASKET POSITION FOR UNIT PLACEMENT ROOF MOUNTING CURB AIR ONLY SEALS NOTES: 1. OVERLAP & POSITION JOINTS IN P.V.C. RUBBER GASKET AS SHOWN. 2. AIR SEALS — APPLY P.V.C. RUBBER LAST TO INSURE THERE IS ADEQUATE P.V.C. FOR THE WATER SEAL. 3. USE TYPICAL SEALING METHODS TO PREVENT DUCT AIR LEAKAGE AT CURBDUIC JOINT



ROOF MOUNTING CURB (Cont.)

IMPORTANT

To set unit into position on Roof Mounting Curb, refer to unit's Installer's Guide BTC-IN-3 (18-AB60D4), BWC-IN-3 (18-BB60D4)

SECOND STAGE INSTALLATION


BAYDUCT001 CONCENTRIC SUPPLY/RETURN DUCT

The BAYDUCT001 Supply/Return Duct may be installed from above prior to setting the unit in place or from below (i.e. inside the building) after setting the unit in place.

IMPORTANT: When concentric duct BAYDUCT001 is used, remove and discard one (1) 1" x 1" and three (3) 1" x 2" duct support flanges from the supply air section. There are three (3) 1" x 1" duct support flanges shipped with and attached to the concentric duct (BAYDUCT001). Secure each 1" x 1" Duct Support Flange to the roof mounting curb in their respective location as shipped, secured to the concentric duct flanges. Screws are provided to secure duct support flanges to curb

INSTALLING FROM ABOVE BAYCURB014 or BAYCURB015 CURB

1. Remove the screws that secure the center rail to each side rail and remove the screws that secure the divider rail to the end rail. Save the center rail, divider rail and screws for later use. See illustration on page 3.



BAYDUCT001 SUPPLY & RETURN DUCT

- 2. Apply a good grade of weatherproof caulking on Flange Support to obtain a good air seal. See illustration at top of page 8.
- 3. Orient the Supply/Return Duct with respect to the unit's supply and return sections.
- 4. Lower Duct into roof opening. See illustration at top of page 8.
- 5. Apply a small bead of caulking on the flange between the supply and return air sections of concentric duct (BAYDUCT001) to form an air tight seal.
- 6. Replace the center rail and divider rail removed in step one (1) by reversing the procedure. The duct support flanges on the center rail should be under the flange of the concentric duct flange.
- 7. Install screws in flange to secure concentric duct BAYDUCT001 to Curb.

INSTALLING FROM BELOW BAYCURB014 CURB ONLY

IMPORTANT: Due to the insulation on the inside parameter of BAYCURB015 roof mounting curb, there is not enough room for the flange of the concentric supply and return duct to be installed from below the curb.

- 1. Apply a good grade of caulking on End Flange support, See illustration at top of page 8.
- 2. Orient the Supply/Return Duct with respect to the Unit's Supply/Return Sections.
- 3. Apply caulking to the duct flange edge (side next to the center rail). See illustration at top of page 8.
- 4. Slip the side that will be against the END RAIL up over the Duct Flange Support as shown in illustration at top of page 8.
- 5. Pivot Duct upward until stopped by support flange on the curb center rail flange.
- 6. Install screws in flange to secure.

CONCENTRIC SUPPLY & RETURN DUCT CONCENTRIC SUPPLY & RETURN DUCT FROM ABOVE ROOF FROM BELOW ROOF ROOF MOUNTING CURB END BEAD OF CAULKING ON ALL CURB FLANGES BEAD OF CAULKING ON ALL CURB FLANGES CONCENTRIC CONCENTRIC DUCT BAYDUCTOO1 DUCT BAYDUCT001 RETURN ROOF MOUNTING RETURN SUPPL

ROOF MOUNTING CURB FIELD FABRICATED (SIDE X SIDE) DUCTS

1. Field Fabricated Ducts may be installed from either below or above the Mounting Curb. See illustration below.


SIDE X SIDE DUCTS INSTALLED FROM ABOVE MOUNTING CURB

2. Apply a continuous bead of caulking on Duct Support Flanges, prior to lowering Field Fabricated Ducts into position on Duct Support Flanges. Make assembly secure with sheet metal screws See illustration below.


SIDE X SIDE DUCTS INSTALLED FROM BELOW MOUNTING CURB

3. Apply a continuous bead of caulking on flanges of Field Fabricated Ducts, prior to raising ducts thru opening in roof and place against Duct Support Flanges, and secure with sheet metal screws.

SIDE X SIDE DUCTS INSTALLED FROM ABOVE MOUNTING CURB



FIELD FABRICATED SIDE BY SIDE DUCTS INSTALLED FROM ABOVE CURB




THIRD STAGE INSTALLATION BAYDFSR001 FLUSH MOUNTED SQUARE DIFFUSER

This AIR DIFFUSER is designed to be used with CON-CENTRIC SUPPLY AND RETURN DUCT BAYDFSR001. It fits directly to the ceiling and secures to the ducts. To simplify installation, a bridge mounting system built into the diffuser frame, allows both the supply and return ducts to be attached to the frame while the core is removed. This eliminates the necessity of separating the supply and return sections of the core to attach the duct...just install frame, attach both ducts and insert core...easily done with stud hangers and quarterturn fasteners. See illustration below.

1. Cut duct off or extend with comparable material, to desired length. Measure from ceiling line back 1-1/2".

- 2. Remove center part of grille, which is held into the frame by 1/4 turn fasteners.
- 3. Press diffuser crossbar frame in proper position to make impressions for crossbar slots (use chalk if necessary) cut slots approximately 1-1/2" in duct.
- 4. The SUPPLY AND RETURN DUCT has 4 metal straps extending down outer sides. With the frame held tight against the ceiling, and the straps taut, drill hole through strap and crossbar frame of diffuser, as shown in illustration.
- 5. Secure all four straps to diffuser with sheet metal screws.
- 6. Replace Supply Return Air Grille removed in Step 2.

DIFFUSER AND CONCENTRIC SUPPLY/RETURN DUCT



FOURTH STAGE INSTALLATION

BAYECON025-A AUTOMATIC ECONOMIZER 0-100% FRESH AIR DAMPER

GENERAL

This instruction covers the installation of the 0-100% fresh air damper in the BYC, BTC, BWC090,120F models. These air conditioning units are designed for downflow application only.

The economizer is factory assembled for ease of installation. The motor and its linkage are factory installed and adjusted.

NOTE: Do not make any adjustments to the damper drive linkage. Linkage has been factory set for correct operation.

INSPECTION

Check carefully for any shipping damage. If damaged, this must be immediately reported to, and claims made against, the transportation company. Replace damaged parts with authorized parts only.

INSTALLATION RECOMMENDATIONS


- 1. Access Place the Disconnect Switch(es) in the "OFF" position. Remove the screws that secure the side panel of the return air section of the unit. Save the screws for securing the economizer later.
- 2. Remove side panel by pulling out slightly and down. Discard the side panel, since the economizer will be installed there. See illustration below.
- 3. Remove the screws that secure the end panel (filter access panel), of the return air section of the unit. Save the screws for later use.
- 4. Remove end panel (filter access panel) by pulling out and slightly down. Save this panel, since it will be reinstalled later. See illustration below.

NOTE: If an economizer is used with a factory installed drive motor, remove jumper plug from the polarized plug and discard. The polarized plug is located at the top and near the outlet end of the filter rack in the unit.

5. There are two (2) angle panels shipped with BAY-ECON025-A and BAYECON024 economizer; the wider angle panel is to be installed across the top side panel opening of the BYC,BTC,BWC120 models. The narrow angle panel is to be installed across the top side panel opening of BYC,BTC,BWC090 models. Select the appropriate panel and insert edge of panel under the top side flange of return air section, and secure with screws removed in step No. 1. See illustration below.

NOTE: The panel and economizer has a factory applied gasket provided.

- 6. Insert the economizer into side panel opening of the return air section of the unit. See illustrations below and on page 11.
- 7. Secure economizer to unit with screws provided. Form a water tight seal between the flanges of the economizer and unit. Use caulking to seal all voids, preventing water leaks.
- 8. The mixed air sensing thermistor was secured to damper drive linkage for shipping. The sensing thermistor must be secured in the mixed air stream.
 - a. Remove tie wrap and free sensing thermistor and wiring.
- b. Attach mixed air sensing thermistor to filter frame flange about 12 to 14 inches from end of filter frame. See illustrations below and on page 11.
- c. Dress wires away from economizer drive linkage. Tie wrap wire to filter frame, with factory provided wire ties, in two places. See illustrations below and on page 11.



0-100% FRESH AIR DAMPER (CONT.)


IMPORTANT: If economizer control adjustments are desired, it should be done at this time. Economizer factory settings are:

1. The mixed air control is set to modulate between 50°F and 56°F. (not field adjustable)

2. The enthalpy control is set at "B" position.


3. The minimum position of damper opening is set for 0% fresh air intake (fresh air damper fully closed when economizer is not enabled).

NOTE: Permanent type filters must be used with economizer.



IMPORTANT:


- 9. Make electrical connections to the economizer by mating the polarized plug of the economizer to the polarized plug of the unit; where the jumper was removed. The damper motor operates on the 24V unit transformer. To complete the 24V circuit to the damper motor, follow the steps outlined below:
- a. Disconnect power to the unit.
- b. Remove the access panel to the unit control box.
- c. Locate the BR/1 wire (brown wire with a '1' stamped on it) in the unit low voltage terminal board enclosure. See the unit wiring diagram for reference. This wire is terminated with a wire connector.
- d. Cut the wire connector off of the wire and strip the wire approx. 1/2".
- e. Remove the BR/1 wire and wire connector from the bag supplied with the economizer.
- f. Crimp both stripped ends of the BR/1 wires together using the factory supplied connector. See the illustration below.
- g. Connect the spade terminal of the factory supplied BR/1 wire to the 'R' terminal on the unit low voltage terminal board.
- h. Replace the unit control box access panel.



10. The economizer is shipped with the linkage rod from the motor disconnected.


NOTE: The set screws on both linkage rods are factory adjusted and should NOT be changed.

To re-install the motor linkage rod see the illustration below. The return air damper should be fully open in order to place the linkage bolt into the bolt hole in the lever arm. Tighten the hex nut securely.



From Dwg. 21B725489 Rev. 0

11. Replace the end panel (filter access panel) and secure with screws saved from step No. 3 on page 10. See illustration on page 11.



ECONOMIZER CONTROL CHECK-OUT

- 1. Set the minimum position potentiometer (if used) to allow outdoor air damper to go to FULLY closed position. Potentiometer is on enthalpy control cover. (OPEN ♠ & CLOSE ♠).
- 2. The following check-out steps for the economizer can be performed only if the outdoor air conditions are to the left of shaded area on psychrometric chart. See Chart below.
- 3. Set indoor thermostat to satisfied position and apply power to unit.
- 4. Set minimum position potentiometer (MPP) to full open position. Outdoor air damper should go to full open.
- Set MPP to close position. Outdoor air damper should close.
- 6. Set indoor thermostat to call for cooling.


CAUTION: Compressor will start. Avoid rapid cycling of compressor during check-out of economizer dampers.

7. This economizer is factory set for mixed air temperature between 50°F and 56°F. Turn the enthalpy control knob to the "A" setting (full clockwise). If the outdoor temperature is less than 75°F., the compressor will stop and outdoor damper will move to full open. If outdoor temperature is too high for


- enthalpy control to switch, the wires to terminals 1 and 3 on the control can be switched to verify proper operation. See illustrations on page 11 for location of enthalpy control knob.
- 8. Set indoor thermostat to satisfied position, stopping indoor blower. Fresh air damper will close and return air damper will open.
- 9. Set indoor thermostat to call for cooling. Allowing time for fresh air damper to open completely. Turn enthalpy control knob counter-clockwise past "D" position. Fresh air damper will close completely if temperature and humidity are above "D" position.
- 10. Set the enthalpy control per illustration below. If maximum combination of relative humidity and temperature is not known, set enthalpy control to the "B" setting.
- 11. Without a call for cooling, ADJUST the minimum position potentiometer, if used, to provide the volume of fresh air required (fresh air ventilation).

CAUTION: DO NOT SET MINIMUM POSITION TO PRO-VIDE OVER 50% VOLUME OF FRESH AIR.

ENTHALPY CONTROL SELECTION CHART



ECONOMIZER CONTROL SELECTION & PSYCHOMETRIC CHART



BAYECON024 MANUAL ECONOMIZER — 0-100% FRESH AIR DAMPER


- 1. The BAYECON024 Economizer is identical to the BAYECON025 with the following exception:
- 2. The drive motor, enthalpy control and polarized plug were omitted from BAYECON024 economizer.

BAYBARM007 BAROMETRIC RELIEF DAMPER

- 1. The BAYBARM007 Barometric Relief Damper is to be used with BAYECON025 and BAYECON024 economizer accessory, if required with your particular application.
- 2. Remove the Eliminator from the economizer by removing two (2) screws from each side of economizer, which secure the eliminator in the economizer. Save the eliminator and screws for later use. See illustration at right.
- 3. Remove bottom cover panel from economizer after the eliminator has been removed. Remove screws from the entire perimeter of the bottom cover panel. Discard the cover panel and save the screws for securing the barometric relief damper BAYBARM007.
- 4. Place the Barometric Relief Damper (BAYBARM007) into the economizer as illustrated at right. Secure the Barometric Relief Damper to the economizer by inserting screws through all clearance holes along the entire perimeter of the BAYBARM007 damper cover.

Insert four (4) screws through clearance holes in barometric damper cover, to secure motor barrier to barometric damper cover. There are two (2) clearance holes for screws in the left side panel of the economizer, insert a screw in each hole to secure the left end of the barometric damper BAYBARM007 to the economizer.


Reinstall and secure the Eliminator in the economizer by reversing the procedure outlined in step 2 above.



BAYDMPR018 MOTORIZED FRESH AIR DAMPER

For those applications which require it, a motorized fresh air damper BAYDMPR018 accessory can be installed and made functional by the following steps.

- 1. Secure bottom panel to the top panel of BAYDMPR018 with screws provided. See Illustration below.
- 1A. For use on BYC,BTC/BWC090F units, secure the bottom panel to the top panel of BAYDMPR018 with screws provided. See illustration below.
- 1B. For use on BYC,BTC/BWC120F units, secure wider filler panel to top panel of BAYDMPR018 with screws provided. Then attach bottom panel to lower edge of filler panel. See illustration below.




NOTE: Make sure that all screws are tight, so that gasket forms a water tight seal.

- 2. Access to unit Place the power disconnect switch(es) in the "OFF" position. Remove the screws that secure side panel of return air section of the unit.
- 3. Remove side panel by pulling out slightly and down. Discard the side panel since the BAYDMPR018 fresh air damper will be installed there.
- 4. Remove the screws that secure the end panel (filter access panel) of return air section of unit. Save screws for later use.
- 5. Remove the end panel (filter access panel) by pulling out slightly and down. Save this panel, since it will be reinstalled later.
- 6. Remove jumper plug from the polarized plug and discard. The polarized plug is located at the top and near the outlet end of the filter rack in the unit.

IMPORTANT: Remove two (2) screws and position plate on top of blade enclosure as shown in illustration. Secure with two (2) screws. PLATE MUST BE REPOSITIONED PRIOR TO INSTALLATION OF DAMPER TO UNIT.

- 7. Insert the BAYDMPR018 damper assembly into side panel opening of the return air section of unit. See illustration below.
- 8. Secure damper and panel assembly to unit with screws provided. Form a water tight seal between the flanges of the panel and unit. Use caulking to seal all voids, preventing water leaks.



BAYDMPR018 MOTORIZED FRESH AIR DAMPER (Cont.)


9. Make the electrical connection to the damper by mating the polarized plug of the damper to the polarized plug of the unit where the jumper plug was removed.

The damper motor operates on 200/230, or 460 volt power source. The polarized plug will match the voltage of the unit to the voltage of the damper activator (motor).

10. Replace the end panel (filter access panel) and secure with

screws saved from Step 4.

- 11. The motorized damper requires a field supplied and installed control. The control is to be connected to BR/1 and BR/3 wire leads in the unit electrical control compartment by the low voltage terminal board.
- 12. Place the power disconnect switch(es) in the "ON" position.



TAB PLACEMENT HERE

DE	SCRIPTION:
	Fresh Air
	Dampers
	Tab page did not contain hand written information
Ó	Tab page contained hand written information *Scanned as next image.

Confidential Records Management, Inc. New Bern, NC 1-888-622-4425 9/08



BLDG # AS-502 INSTALLER'S GUIDE

0-25% Fresh Air Dampers


Library	Service Literature
Product Section	Unitary
Product	Unitary Accessories
Model	Economizers, Dampers, Motors, Low Ambient
Literature Type	Installer's Guide
Sequence	25
Date	July 1985
File No.	SV-UN-ACC-DMPR-IN-25 785
Supersedes	

BAYDMPR023 (BTC/BWC090, 120 F-G)

- Remove the screws that secure the side panel of the return air section (panel has dimples). Save the screws for use in reinstalling the panel.
- 2. Remove the side panel by pulling out slightly and down.
- Drill 5/32" diameter engagement holes at each of the dimples in the panel.
- Cut a hole in the panel to the following dimensions to satisfy fresh air requirement (see diagram 1):

Fresh Air	Opening	Size
Requirements	Н	W
10%	25/16	29
15%	37/16	29
25%	63/8	29

- 5. Attach hood to panel with #10 thread forming screws.
- 6. Re-install panel on unit.
- The aluminum filter located in the hood may be removed for cleaning.



TAB PLACEMENT HERE

DE	SCRIPTION:
	Time Delay
	Rolay
	Tab page did not contain hand written information
M	Tab page contained hand written information

Confidential Records Management, Inc. New Bern, NC 1-888-622-4425 9/08

*Scanned as next image



INSTALLER'S GUIDE

ASCT-IN-3 18-HF10D2 1st Printing, 1984

TIME DELAY RELAY (BAY41X171A)


This accessory may be installed on any compressor bearing outdoor section using 24VAC contactor coil.


This accessory MUST be installed in a weather protected area within the unit cabinet, such as the control box, the fan orifice plate, etc.

BLDG #45-502

CAUTION:


BE SURE ALL POWER TO THE UNIT IS OFF BE-FORE REMOVING ANY PANELS OR GRILLES FROM THE UNIT.





Once the location has been determined, install the kit as follows:

- Use enclosed screws or back out any convenient screws and slip the slotted foot-plate (see Fig. 1) under the screw head, and retighten screw.
- 2. Wire the accessory according to the Connection Diagram in Fig. 2. (The spade terminals of the accessory are numbered as shown on the diagram).
- This time delay has dual (5 or 7 minute) time capability.
 For 5 minute delay connect brown jumper to terminals 5 and 6. For 7 minute time delay, jumper should be left disconnected.
- After completion of installation apply appropriate label denoting 5 or 7 minute time delay inside control panel. Secure all panels, grilles, etc., and restore power to unit.
- 5. Place unit in cooling mode and wait for stabilized running conditions. Turn thermostat to "OFF" momentarily and observe the "cycling-on" time (compressor should cycle on in 5 or 7 minutes after Evaporator fan cycles on).



TAB PLACEMENT HERE

DE	SCRIPTION:
	Quick Attach
	Coupling Vit
	Tab page did not contain hand written information
X	Tab page contained hand written information *Scanned as next image

Confidential Records Management, Inc. New Bern, NC 1-888-622-4425 9/08



INSTALLER'S GUIDE

BLD6 AS-502

ACCSY-IN-19 18-HE26D1 1st Printing, 1987


QUIK-ATTACH TO BRAZE COUPLING KITS BAY71X001A THRU 006A AND BAY71X011A, 012A


ALL phases of this installation must comply with NATIONAL, STATE, AND LOCAL CODES.

- These coupling kits are packaged in a plastic envelope. Remove couplings from envelope and check diaphram on ends of couplings for damage.
- 2. Attach coupling ends to indoor unit (or outdoor unit) perfollowing instructions.
 - a. Remove dust cap.
 - b. Make sure that no dirt or foreign material is permitted to get onto mating surfaces of coupling halves before connecting them together. Oil the face and threads of the coupling halves with clean refrigerant oil before mating.
 - c. Start tightening union nut by hand while holding tube rigid with the other hand.

NOTE: Keep pressure tap in upright position at all times.

- d. When union nut is securely anchored to coil, use holdback wrench on flats of base nut (see Figure 2 below) and with second wrench on union nut tighten until nut is seated. A firm metal to metal contact will be felt.
- e. Then advance the union nut another ¼ turn. This final turn is necessary to insure a proper metal seal of coupling halves, forming a leakproof joint. Do not continue to tighten the coupling as distortion of the coupling nut will result in a leak.
- After assembly of couplings, follow instructions shipped with outdoor unit to complete refrigerant piping installation.






Library	Service Literature					
Product Section	Unitary					
Product Unitary Accesso						
Model Miscellaneo						
Literature Type	Installer's Guid					
Sequence	19					
Date	August 1987					
File No.	SV-UN-ACC-ACCSY-IN-19 8/87					
Supersedes						

The Trane Company
Dealer Products Group
Troup Highway
Tyler, TX 75711
© American Standard Inc. 1987

TAB PLACEMENT HERE

DESCRIPTION:



- ☐ Tab page did not contain hand written information
- Tab page contained hand written information *Scanned as next image

Confidential Records Management, Inc. New Bern, NC 1-888-622-4425 9/08

BLDG# AS-3502



FILE INFORMATION
DIVISION TAB - TRANE REFRIGERATION
PRODUCTS
PRODUCT TAB - UNITARY SPLIT SYSTEM
AIR CONDITIONERS
MODEL TAB - Model Pauls


MODEL TAB - Model RAUB LITERATURE ITEM - Installation, Operation, Maintenance LITERATURE FILE NO.

RAUB-IOM-3

INST.-OPER.-MAIN.

Since the Trane Company has a policy of continuous product improvement, it reserves the right to change specifications and design without notice. The installation and servicing of the equipment referred to in this booklet should be done by qualified, experienced technicians.

MARCH 1983
Supersedes RAUB-IN-10
Dated November 1980,
RAUB-IN-10A Dated
March 1981, RAUB-IN-13
Dated January 1981,
and RAUB-M-10 Dated
November 1980



SPLIT SYSTEM CONDENSING UNITS

RAUB 20 THROUGH 60-TONS A, B, C DESIGN SEQUENCE


TABLE OF CONTENTS

ITEM	PAGE
MODEL NUMBER DESCRIPTION	
GENERAL INFORMATION	
INSTALLATION	
Shipping and Receiving	 6
Location and Clearances	
Foundation	
Handling and Rigging	
Pre-Installation Leak Test	
Refrigerant Piping	
Line Sizes	
Liquid Line Components	
Risers and Tube Routing	
Suction Line	
Refrigerant Piping Installation Instructions	 18
Units Mounted on Isolators	 20
Units Without Isolators	 20
Thermostatic Expansion Valve Selection	 29
Brazing, Leak Testing	 29
Electrical Wiring	 29
Electrical Data	
Thermostat Installation (Electronic Controls)	
Duct Sensor Installation	
Installation Checklist	 39
Pre-Start Checks	 39
Evacuation	
Refrigerant Charging	
Start-Up, Two-Step Controls	
Start-Up, Electronic Controls	
Initial Start-Up Checks	 40
Compressor Oil Charge	
Crankcase Heater	 40
Compressor Motor	 40
Voltage Imbalance	 40
Operating Pressures	 41
Expansion Valve Superheat	 41
Unloading Sequence	 41
Start-Up Log	 42

PERATION	43
System Control	43
Units Shipped With Two-Step Controls	43
Units Shipped with Electronic Thermostat Controls	43
RAUB/EVPA System	43
Fan Sequencing	44
Thermostats	44
Electrical Sequence of Operation	45
Control Settings	48
Safety and Operating Controls	48
MAINTENANCE	50
Periodic Maintenance	50
Maintenance Log	51
Shutdown and Start-up	52
Maintenance Procedures	52
Coil Cleaning	52
Control Testing	53
Evacuation Procedures	53
Leak Testing	54
Brazing Procedures	54
Brazing Procedures	54
Refrigerant Charging	54
Checking Refrigerant Charge	50
Operating Pressures	
Thermostatic Expansion Valve Adjustment and	00
Superheat Measurement	
Measuring Subcooling	67
Compressor Oil Charge	67
Troubleshooting	67

RAUB MODEL NUMBER DESCRIPTION

Trane products are identified by a multiple character model number that precisely identifies a particular type of unit. An explanation of the multiple character RAUB number is listed below to enable the owner or service engineer to define the specific operation, components and options.



RAUB UNIT NAMEPLATE

The RAUB unit nameplate is located in the upper left hand corner of the control box end of the unit. It lists the model number, electrical information, refrigerant type and charge, unit weight and other specific, important unit information.

TRANE AIR CONDITIONING
SERIAL NO
UNIT POWER SUPPLY RATED VOLTAGE
FACTORY CHARGE)-EACH SYSTEM LBS OF R-22 FIELD CHARGED-EACH SYSTEM LBS OF R-12 LBS OF R-22 UNIT WEIGHT DESIGN PRESSURE 405 PSIG TEST PRESSURE HIGH 450 PSIG LOW 300 PSIG
FOR CONTINUED EFFICIENT OPERATION OF THIS UNIT REFER TO OPERATION MAINTENANCE MANUAL THE TRANE COMPANY, LA CROSSE WISCONSIN 54601 MADE IN U.S.A. X39680091-01

GENERAL INFORMATION

Model RAUB condensing units are designed for outdoor mounting with a vertical air discharge. They are usually installed on a flat roof but can also be installed on a concrete slab at ground level. In either case, the unit must be installed so that it is level to within \pm 2-inches side to side and end to end. Each unit is leak-tested and evacuated at the factory, and shipped with a holding charge of Refrigerant-22. An access panel on the end of the unit provides access to the compressor section and a hinged door provides access to the control panel on the side of the unit. Table 1 provides general data.

NOTE: "Warnings" and "Cautions" appear at appropriate places in this instruction manual. Your personal safety and the proper operation of this machine require that you follow them carefully. The Trane Company assumes no liability for installations or servicing performed by unqualified personnel.

An Installation Checklist is provided at the end of the INSTALLA-TION section of this manual and should be completed after all installation procedures have been accomplished. Periodic Maintenance checklists are provided at the beginning of the MAINTENANCE section of this manual for performing recommended maintenance. These checklists should not be substituted for the detailed information given in appropriate sections of this manual.

A Start-Up Log is provided at the end of the START-UP section of this manual. Data should be entered in this log during initial start-up to ensure that the unit is operating properly and that all recommended checks have been completed. A Maintenance Log at the end of the "Periodic Maintenance" section enables the operator/serviceman to maintain a record of system operating data.

INSTALLATION

The installation information contained in this manual applies to the Model RAUB condensing unit only. Supplemental installation instructions are provided for the Model BRCB evaporator unit and for RAUB/EVPA and RAUB/VAV equipment. Refer to the following publications:

BRCB-M-1 for BRCB information.

RAUB-IN-11 for Model RAUB with EVPA control option.

RAUB-IN-12 for Model RAUB with VAV control option.

SHIPPING AND RECEIVING

Model RAUB condensing units are leak-tested and evacuated at the factory and then shipped with a holding charge of R-22 refrigerant. Inspect each unit as it is delivered to the job site for any intransit damage. All shipments are made F.O.B. Trane Company manufacturing plant, therefore claims for shipping damage must be filed with the delivering carrier.

To protect against loss from in-transit damage, complete the following upon receipt of the unit:

- Inspect individual pieces of the shipment before accepting. Check for rattles, bent corners, or other visible damage or indications of shipping damage.
- If a shipment has apparent damage, inspect it throughout before accepting. Make specific notations concerning the damage on the freight bill. Do not refuse delivery.
- Inspect the unit for concealed damage before it is stored and as soon as possible after delivery. Concealed damage must be reported within 15 days.
- Do not move damaged material from the receiving location. It
 is the receiver's responsibility to provide reasonable evidence that concealed damage did not occur after delivery.
- If concealed damage is discovered, stop uncrating the shipment. Retain all internal packing, cartons and crates. Take photographs of the damaged equipment, if possible.

- Notify the carrier's terminal of damage immediately by phone and by mail. Request a joint inspection of the damaged equipment immediately by the carrier and consignee.
- Notify the Trane sales representative of the damage and arrange for repair. Do not repair the unit, however, until damage is inspected by the carrier's representative.

Also, after receiving the unit, rotate the condenser fans manually to make sure that they rotate freely. Check for any materials shortage. If ordered, accessories ship in the positions shown in Figures 1 through 3.

Compare the data on the unit nameplate with the ordering and shipping information to verify that the correct unit has been received.

Before unit start-up, read this manual to become familiar with the unit and its operation.

LOCATION AND CLEARANCES

Refer to Figures 4 through 8 for detailed unit dimensions, connections and clearances.

Locate the condensing unit where air will flow without obstruction upward through the condensing coil and away from the fan discharge.

CAUTION: If unit is placed under an overhang, allow at least 6-feet of clearance above the unit to prevent recirculation of hot discharge air.

If the unit is being placed near a wall or other obstruction which may hinder airflow, the minimum condenser air clearances as shown in Figures 4 through 8 must be maintained. Increase the minimum condenser air clearance to 16 feet if:

- 1. The installation has obstructions on two or more sides.
- 2. The installation includes more than one unit (side by side installation).

If the condensing unit is to be installed in a well, increase the minimum condenser air clearance to 16 feet and make sure that the fan assemblies protrude out of the well and above ground level. Refer to Figure 9.

NOTE: FOUR FEET OF SERVICE CLEARANCE SHOULD BE MAINTAINED ON THE COMPRESSOR SIDE OF THE CONDENSING UNIT.

FOUNDATION

When the unit is about to be set on the ground, place it above the snow line and above any possible blowing debris. Provide concrete footings or foundation for support. Support is not needed around the total perimeter of the unit; only at the four or six mount-

ing feet around the unit. Construct the footings in accordance with the loading data given in Figures 4 through 8. Install isolators, if desired, or hold-down bolts in the footings to anchor the unit. Refer to Figures 10 and 11 for spring isolator and isolation pad selection and location. Figure 12 gives isolator dimensions.

For rooftop installations, make certain the roof is strong enough to adequately support the unit and to avoid the transmission of vibration. Table 1 lists unit operating weights. To reduce vibration transmission into the building, the use of isolators should be considered. Anchor the unit to the roof with hold-down bolts or isolators. Check with a roofing contractor for proper waterproofing installation practices to ensure that the roof does not develop leaks as a result of the unit weight, vibration or hot weather.




FIGURE 1 - Shipping Location of Accessories (RAUB 20 to 30)

TABLE 1 - General Data

IADEL	Gonora: Dan			RE	FRIGERANT			CONDENSE	R FANS	COMPRESSOR			
	UNIT WEIGHTS (LBS.)			HOLDING	OPERATING	PUMPDOWN	1	AND MO	rors			OIL CHG.	
				CHG.	CHG.	STORAGE		FAN DIA.	MOTOR	1		PER COMP	
MODEL	SHIPPING	OPERATING	TYPE	(LBS.)	(LBS.)	(LBS.)	NO.	(IN.)	HP (EA.)	NO.	TYPE	(PINTS) ²	
RAUB 20	1,765	1.745	R-22	1.3	28	67	2	26	1.0	1	Hermetic	19	
RAUB 25	1,945	1,925	R-22	1.3	31	76	3	26	1.0	1	Hermetic	19	
RAUB 30	2.155	2,145	R-22	1.5	40	96	3	26	1.0	1	Hermetic	19	
		3.090	R-22	1.31	291	681	4	26	1.0	2	Hermetic	19¹	
RAUB 40	3,140			100000000000000000000000000000000000000	311	711	6	26	1.0	2	Hermetic	191	
RAUB 50	3,620	3,660	R-22	1.31	Desire Table		10			2			
RAUB 60	3,770	3,720	R-22	1.51	401	921	6	26	1.0	12	Hermetic	191	

NOTE:

- 1. Per refrigeration system.
- 2. Assumes system tubing previously wetted with oil.




FIGURE 2 - Shipping Location of Accessories (RAUB 40)





FIGURE 3 - Shipping Location of Accessories (RAUB 50 and 60)






FIGURE 5 - Dimensional Data, RAUB-C25




FIGURE 6 - Dimensional Data, RAUB-C30




FIGURE 7 - Dimensional Data, RAUB-C40




FIGURE 8 - Dimensional Data, RAUB C50 and C60





FIGURE 9 - Well Installation



CP-1-27

CP-1-28

CP-1-26

CP-1-28

В FIGURE 10 - Spring Isolator Selection and Location

CP-1-27

CP-1-31

RAUB-C60




FIGURE 11 - Isolation Pad Selection and Location




FIGURE 12 - Isolator Dimensions

HANDLING AND RIGGING

All 20 through 60-ton RAUB units can be lifted with a fork truck provided that the middle shipping channels are left under the unit (refer to Figures 1 and 3). Any time a fork truck is used, the forks **must** protrude beyond the width of the unit.

Rig the unit using either belts or cable slings. The slings must be fastened to the unit at the four holes in the base of the unit, as shown in Figure 13. Use spreaders to protect the top of the unit when it is lifted. The point where the slings must meet at the lifting hook must be at least six feet above the unit. Refer to Figures 4 through 8 for center-of-gravity information and to Figure 13 for proper rigging procedures.

WARNING: TO PREVENT OVERSTRESSING THE BASE RAILS, THE UNIT SHOULD BE RIGGED AS SHOWN IN FIGURE 13 AND LIFTED AS SMOOTHLY AS POSSIBLE. FAILURE TO DO SO COULD RESULT IN SERIOUS PERSONAL INJURY AND DAMAGE TO THE UNIT.

PRE-INSTALLATION LEAK TEST

Trane condensing units and some evaporators are shipped with a holding charge of Refrigerant-22. Before installing these units, momentarily open the service port in either the suction or discharge line access valve to verify that the holding charge has not been lost.

If no refrigerant escapes when opening the service port, the condensing unit should be leak tested to determine the source of refrigerant loss. Pressurize the unit to 100 psi with refrigerant and use a halogen leak detector, halide torch or soap bubbles to check for leaks. If a leak is found, release the test pressure and repair the leak. If no leak is found, use nitrogen to increase the test pressure to 150 psi and repeat the leak tests. When repairing leaks, refer to BRAZING PROCEDURES in the MAINTENANCE PROCEDURES section of this manual. Retest the unit to make sure the problem has been corrected.

WARNING: DO NOT USE OXYGEN, ACETYLENE OR AIR IN PLACE OF REFRIGERANT AND DRY NITROGEN FOR LEAK TESTING. A VIOLENT EXPLOSION WILL RESULT WHICH COULD CAUSE SERIOUS PERSONAL INJURY OR DEATH.

REFRIGERANT PIPING

It is essential that refrigerant piping be properly sized and applied since these factors have a significant effect on system performance and reliability. The interconnecting piping must be selected and applied according to Trane recommendations and specifications on the job plan. This should have been completed when components were selected for the system.

RECOMMENDED LINE SIZES

If there is no job specification or piping layout, refer to the following recommendations.

The interconnecting line sizes are listed in Table 2. These tube sizes are within the velocity, pressure drop and refrigerant charge limitations necessary for proper system operation. (The refrigerant charge limitation is the maximum system charge for a specific compressor and is determined by the design of the compressor). The line lengths in Table 2 are based on pressure drop and refrigerant charge limitations in the **liquid line**. Pressure drop limits assume that equivalent length equals two times the physical length. In most applications this is a reasonable assump-




FIGURE 13 - Rigging

tion. However, actual pipe sizes must be calculated (see EB-S/S-38) if one or more of the following situations exist:

- LONG LIQUID RISER installations with liquid line risers have an added pressure drop of 0.5 psi per foot of riser. If the riser is more than 15-feet, the system may require a larger diameter and/or shorter piping run to ensure adequate subcooling at the expansion valve.
- EXCESSIVE BENDS, REDUCERS, VALVES a greater than normal number of tube bends, reducers, and/or valves may increase the equivalent length and pressure drop above the assumption of two times the physical length. Actual pressure drop should be calculated for these situations.

 LONG PIPING LENGTHS — for total piping lengths greater than the lengths given in Table 2, larger liquid lines may be required. However, guidelines specified in Engineering Bulletin EB-S/S-38 must be followed.

Trane recommends the use of Type L (medium wall) refrigerant tubing. Only refrigerant grade copper tubing should be used since it is available cleaned, dehydrated and capped to avoid contamination prior to installation. Copper tubing used for plumbing usually has oil, grease or other contaminants on the interior wall and these can cause serious operating problems if not removed prior to installation. Tube size recommendations in this manual are based on Type L (medium wall) tubing.

LIQUID LINE COMPONENTS

A properly sized liquid line filter drier must be installed upstream from the expansion valve. In addition, a moisture indicator/sight glass should be installed between the expansion valve and filter drier. Both of these components should be installed at the evaporator close to the expansion valve as shown in Figure 14.

The number of other valves, reducers and tube bends should be minimized as these items tend to increase the pressure drop and reduce subcooling at the expansion valve.

At least one liquid line solenoid valve must be installed on each refrigerant circuit. With unloaded compressor operation, max-

TABLE 2 - Interconnecting Line Sizes+

		LENGTH OF INTERCONNECTING LINES (FT)**																		
100	C	-20	2	1-40	4	1-60	61	1-80	81	-100	101	-120	121	-140	141	-160	161	-180	181	-200
CONDENSING		LINE SIZE — O.D. (IN.)																		
UNIT	LIQ	SUCT	LIQ	SUCT	LIQ	SUCT	LIQ	SUCT	LIQ	SUCT	LIQ	SUCT	LIQ	SUCT	LIQ	SUCT	LIQ	SUCT	LIQ	SUCT
RAUB-C20	5/8	15/8	5/8	15/8	5/8	15/8	5/8	21/8	5/6	21/8	7/8	21/6	7/6	21/6	7/6	2%	7/8	21/6	7/8	21/8
RAUB-C25	5/8	15/8	5/8	15/8	5/8	21/8	5%	21/8	7/8	21/8	7/8	21/8	7/8	21/8	7/8	21/8	7/8	21/4	-	-
RAUB-C30	7/8	15/8	7/8	21/8	7/8	21/8	7/8	27/8	7/8	21/8	7/8	21/8	7/8	21/8		-	-			-
RAUB-C40*	5/8	15/8	5/8	15/8	5/8	15⁄8	%	21/6	5/8	21/6	7/8	21/8	7/8	214	7/a	21/6	7/8	21/6	7/a	21/6
RAUB-C50*	5/8	15/8	5/8	15/8	5/8	21/8	5/8	21/8	7/8	21/8	7/8	21/8	7/8	21/8	7/8	21/6	7/8	21/8	-	-
RAUB-C60*	7/8	15/8	7/8	21/8	7/8	21/8	7/8	21/8	7/8	21/s	7/8	21/8	7/8	21/8						

^{*} Two line sets required.




FIGURE 14 - Diagram of Refrigerant Piping Components in Liquid Line

^{**} For vertical suction riser, suction line size in shaded region must either be reduced to 1%, or double riser must be utilized (see Engineering Bulletin EB-S/S-38).

⁺ Refer to Engineering Bulletin No. EB-S/S-38 for applications with liquid line riser greater than 15 feet, or for line lengths greater than listed in table.

imum system efficiency is achieved with a full evaporator coil. However, this can result in poor system moisture removal capacity. Generally, moisture removal is not a problem with 1/2 compressor loading, but can be of concern with RAUB 25 and 30 ton condensing units which unload to 1/3 capacity on each compressor. On these units, better moisture removal capacity can be achieved by separating the refrigerant coil into two equal sections and shutting off half of the coil when the compressor is at 1/3 loading.

Factory-installed solenoid valves are provided on BRCB evaporators to shut off one-half of the evaporator coil. When other air-to-air low sides are utilized a solenoid valve can be installed between the filter drier and sight glass in order to shut off one-half of the evaporator coil. On units where the solenoid valves are factory-installed, it is permissible to install the sight glass between the unit and the filter drier. However, all of these components should be installed close to the expansion valve and no more than one-half of the coil should be shut off.

Liquid line refrigerant velocities should be kept below 5-7 feet per second in order to prevent "liquid hammer" because of the liquid line solenoid valves. However, this is a secondary consideration, and it is more important to insure that compressor refrigerant charge limits are not exceeded.

RISERS AND TUBE ROUTING

Liquid line riser lengths are limited only by the additional pressure drop (0.5 psi/ft.) which results from the liquid column. No limit exists on the length of liquid line drops and no special line sloping considerations are necessary.

Normally it is not necessary or desirable to insulate liquid lines. In most applications the ambient temperature is lower than the refrigerant temperature and has the desirable effect of increasing subcooling at the expansion valve. However, liquid lines routed through extremely high ambient environments (such as a boiler room) may reduce subcooling to below acceptable levels. To minimize this loss, liquid lines passing through extremely warm

(above 110 F) areas should be insulated. Increasing liquid line size will only tend to aggravate this problem.

SUCTION LINE

The suction line sizes recommended in Table 2 will result in sufficient refrigerant vapor velocity to ensure good oil entrainment. It is also important to utilize good tube routing practices to ensure proper oil return to the compressor. Where suction lines must rise more than four feet, a "P" trap should be used at the base of the riser in order to facilitate oil return. This P-trap should be repeated for each 25 feet of riser. However, it is critical that no long traps be used which could accumulate significant quantities of oil. In other words, line traps should be constructed with no horizontal length in the bottom. Two street ells may be directly connected together to form this P-trap.

It is not recommended that horizontal suction lines be pitched towards the compressor. However, they should be reasonably level to prevent the oil from pooling in the line close to the compressor during the OFF cycle. Vertical risers should be no larger than 1-5/8-inch O.D. on 20 through 60-ton RAUB units even if horizontal runs are 2-1/8-inch O.D. If pressure drop in the 1-5/8-inch riser is unacceptable, double risers should be utilized as shown in Figure 15. In this case, the small riser should be 1-5/8-inch O.D. and the large riser should be 2-1/8-inch O.D. On dual compressor 40-60 ton RAUB units, some of the compressors may not unload. In this case, a 2-1/8 inch suction line riser is acceptable.

Insulate the suction line with 1/2-inch thick closed cell neoprene insulation such as Armaflex or similar material. Do not run the suction and liquid line in contact with each other without insulation between them.

REFRIGERANT PIPING INSTALLATION INSTRUCTIONS

One of two methods may be used to properly route piping within the unit. The first method requires the use of unit isolators, yet provides a direct and flexible means of routing the piping. The second method does not require isolators, but necessitates cutting holes in the unit's cabinetry. It also does not offer as much routing flexibility as the first method.




FIGURE 15 - Double Riser Suction Line




FIGURE 16 - Liquid Line(s) Piping (40, 50 and 60-Ton Units)




FIGURE 17 - Suction Line(s) Piping

NOTE: In addition to the following instructions, the refrigerant piping should be installed in accordance with the discussion presented in Engineering Bulletin EB-S/S-38 and this manual.

IMPORTANT: Leave a 4 to 5-foot clearance in front of the compressor section for compressor removal.

Units Mounted On Isolators

Field refrigerant piping can be routed under the framework on units equipped with isolators. Piping the unit in this manner takes a minimum amount of copper and allows the flexibility of running the piping unobstructed in any direction once it is dropped below the unit framework. A 5-1/2-inch minimum clearance must be provided between the unit base and the isolator base for routing insulated suction line. Units equipped with spring isolators have sufficient clearance, however, units equipped with neoprene isolators will need 4-inch blocks placed under each isolator to meet the specified clearance.

RAUB 20 to 60-ton condensing units have refrigerant connections at the liquid line stubs and at the compressor suction service valves. Figure 18 illustrates the connection points in the 20, 25 and 30-ton units and Figure 19 shows the points in the 40, 50 and 60-ton machines.

Procedure:

- 1. Remove all decorative grilles from the unit.
- 2. Release the unit's holding charge.
- Remove the suction flange(s) and closure plates from the suction service valve(s).
- 4. Remove the cap(s) from the liquid line stub connections.
- Proceed to pipe the liquid line(s) as shown in Figures 18 and19.
- Two 90-degree elbows are required to drop each liquid line below the unit framework. Once the drop is made, run the liquid line(s) to the desired location in accordance with the guidelines presented in the Trane Engineering Bulletin EB-S/S-38 and this manual.
 - Allow at least a 1-1/2-inch clearance between the liquid line(s) and any surface or obstruction to prevent direct line contact and possible noise transmission.
 - Clamp the liquid line(s) at a location no less than 3-feet and no more than 6-feet from the stub locations.
- Once the liquid line(s) has been formed, braze all connections.
- Proceed to pipe the suction line(s) as shown in Figures 18 and 19.

WARNING: NEVER USE A TORCH ON A REFRIGERANT LINE UNTIL IT HAS BEEN DETERMINED THAT ALL GAS HAS BEEN ELIMINATED FROM THE LINE – UNSAFE PRESSURES COULD RESULT CAUSING A VIOLENT EXPLOSION AND SERIOUS PERSONAL INJURY OR DEATH. BE SURE THE AREA IS WELL VENTILATED.

CAUTION: Pump dry nitrogen through the system refrigeration piping whenever brazing is in progress. Failure to do this will permit oxides to form and accumulate in the refrigerant system resulting in equipment damage.

Run the suction line(s) vertically downward to the base of the unit.

- A 90-degree elbow will be required to run each suction line horizontally below the unit framework.
- Run the suction line(s) to the desired location in accordance with the guidelines presented in Trane Engineering Bulletin EB-S/S-38 and this manual.
 - Allow at least a 1-1/2-inch clearance between the line(s) and any surface or obstruction to prevent direct line contact and possible noise transmission.
 - Clamp the line(s) at a location no less than 10-feet and no more than 15-feet from the suction service valve(s) to prevent noise transmission and provide adequate support.
- With each suction valve coupling removed from its service valve, braze the coupling to the suction line.

WARNING: NEVER USE A TORCH ON A REFRIGERANT LINE UNTIL IT HAS BEEN DETERMINED THAT ALL GAS HAS BEEN ELIMINATED FROM THE LINE — UNSAFE PRESSURES WOULD RESULT CAUSING AN EXPLOSION AND SERIOUS PERSONAL INJURY OR DEATH. BE SURE THE AREA IS WELL VENTILATED.

CAUTION: Pump dry nitrogen through the system refrigerant piping whenever brazing is in progress. Failure to do this will permit oxides to form and accumulate in the refrigerant system resulting in equipment damage.

- 13. Bolt each suction line up to its service valve and reposition the line.
- Proceed brazing the connections with the line in place or with the connections referenced and the line removed.

Units Without Isolators

Units shipped without vibration isolators will need holes cut in the cabinetry in order to route field refrigerant piping. The following procedure should be used.

20 to 30-Ton Units

- Remove the decorative grilles enclosing the compressor section
- 2. Release the unit's holding charge.
- Remove the suction flange and closure plates from the suction service valve.
- 4. Remove the cap from the liquid line stub connection.
- Cut holes in the center support and filler post as shown in Figure 20.
- 6. Pipe the liquid line as illustrated in Figure 21.
- Run the liquid line through the appropriate hole location using two lengths of liquid line, one coupling and one 90degree elbow.
- 8. Center the line in the opening.
- Clamp the liquid line to the unit base rail just ahead of the notched out hole.
- Run the line to the desired location and proceed brazing the connections with the line in place or with the connections referenced and the line removed.




FIGURE 18 - Piping Installation: 20 Through 30-Ton Units With Isolators




FIGURE 19 - Piping Installation: 40 Through 60-Ton Units Equipped With Isolators




FIGURE 20 - Hole Locations: 20 Through 30-Ton Units

WARNING: NEVER USE A TORCH ON A REFRIGERANT LINE UNTIL IT HAS BEEN DETERMINED THAT ALL GAS HAS BEEN ELIMINATED FROM THE LINE – UNSAFE PRESSURES COULD RESULT CAUSING A VIOLENT EXPLOSION AND SERIOUS PERSONAL INJURY OR DEATH. BE SURE THE AREA IS WELL VENTILATED.

CAUTION: Pump dry nitrogen through the system refrigerant piping whenever brazing is in progress. Failure to do this will permit oxides to form and accumulate in the refrigerant system which may cause damage to the refrigeration system.

- 11. Proceed piping the suction lines as shown in Figure 21.
- Pipe the line through the appropriate hole, using two lengths of pipe, a short radius street elbow and a 45-degree elbow. See Figure 21.
- 13. Center the suction line in the hole.
- Run the line to the desired location in accordance with the guidelines presented in Trane Engineering Bulletin EB-S/S-38 and this manual.
 - a. Allow at least a 1-1/2-inch clearance between the liquid

- line(s) and any surface or obstruction to prevent direct line contact and possible noise transmission.
- Clamp the liquid line(s) at a location no less than 3 feet and no more than 6 feet from the stub locations.
- 15. With each suction valve coupling removed from its service valve, braze the coupling to its respective suction line.

WARNING: NEVER USE A TORCH ON A REFRIGERANT LINE UNTIL IT HAS BEEN DETERMINED THAT ALL GAS HAS BEEN ELIMINATED FROM THE LINE – UNSAFE PRESSURES COULD RESULT. BE SURE THE AREA IS WELL VENTILATED.

CAUTION: Pump dry nitrogen through the system refrigerant piping whenever brazing is in progress. Failure to do this will permit oxides to form and accumulate in the refrigerant system which may cause damage to the refrigeration system.

- Bolt each suction line up to its service valve and reposition the line(s).
- Finish brazing the connections with the line in place or with the connections referenced and the line removed.






FIGURE 21 - Piping Installation: 20 Through 30-Ton Units Without Isolators




FIGURE 22 - Suction Line Hole Locations: 40 Through 60-Ton Units Without Isolators

40 to 60-Ton Units

- Remove the decorative grilles enclosing the compressor section and the liquid line stub locations.
- 2. Release the unit's holding charge.
- Remove the suction flanges and closure plates from the suction service valves.
- 4. Remove the caps from the liquid line stub connections.
- Cut holes in the filler and condenser section end panels as illustrated in Figures 22 and 23.
- 6. Proceed to pipe the liquid lines as shown in Figures 24 and
- Pipe the liquid lines through the two holes, using two couplings and straight lengths of pipe.
- 8. Center the lines in their respective holes.
- Clamp both liquid lines to the unit's base just ahead of the notched out holes with standard straps and sheet metal screws.
- Run the lines to the desired location in accordance with the guidelines presented in Trane Engineering Bulletin EB-S/S-38 and this manual. Proceed to braze the connections with

the lines in place or with the connections referenced and the lines removed.

WARNING: NEVER USE A TORCH ON A REFRIGERANT LINE UNTIL IT HAS BEEN DETERMINED THAT ALL GAS HAS BEEN ELIMINATED FROM THE LINE - UNSAFE PRESSURES COULD RESULT. BE SURE THE AREA IS WELL VENTILATED. FAILURE TO OBSERVE THESE PRECAUTIONS COULD RESULT IN SERIOUS PERSONAL INJURY.

CAUTION: Pump dry nitrogen through the system refrigerant piping whenever brazing is in progress. Failure to do this will permit oxides to form and accumulate in the refrigerant system which may cause damage to the refrigeration system.

- 11. Provide no less than 3 feet and no more than 6 feet of line between the unit and the first clamp location to prevent noise transmission and also to provide adequate support.
- Cut holes in the compressor section filler panels as shown in Figures 22 and 23. The hole locations will vary with unit tonnage.
- Proceed to pipe the suction lines as illustrated in Figures 24 and 25.
- 14. Pipe the suction lines through each hole, using two pipe lengths, a 90-degree street elbow and a 45-degree elbow for each line.




FIGURE 23 - Liquid Line Hole Locations: 40 Through 60-Ton Units Without Isolators

- 15. Center each suction line in its respective hole.
- Run the lines to the desired location in accordance with the guidelines presented in the Trane Engineering Bulletin EB-S/S-38 and this manual.
 - Allow at least 1-1/2-inch clearance between the lines and any surface or obstruction to prevent direct line contact.
 - b. To prevent noise transmission and provide adequate support, allow no less than 10-feet and no more than 15feet of suction line between the suction service valves and the first clamp locations.
- 17. With each suction service valve coupling removed from its valve, braze each coupling to its respective suction line.

WARNING: NEVER USE A TORCH ON A REFRIGERANT LINE UNTIL IT HAS BEEN DETERMINED THAT ALL GAS HAS BEEN ELIMINATED FROM THE LINE – UNSAFE PRESSURES COULD RESULT CAUSING A VIOLENT EXPLOSION AND SERIOUS PERSONAL INJURY OR DEATH. BE SURE THE AREA IS WELL VENTILATED.

CAUTION: Pump dry nitrogen through the system refrigerant piping whenever brazing is in progress. Failure to do this will permit oxides to form and accumulate in the refrigerant system which may cause damage to the refrigeration system.

- Bolt each suction line up to its service valve and reposition the lines.
- Proceed to braze the connections with the lines in place or with the connections referenced and the lines removed.





FIGURE 24 - Piping Installation: 40-Ton Units Without Isolators








FIGURE 25 - Piping Installation: 50 and 60-Ton Units Without Isolators

THERMOSTATIC EXPANSION VALVE SELECTION

The thermostatic expansion valve is a modulating valve designed to regulate the rate of refrigerant flow into the evaporator in exact proportion to the rate of refrigerant evaporation. This can be done such that refrigerant superheat leaving the evaporator is held relatively constant. In order to maximize compressor reliability, Trane recommends that expansion valves be adjusted to achieve approximately 12 F superheat leaving the evaporator at rating point conditions (80/67 - 95 F). Refer to "Thermostatic Expansion Valve Adjustment and Superheat Measurement" in the MAINTENANCE PROCEDURES section of this manual for the recommended superheat adjustment procedures.

Trane recommends that externally equalized valves be utilized in order to compensate for pressure drop between the expansion valve and superheat control point at the evaporator outlet.

Thermostatic expansion valves are more likely to hunt at low system versus valve capacity conditions where the valve pin is close to the valve seat. This is more pronounced on larger tonnage valves and on systems with unloading compressors. Both major expansion valve manufacturers have a balance-ported valve which tend to overcome this problem. The Trane Company recommends this feature (when valve sizing allows) in order to maintain satisfactory superheat control down to lower valve loading conditions.

Various bulb charges are available and are described in valve supplier catalogs. Trane recommends the use of VGA charge (Sporlan) or straight W charge (Alco) on RAUB 20 through 60-ton systems. These charges provide smooth control at air conditioning conditions and are less prone to charge migration than the conventional gas charge.

Thermostatic expansion valves are rated by the valve manufacturer in accordance with A.R.I. Standard 750 and A.N.S.I. Standard B60.1. Capacity application ratings (tons) are given for varying evaporator suction temperatures (F) and valve pressure drops (PSI). Catalog values assume liquid entering the valve at all times and a liquid temperature of 100 F. Correction factors are provided for liquid temperatures other than 100 F.

Thermostatic expansion valves must be selected considering actual operating conditions rather than nominal valve and system capacities. Valve capacity is a function of evaporator saturated suction temperature leaving the evaporator, liquid temperature entering the expansion valve, and valve pressure drop. Pressure drop across the valve is the difference between compressor discharge and suction pressures, less pressure drops in the discharge line, condenser, subcooler, liquid line, suction line, evaporator, distributor tubes and distributor. Valves should normally be selected so that actual system capacity is 70 to 100 percent of valve rated capacity at design conditions.

Normally, the factory superheat setting (static superheat) is made with the valve pin starting to move away from the seat. Valves are generally designed so that an increase in superheat from 4 to 6 F

over the factory static superheat setting is necessary for the valve pin to open to its rated position. Valves in this size range are rated at approximately 75 percent of full stroke to provide a reserve. Valves with a balance port feature can provide satisfactory control with loads 15 to 25 percent of nominal valve capacity.

Recommended expansion valve selections for RAUB 20 through 60-ton systems are given in Table 3. These selections assume two expansion valves per evaporator and Trane Type F coils which have Alco venturi type distributors. Other assumptions are detailed in Table 3.

CAUTION: For proper performance, consult the valve manufacturers catalog for valve and distributor installation recommendations, or for valve sizing procedures on systems with a different configuration than assumed in Table 3.

BRAZING AND LEAK TESTING

For proper brazing techniques when installing refrigerant tubing, refer to BRAZING PROCEDURES in the MAINTENANCE section of this manual.

After completing the installation of all refrigerant piping, the system should be thoroughly checked for possible leaks. Refer to LEAK TESTING in the MAINTENANCE section of this manual.

ELECTRICAL WIRING

WARNING: BEFORE WORKING ON THIS OR ANY ELECTRICAL EQUIPMENT, DISCONNECT ALL ELECTRICAL POWER. FAILURE TO DO SO MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH DUE TO ACCIDENTAL ELECTRIC SHOCK.

Install all electrical wiring in conformance with local and national electrical codes. Ground the unit in accordance with local codes. A grounding lug is provided in the unit control panel. Make certain that all connection and contactor lugs are tight.

Figures 26 and 27 illustrate typical field wiring required for 20 through 60 ton Model RAUB condensing units with standard controls. Figures 28 through 31 illustrate typical field wiring for 20 through 60 ton units with electronic controls.

NOTE: THESE DIAGRAMS ARE "TYPICAL FIELD WIRING" ONLY. THE ACTUAL AS WIRED DIAGRAMS FOR YOUR UNIT, INCLUDING FIELD WIRING AND CONNECTION AND SCHEMATIC WIRING DIAGRAMS, ARE LOCATED INSIDE THE MAIN CONTROL PANEL ACCESS DOOR.

ELECTRICAL DATA

Table 4 lists the electrical characteristics for RAUB 20 through 60-ton units.

CAUTION: The Trane Company recommends only the use of copper conductors with this equipment. Use of other than copper conductors may result in galvanic corrosion and possible damage to the equipment.

TABLE 3 - Recommended Expansion Valve Selections

CONDENSING UNIT	NO. OF	NO. OF		SPORLAN SELEC	ALCO SELECTION			
MODEL NO.	VALVES	CIRC.	VALVE NO.	INLET (ODF)	OUTLET (ODF)	VALVE NO.	INLET (ODF)	OUTLET (ODF)
RAUB-C20	2	8	OVE-10-VGA	5/8	7/s, 11/s	TRAE10HW	56 - 136	7/8 - 13/8
RAUB-C25	2	12	OVE-15-VGA	7/8	11/8	TRAE15HW	5% - 13%	7/8 - 13/8
RAUB-C30	2	12	OVE-15-VGA	7/8	11/8	TRAE15HW	5% - 13%	76 - 136
RAUB-C40	2	16	OVE-20-VGA	7/8	13/8	TRAE20HW	5% - 13%	7/8 - 13/8
RAUB-C50	2	18	OVE-30-VGA	11/8	13/8	TRAE30HW	5/8 - 13/8	7/8 - 13/8
RAUB-C60	2	20	OVE-30-VGA	11/8	13/6	TRAE30HW	5% - 13%	78 - 13/8

- 1. Assumes 2 ALCO venturi type distributors and 5/16" x 30" distributor tubes.
- 2. Assumes coil sized to provide between 35 F and 45 F saturated suction at rating point condition (80/67 95 F).
- 3. Assumes liquid lines and components sized within guidelines specified in Trane Engineering Bulletin EB-S/S-38 on interconnecting lines.

TABLE 4 - Electrical Data

		COMPRESSOR MOTOR					CONDENSER FAN MOTOR					UNIT CHARACTERISTICS®			
MODEL	UNIT VOLTAGE ¹	NO.	FILAZ	LRA2 3 9	KW INPUT ²⁷	NO.	HP (EA.)	RLA ²	LRA2	KW INPUT ²	UNIT	MAX. FUSE SIZE	MIN. CIRCUIT AMP.5	RECOMMENDED DUAL ELEMENT FUSE SIZE®	
RAUB-C206	200/60/3	1	75.4	396	22.1	2	1.0	4.1	20.7	0.95	81.8	175	102.5	110	
RAUB-C203	230/60/3	1	65.6	344	22.1	2	1.0	3.6	18.0	0.95	71.2	150	89.2	100	
RAUB-C201	460/60/3	1	32.8	172	22.1	2	1.0	1.8	9.0	0.95	35.6	70	44.6	50	
RAUB-C204	460/60/3	1	32.8	172	22.1	2	1.0	1.8	9.0	0.95	35.6	70	44.6	50	
RAUB-C202	575/60/3	1	26.2	138	22.1	2	1.0	1.4	7.2	0.95	28.4	60	35.6	40	
RAUB-C20A	380/50/3	1	34.0	166	18.1	2	0.7	1.6	8.0	0.70	35.2	70	45.7	50	
RAUB-C20B	415/50/3	1	31.1	181	18.1	2	0.7	1.7	7.5	0.70	32.3	70	42.3	50	
RAUB-C256	200/60/3	1	91.5	426	27.2	3	1.0	4.1	20.7	0.95	101.8	200	126.7	150	
RAUB-C253	230/60/3	1	79.6	370	27.2	3	1.0	3.6	18.0	0.95	88.6	175	110.3	125	
RAUB-C251	460/60/3	1	39.8	185	27.2	3	1.0	1.8	9.0	0.95	44.3	90	55.2	60	
RAUB-C254	460/60/3	1	39.8	185	27.2	3	1.0	1.8	9.0	0.95	44.3	90	55.2	60	
RAUB-C252	575/60/3	1	31.8	148	27.2	3	1.0	1.4	7.2	0.95	35.3	70	44.0	50	
RAUB-C25A	380/50/3	1	41.5	178	21.8	3	0.7	1.6	8.0	0.70	43.7	90	56.7		
RAUB-C25B	415/50/3	1	38.0	195	21.8	3	0.7	1.7	7.5	0.70	40.1	90	52.6	60 60	
RAUB-C306	200/60/3	1	109.0	489	32.5	3	1.0	4.1	20.7	0.95	121.8				
RAUB-C303	230/60/3	1	94.8	425	32.5	3	1.0	3.6	18.0	the second secon	1.1	250	148.6	175	
RAUB-C301	460/60/3	1	47.4	213	32.5	3	1.0	1.8		0.95	106.0	200	129.3	150	
RAUB-C304	460/60/3	1	47.4	213	32.5	3	1.0	1.8	9.0	0.95	53.0	110	64.7	70	
RAUB-C302	575/60/3	i	37.9	170	32.5	3	1.0	1.4	9.0 7.2	0.95	53.0	110	64.7	70	
RAUB-C30A	380/50/3	1	50.0	205	26.2	3	0.7	1.6	8.0	0.95	42.3	80	51.6	60	
RAUB-C30B	415/50/3	1	45.8	224	26.2	3	0.7	1.7	7.5	0.70	52.3 48.0	110	67.3	80	
RAUB-C406	200/60/3	2	75.4	396	22.1	4					-		62.4	70	
RAUB-C403	230/60/3	2	65.6	344	22.1		1.0	4.1	20.7	0.95	163.6	250	186.1	200	
RAUB-C401	460/60/3	2	32.8	172	22.1	4	1.0	3.6	18.0	0.95	142.4	225	162.0	175	
RAUB-C404	460/60/3	2	32.8	172	22.1	4	1.0	1.8	9.0	0.95	71.2	110	81.0	90	
RAUB-C402	575/60/3	2	26.2	138	22.1		1.0	1.8	9.0	0.95	71.2	110	81.0	90	
RAUB-C40A	380/50/3	2	34.0	166		4	1.0	1.4	7.2	0.95	56.8	90	64.6	70	
RAUB-C40B	415/50/3	2	31.1	181	18.0	4	0.7	1.6	8.0	0.70	70.2	110	82.9	90	
					18.0	4	0.7	1.7	7.5	0.70	64.4	100	76.8	80	
RAUB-C506	200/60/3	2	91.5	426	27.2	6	1.0	4.1	20.7	0.95	203.6	300	230.5	250	
RAUB-C503	230/60/3	2	79.6	370	27.2	6	1.0	3.6	18.0	0.95	177.2	250	200.7	200	
RAUB-C501	460/60/3	2	39.8	185	27.2	6	1.0	1.8	9.0	0.95	88.6	125	100.4	110	
RAUB-C504	460/60/3	2	39.8	185	27.2	6	1.0	1.8	9.0	0.95	88.6	125	100.4	110	
RAUB-C502	575/60/3	2	31.8	148	27.2	6	1.0	1.4	7.2	0.95	70.6	110	80.0	80	
RAUB-C50A	380/50/3	2	41.5	178	21.7	6	0.7	1.6	8.0	0.70	87.4	125	103.0	110	
RAUB-C50B	415/50/3	2	38.0	195	21.7	6	0.7	1.7	7.5	0.70	80.2	125	95.7	100	
RAUB-C606	200/60/3	2	109.0	489	32.5	6	1.0	4.1	20.7	0.95	243.6	350	269.9	300	
RAUB-C603	230/60/3	2	94.8	425	32.5	6	1.0	3.6	18.0	0.95	212.0	300	234.9	250	
RAUB-C601	560/60/3	2	47.4	213	32.5	6	1.0	1.8	9.0	0.95	106.0	150	117.5	125	
RAUB-C604	460/60/3	2	47.4	213	32.5	6	1.0	1.8	9.0	0.95	106.0	150	117.5	125	
RAUB-C602	575/60/3	2	37.9	170	32.5	6	1.0	1.4	7.2	0.95	84.6	125	93.7	100	
RAUB-C60A	380/50/3	2	50.0	205	26.2	6	0.7	1.6	8.0	0.70	104.6	150	122.1	125	
RAUB-C60B	415/50/3	2	45.8	224	26.2	6	0.7	1.7	7.5	0.70	96.0	150	113.3	125	

- 1. Voltage is three phase, 60 or 50 hertz. Range is plus or minus 10 percent of nominal voltage.
- 2. Electrical information is for each individual motor.
- 3. Part winding starters standard on all 200 and 230-volt units for incremental start.
- 4. Maximum fuse size permitted by N.E.C. 440-22 is 225 percent of one compressor motor RLA plus the total RLA of the other motors in circuit. Select the next smaller standard
- 5. Minimum circuit ampacity equals the RLA of one compressor times 1.25 plus the total RLA of the remaining motors.
- 6. Local codes may take precedence.
- 7. Compressor kw at 95 F ambient and 45 F saturated suction temperature.
- 8. Recommended dual element fuse size is 150 percent of the RLA of one compressor plus the RLA of the remaining motors. Select the next smaller fuse size unless the number exceeds the next smaller fuse size plus 90 percent of the increment to the next larger fuse. If so, then select the next larger fuse size.
- 9. All unit voltages use part winding starters except the 460/60/3 which may be either part winding starter or across the line starter. All unit nameplates will show only across the line locked rotor amps.




FIGURE 26 - Field Wiring, Two Step Controls (20, 25 and 30-Ton Units)






FIGURE 27 - Field Wiring: Two Step Controls (40, 50 and 60-Ton Units)




FIGURE 28 - Field Wiring, Electronic Thermostat Controls (20, 25 and 30-Ton Units)




FIGURE 29 - Field Wiring, Electronic Thermostat Controls (40, 50 and 60-Ton Units)




FIGURE 30 - Field Wiring, Multi-Step Controls (25 and 30-Ton Units)








FIGURE 31 - Field Wiring, Multi-Step Controls, (40, 50 and 60-Ton Units)



IGURE 32 - Control Panel (20, 25 and 30-Ton Units)



THERMOSTAT INSTALLATION (ELECTRONIC THERMOSTAT CONTROLS)

Recommended wire sizes and lengths for installing the unit thermostat (24 VAC circuit) are provided in Table 5. The total resistance of these low voltage wires must not exceed one ohm. Any resistance in excess of one ohm may cause the control circuit to malfunction.

TABLE 5 - Recommended Thermostat Wire Size

WIRE GAUGE	MAXIMUM WIRE LENGTH
22 Gauge	30 Ft.
20 Gauge	50 Ft.
18 Gauge	75 Ft.
16 Gauge	125 Ft.
14 Gauge	200 Ft.

When selecting a thermostat location, be sure to choose a site in a frequently occupied area with good air circulation at an average temperature. The thermostat should be positioned approximately five feet above the floor.

Avoid mounting the thermostat in areas subject to the following:

- drafts or "dead" spots behind doors or in corners:
- hot or cold air from ducts:
- radiant heat from the sun, or from appliances;
- concealed pipes and chimneys;
- unheated or uncooled surfaces behind the thermostat, such as outside walls;
- in an area where the thermostat will be affected by a unit in another zone.

CAUTION: If an energy management device, time clock, or other power consuming device is used, a separate power supply must be provided for that device. Do not use the unit control circuitry, or damage to the unit may result.

DUCT SENSOR INSTALLATION (ELECTRONIC THERMOSTAT CONTROL)

All units with electronic thermostat control are shipped with a duct sensor which must be installed for proper unit operation. Refer to Figure 34 for duct sensor dimensions. Resistor R1 is factory installed and serves a protective function in the event the duct




FIGURE 34 - Duct Sensor Dimensions




FIGURE 35 - Duct Sensor Assembly

sensor is not installed. Use the following procedure when installing the duct sensor:

- Remove resistor 1R1 from Terminals 1TB5-11 and 1TB5-12.
- Mount the duct sensor (2RT1) in an average temperature location at the outlet of the supply air ductwork. See Figure 35. If an economizer or heating section is incorporated in the system, the duct sensor must be located downstream (after mixing has occurred).
- 3. Connect the leads of the duct sensor across terminals 1TB5-11 and 1TB5-12.

NOTE: When an economizer is being used with these controls, the duct sensor must be installed.

INSTALLATION CHECKLIST

Complete this checklist as the unit is installed to verify that all recommended installation procedures are accomplished before the unit is started. This checklist does not replace the detailed instructions provided in the INSTALLATION section of this manual. Read the entire section carefully to become familiar with the installation procedures before installing the unit.

HE	CEIVING
	Unit nameplate data corresponds with ordering information. Unit inspected for shipping damage and claim filed, if necessary.
	Unit checked for material shortage and any shortages reported.
NΝ	IT LOCATION
	Condenser air clearances over unit good. Service clearances around unit good. Unit secured in correct location.
RE	FRIGERANT PIPING
	Liquid line sized properly and within recommended maximum line length. Suction line sized properly.
	Thermostatic expansion valve properly sized and installed

ELECTRICAL WIRING

filter drier.

close to evaporator.

Field installed wiring complies will all applicable codes. Compressor contactor and terminal block lugs checked for tightness.

Liquid line filter drier installed near expansion valve. Sight glass installed in liquid line between evaporator and

Low ambient accessories installed, if necessary. Check all unit and piping connections for leaks.

Thermostat properly mounted and wired.

Any other accessories properly installed and wired.

Grounding wires securely bonded to earth ground.

Duct sensor(s) properly installed (units with electronic ther-mostat controls or supply air controls).

PRE-START CHECKS

Before starting the unit, complete the procedures outlined below to make sure that the unit is properly installed and ready for startup.

WARNING: OPEN THE UNIT DISCONNECT SWITCH AND LOCK IT IN THAT POSITION TO PREVENT ACCIDENTAL START-UP. NEVER OPEN AN ACCESS PANEL TO INSPECT OR SERVICE THE UNIT WITHOUT FIRST OPENING THE DIS-CONNECT SWITCH, FAILURE TO DO SO MAY RESULT IN INJURY OR DEATH DUE TO ACCIDENTAL ELECTRICAL SHOCK OR ENTANGLEMENT IN MOVING PARTS.

- 1. Inspect all electrical connections to be sure that the wires are securely attached to their terminals. Make sure that all wires are clear of any rotating parts such as fan blades.
- 2. Check the condenser and evaporator fans. Fan blades must be secure on the motor shafts and must rotate freely. Airflow must be unobstructed.
- 3. Make sure the evaporator air filters are clean.
- 4. Check the evaporator and condenser coils to ensure that they are clean, that the fins are straight, and that there are no obstructions to airflow.
- 5. Check the voltage at the line side of the disconnect switch. The voltage must be within 10 percent of the unit nameplate voltage.
- 6. Check the compressor oil level sight glass. If oil is not visible and the unit has not yet been operated, add oil. The oil level must be visible in the sight glasses. If the unit has been operated and no oil is visible, determine the reason for the shortage before adding oil.

EVACUATION

After completing the PRE-START CHECKS use a vacuum pump to remove air, moisture and contaminants from the system. The system should be evacuated to a pressure of 500 microns or less. Refer to EVACUATION PROCEDURES in the MAINTENANCE PROCEDURES section of this manual.

REFRIGERANT CHARGING

With the system properly evacuated, determine the required charge of Refrigerant-22 and charge the system as outlined under REFRIGERANT CHARGING in the MAINTENANCE PROCEDURES section of this manual.

START-UP, TWO-STEP CONTROLS

Set the room thermostat as follows to start the unit:

- 1. Turn the System Control switch to cool.
- 2. Set the thermostat at a point below room temperature.

The unit will operate automatically in response to cooling needs as determined by the thermostat setting.

START-UP, ELECTRONIC THERMOSTAT CONTROLS

To start the system:

- Close the unit disconnect switch.
- 2. Place the thermostat sub-base fan switch in the AUTO position. Fan operation is continuous in the ON or AUTO position.
- 3. Place the thermostat sub-base system switch in the COOL position.

- Lower the room thermostat to a setting below the room temperature.
- 5. Close the control circuit switch 1S1.

The unit will operate automatically in response to the cooling needs as determined by the thermostat setting.

INITIAL START-UP CHECKS

Compressor Oil Charge

Proper oil charge is critical for reliable operation of reciprocating compressors. Both undercharging and overcharging will result in compressor damage.

On most applications, the factory oil charge is correct and no addition of oil is required. However, it may be necessary to add oil to systems which have extremely long interconnecting lines.

An oil level sight glass is provided integral to the compressor shell in order to confirm proper oil charge on all 20 through 60-ton units. The following procedure should be followed:

- Check the oil level prior to initial refrigerant charging and start-up of a new system. To be proper, the oil level must be visible in the sight glass. Note the oil level mark for future reference.
- Approximately one hour after initial start-up and after the oil sump is warm to the touch, check the oil level with the compressor running fully loaded. The oil level must be visible in the sight glass. If it is not visible, add oil until the level is halfway up the sight glass.

CAUTION: Do not attempt to check the oil level at part load compressor operation. It is not intended that the oil level be visible in the sight glass under these conditions. Adding oil could result in a compressor oil overcharge and subsequent compressor damage.

Allow the compressor to run at full load until the oil sump is warm to the touch. If the oil level increases from Step 2, oil should be removed and the process repeated until the sight glass level remains at the halfway mark.

CAUTION: Checking oil level with a cold sump can incorrectly indicate excess oil in the sump due to refrigerant in the oil.

Crankcase Heater

Normally, it is not necessary to energize the crankcase heater prior to **initial start-up.** However, if more than 30-minutes has elapsed between refrigerant charging and start-up a significant amount of refrigerant could migrate to the compressor. When there is a time lapse between charging and start-up, the crankcase heater should be energized for at least eight hours prior to starting the unit.

CAUTION: Failure to energize the crankcase heater and wait eight hours before starting the compressor may result in excessive oil foaming at start-up and possible damage to the compressor bearings.

COMPRESSOR MOTOR

With the compressor operating, check the amp draw. The amperage should not exceed the "Maximum Allowable Amps" listed in Table 6. The amp draw may be less than the value listed in the table.

Voltage at the compressor terminals must be within the "Allowable Voltage Range" listed in Table 4. If not, check the voltage at the unit terminal block and at the disconnect switch to determine if voltage problems are being caused by feeder line, loose terminals, or defective unit wiring.

VOLTAGE IMBALANCE

Voltage imbalance on three phase systems can cause motor overheating and eventual failure. Maximum allowable imbalance is two percent, which must be measured at the compressor terminals. Voltage imbalance is defined as 100 times the maximum de-

TABLE 6 - Maximum Allowable Amp Draw

		ALLOWABLE	MAX. ALLO	OWABLE AMPS
CONDENSING ELECTRICAL CHARACTERISTICS		VOLTAGE RANGE	MATCHED EVAP.	OVERSIZED EVAP.
RAUB-C206	200/60/3	180-220	97	100
RAUB-C203	230/60/3	207-253	84	87
RAUB-C204	460/60/3	414-506	42	43
RAUB-C202	575/60/3	517-633	34	35
RAUB-C256	200/60/3	180-220	118	121
RAUB-C253	230/60/3	207-253	103	106
RAUB-C254	460/60/3	414-506	51	53
RAUB-C202	575/60/3	517-633	41	42
RAUB-C306	200/60/3	180-220	143	149
RAUB-C303	230/60/3	207-253	124	130
RAUB-C304	460/60/3	414-506	62	65
RAUB-C302	575/60/3	517-633	50	52
RAUB-C406	200/60/3	180-220	97	100
RAUB-C403	230/60/3	207-253	84	87
RAUB-C404	460/60/3	414-506	42	43
RAUB-C402	575/60/3	517-633	34	35
RAUB-C506	200/60/3	180-220	119	122
RAUB-C503	230/60/3	207-253	103	106
RAUB-C504	460/60/3	414-506	52	53
RAUB-C502	575/60/3	517-633	41	43
RAUB-C606	200/60/3	180-220	143	150
RAUB-C603	230/60/3	207-253	125	130
RAUB-C604	460/60/3	414-506	62	65
RAUB-C602	575/60/3	517-633	50	52

TABLE 7 - RAUB 20-60 Operating Modes

SYSTEM		COMPRESSOR LOADING								REC. EVAP.						
CONDENSING	LOADING	COMPRESSOR NO.1			COMPRESSOR NO. 2			COIL	CONDENSER FAN OPERATION							
UNIT	(SEE NOTE 1)	33%	50%	66%	100%	33%	50%	66%	100%	LOADING	#1	#2	#3	#4	#5	#6
RAUB-C20	50%		X			Man a	N Posts	g-1117/j	16 Sept	1/2	Р	X	1000	de alec	60.1.3	1
La company	100%			14.	X	E Jan			The said	FULL	Р	X	17.76	1000		
	33%	X			1			7.07.00		1/2	Р	X	72-4 76	7		113
RAUB-C25	66%			X	117					FULL	P	X	X			
	100%				X				SEA COM	FULL	Р	X	X		me Sint	1.85
J 7 7 3	33%	X	Touch							1/2	P	X		in The		
RAUB-C30	66%	- 64		X	54.45		Sept.		1 3	FULL	P	X	X	E WELL	Define.	
	100%				X			200	15.	FULL	Р	X	X	VA		
W. 1	25%		X					14	1	1/2	P	X		A 52		
RAUB-C40	50%	1	1		X	Baller		000	Literal	1/2	P	X		Den 12	lie in the sale	
	75%	100	X					A. Ser	X	FULL	P	X		P	X	
	100%	1	110	ET.	X			2.273	X	FULL	Р	X		P	X	
	33%	1 2 3		X				100	F 35 3	1/2	Р	X	X			3.70
RAUB-C50	50%	7	W.		X	William .		1		1/2	P	X	X	128	12, 3	
	83%			X				-	X	FULL	P	X	X	P	X	X
1	100%	100	- 1	ANG	X				Х	FULL	P	X	X	Р	X	X
	33%			X	1000	101				1/2	Р	X	X	1,000		
RAUB-C60	50%		1.000	14.9	X					1/2	P	X	X	6:5:		3,00
	83%	1 300		X	in the second	14.50		date of	X	FULL	Р	X	X	P	X	X
1	100%	138			X	MA.	Park I		Х	FULL	P	X	X	P	X	X

NOTES:

1. Assumes use of 2-step controller on 20 ton unit, 3-step controller on 25 and 30 ton units, and 4-step controller on 40, 50 and 60 ton units.

This table does not apply to Multi-Step control (Option "B"). Unloading modes determined by the type of capacity controls.

2. Legend:

X — In operation with compressor.

P — In operation in response to fan pressure switch.

viation of the three voltages from the average, without regard to sign, divided by the average voltage. For example, if the three measured voltages are 221, 230 and 227, the average voltage would be:

$$\frac{221 + 230 + 227}{3} = 226 \text{ volts}$$

and the percent voltage imbalance would be:

$$\frac{100 \times (226-221)}{226} = 2.2\%$$

In this example, 2.2 percent imbalance is not acceptable and could result in as much as 20 percent current imbalance. This will increase the motor winding temperature, and thus decrease the life of the motor.

If more than 2.0 percent imbalance exists, check the voltage readings at the disconnect switch to determine if the imbalance is present in the incoming power lines. If so, the power company should be notified to correct it. If the imbalance is due to problems within the unit, check the unit electrical wiring connections.

OPERATING PRESSURES

Install pressure gauges on the discharge and suction line access valves next to the compressor. When the unit reaches stabilized operation, suction and discharge pressures can be read. Refer to "Operating Pressures" in the MAINTENANCE PROCEDURES section of this manual to compare the measured pressures with the normal system operating pressures.

EXPANSION VALVE SUPERHEAT

After checking operating pressures, check the expansion valve superheat as detailed in the MAINTENANCE section of this manual. The valve should be controlling smoothly without continuing superheat "hunting".

UNLOADING SEQUENCE

After checking to see that the pressures, oil level, superheat setting and refrigerant charge are correct, raise and lower the thermostat setting to confirm that the system loading and unloading sequence is correct. See Table 7.

START-UP LOG

	DAIE
I. NAMEPLATE INFORMATION	
Model No.	Serial No.
Voltage	RLA
II. COMPRESSOR(C)	
II. COMPRESSOR(S)	
A. VOLTAGE AT COMPRESSOR TERMINALS	
Comp. No. 1: T1	
Comp. No. 2: T1	네트 전 그 이렇게 맛먹어서 이번 먹지만 그렇게 되었다면 그 물로 모르는데 이 때 화를 했습니다. 생각이 되었다.
Voltage Imbalance: Comp. No. 1	Comp. No. 2
B. AMP DRAW	
Comp. No. 1: L1	L2 L3
Comp. No. 2: L1	L2 L3
III. OPERATING CONDITIONS	
A. COMPRESSOR NO. 1	
Discharge Pressure	Suction Pressure —
Liquid Line Pressure	Suction Line Temp.
Liquid Line Temp.	Superheat
Subcooling —	Evap. Entering Air Temp. (DB/WB)
Ambient Temp.	Evap. Discharge Air Temp. (DB/WB)
B. COMPRESSOR NO. 2	
Discharge Pressure	Suction Pressure —
Liquid Line Pressure	Suction Line Temp.
Liquid Line Temp.	Superheat
Subcooling	Evap. Entering Air Temp. (DB/WB)
Ambient Temp.	Evap. Discharge Air Temp. (DB/WB)
V. CONTROLS	
Fans Operating (Yes or No): Fan No. 1	No. 2 No. 3
Crankcase Heater Operating (Yes or No): Comp	
/. REFRIGERANT PIPING	
Evacuation Level	System Charge

OPERATION

SYSTEM CONTROL

Four different types of system control are available with the Model RAUB Split System Condensing Unit. They include two-stage electro-mechanical (shipped less thermostat and toggle switch), electronic with room thermostat, electronic with supply air sensor (RAUB/VAV systems) and four-stage electronic Honeywell (RAUB/EVPA systems).

Units With Two-Step Control

The recommended controls (to be supplied by others) for units with two-step controls are a Penn T25A two-stage electro-mechanical thermostat and a Cutler-Hammer 7562K53 2PDT toggle switch or equivalent. With the control circuit switch closed, the evaporator fan can be operated independently by placing the "Fan-Off-Cool" switch in the "Fan" position. Moving the switch to the "Cool" position will allow the system to operate in the cooling cycle according to thermostat demand.

NOTE: A detailed sequence of operation is contained in RAUB-W-35.

Units Shipped With Electronic Thermostat Controls

Refer to Figure 36.

RAUB units shipped with electronic thermostat controls are controlled by a Honeywell T7067A electronic thermostat coupled with a W973 logic panel (MEC). With the control circuit switch (1S1) in the closed position, the evaporator fan may be operated independently by moving the fan switch located on the thermostat subbase to the "On" position. With the fan in either the "On" or "Auto" position and the thermostat switch in either the "Auto" or "Cool" position, the unit will operate according to thermostat demand.

NOTE: A detailed sequence of operation is contained in RAUB-W-36.




FIGURE 37 - Honeywell CR71A 4-Step Controller

RAUB/EVPA Systems

Refer to Figure 37.

RAUB units equipped with EVPA control panels are controlled by an electronic Honeywell CR71A four-stage controller. To operate the system, start the chilled water pump and close the control circuit switch. The controller will operate the unit according to the return chilled water temperature.

NOTE: A detailed sequence of operation is contained in RAUB-W-37.

Multi-Step Control

RAUB units shipped with multi-step controls are designed for use with field-provided controls where maximum unloading is desired.




FIGURE 36 - Honeywell Electronic Thermostat With Switching Sub-base

NOTE: A detailed sequence of operation is contained in RAUB-W-39.

Electronic Supply Air VAV


RAUB units shipped with electronic supply air VAV controls are controlled by an electronic VAV transmitter in conjunction with an electronic logic panel. With the field-provided system control switch in the closed position and the unit control circuit switch (1S1) in the closed position, the evaporator fan will operate continuously and cooling will be in response to supply air temperature.

FAN SEQUENCING

Refer to Figure 38 and Table 8.

- On 20-ton units, fan number 2 will operate with the compressor and fan number 1 will cycle in response to liquid pressure.
- On 25 and 30-ton units, fan number 2 will operate with the compressor, fan number 1 will cycle in response to liquid pressure and fan number 3 will operate with compressor unloading.

20-TON UNIT




 On 50 and 60-ton units, fans 2, 5, 3 and 6 will operate with the compressors and fans 1 and 4 will cycle in response to liquid pressure.


THERMOSTATS


In operation, the zone thermostat measures continuously the temperature of the air being supplied to the zone. If controlled by the electro-mechanical thermostat, temperature sensitive elements merely make and break switches, enabling various stages of cooling to come on.

If controlled by the electronic thermostat, a 20-volt DC regulated power supply is provided to the thermostat. A continuous signal of 1 to 16 volts DC is returned to the Honeywell master energy controller by the thermostat. This signal is monitored by the controller to determine actual zone cooling requirements. The controller will then, according to the voltage value received, operate the necessary mechanical components through relay stages which are sensitive to the zone signal.

25 AND 30-TON UNITS







50 AND 60-TON UNITS




FIGURE 38 - Condenser Fan Sequence

TABLE 8 - Fan Sequencino

	FAN OPERATES WITH COMPRESSOR(S)	FAN CONTROLLED BY FAN PRESSURE SWITCH	FAN OPERATES WITH COMPRESSOR UNLOADING
MODEL	FAN NUMBER	FAN NUMBER	FAN NUMBER
RAUB 20	2	1	
RAUB 25	2	1	31
RAUB 30	2	1	31
RAUB 40	2 and 5	1 and 4	
RAUB 50	2, 5, 3, 6	1 and 4	
RAUB 60	2, 5, 3, 6	1 and 4	

NOTE:

- 1. Fan #3 operates with cooling stages 2 and 3.
- 2. Fans 3 and 6 operate with compressor unloading on multi-step controls.

Electrical Sequence of Operation, 2-Step Controls

See Figure 39.

Although the controls used with these units are optional, a Penn T25A thermostat and Cutler-Hammer 7562K53 2PDT toggle switch are the recommended equipment. The following discussion assumes the use of the recommended controls.

The system's operation is controlled by a system control switch and a two-stage thermostat. Closing the unit disconnect switch supplies power to the system control switch (1S1), control power transformer and compressor crankcase heater (2B7HR1).

The evaporator fan can be operated independently by placing the Fan-Off-Cool switch in the "Fan" position. This energizes the evaporator fan contactors, starting the fan. Moving the Fan-Off-Cool switch to the "Cool" position, energizes the evaporator fan contactors and closes the evaporator fan interlock contacts, supplying power to the thermostat and the normally open contacts (1K13) of the low ambient relay.

20 To 30-Ton Units

Sensing a need for cooling, the first-stage contacts of the two-stage thermostat will close, supplying power to the compressor fixed "on" timer (1U3). The fixed "on" timer times to close upon de-energization or when the compressor stops. If the compressor has been off for five minutes and the timer has timed out, power will be supplied through the 1U3's closed contacts to the first-stage cooling relay (1K1), the low ambient timer (1U5) and the compressor unloader solenoid (2B7L3). Compressor unloader solenoid 2B7L4 is also energized on 25 and 30-ton units.

Energizing 1K1 closes its two normally open sets of contacts. One set energizes the first-stage liquid line solenoid valve (2L1) and the second set supplies power to the compressor control circuit.

Supplying power to the low ambient timer (1U5) will energize the low ambient relays (1K13 and 1K14) through its normally closed time-to-open contacts for approximately three minutes. Energizing 1K13 will close its two normally open sets of contacts. The first set bypasses the thermostat and the second set bypasses the low pressure cut-out switch (2B7S4), supplying power to the condenser fan contactor (1K8), condenser fan pressure control (1S10) and compressor contactor (1K3). Energizing 1K3 will close its axuiliary compressor contacts.

NOTE: Units equipped with part-winding starter, supply power to the part-winding time delay (1DL1) and compressor contactor 1K5's auxiliary contacts in addition to 1K8, 1S10 and 1K3. After 0.5 second timing, 1DL1 will close, energizing 1K5. This will close the auxiliary contacts of 1K5 and also supply power to the second set of compressor motor windings.

Energizing 1K14 will open its two normally closed set of contacts, de-energizing two optional hot gas bypass valves for a three-minute period. This allows sufficient head pressure to build up before hot gas is allowed to pass. After approximately three minutes, the 1U5 contacts will open de-energizing the 1K13 and 1K14 low ambient relays. At this point, the control circuit will once again operate according to thermostat demand and the compressor and the condenser fans will operate through the low pressure control. NOTE: On units equipped with hot gas bypass, the hot gas solenoid valve will energize, allowing the hot gas valve to operate according to suction pressure.

As the cooling load increases, the second-stage contacts of the thermostat will close, energizing the second-stage cooling relay (1K2). The normally closed set of 1K2 contacts will open, de-energizing the compressor unloader solenoid (2B7L3), which will fully load the compresor. NOTE: On 25 and 30-ton units, compressor unloader solenoid 2B7L4 is de-energized in addition to the 2B7L3 solenoid to provide 100 percent compressor operation. The normally open set of 1K2 contacts will close, energizing the second circuit's liquid line solenoid valve. NOTE: On units with hot gas bypass, the second circuit hot gas bypass solenoid valve will also be energized by way of the closed set of 1K14 contacts. The unit is now operating at 100 percent capacity.

As the cooling load subsides, the second-stage thermostat contacts will open, de-energizing 1K2 and returning the unit to first-stage operation. As the cooling load is further reduced and finally satisfied, the first-stage thermostat contacts will open, de-energizing the first control relay (1K1). De-energizing 1K1 will open its two sets of contacts. The first set will de-energize (close) the liquid line solenoid valve, shutting off refrigerant flow to the evaporator. Opening the second set will leave only the compressor auxiliary contacts (1K3 Aux.) to supply power to the compressor control circuit.

The compressor will continue to operate, removing the remaining refrigerant from the evaporator and lowering the suction pressure. When the suction pressure is reduced to approximately 7 psig, the low pressure control will open, de-energizing the compressor and condenser fan contactor relays. De-energizing 1K3 will open its auxiliary contacts, locking out the control circuit.

The unit will restart after a call for cooling is established and the compressor fixed "off" timer times out.

40 To 60-Ton Units


Sensing a need for cooling, the first-stage contacts of the thermostat will close, supplying power to the first circuit's fixed "off" timer (1U3). 1U3's contacts time to close upon de-energization and will be closed provided the unit has not operated for five minutes. Current passing through 1U3's closed contacts will supply power to the cooling relay (1K1), low ambient timer (1U5) and time delay between compressors timer (1DL3).

Energizing 1K1 will close its two sets of contacts. One set will energize the liquid line solenoid valve (2L1) and the second set will supply power to the first compressor's control circuit (the reset relay circuit).

Supplying power to the low ambient timer (1U5) will energize relay 1K13 for a three-minute period and close its two sets of contacts. One set will bypass the thermostat's first-stage contacts which will insure a three-minute compressor operation despite the thermostat's demand. The second set will bypass the low pressure cut-out, providing power to the compressor contactor (1K3), condenser fan contactor (1K8) and condenser fan pressure control (1S10). NOTE: On part-winding starter units, power is also supplied to part-winding start time delay 1DL1 which will close 0.5 seconds after energization, supplying power to compressor contactor 1K5. NOTE: On units equipped with hot gas bypass, an additional set of normally closed 1K13 contacts will open, de-energizing the first circuit's hot gas bypass solenoid for a three-minute period.

NOTES:

- 1. UNLESS OTHERWISE NOTED ALL SWITCHES ARE SHOWN AT 25°C(77°F), AT ATMOSPHERIC PRESSURE, AT 30% RELATIVE HUMIDITY, MITH ALL UTILITIES TURNED OFF, AND AFTER A NORMAL SHUTDOWN HAS OCCURED. DASHED LINES INDICATE RECOMMENDED FIELD HIRING BY OTHERS. DASHED LINE ENCLOSURES AND/OR DASHED DEVICE OUTLINES INDICATE COMPONENTS PROVIDED BY THE FIELD. PHANTOM LINE ENCLOSURES INDICATE ALTERNATE CIRCUITRY OR AVAILABLE SALES OPTIOMS. NUMBERS ALONG THE RIGHT SIDE OF THE SCHEMATIC DESIGNATE THE LOCATION OF THE CONTACTS BY LINE NUMBER. AN UNDERLINED NUMBER INDICATES A NORMALLY CLOSED CONTACT. AN OPEN ARROWHEAD BELOW THE LINE NUMBER POINTING UPMAND INDICATES A TIMED CONTACT WHICH BEGINS TIMING HHMEN EMERGIZED.
- 2 283, 286, AND ASSOCIATED WIRING ARE USED ONLY ON 50 AND 60 TON UNITS.
- 3 SUGGESTED PARTS ARE A PENN 129A THERMOSTAT AND A CUTLER-HAMMER 7562553 2PDT TOGGLE SMITCH OR EQUIVALENT



	LEGEND	
DEVICE DESIGNATION	DESCRIPTION	LINE
1DL3	DELAY BETHEEN COMPRESSORS	30
1F11F6	CONDENSER FAN FUSE	13
1F7	CONTROL CIRCUIT FUSE	24
IF44. IF45	COMPRIPROTECTOR FUSE	41,49
1K1, 1K2	COOLING RELAY	27, 32
1K3	COMPRESSOR CONTACTOR	43
1K4	COMPRESSOR CONTACTOR	52
1K7, 1K8	CONDENSER FAN CONTACTOR	40.44
1K9, 1K10	CONDENSER FAN CONTACTOR	49, 53
1K11, 1K12	RESET RELAY	
1K13, 1K12	LOW AMBIENT RELAY	40, 48
1813, 1814	LUW ANDIENT RELAT	28. 33
151	CONTROL CIRCUIT SHITCH	28
1510. 1511	FAN PRESSURE CONTROL	40, 49
1514	MANUAL DISCONNECT SHITCH	5
111	CONTROL POWER TRANSFORMER	21
1TB1	POWER TERMINAL BLOCK	5
1TB4, 5, 6, 7	CONTROL TERMINAL BLOCK	STATE NO.
101, 102	COMPR CURRENT OVERLOAD	8
103, 104	COMFR FIXED OFF TIMER	28, 33
105, 106	LOW AMBIENT TIMER	29, 34
	2010511050 5411 110700	
281286	CONDENSER FAN MOTOR	55
287, 288 287HR1	COMPRESSOR CRANKCASE HEATER	2
288HR2	CRANKCASE HEATER	25
COBHRZ	CHARLASE HEATER	20
28752, 28853	HIGH PRESSURE CUTOUT	41, 49
28754, 28855	LOH PRESSURE CUTOUT	41, 49
28756	COMPR WINDING THERMOSTAT	41
28857	COMPR WINDING THERMOSTAT	49
2L1, 2L2	LIQUID LINE SOLENDID .	39, 48
2L5, 2L6	HOT GAS BYPASS SOLENOID	37, 46

DE	ICE PREFIX LOCATION CODE
AREA	LOCATION
1	INSIDE UNIT CONTROL PANEL
2	DUTSIDE UNIT CONTROL PANEL

(CONTINUED ON NEXT PAGE)

á






FIGURE 39 - System Wiring Diagram, 40, 50 and 60-Ton Units, Across-the-Line Start, 460/60/3, 2-Step Control

After approximately three minutes, the low ambient timer contacts will reopen, de-energizing the low ambient relay (1K13). At this point, the first control circuit will once again operate according to thermostat demand and the compressor and condenser fans will operate through the low pressure cut-out. The first compressor is now operating at 100 percent capacity.

As the need for cooling increases, the thermostat's second stage contacts will close, supplying power to the second circuit's compressor fixed "off" timer (1U4) through the time delay between compressor contacts (1DL3). 1DL3 will close 0.5 second after the first control relay energizes. 1U4's contacts time to close upon de-energization and will be closed provided 1U4 has been de-energized for five minutes. Current passing through 1U4's closed contacts supplies power to the second cooling relay (1K2) and the second circuit low ambient timer (1U6).

Energizing 1K2 will close its two sets of contacts. One set will energize the liquid line solenoid valve (2L2) and the second set will supply power to the second compressor control circuit (the reset relay circuit).

Supplying power to the low ambient timer (1U6) will energize the low ambient relay (1K14) for a three-minute period and close its two sets of normally open contacts. One set of 1K14's contacts bypasses the thermostat's second-stage contacts, allowing three-minute compressor operation regardless of the thermostat's demand. The second set bypasses the second circuit's low pressure cut-out (2B8S5), providing power to compressor contactor (1K4), condenser fan contactor (1K10) and condenser fan pressure control switch (1S11). NOTE: On part-winding starter units, power is also supplied to the part-winding start time delay (1DL2) which will close 0.5 seconds after energization, supplying power to compressor contactor 1K5. NOTE: On units equipped with hot gas bypass, an additional set of normally closed 1K14 contacts will open, de-energizing the hot gas solenoid for a three-minute period.

After approximately three minutes, the second circuit's low ambient timer contacts will open, de-energizing relay 1K14. At this point, both circuits will be operating according to thermostat demand and the compressors and condenser fans will operate through their respective low pressure cut-out controls. The unit is now operating at full capacity.

As the cooling load diminishes, the thermostat's second stage contacts will open, de-energizing cooling relay 1K2. De-energizing 1K2 will open its two sets of normally open contacts. The first set will de-energize the liquid line solenoid valve (2L2), shutting off refrigerant flow to the evaporator. The second set which supplies the compressor control circuit will open, leaving only the second compressor's auxiliary contacts to supply control power. The suction pressure will reduce until the second circuit's low pressure cut-out opens, de-energizing the compressor and condenser fan relays. The compressor auxiliary contacts will open, locking out the second control circuit. It should be noted that the second circuit cannot re-energize until the second stage thermostat contacts have reclosed and timer 1U4 has remained de-energized for five minutes.

When the cooling load has been satisfied, the thermostat's first-stage contacts will open, de-energizing cooling relay 1K1. Just as on the second circuit, the liquid line solenoid valve will shut and control power will be provided through only the first compressor's auxiliary contacts. At approximately 7 psi, the low pressure cut-out will open, de-energizing the compressor and condenser fan relays and also the first compressor's auxiliary set of contacts. The unit will not restart until a call for cooling has been re-established and timer 1U3 has timed out.

SAFETY AND OPERATING CONTROLS

The operation of the High Pressure Cut-out, Low Pressure Control, Compressor Fixed Off Timer and the Low Ambient Timer has been checked at the factory and does not require extensive rechecking at the jobsite. The control settings are listed in Table 9.

High Pressure Cut-out (2B7S2)

The high pressure cut-out, sensing the compressor discharge pressure, prevents the compressor motor from being overloaded. It opens the control circuit, stopping the compressor should condensing pressure exceed safe operating limits (405 ± 10 psig).

Low Pressure Control (2B7S4)

Sensing pressure on the suction side of the compressor, the low pressure control terminates the pumpdown cycle when the pressure is reduced to the cut-out setting of the control (7 \pm 3 psig). When the system is to be restarted, the build-up of suction pressure is to be restarted, the build-up of suction pressure is to be restarted.

TABLE 9 - Control Settings

		SETTINGS				
CONTROL	FAN NO.	CUT-IN	CUT-OUT			
High Pressure (2B7S2 & 2B8S3*)		300 ± 20 PSIG	405 ± 10 PSIG			
Low Pressure (2B7S4 & 2B8S5*)		22 ± 3 PSIG	7 ± 3 PSIG			
Discharge Temperature Limit		Manual**	280 ± 7.5 F			
Fan Pressure						
20-Ton (1S10)	1	300 ± 10 PSIG	155 ± 10 PSIG			
25-Ton (1S10)	1	300 ± 10 PSIG	155 ± 10 PSIG			
30-Ton (1S10)	1	300 ± 10 PSIG	155 ± 10 PSIG			
40-Ton (1S10 & 1S11)*	1 & 4	300 ± 10 PSIG	155 ± 10 PSIG			
50-Ton (1S10 & 1S11)*	1 & 4	300 ± 10 PSIG	155 ± 10 PSIG			
60-Ton (1S10 & 1S11)	1 & 4	300 ± 10 PSIG	155 ± 10 PSIG			
Compressor Fixed Off						
Timer (1U3 & 1U4*)		5-Mi	nutes			
Low Ambient Timer						
(1U5 & 1U6*)		3-Mi	nutes			

^{*} Used on 40 thru 60-ton units only.

TABLE 10 - Damper Operation

FULLY	FULLY
CLOSED	OPEN
170 PSI	250 PSI

^{**} Cannot be reset until discharge gas temperature drops below 180 F.

sure, resulting from the opening of the first liquid solenoid valve, will close the control contacts at 22 ± 3 psig.

Condenser Fan Pressure Control (1S10 and 1S11)

The last condenser fan energized by each compressor circuit operates in response to liquid line pressure. See Figure 40 for fan numbering sequence. At 300 \pm 10 psig the condenser fan contactor is energized. When condenser pressure falls to 155 \pm 10 psig the contactor is de-energized.

Compressor Fixed Off Timer(s) (1U3 and 1U4)

Units equipped with compressor fixed off timers provide a 5-minute compressor fixed off period which will prevent rapid compressor cycling. The timers begin timing upon de-energization.

Low Ambient Timers (1U5 and 1U6)

Low ambient timers are standard equipment on units shipped without controls (ninth model number digit is A, B or F) and are optional equipment on all other units.

The timers are called fixed on timers on units shipped without controls and serve a dual function. Low ambient timers act as anti-recycle timers by incurring a three minute compressor fixed on period and also provide low ambient compressor start-up by bypassing the low pressure switch for three minutes.

On all other units, the timers are provided only for low ambient start-up.

Low Ambient Dampers

Refer to Figure 40.

Low ambient dampers on 20 through 60-ton units are factory installed optional items. They control the flow of air across the coils. During start-up, the blades must be inspected for proper alignment, obstructions and free operation.

To check damper operation, the damper must be fully open when the discharge pressure reaches 250 psig. On dual compressor units, check damper operation for each circuit separately in the same manner as single compressor units. Damper operation will occur between the liquid line pressures given in Table 10.

Discharge Temperature Limit

The discharge temperature limit control senses compressor discharge gas temperature and shuts the system off by opening the control circuit when discharge temperature exceeds $280\pm7.5~\text{F}$. This manual reset control protects the compressor from excessive oil and/or refrigerant temperatures, which commonly occur due to loss of refrigerant charge. Reset cannot be accomplished until the discharge line temperature drops below 180 F.




FIGURE 40 - Low Ambient Dampers

MAINTENANCE -

PERIODIC MAINTENANCE

Perform all of the indicated maintenance procedures at the intervals scheduled. This will prolong the life of the unit and reduce the possibility of costly equipment failure. A MAINTENANCE LOG is provided on page 51 of this manual for recording operating data on a regular basis.

ONCE A MONTH

Conduct the maintenance inspections outlined below on a monthly basis during the cooling season.

- 1. Inspect the evaporator coil air filters. Clean or replace if necessary.
- 2. Inspect the evaporator and condenser coils for dirt and foreign debris. If the coils appear dirty, clean them according to the instructions provided under "Coil Cleaning" in the MAINTENANCE PROCEDURES section of this manual.
- ☐ 3. Check compressor oil level.

ONCE A YEAR


The following maintenance practices must be performed at the beginning of each cooling season to ensure efficient unit operation.

WARNING: OPEN THE UNIT DISCONNECT SWITCH AND LOCK IT IN THAT POSITION TO PREVENT ACCIDENTAL START-UP. NEVER OPEN AN ACCESS PANEL TO INSPECT OR SERVICE THE UNIT WITHOUT FIRST OPENING THE DISCONNECT SWITCH. FAILURE TO DO SO MAY RESULT IN INJURY OR DEATH FROM ELECTRICAL SHOCK OR CONTACT WITH MOVING PARTS.

- 1. Inspect the evaporator coil air filters. Clean or replace if necessary.
- 2. Clean both the evaporator and condenser coils. Follow the procedures outlined under "Coil Cleaning" in the MAINTENANCE PROCEDURES section of this manual.
- 3. With the unit disconnect switch open, check to see that each condenser and evaporator fan is securely fastened to its motor shaft. All fans should turn freely and airflow should be unobstructed.
- 4. Replace worn or frayed evaporator fan belts. Check the belt tension of the evaporator fans. A 1/2-inch deflection under light hand pressure is normal. Tighten if necessary.
- 5. Remove the condensing unit control box cover and inspect the panel wiring. All electrical connections should be secure. Inspect the compressor and condenser fan motor contactors. If the contacts appear severly burned or pitted, replace the contactor (refer to Figure 41). Do not clean the contacts. Inspect the condenser fan capacitors for visible damage.
- 6. Remove any accumulation of dust and dirt from the condensing unit.



NEW CONTACTS - SMOOTH SURFACES, MAY BE BRIGHT, DULL OR DISCOLORED BY TARNISH



NORMAL WEAR - SURFACES MILDLY PITTED, DISCOLORED AREAS EITHER BLACK, BLUE OR BROWN, 75% OF MASS STILL INTACT. SLIGHT FEATHERING OF EDGES WITH NO LIFTING. CONTACTS STILL SERVICEABLE.



BADLY WORN - SURFACES BADLY ERODED. EDGES FEATHERED AND LIFTED. REPLACE CONTACTOR.

FIGURE 41 - Compressor Contactor Replacement Guide

- 7. Clean and inspect the drain pan of the evaporator unit.
 Make sure the drain piping is clear.
- 8. Observe the compressor oil level sight glass while the unit is running. If oil is visible, the level is normal. If an oil level does not appear in the sight glass, refer to page 40 of this manual.
- 9. Check the superheat and subcooling.
 - a. The condenser and evaporator coils must be clean before making the following checks.
 - b. Determine the superheat of the system. Refer to "Measuring Superheat" in the MAINTENANCE PRO-CEDURES section of this manual.
 - Adjust the superheat if necessary (instructions are provided in the "Measuring Superheat" section of this manual).
 - d. When the superheat setting is correct, check the subcooling. Refer to "Measuring Subcooling" in the MAINTENANCE PROCEDURES section of this manual.
 - e. If the subcooling is low, leak test the system to determine if there is a leak. Refer to "Leak Testing" in the MAINTENANCE PROCEDURES section of this manual.
 - f. Charge the system with refrigerant if necessary. Instructions are provided under "Checking Refrigerant Charge" in the MAINTENANCE PROCEDURES section of this manual.
 - g. Enter the operating pressures, superheat, and subcooling in the MAINTENANCE LOG provided on the following page.



MAINTENANCE LOG

DATE	AMBIENT TEMP. (F)	EVAPORATOR ENTERING AIR		COMPRESSOR NO. 1		COMPRESSOR NO. 2*		SUPERHEAT		SUBCOOLING	
				SUCTION	DISCHARGE	SUCTION PRESSURE	DISCHARGE PRESSURE	CIRCUIT NO. 1 (F)	CIRCUIT	CIRCUIT	CIRCUIT
		DRY BULB	WET BULB	PRESSURE	PRESSURE	PRESSURE	PRESSURE	NO. 1 (F)	NO. 2 (F)*	NO. 1 (F)	NO. 2 (F)*
. 20											
-						C 45 AV					
									医乳上斑		
									1997年		
	3011										Part Con
									44 10 10 10		100
	1			The state of the s		- 17-18					
						0.1 (0)					
									133 # 5 1		
-						19 k			340		
1/6			4			10 6		100			4.8
									No.		
									2 5 4 2 3		12.5
											科 美
								55 000	THE REAL PROPERTY.		
				W 其 4 多							
					15 x 3						
										200	

^{*} RAUB 40, 50 and 60 Ton Units Only

SHUTDOWN AND START-UP

Shutdown: Short Duration

The system can be shutdown for short periods of time, such as over the weekend by placing the control circuit switch or the system control switch in the OFF position.

NOTE: The unit disconnect switch must remain closed. This will permit the crankcase heater to continue to function, preventing refrigerant from condensing in the compressor oil sump.

Start-up: Short Duration

The system is returned to operation after a shutdown of short duration, such as over a weekend, by adjusting the thermostat setting to the desired temperature, placing the control circuit switch in the ON position, and setting the system control switch in the COOL position.

Shutdown: Seasonal

For seasonal shutdown, open the unit electrical disconnect switch to prevent the unit from starting accidentally.

Start-up: Seasonal

To start the unit after an extended shutdown period, complete the following procedures.

- Perform all of the "Once a Year" checks listed in the PERI-ODIC MAINTENANCE section of this manual.
- 2. Move the control circuit and/or system control switch to OFF.
- Close the condensing unit electrical disconnect switch. This
 will energize the compressor crankcase heater. If operating
 properly, the crankcase should be hot to the touch. Wait a
 minimum of eight hours before turning the system control
 switch to the COOL position.

CAUTION: Failure to wait eight hours before turning the system control switch to COOL may result in damage to the compressor bearings.

- Start the system by adjusting the thermostat setting to the desired temperature, placing the system control switch in the COOL position, and placing control circuit switch in the ON position.
- Place a clamp-on ammeter on each compressor lead and check the motor amperage. The amperage draw should not be greater than that given in Table 6, "Maximum Allowable Amp Draw".
- Place the clamp-on ammeter around one of the three leads from the outdoor fan motor. The amp draw should be no greater than the nameplate rating for the condenser fan motors.

MAINTENANCE PROCEDURES

This section of the manual describes specific maintenance procedures which must be performed as a part of the unit's maintenance program. Before performing any of these operations, however, be sure that power to the unit is disconnected unless otherwise instructed.

WARNING: WHEN MAINTENANCE CHECKS AND PRO-CEDURES MUST BE COMPLETED WITH THE ELECTRICAL POWER ON, CARE MUST BE TAKEN TO AVOID CONTACT WITH ENERGIZED COMPONENTS OR MOVING PARTS. FAIL-URE TO EXERCISE CAUTION WHEN WORKING WITH ELEC-TRICALLY-POWERED EQUIPMENT MAY RESULT IN SERIOUS INJURY OR DEATH.

COIL CLEANING

Refrigerant coils must be cleaned at least once a year, or more frequently if the unit is located in a dirty environment. This will help maintain unit operating efficiency and reliability. The relationship between regular coil maintenance and efficient/reliable unit operation is outlined below.

- Clean condenser coils minimize compressor head pressure and amperage draw, and promote system efficiency.
- Clean evaporator coils minimize water carry-over and help eliminate frosting and/or compressor flood back problems.
- Clean coils minimize required fan brake horsepower and maximize efficiency by keeping coil static pressure loss at a minimum.
- Clean coils keep motor temperature and system pressure within safe operating limits for good reliability.

Specific instructions for cleaning condenser coils are provided in the following paragraphs. Follow these instructions as closely as possible to avoid potential damage to the coils.

To clean condenser coils, the following equipment is required: a soft brush and either a garden pump-up sprayer or a high pressure sprayer. In addition, a high quality detergent must be used: suggested brands include SPREX A.C., OAKITE 161, OAKITE 166, and COILOX. Follow the manufacturer's recommendations for mixing to make sure the detergent is alkaline with a pH value less than 8.5.

1. Disconnect power to the unit.

WARNING: OPEN UNIT DISCONNECT SWITCH. FAILURE TO DISCONNECT UNIT FROM ELECTRICAL POWER SOURCE MAY RESULT IN SEVERE ELECTRICAL SHOCK, AND POSSIBLE INJURY OR DEATH.

- Remove enough panels from the unit to gain access to the coil.
- Protect all electrical devices such as motors and controllers from dust and spray.
- 4. Straighten coil fins with a fin rake, if necessary.
- Use a soft brush to remove loose dirt and debris from both sides of the coil.
- Mix the detergent with water according to the manufacturer's instructions. The detergent-and-water solution may be heated to a maximum of 150 F to improve its cleansing ability.



WARNING: DO NOT HEAT THE DETERGENT-AND-WATER SOLUTION TO TEMPERATURES IN EXCESS OF 150 F. HIGH-TEMPERATURE LIQUIDS SPRAYED ON THE COIL EXTERIOR WILL RAISE THE PRESSURE WITHIN THE COIL AND MAY CAUSE IT TO BURST, RESULTING IN POSSIBLE INJURY TO SERVICE PERSONNEL AND EQUIPMENT DAMAGE.

- Place the detergent-and-water solution in the sprayer. If a high-pressure sprayer is used, be sure to follow these guidelines:
 - Minimum nozzle spray angle is 15 degrees.
 - Spray the solution perpendicular (at a 90 degree angle) to the coil face.
 - Keep the sprayer nozzle at least six inches from the coil.
 - Sprayer pressure must not exceed 600 psi.

CAUTION: Do not spray motors or other electrical components. Moisture can cause component failure.

- Spray the leaving air side of the coil first, then spray the entering air side of the coil. Allow the detergent-and-water solution to stand on the coil for five minutes.
- 9. Rinse both sides of the coil with cool, clean water.
- Inspect the coil. If it still appears to be dirty, repeat Steps 8 and 9.
- Replace all unit panels and parts, and restore electrical power to the unit.
- 12. Remove protective covers installed in Step 3.

CONTROL TESTING

The following procedures can be used to check the operation of the high and low pressure controls. To determine operating pressures, attach gauges to the compressor suction and discharge access ports.

High Pressure Control

WARNING: BEFORE DISCONNECTING ANY WIRING, OPEN THE UNIT DISCONNECT SWITCH. FAILURE TO DO SO MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH CAUSED BY ACCIDENTAL ELECTRIC SHOCK.

- 1. Open the unit electrical disconnect switch.
- Disconnect the condenser fan motor leads at the condenser fan relays. This will de-energize the condenser fans.
- Remove the reset relay controlling compressor number two from its socket to prevent compressor number two from starting while checking the high pressure control for compressor number one.
- 4. Close the unit disconnect switch and start the unit.

CAUTION: Be prepared to open the unit disconnect switch immediately if the compressor continues to run after the discharge pressure exceeds the high pressure control cut-out range. Failure to do so could damage the system.

5. Observe the rising discharge pressure. When the pressure reaches 405 ± 10 psig, as shown in Table 9, the compressor should shut-off. If the pressure reaches 415 psig without the high pressure control contacts opening, immediately open the unit disconnect switch. Check to make sure that the high

- pressure control attached to liquid line number one is wired to low voltage circuit number one. If this is not a problem, replace the faulty high pressure control.
- 6. On RAUB 40, 50 and 60-ton units, repeat steps 1 through 5 to test the high pressure control in the second compressor circuit. Replace the reset relay for compressor number two and then remove the reset relay controlling compressor number one. This will prevent compressor number one from operating while checking the operation of the high pressure control for compressor number two.
- 7. Open the unit disconnect switch.
- 8. Reconnect the wires removed in Step 2.
- Allow the discharge pressure(s) to drop below the cut-in setting in Table 9 and then close the unit disconnect switch. This will close the reset relay that locked out the compressor contactor when the high pressure control tripped.
- The unit should start. If not, allow the discharge pressure to decrease further and repeat Step 9.

Low Pressure Control

To check the operation of the control, simply observe the control cut-out pressure during a normal pump-down sequence. If the control fails to function at the cut-out pressure, replace the control with a new control.

EVACUATION PROCEDURES

For field evacuation, use a rotary-style vacuum pump capable of pulling a vacuum of 100 microns or less.

When hooking the vacuum pump to a refrigeration system, it is important to manifold the pump to both the high and low side of the system (liquid line access valve and compressor suction access valve). Follow the pump manufacturer's directions as to the proper methods of using the vacuum pump.

CAUTION: Do not, under any circumstances, use a megohm meter or apply power to the windings of a compressor while it is under a deep vacuum. In the rarified atmosphere of a vacuum, the motor windings can be damaged.

The lines used to connect the pump to the system should be copper and of the largest diameter that can practically be used. Using larger line sizes with minimum flow resistance can significantly reduce evacuation time. Rubber or synthetic hoses are not recommended for unit evacuation because they have moisture absorbing characteristics which result in excessive rates of outgassing and pressure rise during the standing vacuum test. This makes it impossible to determine if the unit has a leak, excessive residual moisture, or a continual or high rate of pressure increase due to the hoses.

An electronic micron vacuum gauge should be installed in the common line ahead of the vacuum pump shutoff valve, as shown in Figure 42. Close Valves B and C, and open Valve A. After several minutes, the gauge reading will indicate the minimum blank-off pressure the pump is capable of pulling. Rotary pumps should produce vacuums of less than 100 microns.

Open Valves B and C. Evacuate the system to a pressure of 500 microns or less. Once 500 microns or less is obtained, with Valve A closed, a time versus pressure rise should be performed. The maximum allowable rise over a 15 minute period is 200 microns. If the pressure rise is greater than 200 microns but levels off to a

constant value, excessive moisture is present. If the pressure steadily continues to rise, a leak is indicated. Figure 43 illustrates three possible results of the time versus temperature rise check.

LEAK TESTING

When leak testing the unit, the following safety precautions must be observed:

WARNING: DO NOT WORK IN A CLOSED AREA WHERE RE-FRIGERANT OR NITROGEN MAY BE LEAKING. A SUFFICIENT QUANTITY OF VAPORS MAY BE PRESENT TO CAUSE PER-SONAL INJURY. PROVIDE ADEQUATE VENTILATION.

WARNING: DO NOT USE OXYGEN, ACETYLENE, OR AIR IN PLACE OF REFRIGERANT AND DRY NITROGEN FOR LEAK TESTING. A VIOLENT EXPLOSION WILL RESULT WHICH COULD CAUSE SERIOUS INJURY OR DEATH.

WARNING: ALWAYS USE A PRESSURE REGULATOR, VALVES, AND GAUGES TO CONTROL DRUM AND LINE PRESSURES WHEN PRESSURE TESTING THE SYSTEM. EXCESSIVE PRESSURES MAY CAUSE LINE RUPTURES, EQUIPMENT DAMAGE, OR AN EXPLOSION WHICH COULD RESULT IN PERSONAL INJURY OR DEATH.

Leak test the liquid line, evaporator, and suction line at pressures dictated by local codes.

CAUTION: Do not exceed 200 psig when leak testing the system.

- Charge enough refrigerant into the system to raise the pressure to 100 psig.
- Use a halogen leak detector or halide torch to check for leaks. Be thorough in this test, checking the interconnecting piping joints, the evaporator unit, and the condensing unit.
- If a leak is found during the testing, release the test pressure, break the connection, and remake it as a new joint. Refer to the "Brazing Procedures" in this section of the manual for proper brazing techniques.




FIGURE 42 - Vacuum Pump Hook-up

- 4. If no leak is found, use nitrogen to increase the test pressure to 150 psig, and repeat the leak test. Soap bubbles should be used to check for leaks when nitrogen is added. If a leak is found after increasing the pressure to 150 psig using nitrogen, release the pressure and repair the leak.
- 5. Retest the system to make sure the new connection is solid.
- If a leak is suspected after the system has been fully charged with refrigerant, use a halogen leak detector, halide torch, or soap bubbles to check for leaks.

BRAZING PROCEDURES

Proper brazing techniques are essential when installing refrigerant piping. The following factors should be kept in mind when forming sweat connections.

- When copper is heated in the presence of air, copper oxide forms. To prevent copper oxide from forming inside the tubing during brazing, sweep an inert gas, such as dry nitrogen, through the tubing. Nitrogen displaces air in the tubing and prevents oxidation of the interior surfaces. A nitrogen flow of one to three cubic feet per minute is sufficient to displace the air. Use a pressure regulating valve or flow meter to control the flow.
- Ensure that the tubing surfaces to be brazed are clean, and that the ends of the tubes have been carefully reamed to remove any burrs.
- 3. Make sure the inner and outer tubes of the joint are symmetrical and have a close clearance, providing an easy slip fit. If the joint is too loose, the tensile strength of the connection will be significantly reduced. The overlap distance should be equal to the diameter of the inner tube.
- 4. Wrap the body of each refrigerant line component with a wet cloth to keep it cool during brazing. Also move line insulation and tube grommets away from the joints. Excessive heat can damage these components.
- If flux is used, apply it sparingly to the joint. Excess flux will contaminate the refrigerant system.
- Apply heat evenly over the length and circumference of the joint. The entire joint should become hot enough to melt the brazing material.
- Begin brazing when the joint is hot enough to melt the brazing rod. The hot copper tubing, not the flame, should melt the rod.
- 8. Continue to apply heat around the circumference of the joint until the brazing material is drawn into the joint by capillary action, making a mechanically sound and gas-tight connection. Remove the brazing rod as soon as a complete fillet is formed to avoid possible restriction in the line.
- Visually inspect the connection after brazing to locate any pin holes or crevices in the joint. The use of a mirror may be required, depending on joint location.

REFRIGERANT CHARGING

Once the system is properly installed, leak tested and evacuated, refrigerant charging should begin. Liquid refrigerant is charged into the system through the liquid line access valve.




FIGURE 43 - Time Vs. Pressure Rise After Evacuation

Refrigerant should be charged into the system by weight. Use an accurate scale or a charging cylinder to determine the exact weight of the refrigerant entering the system. Failure to use either a scale or charging cylinder can lead to under-charging or overcharging, resulting in unreliable operation.

The weights of refrigerant required for the evaporator unit and the condensing unit are given in Table 11. The weight of refrigerant required for the system piping can be determined by measuring the refrigerant lines and using the data in Tables 12 and 13. The total system operating charge is calculated by adding the charge weight requirements of each part of the system. Refer to the following example.

TABLE 11 - Operating Unit Refrigerant Charge Weight

	CONDENSING UNIT		EVAPORATOR			
MODEL	R-22	CHARGE	MODEL	R-22 CHARGE		
NUMBER	LBS./CIRC.	TOTAL, LBS.	NUMBER	LBS./CIRC.	TOTAL, LBS	
RAUB-C20	28 lbs.	28 lbs.	BRCB-C20 BRCB-C25	4 lbs. 5 lbs.	4 lbs. 5 lbs.	
RAUB-C25	31 lbs.	31 lbs.	BRCB-C25 BRCB-C30	5 lbs. 6 lbs.	5 lbs. 6 lbs.	
RAUB-C30	40 lbs.	40 lbs.	BRCB-C30 BRCB-C40*	6 lbs. 8 lbs.	6 lbs. 6 lbs.	
RAUB-C40	29 lbs.	58 lbs.	BRCB-C40 BRCB-C50 (2) BRCB-C20 (2) BRCB-C25	4 lbs. 5 lbs. 4 lbs. 5 lbs.	8 lbs. 10 lbs. 8 lbs. 10 lbs.	
RAUB-C50	31 lbs.	62 lbs.	BRCB-C50 (2) BRCB-C25 (2) BRCB-C30	5 lbs. 5 lbs. 6 lbs.	10 lbs. 10 lbs. 12 lbs.	
RAUB-C60	40 lbs.	80 lbs.	(2) BRCB-C30 (2) BRCB-C40	6 lbs. 8 lbs.	12 lbs. 16 lbs.	

^{*} Tee together as one circuit.

EXAMPLE: The installation consists of an RAUB 25 condensing unit, a BRCB 2500 evaporator, and 30-feet of 7/8-inch liquid line and 1-5/8-inch suction line and a filter drier. The refrigerant charges are as follows:

RAUB 25	= 31 lbs.
BRCB 2500	= 5 lbs.
Liquid line	
(3.79 oz./ft. x 30 ft. x 1/16 oz./lb.)	= 7.2 lbs.
Suction Line	
(.288 oz./ft. x 30 ft. x 1/16 oz./lb.)	= 0.5 lbs.
Filter Drier	= 1.1 lbs.
TOTAL CHARGE	44.8 lbs.
	or approx. 44 lbs13 oz.

WARNING: DO NOT APPLY FLAME TO A REFRIGERANT DRUM IN AN ATTEMPT TO INCREASE THE DRUM PRESSURE. UNCONTROLLED HEAT MAY CAUSE EXCESSIVE DRUM PRESSURES AND AN EXPLOSION MAY RESULT CAUSING SERIOUS PERSONAL INJURY OR DEATH.

WARNING: SHOULD LIQUID REFRIGERANT COME IN CONTACT WITH THE SKIN, THE INJURY SHOULD BE TREATED AS IF THE SKIN HAS BEEN FROSTBITTEN OR FROZEN. SLOWLY WARM THE AFFECTED AREA WITH LUKEWARM WATER. SEEK MEDICAL ATTENTION.

Proceed as follows to charge the system with refrigerant.

Charge liquid refrigerant into the liquid line of the No. 1 compressor circuit, using the liquid line access valve. The vacuum within the system will draw most of the required refrigerant into the system. If the pressure within the system equalizes with the pressure in the charging cylinder before the required charge has been drawn in, proceed to Step 2.

NOTE: On 40, 50 and 60-ton units, this charging process must be repeated for compressor circuit Number 2.

- If the system cannot be completely charged by liquid refrigerant entering the system liquid line as outlined in Step 1, complete the process by charging gaseous refrigerant into the suction line. Proceed as follows:
 - a. Close the liquid line valve on the manifold gauge set.
 - Connect the manifold gauge set to the suction and discharge access valves (shown in Figure 44). The manifold valves should be closed.
 - Start the unit by following the procedures outlined in the SYSTEM START-UP section of this manual.
 - d. With the condensing unit operating, slowly open the suction line valve on the manifold gauge set. The remainder of the refrigerant will be drawn into the system.

CAUTION: Do not allow liquid refrigerant to enter the suction line. Excessive liquid will damage the compressor.

CHECKING REFRIGERANT CHARGE

Before taking measurements to determine if the system is correctly charged with refrigerant, verify that all other aspects of the system operation are proper. The following conditions must be checked and satisfied.

TABLE 12 - Refrigerant Line Charge Weight

TUBE O.D.	REFRIGERANT LINE CHG. WT. (Oz/Ft)				
(INCHES)	LIQUID LINE	SUCTION LINE			
5/8	1.827				
3/4	2.728				
7/8	3.790				
11/8	6.461	Maria de Caración			
13/8		0.203			
15/8		0.288			
21/8		0.500			

TABLE 13 - Filter Drier Refrigerant Charge

CONDENSING UNIT	LIQUID LINE O.D.	SPORLAN PART NO.	REFRIGERANT CHARGE OUNCES
RAUB-C20/C40	5/8	C-305-S	1 lb 1 oz.
	3/4	C-307-S	1 lb 1 oz.
	7/8	C-307-S	1 lb 1 oz.
	11/8	C-419-S	1 lb 8 oz.
RAUB-C25/C50	5/8	C-305-S	1 lb 1 oz.
	3/4	C-307-S	1 lb 1 oz.
	7/8	C-307-S	1 lb 1 oz.
	11/8	C-419-S	1 lb 8 oz.
RAUB-C30/C60	3/4	C-417-S	1 lb 8 oz.
	7/8	C-417-S	1 lb 8 oz.
	11/8	C-419-S	1 lb 8 oz.

WARNING: EXERCISE EXTREME CAUTION WHEN CHECK-ING ROTATION OF CONDENSER AND EVAPORATOR FANS TO AVOID ENTANGLEMENT IN FAN BLADES. FAILURE TO EX-ERCISE CAUTION MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH.

- Check the evaporator and condenser fans to ensure that they are rotating in the proper direction, that the fan blades do not have dirt buildup, and that each fan is turning at the proper RPM. Make sure that the evaporator fan RPM is correct for the airflow desired and for the external static pressure being imposed by the duct system.
- 2. Make sure the evaporator air filters are clean.
- Check the evaporator and condenser coils to ensure that they are clean, that the fins are straight, and that there are no obstructions to airflow.
- 4. Measure the suction line superheat and adjust the expansion valve, if necessary. (Refer to "Measuring Superheat" in the MAINTENANCE PROCEDURES section of this manual.) The expansion valve superheat setting must be between 12 and 16 F.

Visually inspect the liquid line sight glass to see if clear liquid is present. Bubbles in the liquid line sight glass indicate either low refrigerant charge, excess liquid line pressure drop, or excess liquid line heat gain.

CAUTION: A clear sight glass does NOT necessarily mean the system has sufficient refrigerent.

After verifying that the system is operating properly, determine if the refrigerant charge is correct. This is accomplished by checking both system operating pressures **and** subcooling leaving the condensing unit.

CAUTION: It is not sufficient to check only operating pressures or only subcooling. Both must be in the acceptable range in order to establish correct system charge.




FIGURE 44 - Compressor Access Valves

Operating Pressures:

Measure the suction and discharge line pressures and compare these readings with the normal operating pressures listed in Figures 45 through 50 and Tables 14, 15 and 16. Refer to "Operating Pressures" in the MAINTENANCE PROCEDURES section of this manual. Figure 44 illustrates suction and discharge service valves.

Subcooling:

Determine the system subcooling. (Refer to "Measuring Subcooling" in the MAINTENANCE PROCEDURES section of this manual.) If the system is properly charged, subcooling at the liquid line access valve should be 14 to 19 F.

The system is low on refrigerant if: 1) the suction and discharge pressures are lower than the normal operating pressures as determined from Figures 45 through 50 and Tables 14, 15, and 16, 2) liquid subcooling is low (less than 14-19 F).

The system is overcharged with refrigerant if: 1) the suction and discharge pressures are higher than normal operating pressures, and 2) liquid subcooling is high (greater than 14-19 F).

CAUTION: If both the suction and discharge pressures are low but subcooling is in the acceptable range, the system has a problem other than a shortage of refrigerant. Do not add refrigerant. Refer to the TROUBLESHOOTING section of this manual.

Adding Refrigerant:

Use the suction line access valve to add refrigerant to a system with a low charge, making sure that only refrigerant vapor enters the suction line. Continue to add refrigerant until the subcooling is between 14 and 19 F. At this point, the operating pressures should be within the limits defined by Figures 45 through 50 and Tables 14 through 16.

Removing Refrigerant:

If the system is overcharged, some refrigerant must be removed to lower the subcooling to the 14-19 F range. Refrigerant should be discharged from the system slowly to keep oil loss at a minimum. The liquid line access valve can be depressed to remove refrigerant. However, refrigerant should not be discharged into the atmosphere.

CAUTION: Do not allow refrigerant to come in contact with the skin. If this occurs, the injury should be treated as if the skin has been frostbitten or frozen. Slowly warm the affected area with lukewarm water.

OPERATING PRESSURES

Operating pressure data can be used to determine if the system is operating properly. System malfunctions — such as low airflow, line restrictions, incorrect refrigerant charge, malfunctioning expansion valve, damaged compressor, and so on — will result in pressure variations which are outside the normal range. If the

condensing unit and evaporator are checked individually, as described below, the operating pressures can be used to determine which side of the system (high side or low side) is malfunctioning. In addition, the relationship of suction vs. discharge pressure, as well as whether these pressures are higher or lower than expected, will provide valuable clues for determining the specific problem(s).

CAUTION: Operating pressure data, by itself, cannot be used to accurately charge system. Charging by weight is preferred. If this is not feasible, a combination of operating pressures and subcooling measurement is necessary to properly charge the system. Refer to "Checking Refrigerant Charge" in the MAINTENANCE section of this manual.

Unfortunately, many application variables exist which affect operating pressures. These include indoor dry bulb and wet bulb temperature, outside dry bulb temperature, suction line pressure drop, and evaporator airflow. Since these variables can give misleading results, it is not recommended that operating pressures be used as the sole check of system operation. Further, the following conditions must be satisfied before checking system operating pressures.

- The outdoor ambient temperature must be between 65 and 105 F. At ambient temperatures outside of this range, meaningful operating pressures cannot be measured.
- The relative humidity of the air entering the evaporator must be above 40 percent. If it is less than 40 percent, meaningful operating pressures cannot be measured.
- All compressors must be operating fully loaded. Set the thermostat as necessary to accomplish this.
- All condenser fans must be operating. If necessary, jumper the fan pressure switches. Be sure to remove the jumpers when measurements are completed.
- 5. Do not take measurements with the low ambient dampers and/or hot gas bypass operating. Disconnect the low ambient dampers and de-energize the hot gas bypass before taking measurements. Be sure to reconnect low ambient dampers/hot gas bypass after taking measurements.

Use the following steps to check operating pressures.

- Condensing unit performance (this is a check of only the condensing unit, not the system).
 - Measure pressures (psig) at the suction and discharge line access valves next to the compressor.
 - Measure the dry bulb air temperature (F) entering the condenser coil.
 - c. If the outside ambient is between 65 and 105 F, enter the appropriate graph in Figures 45 through 50 at the measured suction pressure and condenser ambient. Read the corresponding discharge pressure.
 - d. The measured discharge pressure should be within ±7 psig of the graph pressure. If the difference is greater than ±7 psig, refer to the TROUBLESHOOTING section of this manual.

2. Evaporator Performance:

- Measure the actual wet bulb temperature (F) of the air entering the evaporator. Be sure to measure the mixed air condition if outside air is being ducted in.
- b. Find the correct combination of condensing unit and evaporator from Table 14. Match the condenser entering air temperature (measured in Step 1) with the evaporator wet bulb temperature (measured in Step 2) to determine the correct suction pressure.
- Use Table 15 to correct the suction pressure (from Table 14) for the line sizes used in your installation.
- d. Use Table 16 to correct the suction pressure (from Step
 2) for the airflow of your evaporator.
- The measured suction pressure at the compressor should be within ±2 psi of the corrected pressure from Tables 14 through 16. If not, improper system operation is indicated. Refer to the TROUBLESHOOTING section of this manual.

CAUTION: Table 14 is not accurate if the relative humidity of the entering evaporator air is less than 40%, or if an evaporator/condensing unit other than those listed is used.

TABLE 14 - Compressor Suction Pressures (PSIG)

								C	ONDEN	SER AN	ABIENT	F					
						65 75 85							95			105	
			EVAP.	WET BULB, F			WET BULB, F		WET BULB, F			WET BULB, F			WET BULB, F		
CONDENSING		AIRFLOW	55	60	65	55	64	72	55	65	75	55	65	75	55	65	75
UNIT	EVAPORATOR	(SCFM)					CON	APRESS	SOR SU	CTION	PRESSI	JRES, I	SIG	•			
RAUB-C20	BRCB-C20	8,000	48.1	53.3	58.9	50.2	60.1	70.0	52.2	63.6	76.7	54.1	65.8	79.3	56.0	68.0	81.8
	BRCB-C25	10,000	51.6	57.4	63.7	53.5	64.5	75.6	55.4	67.9	82.5	57.2	70.0	84.8	58.9	72.0	87.1
RAUB-C25	BRCB-C25	10,000	50.2	55.6	61.4	51.7	61.9	72.1	53.4	65.1	78.4	55.3	67.2	80.8	57.4	69.6	83.5
	BRCB-C30	12,000	53.9	59.6	65.7	55.3	66.1	76.8	56.9	69.2	83.2	58.7	71.2	85.5	60.6	73.4	87.9
RAUB-C30	BRCB-C30	12,000	50.3	55.7	61.5	51.9	62.1	72.4	53.6	65.3	78.7	55.4	67.3	81.0	57.2	69.4	83.4
A SECOND SECURITY	BRCB-C40	16,000	55.2	61.4	67.7	56.6	68.1	79.4	58.2	71.2	86.0	59.8	73.0	88.0	61.4	74.9	90.1
RAUB-C40	BRCB-C40	16,000	48.5	53.7	59.3	50.5	60.5	70.5	52.5	64.0	77.2	54.5	66.2	79.7	56.3	68.4	82.3
	BRCB-C50	20,000	52.4	58.1.	64.2	54.4	65.1	75.9	56.3	68.5	82.7	58.1	70.7	85.1	59.8	72.7	87.4
	BRCB-C20(2)	16,000	48.0	53.2	58.8	50.1	60.0	69.9	52.1	63.5	76.5	54.1	65.7	79.1	55.9	67.9	81.7
	BRCB-C25(2)	20,000	51.5	57.3	63.5	53.4	64.4	75.4	55.3	67.8	82.3	57.1	69.9	84.7	58.9	71.9	87.0
RAUB-C50	BRCB-C50	20,000	50.7	55.9	61.5	52.2	62.1	72.0	53.9	65.2	78.2	55.9	67.4	80.7	58.1	69.9	83.4
	BRCB-C25(2)	20,000	50.3	55.7	61.5	51.8	62.0	72.3	53.5	65.2	78.6	55.4	67.4	81.0	57.5	69.8	83.7
AND PART	BRCB-C30(2)	24,000	54.0	59.7	65.8	55.4	66.2	77.0	57.0	69.3	83.4	58.8	71.4	85.7	60.8	73.6	88.2
RAUB-C60	BRCB-C30(2)	24,000	50.3	55.7	61.6	52.0	62.2	72.5	53.7	65.4	78.9	55.5	67.5	81.2	57.3	69.6	83.6
	BRCB-C40(2)	32,000	55.2	61.3	67.8	56.7	68.2	79.6	58.3	71.3	86.1	59.9	73.2	88.2	61.5	75.1	90.3

NOTES:

^{1.} Table only good for relative humidity of air entering evaporator greater than 40%.

^{2.} Interpolation between wet bulb temperatures is allowable. Do not extrapolate outside range given.


TABLE 15 - Suction Pressure Correction for Line Size (PSI)

CONDENSING	1%" O.D. SUCTION LINE LENGTH, FEET												
UNIT	0*	25	50	75	100	125	150	175	200				
RAUB-C20	-1.1	-2.5	-3.7	-4.9	-6.0	-7.0	-7.9	-8.8	-9.7				
RAUB-C40	-1.1	-2.5	-3.8	4.9	-6.0	-7.0	-8.0	-8.9	-9.7				
CONDENSING	144" O.D. SUCTION LINE LENGTH, FEET												
UNIT	0	25	50	75	100	125	150	175	200				
RAUB-C20	+0.7	0	-0.6	-1.3	-1.8	-2.4	-3.0	-3.5	-4.0				
RAUB-C25	-1.3	-2.3	-3.2	-4.1	4.9	-5.7	-6.4	-7.1	-7.8				
RAUB-C30	-1.7	-3.0	4.2	-5.3	-6.3	-7.3	-8.2	-9.0	-9.9				
RAUB-C40	+0.7	0	-0.6	-1.2	-1.8	-2.4	-3.0	-3.5	4.0				
RAUB-C50	-1.3	-2.2	-3.1	-3.9	-4.7	-5.4	-6.1	-6.8	-7.4				
RAUB-C60	-1.8	-3.1	4.2	-5.4	-6.4	-7.3	-8.2	-9.1	-9.9				
CONDENSING	21/4" O.D. SUCTION LINE LENGTH, FEET												
UNIT	0	25	50	75	100	125	150	175	200				
RAUB-C20	+1.8	+1.6	+1.4	+1.2	+1.0	+0.8	+0.7	+0.5	+0.3				
RAUB-C25	+0.3	0	-0.2	-0.5	-0.8	-1.1	-1.3	-1.6	-1.8				
RAUB-C30	+0.4	0	-0.3	-0.7	-1.1	-1.4	-1.8	-2.1	-2.4				
RAUB-C40	+1.8	+1.6	+1.4	+1.2	+1.0	+0.9	+0.7	+0.5	+0.3				
RAUB-C50	+0.2	0	-0.3	-0.6	-0.8	-1.1	-1.3	-1.6	-1.8				
RAUB-C60	+0.4	0	-0.4	-0.7	-1.1	-1.5	-1.8	-2.2	-2.5				

^{* 0} feet provided for interpolation purposes only.


TABLE 16 - Suction Pressure Correction for Airflow (PSI)

			100	PERCENT OF I	RATED EVAPOR	RATOR AIRFLO	N		
CONDENSING UNITS	-20%	-15%	-10%	-5%	0%	+5%	+10%	+15%	+20%
RAUB-C20-60	-2.6	-1.9	-1.2	-0.6	0	+0.5	+1.0	+1.4	+1.9



COMPRESSOR SUCTION PRESSURE (PSIG)


FIGURE 45 - RAUB-C20 Operating Pressures



COMPRESSOR SUCTION PRESSURE (PSIG)


COMPRESSOR DISCHARGE PRESSURE (PSIG)

NOTE: PRESSURES GIVEN WITH ALL CONDENSER FANS OPERATING




COMPRESSOR SUCTION PRESSURE (PSIG)

FIGURE 47 - RAUB-C30 Operating Pressures




COMPRESSOR SUCTION PRESSURE (PSIG)



COMPRESSOR SUCTION PRESSURE (PSIG)

FIGURE 49 - RAUB-C50 Operating Pressures



COMPRESSOR SUCTION PRESSURE (PSIG)

THERMOSTATIC EXPANSION VALVE ADJUSTMENT AND SUPERHEAT MEASUREMENT

Since the reliability and performance of the refrigeration system is heavily dependent on proper expansion valve adjustment, the importance of proper suction gas superheat cannot be overemphasized. The accurate measurement of suction superheat will provide the following information:

- How well the expansion valve is controlling the refrigerant flow.
- 2. The efficiency of the evaporator coil.
- The amount of protection the compressor is receiving against flooding or overheating.

The safe setting range for suction gas superheat on Trane equipment is 12 to 16 degrees at the evaporator. Settings within this range will allow for measurement error. Superheat of less than 12 degrees can cause refrigerant floodback which could cause serious compressor damage. Superheat greater than 16 degrees can reduce system efficiency by reducing the effective evaporator surface.

CAUTION: When checking the superheat setting, the outdoor ambient must be between 65 and 105 F. Entering evaporator air should be above 40 percent relative humidity and all condenser fans and compressors must be operating fully loaded.

To determine suction gas superheat, the pressure at the outlet of the evaporator must be measured and then converted to saturated vapor temperature by using a Refrigerant-22 pressure/temperature chart. The saturated vapor temperature can then be subtracted from the actual suction temperature which is measured on the suction line close to the expansion valve bulb. The difference between the two temperatures is known as suction gas superheat. On many Trane fan/coil units an access valve is provided close to the expansion valve bulb. This valve must be added on Climate Changers and other evaporators which are not so equipped. To obtain an accurate reading, an access valve

TABLE 17 - Pressure/Temperature Conversions for Calculating Suction Line Superheat

SATURATED TEMPERATURE	PRESSURE USING REFRIGERANT-22
30	54.9
31	56.2
32	57.5
33	58.8
34	60.1
35	61.5
36	62.8
37	64.2
38	65.6
39	67.1
40	68.5
41	70.0
42	71.4
43	73.0
44	74.5
45	76.0
46	77.6
47	79.2
48	80.8
49	82.4
50	84.0

close to the expansion valve bulb must be utilized when determining suction gas superheat.

Instruments to Use

- The gauge used to measure suction pressure should be of the best quality available. Gauges permanently installed on the equipment should not be used. A good quality gauge on a standard refrigerant manifold set is recommended.
- To measure suction temperature, an electronic temperature tester will be sufficient. Testers manufactured by Robinnaire, Annie, and Thermal are among those available. Glass thermometers do not have sufficient contact area to give accurate readings.

Procedure

- Cut the suction line insulation to gain access to the suction line. If armaflex is used, it is best to cut around the circumference of the tubing.
- Clean the line carefully and attach the electronic temperature sensor. Black electrical tape works well when securing the sensor of the temperature tester to the suction line. (Make sure the sensor is making good contact with the tube.)
- Rejoin the armaflex and seal with plastic tape to prevent sensor contact with ambient air.

NOTE: For measurement accuracy the temperature sensor **must** be installed and insulated properly. Make sure the armaflex extends at least six inches on both sides of the sensor location. Seal both ends of the armaflex to keep ambient air from getting under the insulation and affecting the temperature readings.

- 4. Install a pressure gauge to monitor suction pressure.
- Operate the system for approximately 10 to 15 minutes to be sure that the expansion valve has time to stabilize.
- To measure superheat, compare the saturated vapor temperature of the refrigerant converted from the suction pressure reading (see Table 17) to the actual temperature measured at the line by the electronic tester. Proper suction superheat is 12 to 16 degrees.

EXAMPLE:

Suction Pressure = 66.0 psig

Suction Temperature = 52 F

Suction Pressure converted to Saturated Vapor Temperature (from Table 17) = 38 F

Suction Superheat

- = (Actual Line Temp.) (Saturated Vapor Temp.)
- = (52 F) (38 F)
- = 14 F

If initial suction superheat readings fall below 12 degrees, the adjusting stem on the expansion valve should be adjusted clockwise to close the valve, limiting the flow of refrigerant to the evaporator and thus increasing superheat. Adjustment should be made a half turn at a time. Conversely, if the initial suction superheat reading is greater than 16 degrees, the adjusting stem on the expansion valve should be adjusted counterclockwise to open the valve, increasing the flow of refrigerant to the evaporator and thus decreasing superheat. Adjustments should be made until an acceptable reading is obtained. The system should be allowed to restabilize for 10 minutes after each adjustment.

MEASURING SUBCOOLING

- The outdoor ambient temperature must be between 65 and 105 F. At ambient temperatures outside of this range, meaningful operating pressures cannot be measured.
- The relative humidity of the air entering the evaporator must be above 40 percent. If it is less than 40%, meaningful operating pressures cannot be measured.
- All compressors must be operating fully loaded. Set the thermostat as necessary to accomplish this.
- All condenser fans must be operating. If necessary, jumper the fan pressure switches. Be sure to remove the jumpers when measurements are completed.
- 5. Do not take measurements with the low ambient dampers and/or hot gas bypass operating. Disconnect the low ambient dampers and de-energize the hot gas bypass before taking measurements. Be sure to reconnect low ambient dampers/hot gas bypass after taking measurements.

The proper setting range for liquid subcooling is 14 to 19 F. The compressor must be fully loaded and both compressors must be operating if so equipped. Use these steps to measure subcooling:

- Measure the liquid line pressure at the liquid line access valve installed inside the condensing unit. Convert this pressure reading to saturated temperature by using a Refrigerant-22 pressure/temperature chart (refer to Table 18).
- 2. Measure the actual liquid line temperature on the liquid line close to the access valve. To ensure an accurate reading, clean the line thoroughly where the electronic temperature sensor will be attached. Glass thermometers do not have sufficient contact area to give accurate readings. After securing the sensor to the line, wrap the sensor and line with insulation to prevent contact with ambient air.
- Determine the system subcooling by subtracting the actual liquid line temperature (measured in Step 2) from the saturated liquid temperature (calculated in Step 1).
- If the system is properly charged, subcooling at the liquid line access valve should be 14-19 F.

COMPRESSOR OIL CHARGE

Proper oil charge is critical for reliable operation of reciprocating compressors. Both undercharging and overcharging will result in compressor damage.

On most applications, the factory oil charge is correct and no addition of oil is required. However, it may be necessary to add oil to systems which have extremely long interconnecting lines.

An oil level sight glass is integral to the compressor shell in order to confirm proper oil charge on all 20 through 60-ton units. The following procedure should be followed:

- Check the oil level prior to initial refrigerant charging and start-up of a new system. To be proper, the oil level must be visible in the sight glass. Note the oil level mark for future reference.
 - Approximately one hour after initial start-up, and after the oil sump is warm to the touch check the oil level with the compressor running **fully loaded**. The oil level must be visible in the sight glass. If it is not visible, add oil until the level is halfway up the sight glass.

TABLE 18 - Pressure/Temperature Conversion for Calculating Liquid Line Subcooling

SATURATED TEMPERATURE	PRESSURE USING REFRIGERANT-22				
70	121.4				
75	132.2				
80	143.6				
85	155.7				
90	168.4				
95	181.8				
100	195.9				
105	210.8 226.4				
110					
115	242.7				
120	259.9				
125	277.9				
130	296.8				
135	316.6				
140	337.2				
145	358.9				
150	381.5				

CAUTION: Do not attempt to check the oil level at part load compressor operation. It is not intended that the oil level be visible in the sight glass under these conditions. Adding oil could result in a compressor overcharge and subsequent compressor damage.

 Allow the compressor to run at full load until the compressor sump is warm to the touch. If the oil level increases from Step 2, oil should be removed and the process repeated until the sight glass level is maintained at the halfway mark.

CAUTION: Checking oil level with a cold sump can incorrectly indicate excessive oil charge due to refrigerant in the oil.

TROUBLESHOOTING

The Troubleshooting Chart on the following pages is provided to serve as an aid for identifying the cause of any system malfunctions that may occur. The chart is divided into three columns:

- the "SYMPTOM" column describes the behavior the unit is exhibiting;
- the "PROBABLE CAUSE" column identifies possible sources of malfunction;
- the "RECOMMENDED ACTION" column indicates the procedures required to correct the malfunction.

If operating difficulties are encountered, make the following preliminary checks before referring to the Troubleshooting Chart:

Check the thermostat to ensure that it is properly set, re-
ceiving control power, and "making/breaking" on a call for
heating or cooling.

Verify that the unit is receiving electrical supply power, an	IC
that the fuses are intact.	

Check the filters to make sure they are positioned properly, and free of dirt and debris.

After completing the checks listed above, inspect the system for other obvious causes of trouble such as broken fan belts, a clogged condenser coil, or restricted air ducts. If everything appears to be in order, but the unit still fails to operate properly, refer to the appropriate section of the Troubleshooting Chart.

NOTE: The Troubleshooting Chart which follows is provided solely as a guide for determining the cause of mechanical failure or malfunction. When mechanical problems do occur, Trane recommends that trained service personnel be contacted to help ensure proper diagnosis and repair of the unit.

WARNING: OPEN THE UNIT DISCONNECT SWITCH AND LOCK IT IN THAT POSITION TO PREVENT ACCIDENTAL START-UP. NEVER OPEN AN ACCESS PANEL TO INSPECT OR SERVICE THE UNIT WITHOUT FIRST OPENING THE DISCONNECT SWITCH. FAILURE TO DO SO MAY RESULT IN INJURY OR DEATH FROM ELECTRICAL SHOCK OR CONTACT WITH MOVING PARTS.

TROUBLESHOOTING CHART

	SYMPTOM	P	PROBABLE CAUSE		RECOMMENDED ACTION
A.	Compressor does not start, and does not hum.	1.	No power to unit.	1.	Check for the following:
					a. Disconnect switch open.
				\$. ·	b. Fuses blown.
		2.	No call for cooling.	2.	Check for the following:
					a. Defective thermostat.
					b. Broken or improper control wiring.
					c. Blown control power fuse.
		3.	Anti-recycle timer has not timed out (if installed).	3.	Wait at least five minutes for the anti-recycle timer to time out.
		4.	Unit locked out by reset relay.	4.	Check for the following:
				V	 a. Excessive discharge pressure. Refer to Symptom L, "Discharge pressure too high".
					b. Defective high pressure control.
					 c. Compressor winding stat open. Refer to Low Suction Pressure.
					 Defective comp. protector or fuse-check for winding stats shorted to motor windings.
		E. W.			e. Defective reset relay contact.
					f. Comp. current overload open. Refer to Symptom F.
		5.	Compressor contactor will not close.	5.	Check for the following:
				- 4/8	a. Defective comp. contactor.
					b. Improper wiring.
					c. Reset relay open.
					d. Low pressure control open.
					 Cooling relay not energized. Defective relay-check thermostat circuit. See Symptom A, Cause 2.
		6.	Compressor winding stat open.	6.	Refer to Symptom F.
		155			a. Check compressor amp draw.
		1			b. Defective low pressure control - replace.

	SYMPTOM	A COLA	PROBABLE CAUSE		RECOMMENDED ACTION
B.	Compressor hums, but will not start.	1.	Low voltage at the compressor.	1.	Check for the following:
		Diam.			a. A single blown fuse.
					b. Low line voltage.
	ar days kara took blooms	(per			c. Defective compressor contactor.
					d. Loose wiring connections.
					e. Defective part winding start time delay.
		2.	Defective compressor.	2.	Check for the following:
					a. Open motor winding.
					b. Excessive amp draw on all phases.
) .	Second stage compressor fails to start.	1.	Time delay contacts fail to close.	1.	Replace time delay relay.
		2.	No call for cooling.	2.	Check for the following:
					a. Defective thermostat.
					b. Broken or improper control wiring.
		3.	Unit locked out by reset relay.	3.	Same as A-4.
		4.	Compressor contactor will not close.	4.	Same as A-5.
D.	Compressor short cycles.	1.	Intermittent contact in control circuit.	1.	Check for the following:
			rice and the		a. Defective relay contacts.
		1	1910 Har 37 - 18		b. Loose wiring connections.
		2.	Poor thermostat placement.	2.	Refer to "Thermostat Installation" in the ELECTRICAL WIRING section of this manual.
		3.	Defective anti-recycle timer.	3.	Replace.
		4.	Defective liquid line solenoid valve.	4.	Replace.
		5.	Low refrigerant charge.	5.	Check for leak, add refrigerant.
		6.	Plugged liquid line filter- driers.	6.	Replace.
		7.	Defective low pressure control.	7.	Replace.
		8.	Defective low ambient time delay relay.	8.	Replace.
	Compressor runs continuously.	1.	Unit undersized for load (cannot maintain space temperature).	1.	Check for cause of excessive load.
		2.	Thermostat setpoint too low.	2.	Readjust thermostat.
		3.	Defective thermostat or control wiring (conditioned space too cold).	3.	Replace thermostat. Replace or repair control wiring.
		4.	Welded contacts on compressor contactor.	4.	Repair or replace contactor.

SYMPTOM	PROBABLE CAUSE	RECOMMENDED ACTION
	5. Leaky valves in compressor (indicated by operation at abnormally low discharge and high suction pressures).	5. Replace compressor.
	6. Shortage of refrigerant (indicated by reduced capacity coupled with high superheat, low subcooling, and low suction pressure).	6. Find and repair refrigerant leak. Recharge system.
	Liquid line solenoid valve stuck open.	7. Repair/replace.
	Defective low pressure control.	8. Replace.
F. Compressor motor winding stat open.	Excessive load on evaporator (indicated by high supply air temperature).	Check for the following:
		a. Excessive airflow.
		b. High return air temperature.
	Lack of motor cooling (indicated by excessive superheat).	2. Check for the following:
		a. Improper expansion valve setting.
		b. Faulty expansion valve.
	eron kalina kanana arang arang kanana	c. Restriction in liquid line.
	Improper voltage at compressor.	3. Check for the following:
		a. Low or imbalanced line voltage.
		b. Loose power wiring.
		c. Defective compressor contactor.
	Internal parts of compressor damaged.	4. Replace compressor.
G. Compressor is noisy.	Internal parts of compressor damaged or broken (compressor knocks).	Replace compressor.
	Liquid floodback (indicated by abnormally cold suction line and low superheat).	2. Check and adjust superheat.
	Liquid refrigerant in the compressor at start-up. (Indicated by abnormally cold compressor shell.)	3. Replace crankcase heater.
H. System short of capacity.	Low refrigerant charge (indicated by low subcooling and high superheat).	Add refrigerant.
	Clogged filter drier (indicated by temperature change in refrigerant line through drier).	2. Replace filter drier or core of drier.
	Incorrect thermostatic expansion valve setting.	Readjust expansion valve.

SYMPTOM	PROBABLE CAUSE	RECOMMENDED ACTION
	Expansion valve stuck or obstructed (indicated by high superheat and high space temperature).	4. Repair or replace expansion valve.
	5. Low evaporator airflow.	5. Check filters. Adjust airflow.
	6. Noncondensibles in system.	Evacuate and recharge system.
	7. Leaky valves in compressor (indicated by operation at abnormally low discharge and high suction pressures).	7. Replace compressor.
I. Suction pressure too low.	Shortage of refrigerant (indicated by high superheat and low subcooling).	Find and repair refrigerant leak. Recharge system.
	Thermostat set too low (indicated by low discharge pressure and low space temperature).	2. Re-adjust thermostat.
	3. Low airflow.	 Check for clogged filters, incorrect fan speed, or high duc static pressure.
	4. Clogged filter drier.	4. Check for frosting on filter drier. Replace if necessary.
	Expansion valve power assembly has lost charge.	5. Repair or replace expansion valve power head assemble
	Obstructed expansion valve (indicated by high superheat).	6. Clean or replace valve.
Suction pressure too high.	Excessive cooling load (indicated by high supply air temperatures).	See Symptom E, "Compressor runs continuously".
	Overfeeding of expansion valve (indicated by abnormally low superheat and liquid flooding to compressor).	Adjust superheat setting and check to see that remote bul is properly attached to suction line.
	Suction valves broken (indicated by noisy compressor).	3. Replace compressor.
K. Discharge pressure too low.	Shortage of refrigerant (indicated by low subcooling and high superheat plus bubbles in sight glass).	Repair leak and recharge system.
	Broken or leaky compressor discharge valves (indicated by suction and discharge pressures that equalize rapidly after shutdown).	2. Replace compressor.
	Condenser fan control stuck in closed position (contacts closed when pressure is below 155 psig.)	3. Replace defective control.
	Unit running below minimum operating ambient.	 Provide adequate heat pressure controls or a unit ambier lockout switch.
	5. Low ambient damper stuck open (indicated by low discharge pressure).	Repair or replace damper operator.

(CONTINUED FROM PREVIOUS PAGE)

	SYMPTOM	The state of	PROBABLE CAUSE		RECOMMENDED ACTION
•	Discharge pressure too high.	1.	Too little or too warm condenser air; restricted air flow.	1.	Clean coil. Check fan and motors for proper operation.
		2.	Air or noncondensible gas in system (indicated by exceptionally hot condenser and excessive discharge pressure).	2.	Evacuate and recharge system.
		3.	Overcharge of refrigerant (indicated by high subcooling, low superheat, and high suction pressure).	3.	Remove excess refrigerant.
		4.	Excessive system load.	4.	Reduce load.
		5.	Defective condenser fan or fan pressure control (indicated by one fan off and high condenser pressure).	5.	Repair or replace switch.
		6.	Defective or inoperative low ambient dampers.	6.	Repair or replace defective parts.

IMPORTANT: Fill out the following form when contacting your Trane Service Compan for parts or information.	y
UNIT MODEL NUMBERUNIT TYPE NUMBERDATE OF INSTALLATION	
INSTALLED BY	
ADDRESS	
PHONE	

FWB/DJL



BLDG#AS-3502

Installation Operation Maintenance

RAUB-IOM-4


Library	Service Literature	
Product Section	Unitary	
Product	Split System, 20-60 Tons	
Model	RAUB	
Literature Type	InstOperMain.	
Sequence	4	
Date	March 1985	
File No.	SV-UN-S/S-RAUB-IOM-4-385	
Supersedes	male digher than the area with the	

Supplement to RAUB-IOM-3 for D and E Design Sequence Units

Liquid Line Components

A properly sized liquid line filter drier must be installed upstream from the expansion valve. In addition, a moisture indicator/sight glass should be installed between the expansion valve and filter drier. Both of these components should be installed at the evaporator close to the expansion valve, as shown in Figure 1.

Figure 1 - Diagram of Refrigerant Piping Components in Liquid Line



^{*} Required for charge isolation, for evaporator unloading, or when used with control option F (Remote EYPA).

Note: Install the expansion valve, sight glass, solenoid valve, and filter drier as close to the evaporator as possible.

The number of other valves, reducers and tube bends should be minimized as these items tend to increase the pressure drop and reduce subcooling at the expansion valve.

Liquid line solenoid valves are required for only three reasons: 1) evaporator coil unloading, 2) refrigerant charge isolation, and 3) EVPA control. Refer to the connection diagram pasted on the main control panel access door for proper field wiring.

Evaporator Coil Unloading -- A solenoid valve may be used to unload part of the evaporator coil when the compressor is unloaded. When unloading the evaporator coil, make sure that the percentage of coil surface active is always greater than or equal to the percentage of compressor capacity.

Refrigerant Charge Isolation -- For charge isolation, liquid line solenoid valves can be installed to entirely shut off refrigerant flow. This reduces the refrigerant migrating from the condenser to the evaporator during the off cycle and in some situations reduces the amount of liquid refrigerant entering the compressor. This measure is not necessary; charge isolation is most effective when refrigerant line lengths are greater than 100 feet.

EVPA Control -- A liquid line solenoid for each refrigerant circuit is always required on units applied with remote EVPA.

Hot Gas Bypass Solenoid Valve

The removal of pumpdown does not affect the application of hot gas bypass. However, some hot gas bypass systems will no longer require the hot gas shutoff solenoid valve that is now used with hot gas bypass valves. This will save jobsite installation costs. Use the following table to determine if hot gas solenoid valves are required.

Unit Size	Control Option	Hot Gas Solenoid Valve and Wiring Required?
RAUB-C20 - 60	A, B, C, D, F	Yes
RAUB-C20, 25, 30, 40	E	No*
RAUB-C40, 50, 60	E	No**

^{*} No. 1 Compressor only on RAUB-C40.

Valves requiring solenoid valves and wiring are pilot operated and have an integral pilot solenoid which must be wired for the valve to operate. When charge isolation is required, a hot gas shutoff solenoid is required. Refer to the connection diagram pasted on the main control panel access door for proper field wiring.

Suction Line Components

A suction line filter is factory-installed and connected with a short stub to the suction service valve. This suction line filter increases the reliability of the compressor by improving the cleanliness of the system.

^{**} No. 2 Compressor on RAUB-C40.

TAB PLACEMENT HERE

DE	SCRIPTION:
	BurnHam
	Steel Boiler
Ц	Tab page did not contain hand written information
	Tab page contained hand written information *Scanned as next image

Confidential Records Management, Inc. New Bern, NC 1-888-622-4425 9/08





OPERATION AND MAINTENANCE MANUAL

for

STEEL BOILERS

(Including Water Treatment)



BURNHAM CORPORATION HYDRONICS DIVISION Lancaster, PA 17604

THE HYDRONICS INSTITUTE

35 Russo Pl. Berkeley Heights, N.J. 07922

April 1985

PREFACE

The useful service life of a steel boiler depends almost entirely on the diligence of those who are charged with the responsibility of boiler maintenance.

This manual contains recommendations covering boiler maintenance, operation and other details useful to the owner, the maintenance crew, and the operators. It is based on actual experience of many boiler manufacturers, and upon test work done in laboratories, and in the field. It is not intended that this manual should take precedence over the manufacturer's maintenance and operating instructions, if any are supplied, but rather to complement them. In every instance, the manufacturer's recommendations for maintenance and operation of the particular boiler that has been installed should be followed.

This booklet is intended to cover steel boilers which are constructed in accordance with Section IV of the ASME Boiler and Pressure Vessel Code. "Suggested Rules for the Care of Power Boilers", as stated in the ASME Boiler and Pressure Vessel Code Section VII, are recommended as instructions covering the operation and maintenance of high pressure boilers.

A section on Water Treatment is included because of the importance of proper water treatment on the life expectancy of a boiler. It is recommended that a water treatment consultant be engaged to develop the proper program for a boiler as related to local water conditions.

Be sure to check local codes and ordinances before completing plans for any new or replacement boiler installation. It is also advisable to consult a qualified engineer.

Every effort has been made to assure the accuracy of this manual and other publications of the Hydronics Institute, formerly the Institute of Boiler and Radiator Manufacturers. However, neither The Institute nor those responsible for the preparation of I = B = R publications make any representation, or guaranty, or assume, or accept any responsibility or liability with respect thereto.

BOILER ROOM

The boiler room should be well lighted and should have an emergency light source for use in case of power failure. If a flashlight is used for this purpose, it should be maintained in good condition and should be protected against removal from the boiler room.

Proper and convenient water fill connections should be installed and provision should be made to prevent boiler water from back feeding into the service water supply. Provision should also be made in every boiler room for a convenient water supply which can be used to flush out the boiler or to clean the boiler room floor.

Proper and convenient sewer connections should be provided for draining boilers. Unobstructed floor drains, properly located in the boiler room, will facilitate proper cleaning of the boiler room.

The boiler room must have an adequate air supply to permit clean, safe combustion and to minimize soot formation. An unobstructed air opening should be provided. It may be sized on the basis of one square inch per 2000 Btuh maximum fuel input of the combined burners located in the boiler room, or as specified in The National Fire Protection Association, or American Insurance Association standards for oil installations and for gas installations for the particular job conditions. The boiler room air supply opening must be kept clear at all times.

CLEANING AND FILLING A NEW BOILER

Steam Boiler

Before putting water into a new boiler, make certain that the firing equipment is in operating condition to the extent that this is possible without actually lighting a fire in the empty boiler. This is necessary because raw water must be boiled (or heated to at least 180° F) immediately after it is introduced into the boiler, in order to drive off the dissolved gases, which might otherwise corrode the boiler.

Fill the boiler to the proper water line and operate the boiler with steam in the entire system for a few days to bring the oil and dirt back from the system to the boiler. This is not necessary if the condensate is to be temporarily wasted to the sewer, in which case the system should be operated until the condensate runs clear.

The oil and greases which accumulate in a new steam boiler can usually be washed out by boiling as follows:

- (a) Fill the boiler to the normal waterline.
- (b) Remove the safety valve.
- (c) Provide a boil-out compound of caustic soda and trisodium phosphate in the proportions of 2½ lbs. of each chemical per 120 gallons of boiler water. Caution: Use care in handling these chemicals. The caustic soda is extremely corrosive to skin and clothing. Do Not Permit Either the Dry Material or the Concentrated Solution to Come into Contact with Skin or Clothing.
- (d) Mix the chemicals with water and pour into the boiler through the safety valve opening.
- (e) Replace the safety valve.
- (f) Start the firing equipment.
- (g) Boil the water for at least 5 hours.
- (h) Stop the firing equipment.
- (i) Drain the boiler in a manner and to a location that hot water can be discharged with safety.
- (j) Wash the boiler thoroughly, using a hose with sufficient pressure.
- (k) Fill the boiler to the normal waterline.
- (1) Add a charge of boiler water treatment compound.
- (m) Boil, or bring water temperature to at least 180° F immediately.
- (n) The boiler is now ready to be put into service or on stand-by.

In stubborn cases this simple boil-out may not remove all the oil and grease, and another boil-out with surface blow-off may be necessary. For this type of cleaning proceed as follows:

- (1) Prepare the boiler for cleaning by running a temporary pipe line from the surface blow-off connection to an open drain or some other location where hot water may be discharged with safety. If no such tapping is available, use the safety valve tapping but run the pipe full size and as short a length as possible. Do not install a valve or any other obstruction in this line.
- (2) Fill the boiler until water reaches the top of the water gauge glass.

- (3) Add caustic soda and trisodium phosphate in the proportions of 2½ lbs. of each chemical per 120 gallons of boiler water. Caution: Use care in handling these chemicals. The caustic soda is extremely corrosive to skin and clothing. Do Not Permit Either the Dry Material or the Concentrated Solution to Come into Contact with Skin or Clothing.
- (4) Start the firing equipment and operate sufficiently to boil the water without producing steam pressure.
- (5) Boil for about five hours.
- (6) Open boiler feed valve sufficiently to permit a steady trickle of water to run out the overflow pipe.
- (7) Continue this slow boiling and trickle of water for several hours until the water coming from the overflow pipe is clear.
- (8) Stop the firing equipment.
- (9) Drain the boiler in a manner and to a location that hot water can be discharged with safety.
- (10) Remove covers and plugs from all washout openings and wash the water side of the boiler thoroughly, using a hose with sufficient pressure.
- (11) Refill boiler to 1" of water in the water gauge glass.

 Note: If water in water gauge glass does not appear to be clear, repeat steps 2 to 11 and boil out the boiler for a longer time.
- (12) Remove temporary piping.
- (13) Close boiler.
- (14) Replace safety valve.
- (15) Add a charge of boiler water treatment compound.
- (16) Boil, or bring water temperature to at least 180° F immediately.
- (17) The boiler is now ready to be put into service or on stand-by.

Hot Water Boiler

Before putting water into a new boiler, make certain that the firing equipment is in operating condition to the extent that this is possible without actually lighting a fire in an empty boiler. This is necessary because raw water must be heated to at least 180° F *immediately* after it is introduced into the boiler, in order to drive off the dissolved gases which might otherwise corrode the boiler.

The oil and grease which accumulate in a new hot water boiler can be washed out in the following manner:

- (a) Add caustic soda or trisodium phosphate to the boiler water at the rate of 1 lb. of either chemical per 50 gallons of total water in the system. Caution: Use care in handling these chemicals. The caustic soda is extremely corrosive to skin and clothing. Do Not Permit Either the Dry Material or the Concentrated Solution to Come Into Contact with Skin or Clothing.
- (b) Fill the entire system with water.
- (c) Start the firing equipment.
- (d) Circulate the water through the entire system.
- (e) Vent the system, including the radiation.
- (f) Allow boiler water to reach operating temperature if possible.
- (g) Continue to circulate the water for a few hours.
- (h) Stop the firing equipment.
- (i) Drain the system in a manner and to a location that hot water can be discharged with safety.
- (j) Wash the water side of the boiler thoroughly, using a hose with sufficient pressure.
- (k) Refill the system with fresh water.
- (1) Bring water temperature to at least 180° F immediately.
- (m) Tighten hand holes, manholes and plugs while boiler is hot.
- (n) The boiler is now ready to put into service or on stand-by.

Deaeration

It is strongly recommended that the water in a boiler be deaerated and be treated with a suitable boiler water treatment compound whenever the boiler is filled with water. This is applicable whether the boiler is in operation or on stand-by, and is particularly necessary immediately upon refilling the boiler after washing, inspection or repair. (See section on Water Treatment.)

Feeding Water Treatment Compound into the System

A feeder for introducing boiler water treatment compound into a boiler is convenient. The feeder may be made of pipe fittings and placed in the return line.

In a system equipped with a pump-assisted return or with a boiler feed pump, the feeder should be placed in the piping on the discharge side of the pump.

Do not introduce water treatment by placing it in a condensate receiver, hot well, or make-up tank.

Local Water Conditions

Local water conditions may necessitate analysis by a suitable water treatment consultant.

START UP

When initially firing the boiler observe the following:

- (a) Never operate a boiler without being sure it is filled with water. This should be obvious but it is repeated here because insurance company records show that many boilers are damaged because a fire was started in an empty boiler.
- (b) When starting the firing equipment, follow the firing equipment manufacturer's instructions, which should be posted in the boiler room.
- (c) Do not light the pilot light until the combustion chamber has been vented.
- (d) Do not turn on the fuel supply at any time unless you know the combustion chamber has been properly vented and unless you know the pilot light is in proper operation.
- (e) In case of "flash-back", shut off the fuel supply at once and do not turn it on again until the boiler has been thoroughly vented.
- (f) Bring the temperature up slowly.

Following a cold start, condensation may occur in a gas fired boiler to such an extent that it appears that the boiler is leaking. This condensation can be expected to stop after the boiler is hot.

CUTTING-IN

When placing a boiler on the line with other boilers which are already in service, keep its stop valve at the boiler outlet and return stop valve closed until the pressure within the boiler is exactly the same as the pressure in the steam main. See that the line between the stop valve at the boiler outlet and the steam main is drained, then open the stop valve very slightly. If there is no unusual disturbance, such as noise, vibration etc., continue to slowly open the valve to a "full open" position, then open the valve in the return line.

Caution: When the stop valve at the boiler outlet is closed, the stop valve in the return line of that boiler must also be closed.

OPERATION

Steam Boilers

Whenever going on duty, check the water level in all steam boilers at once.

The maximum operating pressure of a steam boiler should be 3 or 4 psi lower than the "set" pressure of the safety valve. This pressure differential is required to permit the valve to close tightly after it has popped under pressure.

Where low pressure steam boilers are used solely for heating and where practically all of the condensate is returned to the boiler, do not "blowdown" the boiler. High pressure boilers and low pressure process boilers should be "blowndown" as required to maintain chemical concentrates at the desired level and to remove precipitated sediments. Boilers which are equipped with a slow opening blowoff valve and a quick opening blowoff cock, should have the lever valve or cock opened first, followed by gradual opening and closing of the slow opening valve. When the slow opening valve has been shut tight, then close the lever valve or cock. Caution: Do not open the slow opening valve first and pump the lever action valve open and closed, as the water hammer is apt to break the valve bodies or pipe fittings.

If rust appears in the water gauge glass, this is an indication of corrosion that must not be ignored. Check the boiler water to be sure that the water treatment compound is at proper strength and make sure the boiler is not requiring considerable quantities of make-up water. Check the return line and other parts of the system for evidence of corrosion.

A wide fluctuation of water line may indicate that the boiler is foaming or priming. This may be due to the water line being carried too high, or especially in low pressure boilers, a very high rate of steaming. Foaming may also be caused by dirt or oil in the boiler water. Foaming can sometimes be cured by blowing the boiler down, draining two or three inches, then refilling a few times. In persistent cases, it may be necessary to take the boiler out of service, drain and wash out thoroughly as described for a new steam boiler installation and then refill and put back into service.

If the water disappears from the water gauge glass, stop the boiler immediately, and in the case of a coal fired boiler, close the ashpit door and open the fire doors and cover the fire with ash, fresh fine coal or earth. Do Not turn on the the water feed line. Do Not open safety valve. Let the boiler cool until the crown sheet is at hand touch temperature. Then add water to 1" in the water gauge glass. Do Not put the boiler back into service until you have located and corrected the condition responsible for low water.

Low Water Cutoff, Pump Control and Waterfeeder

Check the operation of the low water cutoff, pump control, and the water feeder if one is installed. Follow the instructions on the tag or plate, attached to each control, to "blowdown" the control regularly as recommended by the manufacturer.

Due to mud accumulations, despite "blowdowns", some manufacturers recommend that the float chamber be opened once a year and cleaned out. It is advisable to test the low water cutoff under actual operating conditions. With the burner operating and the boiler steaming at proper water level, close all the valves in the feedwater and condensate return lines so that the boiler will not receive any replacement water. Then carefully observe the waterline to determine where the cutoff switch stops the burner in relation to the lowest permissible waterline established by the boiler manufacturer.

If the burner cutoff level is not at, or slightly above, the lowest permissible waterline, in a new installation the low water cutoff should be moved to the proper elevation, or in an existing installation should be serviced, repaired, or replaced if necessary.

Hot Water Boilers

Whenever going on duty, check the pressure and temperature in all water boilers.

When the boiler is cold the stationary and movable hands of the combination altitude pressure gauge should be together; when the boiler is hot, the movable hand should be above the stationary hand.

The stationary hand should be aligned with the movable hand at the time the system is initially filled, or it may be set to indicate the minimum pressure under which the system can operate and still maintain a positive pressure at the highest point in the system.

The maximum operating pressure of a hot water boiler should be 3 or 4 psi lower than the relieving pressure of the relief valve. This pressure differential is required to permit the valve to close tightly after it has opened under pressure.

General

Where water losses from a steam boiler or a hot water boiler become abnormal, as indicated by the requirements of large amounts of make-up water, an investigation should be made immediately to determine the cause. Proper repair or replacement of parts should be made at once rather than to increase the water treatment to protect the system due to excessive raw water make-up. If the operator cannot determine the cause of the water loss, a competent contractor or consulting engineer should be contacted.

When make-up water is needed and the boiler or condensate tank is not equipped with an automatic water feeder, manually add feed water to a steam boiler, preferably when the boiler is not steaming, or to a water boiler when it is not at its maximum operating water temperature.

(a) Use every practical means for excluding oxygen from the boiler water. Oxygen will be brought in with the make-up water; therefore, hold make-up to a minimum. If the boiler loses more than

- 3" of water per month, this is an indication of a probable leak in some part of the system. The leak should be discovered and corrected.
- (b) If the system includes a pump for returning condensate or adding feed water, be certain that the air vent at the receiver is operating properly.

If large quantities of feed water are required, deaerating equipment is highly desirable to remove dissolved gases, thereby minimizing oxygen corrosion.

MAINTENANCE

General

Clean the boiler tubes and other heating surfaces whenever required. The frequency of the cleaning must be determined by trial. It cannot be predicted. Clean the smoke boxes when required.

Draining and Washing Steam or Water Boilers

A clean, properly maintained, steam heating boiler or hot water system should not be drained unless there is a possibility of freezing, unless the boiler has accumulated a considerable amount of sludge or dirt on the water side, or unless draining is necessary to permit repairs.

Very little sludge should accumulate in a boiler where little make-up water is added and where an appropriate boiler water treatment is maintained at proper strength.

Anti-Freeze Solutions

Anti-Freeze solutions, when used in a heating system, should be tested from year to year as recommended by the manufacturer of the anti-freeze which is used. Anti-freeze solutions must not be circulated through

Water Heaters

Any water heater installed in, or connected to a boiler, should be back-washed periodically, using valves to reverse the direction of flow through the heater. The purpose of this back-washing is to reduce the amount of scale which will accumulate at the outlet side of the heater. Continue the back-washing until the water runs clear. The back-washing may be done frequently and the maximum interval should be determined by trial.

Fireside Corrosion

In this manual some of the causes of water side corrosion have been outlined and procedures recommended which, if followed, may be expected to minimize trouble from this source. Boilers can, however, also corrode on the fireside. This results from corrosive substances in the fuel and it may be difficult to control. Some fuel oils contain substances which cause fireside corrosion. Sulphur, vanadium and sodium are among the materials that may contribute to this problem. Fuel oils in use today are commonly specified according to United States Department of Commerce Commercial Standard CS12-48 and this Standard does not place any quantity limits on sulphur for No. 4 and heavier oils and does not mention vanadium nor sodium.

In the distillation of oils, the vanadium, sodium and much of the sulphur remain in the residuals. Therefore, the probability of this type of corrosion is greater when the fuel oil is a residual (No. 6) or is a No. 4 or No. 5 mixture containing residual.

Deposits of sulphur compounds may cause fireside corrosion. The probability of trouble from this source depends to a large degree on the amount of sulphur in the fuel and on the care used in cleaning the fireside heating surfaces. This is particularly true when preparing a boiler for a period of idleness. Preventing this trouble depends also on keeping the boiler heating surfaces dry when a boiler is out of service.

Deposits of vanadium, or vanadium and sodium compounds also may cause fireside corrosion and these compounds may be corrosive during the season when boilers are in service.

The man responsible for boiler maintenance should be certain that the fireside surfaces of the boilers in his care are thoroughly cleaned at the end of the firing season. He should also observe the fireside surfaces during the firing season and if signs of corrosion are discovered, a reputable consultant should be engaged.

Steam Boilers

If rust appears in the water gauge glass, this is an indication of corrosion that must not be ignored. Check the boiler water to be sure that the treatment is at proper strength and make sure that the boiler is not requiring considerable quantities of make-up water. Check the return line and other parts of the system for evidence of corrosion.

Check the water gauge glass regularly. The required frequency must be determined by trial. The check should be made when there is steam pressure on the boiler. Close the lower gauge glass valve, then open the drain cock which is on the bottom of this valve, and blow the glass clear. Close the drain cock and open the lower gauge glass valve. Water should return to the gauge glass immediately. If water return is sluggish, leave the lower gauge glass valve open and close the upper gauge glass valve. Then open the drain cock and allow water to flow until it runs clear. Then close the drain valve and repeat the first described test, with the lower gauge glass valve closed.

If leaks appear around the water gauge glass or fittings, correct the leaks at once. Steam leaks may result in a false water line reading and may damage the fittings.

In a clean boiler room, safety valves on steam boilers should be checked for proper operation at the beginning of the regular heating season and about every six months. If the presence of chemical fumes or dirt might tend to affect proper operation, the safety valves should be checked about every month. It is preferred that the safety valves be tested by raising the steam pressure until the valve pops. If this is not practical, the valves may be tested by operating the hand lever, but the steam pressure should be as high as practical so that the seat and valve passages will be blown clear of any foreign matter.

Caution: Take necessary precautions to prevent the possibility of scalding the operator, or others, during this test.

- (a) If the popping pressure remains constant, no attention is required. If a valve fails to seal tight, blow it at the set pressure. If it still leaks, or if popping pressure is higher than that marked on the valve, replace it. Do not dismantle the safety valve or attempt to adjust it except under supervision of an authorized boiler inspector.
- (b) ASME rated safety valves were supplied as part of the original equipment with the boiler. When replacement is necessary, use only ASME rated valves.

Water Boilers

Relief valves on water boilers need to be tested only once a year at the beginning of the heating season, unless the presence of chemical fumes or other injurious materials make more frequent testing necessary.

These valves should be tested by operating the hand lever. Observe valves closely after the test to be sure they are closed tightly and do not drip. Continued dripping may indicate the presence of dirt on the valve seat, and the valve should be reflushed. If dripping continues, the valve should be replaced.

ASME rated relief valves were supplied as a part of the original equipment with the boiler. When replacement is necessary, use only ASME rated valves.

REMOVAL OF BOILER FROM SERVICE

Steam Heating Boiler

When a steam heating boiler is to be taken out of service at the end of the heating season, or for repairs, proceed as follows: While maintaining boiler temperature (from 180°F to 200°F), drain off the boiler water until it runs clear. Then refill to the top of the water gauge glass, and add sufficient water treatment compound to bring the treatment up to strength. When all the gases are dissolved, the firing equipment may be shut down.

High Pressure Boiler

For high pressure units, a different approach is used. At least 15 minutes before going off the line, the proper amount of chemical to protect the boiler during standby should be added. After going off the line, fill the boiler to the top. Shut off the steam valve and seal the boiler when it is cool to prevent any ingress of air into the boiler. Test the boiler water for proper chemical content at least once a month. The company supplying the water treatment compound for the boiler will give the proper chemical treatment for boilers in standby condition.

Water Boiler

For a water boiler, the procedure is to drain from the bottom of the boiler while it is still hot (180°F to 200°F) until the water runs clean, then to refill to the normal water fill pressure. This should be a yearly procedure. If water treatment is used in the system, sufficient treatment compound should be added to condition the added water.

General

When the boiler (any of those referred to above) is cool, clean the tubes and other heating surfaces thoroughly, and scrape the surfaces down to clean metal. Clean the smoke boxes and other areas where soot or scale may accumulate.

Soot is not corrosive when it is perfectly dry, but can be very corrosive when it is damp. For this reason it is necessary to remove all the soot from a boiler at the beginning of the non-operating season, or any extended non-firing period.

Swab the heating surfaces with neutral mineral oil to protect against rust. If the boiler room is damp, place a tray of calcium chloride or slaked lime in the combustion chamber and replace the chemical when it becomes mushy.

Drain a steam boiler back to normal water level before putting the boiler back in service.

Check the boiler occasionally during the idle period and make certain it is not rusting.

This is an opportune time to repaint the exposed metal parts of the boiler and to inspect and service the firing equipment and combustion chamber.

BOILER REPAIRS

Do not permit repairs to the boiler while it is in service, or under pressure, except with the approval and under the supervision of an authorized boiler inspector or responsible engineer.

When repair work is required, notify the representative of the company who insures the boiler and be guided by his instructions.

All repair work should be done by experienced boiler mechanics. Welding should be done by ASME Code Certified Welders.

Take every precaution necessary to insure against injury to men who are working in the boiler room and particularly to those working inside the steam space or in the combustion chamber of the boiler. Pull the main burner switch and lock it out or tag it, swing the burner out of place, if possible, close and lock valves, etc., and always have one man standing by outside when a man is working inside a boiler.

When practical, use a flashlight in preference to an extension light for internal inspection purposes. If an extension cord is taken into a boiler, be certain that the cord is rugged and in good condition and that it is properly grounded.

If one tube in a boiler should develop a leak due to corrosion, it is likely that other tubes are corroded also. Have the boiler examined by a capable and experienced inspector before ordering the replacement of one or a few tubes. If all tubes will need replacement soon, it is preferable and less expensive to have the work done at one time.

When a sealer is used to eliminate system leaks and similar problems, or if the sealer is used in conjunction with other compounds, the system should be completely flushed and drained after the sealers have performed their function. A maximum interval of five days with a sealer in the system is recommended. Sealers have a detrimental effect on boilers, pumps and relief valves and should be flushed out as quickly as possible.

BOILER WATER TREATMENT

Use every practical means for protecting the boiler water against contamination by free oxygen or carbon dioxide gases.

Determine the water containing capacity of your boiler so you can instruct your maintenance crew regarding the required amount of boiler water treatment compound. If this information is not given on the boiler, in the boiler catalog, or other publications, then meter the water at the time of the initial filling and record the information.

Whenever a boiler is refilled with water, boil the water or heat it to at least 180°F immediately to drive off the dissolved gases, and add a charge of boiler water treatment compound to control corrosion. If a chromate water treatment compound is used, follow the instructions listed below to determine the amount required. Draw a color comparison sample as described below. Use other boiler water treatment compounds in the amounts specified by the supplier. The material may be introduced through an opening such as the safety valve or manhole opening, or through a feeder if one is available. In high pressure units a reliable water treatment firm should be consulted and their recommendations put into effect.

A chromate boiler water treatment compound is effective for use as a boiler water conditioner in all regular low pressure steam boilers where all, or practically all, of the condensate is returned to the boiler. This material is effective in controlling corrosion and pitting. When maintained at the recommended concentration in a clean boiler, it will prevent or arrest oxygen and CO₂ corrosion. This compound is intended solely for controlling corrosion and is not a cleaner, nor does it control for formation of scale.

The use of chromate boiler water treatment compound in a water boiler involves different considerations. Too high a concentration must be avoided as it may damage pump seals. Therefore, with a lower level of protection, it is necessary to take even greater precautions to keep free oxygen out of the system. Free oxygen can enter from system leaks, faulty vents, or vents improperly located with regard to pumps, and from makeup water.

If a chromate boiler water treatment compound is used, draw a color test sample of water into a clear glass bottle. Mark and retain this sample for use in making periodic tests as described below. Draw a new sample whenever a new charge of boiler water treatment compound is added. The sample should be drawn after the compound is completely dissolved and thoroughly mixed in the boiler water, and should be stored in an air tight bottle.

A chromate boiler water treatment compound, consisting of 95% sodium chromate and 5% sodium borate has been tested extensively over a five-year period in the laboratories of a reliable and well known boiler tube manufacturer. These tests have shown that the material, when used and maintained at the concentrations listed below, is effective in controlling or arresting corrosion. These chemicals may be purchased from any reliable chemical company. Caution: Chromate is still recognized as one of the best inhibitors for protection of metal, although it is now prohibited by many states or cities for use as water treatment, due to the toxic effect of the chromate when dumped in rivers, streams, and sanitary sewage systems.

a. Water Treatment for Low Pressure Steam Boilers

Low pressure steam boilers should be maintained with a chromate concentration of 2 lbs. per 100 gallons of boiler water (2200 PPM). This concentration will be effective where all or practically all of the condensate is returned to the boilers. After boiler and system have been cleaned and refilled as previously described, test the pH of the water in the system as described below. The pH should be higher than 7, but lower than 11. Add some of the washout chemical if necessary, to bring the pH within the specified range. Under service conditions where a considerable amount of make-up is required, the owner should employ a professional water treatment company to provide and supervise the use of the required water treatment.


b. Water Treatment for High Pressure Boilers


In high pressure boilers the water treatment should be prescribed by a reputable water treatment company. Water conditions vary from time to time, and from place to place, and in these boilers, to have good service results, the water treatment should be tailored to fit the boiler and the water conditions.


c. Water Treatment for Low Pressure Water Boilers

Low pressure water boilers should be maintained with a chromate concentration of 1 lb. per 400 gallons of boiler water (300 PPM). Test the pH of the water in the system. The pH should be higher than 7, but lower than 9. Add some of the washout chemical, if necessary, to bring the pH within the specified range. As previously noted, with this lower level of protection, care must be exercised to eliminate all of the free oxygen in the system.

Making a pH or Alkalinity Test — The condition of the boiler water can be quickly tested with hydrion paper which is used in the same manner as litmus paper, except it gives specific readings. A color chart on the side of the small hydrion dispenser gives the reading in pH. Hydrion paper is inexpensive and obtainable from any chemical supply house or through your local druggist.







BLDG. AS-3504

TAB PLACEMENT HERE

DE	SCRIPTION:
	NIA
	Tab page did not contain hand written information
	Tab page contained hand written information *Scanned as next image

Confidential Records Management, Inc. New Bern, NC 1-888-622-4425 9/08

Chet Adams Company

HEATING

Sales Engineers

AIR CONDITIONING EQUIPMENT

VENTILATING

AIR POLLUTION SYSTEMS

ENERGY CONSERVATION

February 16, 1988

MAINTENANCE AND OPERATING INSTRUCTIONS

Project:

Replace Air Conditioning Units

Marine Corps Air Station, New River

Jacksonville, NC

Contractor:

Humphrey Heating & Roofing, Inc.

Jacksonville, NC

P.O.#

103-284

Sales Rep:

Chet Adams Company


Cary, NC

Manufacturer:


Ilg Industries

EXHAUST FANS


3 - PV 83 Direct drive propeller wall exhaust fans, 230 CFM @1/8"SP, 1/40 HP, 115/1/60, with rear guard and backdraft damper.



DRAWN BY: AL. LUTZ
DATE: DEC. 1985
APPROVED BY: G.R.I.



		A CONTRACTOR OF THE PROPERTY O	03	00	103		
NO.	NAME OF PART	New York		PART NO.			
1	PANEL ASSY.	BN 15370	1006-9003B	1008-9002B	1010-9003B		
2	GUARD MOTOR SUPPORT		B1006-1100A				
2A	GOARD MOTOR SUPPORT			B1008-1101C	B1010-1101D		
3	MOTOR			AS SPECIFIED			
4	WHEEL ASSY.		B1006-9001A	A1008-9000A	A1210-9047A		
5	SET SCREW, SQ. HD.		10-24 × 1/4	10-24	4 × ½		
6	CONDUIT CLAMP		5 4 16.7	8500-4213			
7	OUTLET BOX COVER	LET BOX COVER A9917-1702A					
8	CONNECTOR	8500-4200					
9	FLEXIBLE CONDUIT		8500-4210				





A CHECK IN THE APPROPRIATE SQUARE INDICATES THE TYPE OF BEARINGS USED IN THE MOTOR POWERING THIS EQUIPMENT

GENERAL INSTRUCTIONS FOR FAN MOTORS


RELUBRICATABLE BALL BEARINGS - An instruction tag from the manufacturer is included with the motor and the recommendations contained therein should be followed.
SEALED BALL BEARINGS - The bearings are factory-packed with a general purpose bearing lubricant and require no further attention. The life of the grease is dependent upon the number of operating hours and temperature. Under normal conditions of operation (8 hours per day, 5 days per week and average ambient temperature of 80 deg. F) the expected grease-life will be approximately seven years. The life may be greater or less depending upon the enclosure of the motor, RPM, type of mounting, variation in ambient temperature and operating duty cycle. In terms of hours of operation, expected life may be stated as approximately 30,000 hours for open motors and 20,000 hours for enclosed motors when working in an average ambient temperature of 80 deg. F.
SEALED SLEEVE BEARINGS - Bearings of this type are provided with a large lubricant reservoir and require no attention. Because of the extremely light loads on motors with this type of bearing, the life will compare favorably with larger motors having sealed ball bearing
RELUBRICATABLE SLEEVE BEARINGS - The bearing is essentially the same as the sealed sleeve bearing with the exception that it may be relubricated to secure extended life. To obtain maximum life, 5 or 6 drops of SAE20 Motor Oil or Electric Motor Bearing Oil should be added after every 1,000 hours of operation. NOTE: THE STATEMENTS REGARDING EXPECTED LIFE DO NOT CONSTITUTE A GUARANTEE, EXPRESSED OR IMPLIED - BUT SERVE ONLY AS AN INDICATION OF WHAT MAY BE EXPECTED OF THE EQUIPMENT. (REFER TO STANDARD TERMS AND CONDITIONS OF SALE.)

GENERAL NOTES REGARDING FAN EQUIPMENT

- OVERLOAD PROTECTION Some motors are provided with built-in overload protection. This fact is so noted on the Motor Rating Plate.
 If the motor does not contain built-in overload protection, it is mandatory that this protection be provided by starters in the
 motor circuit. The starters are to be equipped with overload protection devices of a rating suitable for the current rating of
 the motor.
- 2. PERIODIC CLEANING Periodic cleaning of all fan equipment is strongly recommended. Dirt and grease accumulations on the impeller cause vibration which greatly increases stresses and loads on the motor bearings. A program of preventive maintenance will greatly increase fan and motor life.
- 3. CHECKING DIRECTION OF ROTATION Care should be taken to insure the proper direction of rotation. This is particularly true in the case of centrifugal type roof ventilators. This type of equipment will deliver air when running in either direction; however, the load is greatly increased when operation is in the wrong rotation. This is a very common cause of overload tripping in centrifugal type roof ventilators. When this trouble is experienced, try reversing fan rotation before increasing the size of the overload protection.
- 1. MOTOR OVERLOAD Forward-curve and radial-bladed fans consume maximum horsepower at 0 in. Static Pressure. Some fans of this type are powered so that operation at 0 in. Static Pressure will overload the motor. Check Catalog Ratings to determine minimum Static Pressure operation if overloading is experienced with this type of equipment.
- 5. CHECKING RUNNING CLEARANCE To achieve maximum performance and efficiency, fans are precision-built machines. Upon occasion, parts will shift slightly due to mishandling in shipment. This can cause binding of the rotating assembly. Before placing any fan in operation, the impeller should be turned by hand to ensure that no binding or interference is present.

ILG INDUSTRIES INC.

2850 North Pulaski Road, Chicago, Illinois 6064



STANDARD TERMS AND CONDITIONS OF SALE

No provision, term or condition of Buyer's order which is inconsistent with, different from or in addition to Seller's terms and conditions shall be binding upon Seller unless expressly agreed to in writing and signed by a duly authorized representative of Seller. Seller shall not be obligated to Buyer in any way until written acceptance of Buyer's order is made by Seller's duly authorized representative at its offices: 2850 North Pulaski Road, Chicago, Illinois. Seller's quotation shall be considered as an invitation to trade and shall not be construed as an offer to contract. The equipment and products described are herein referred to as the "goods."

RICE

Prices are F.O.B. point of shipment.

- Prices set forth on Seller's quotation are firm for a period of thirty (30) days from the date of the quotation. In the event of any changes in specifications indicated by Buyer's purchase order, Seller may adjust the price to cover such changes.
- 3. If, at Buyer's request, shipment is extended beyond six (6) months from date of Seller's written quotation, Seller may increase the stated price of the unshipped goods one percent (1%) per month.

Prices of goods not manufactured by Seller are at all times subject to revision to reflect price increases by Seller's suppliers.
 All prices are subject to the addition of any Federal, State or local taxes which may be applicable to the sale, purchase, delivery, storage, use or processing of the goods sold. Any such tax shall be due and payable to Seller at or before the time the tax is payable by Seller to the taxing authority, or in lieu thereof, Buyer may provide Seller with a tax exemption certificate acceptable to the taxing authority.

PAYMENT TERMS

- 1. Terms of payment are thirty (30) days net from date of invoice, no discounts, unless otherwise specified.
- Interest at the rate of one and one-half percent (1.5%) per month (18% per annum), or the maximum lawful rate allowable, will be charged, whichever is less, on all past due invoices.
- No payments made to representatives or agents will be valid. Payments shall be made directly to Seller, at its home office, Chicago, Illinois.

Minimum billing for any goods sold by the Seller shall be \$25.00 net, exclusive of all transportation.

5. Pro rate retainage fees or back charges will not be accepted by Seller. Collection of such deductions from payments will be enforced at Buyer's expense.

Seller shall not be liable for any liquidated damages or penalties whatsoever unless otherwise agreed to in writing.

7. Seller reserves the right to require full payment in advance of shipment, posting of security for payment, or other payment arrangements when in Seller's judgment, open billing terms are not acceptable.

DELIVERY AND ACCEPTANCE

1. Delivery dates are estimated by Seller and are not guaranteed.

Shipments shall be made by the method or carrier deemed most feasible by Seller and Seller reserves the right to ship all or part of the goods from any shipping point other than the points specified herein.

Risk of loss or damage passes to the Buyer upon delivery of the goods to the carrier at point of shipment.

4. Buyer shall inspect all goods upon receipt. If Buyer rejects all or part of the goods, Buyer shall give Seller written notice of rejection, specifying the reasons therefore within five (5) days after receipt of the goods. In the event Buyer does not so notify Seller, Buyer shall be deemed to have accepted the goods.

WARRANTY AND LIMITATIONS OF LIABILITY

SELLER WARRANTS THAT THE GOODS SHALL BE FREE FROM DEFECTS IN MA. ERIALS OR WORKMANSHIP FOR A PERIOD OF ONE (1) YEAR FROM THE DATE OF INITIAL INSTALLATION OR FOR A PERIOD OF EIGHTEEN (18) MONTHS FROM DATE OF SHIPMENT, WHICHEVER PERIOD FIRST EXPIRES. NO WARRANTY IS MADE OR OFFERED WITH RESPECT TO ANY PROTECTIVE COATINGS APPLIED TO THE GOODS. SELLER'S WARRANTY OBLIGATIONS WITH RESPECT TO GOODS NOT MANUFACTURED BY SELLER SHALL NOT EXCEED THE OBLIGATIONS UNDERTAKEN BY THE MANUFACTURER THEREOF UNDER EXPRESS WARRANTY TO SELLER. of, in Buyer's judgment, the goods do not meet the warranties expressed above, and the Buyer notifies Seller of the defect within a reasonable time after discovery of the defect and within the warranty period, Seller agrees to correct the defect by repairing or replacing, F.O.B. point of manufacture, any parts or components of the goods determined by Seller to be defective, or at its option by issuing credit for the defective parts or components. Seller shall not be liable for labor or other charges, costs or expenses related to the removal, shipping, handling, installation or re-installation of any goods or components.

THE EXPRESS WARRANTIES SET FORTH ABOVE ARE GIVEN BY SELLER IN LIEU OF ANY OTHER WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTAGE OF OPERIOR OF THE INSTITUTE OF DEFENTIVE OF THE INSTITUTE OF THE IN PARTICULAR PURPOSE. IT IS EXPRESSLY AGREED THAT BUYER'S EXCLUSIVE REMEDY AND SELLER'S LIABILITY SHALL BE LIMITED TO THE REPAIR OR REPLACEMENT OF, OR THE ISSUANCE OF CREDIT FOR, DEFECTIVE

PARTS OR COMPONENTS. SELLER EXPRESSLY DISCLAIMS ANY AND ALL LIABILITY FOR AND SHALL NOT BE LIABLE FOR SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES OR LOSSES RESULTING FROM OR ARISING FROM OR OUT OF FECTIVE GOODS, SELLER'S NEGLIGENCE, BREACH OF WARRANTY, BREACH OF CONTRACT, ANY TORT, OR CLAIMS BASED UPON STRICT LIABILITY OF THE SELLER. IN NO EVENT SHALL SELLER BE LIABLE FOR INSEQUENTIAL DAMAGES OR LOSSES COMMERCIAL IN NATURE.

NUCLEAR USE

1. Buyer covenants, represents and warrants that neither Buyer nor any third party shall use, re-sell or otherwise dispose of any goods or part thereof in connection with any activity or process involving nuclear fission or fusion or any use or handling of any source, special nuclear or by-product material, as those materials are defined in the U.S. Atomic Energy Act of 1954 (as amended), without Seller's prior written consent, and until such time as Buyer, or such third party, at no expense to Seller, shall have arranged for insurance coverage, indemnities, and waivers of liability, recourse and subrogation, all acceptable to Seller, and all fully adequate in the opinion of Seller, to protect Seller (and its subcontractors and suppliers) against liability of any kind whether in contract, tort (including negligence), strict liability or otherwise. The aforesaid covenants, representations and warranties shall survive this contract and sale.

Seller shall not be obligated to deliver the goods until such insurance, indemnities and waivers have been procured and are legally operative in Seller's favor. Buyer's failure to comply with any provisions of this paragraph entitled "Nuclear Use" shall be cause for Seller to cancel this contract without liability to Seller, and pursue any remedies provided in law or equity by this contract, the Uniform Commercial Code, or otherwise.

EXCUSABLE DELAY

Seller shall not be deemed to be in default on account of delays in the delivery of goods or in the performance of this contract or any other act to be performed by Seller due to any of the following causes: acts of God; acts of Buyer; insurrections or riots; fires; floods; explosions; earthquake or serious accidents; epidemics or quarantine restrictions; any act of government affecting prices, fuels, materials, facilities or completed goods; strikes, labor troubles causing cessation, slow-down or interruption of work; shipment delays; inability to obtain materials, fuel, accessories, manufacturing facilities, transportation, equipment or parts; any other cause to the extent it is beyond Seller's control.

TERMINATION AND RETURNED GOODS

1. Termination of the order by Buyer, or any part thereof, will not be effective unless agreed to in writing by Seller. Accepted terminations will be subject to all charges incurred by Seller for material consumed, work performed and all other expenses incurred to the date of acceptance.

2. Goods accepted for return and credit are subject to a twenty percent (20%) charge for handling and/or reconditioning, unless otherwise agreed by Seller. Transportation charges for returned goods must be prepaid by Buyer. Before returning goods Buyer must obtain Seller's authorization, and attach Seller's "Return Material Tag" to all shipments. Notice of shipment must be given to Seller on the day of shipment and Buyer must furnish a copy of the Bill of Lading, order number and invoice date.

3. Goods manufactured specifically to order or to specifications of Buyer may not be returned for credit. Changes requested by Buyer in non-stock goods after commencement of manufacturer will be subject to a

revision in price to reflect additional costs.

Use of materials, parts or equipment furnished by Buyer will subject the order to termination without any liability on the part of Seller if the said materials, parts or equipment are defective or will not perform to Seller's requirements. However, Buyer shall be liable to pay Seller's costs and expenses through date of termination.

PATENTS AND TRADEMARKS

Seller shall indemnify the Buyer against liability for infringement of any United States Letters Patent arising out of the manufacture, sale or use of any of Seller's goods furnished, provided that the Buyer shall promptly notify Seller of any such claim and give Seller the opportunity to defend against such claim. The Buyer shall be responsible for all such claim and give Seller the opportunity to defend against such claim. The Buyer shall be responsible for all such claim and give Seller the opportunity to defend against such claim. The Buyer shall be responsible for all such claim and give Seller the opportunity to defend against such claim. The Buyer shall be responsible for all such claim and give Seller the opportunity to defend against such claim. The Buyer shall be responsible for all such claim and give Seller the opportunity to defend against such claim. The Buyer shall be responsible for all such claim and give Seller the opportunity to defend against such claim. The Buyer shall be responsible for all such claim and give Seller the opportunity to defend against such claim. The Buyer shall be responsible for all such claim and give Seller the opportunity to defend against such claim. The Buyer shall be responsible for all such claim and give Seller the opportunity to defend against such claim. The Buyer shall be responsible for all such claim and give Seller the opportunity to defend against such claim. The Buyer shall be responsible for all such claim. remain its property and shall be returned to Seller upon request.

DEVELOPMENT CHANGES, DESIGN AND SPECIFICATIONS

1. Changes in design or specifications may be made at Seller's discretion and Seller has no obligation to incorporate such changes in goods manufactured prior to the change.

2. Seller may furnish Buyer with goods which have been subject to changes in design or specifications provided such changes do not adversely affect price, delivery, or any guaranteed performance of the goods or make unusable or obsolete any other item of goods furnished to Buyer under this contract.

All drawings, instructions and/or technical and engineering services which Seller may furnish with respect to installation or use of the goods are furnished solely for the review and approval of the Buyer. Seller makes no representation or warranty with respect to the accuracy or sufficiency of any such information and disclaims all liability in connection with their use or application.

Seller reserves the right to correct any factory, engineering, clerical or stenographic errors or omissions which may appear upon review and verification of data referred to in Seller's quotation, or Buyer's order


COMPLIANCE WITH LAWS No representation or claim is made regarding compliance with the Occupational Safety and Health Act of 1970, or its amendments, or any other federal, state or local laws, ordinances, codes, rules or regulations which may apply to the goods or their installation.

GOVERNING LAW AND SEVERABILITY

1. This agreement shall be governed in all respects by the law of Illinois.

This contract shall be binding upon and shall inure to the benefit of the parties, their successor and assigns.

3. If any provision or term herein is found to be invalid or unenforceable as a matter of law or by public policy, it shall be considered to be severed from the remainder of the terms and conditions which shall remain in full force and effect.



DE	SCRIPTION:
	Air control
	3/sTem
	Tab page did not contain hand written information
Ø	Tab page contained hand written information *Scanned as next image



Submittal Data Information Air Separator

401-001


Supersedes: 401-001 dated 6/1/87

Effective: August 5, 1987

JOB: VARIOUS BLOGS (BB5548) NEW RIVER, M.C.A.S

BLD ASSOS	QUANTITY	AC 2 5 MODEL NO.	2" SIZE
BLD AS 3504		AC2F	2"
BLD AS - 236	1	ACATE	2"2"

DIMENSIONS




PIPE	PRODU	ICT NO.	A	8	С	D	E	F	G	н		K	MAX	AREA In)	STRAINER C, FACTOR	CION	SHIP	ROX. PING VI.
SIZE	tess stroines	with singiner		Max				ľ					ROW (gpm)	FREE	28 5 8 5 8 5 8 5 8 5 8 5 8 5 8 5 8 5 8 5	SHA.	inss strongs	MATO.
2	AGA	AC2F	8.525	18.00	6.31	5.38	12.00	13	3/4" NPT	3/4"NPT			80	22	86	72	32	3
21/2	ASSE	AC25F	10 750	20.00	7.06	5.88	16.00	16	3/4 NPT	3/8"NPT			130	34	122	102	72	71
3	AC3	AC3F	14	27.25	8.00	11.25	20.75	19	3/4NPT	11/4"NPT			190	51	190	162	92	120
4	AC4	AC4F	16	31.39	9.32	12.75	25.25	19	3/4" NPT	11/4"NPT		63/41	330	80	325	272	140	174
5	AC5	AC5F	16	3:.39	8.82	13.75	25.25	22	3/4 NP!	11/4"NPT		63/4	550	112	510	422	180	221
6	AC5	AC6F	20	34.88	10.06	14 75	29.25	26	3/4 NPT	11/4"NPT		61/21	900	180	750	618	240	290
8	AC8	ACSF	20	45.50	14.06	17.38	29.75	26	PANPI	11/4"NPT		61/21	1500	246	1260	1060	322	410
10	AC10	AC10F	24	47.50	14.81	17.88	34.75	32	3/4"NPT	11/4"NPT		63/4	2600	392	2000	1670	545	670
12	AC12	AC12F	30	50 94	1685	23 25	42.00	37	3/4"NPT	1 1/2"NPT	22	74/2	3400	548	2900	2400	860	1060
14	AC14	AC14F	36	65 00	19.88	25 25	48.75	43	3/4"NPT	11/2"NPT	24	71/2	4700	732	3500	2850	980	1170
16	AC16	AC16F	36	71.50	21 75	28 00	49.75	44	3/4"NPT	11/2"NPT	24	71/2	6000	845	4600	3800	1200	1300
18	AC18	AC18F	42	74 61	22,59	29 63	55.75	51	3/4' NPT	11/2"NPT	30	71/2	8000	1125	5900	4900	1648	1764
20	AC20	AC20F	48	82 81	25.28	32.25	62.25	58	3/4"NPT	11 Z NPI	36	71/2	10,000	1435	7400	5200	2600	3200

Rated @ 125 PSI @ 375°F

Designed and constructed per ASME Section VIII Div. 1

tOptiono!

COMPARE. YOU'LL TAKE TACO.



DE	SCRIPTION:
	NA
	Tab page did not contain hand written information
	Tab page contained hand written information *Scanned as next image




Submittal Data Information aco 1600 Series Pumps 301-004

MODEL 1619

SUPERSEDES: SD300-1.4

JOD BLDG AS205 (B55548) NEW RIVER, M.C.A.S


ITEM NO.	MODEL NO.	IMPELLER DIA.	G.P.M.	HEAD IN FT.	H.P.	ELECTRICAL CHARACTERISTICS
H.W.	16190	7.1	30	50	12	208/3/60



SIZES & DIMENSIONS: (APPROXIMATE)

-	MODEL	Flange Size	H.P. (W)	A	В	С	D
X	1619	2	% (560)* 4 (746)* 4% (1119)* 2 (1492)*	3 (76)*	18½ (469)* 19 (483)* 21 (533)* 23 (584)*	14½ (368)*	17% (441)*

Millimeters



SPECIFICATIONS:

MOTORS

1750 RPM, Three Phase 200V or 230/460V 60C Sleeve Bearing

Aiso available in Single Phase with overload protection except 3 HP (2238W).

BODY

Cast from with flanged in-line connections. Companion flanges are included.

IMPELLER

Cast Bronze, Closed, Dynamically Balanced.

DRIVE COUPLING

Non-Metallic Vibration Dampening

Alloy Steel with Cupro-Nickel Sleeve.

Sleeve Bearing, Disc Type, Oil lubricated. REMOVABLE BEARING CARTRIDGE FITS ALL MODELS. Dip Stick to measure


MECHANICAL SEAL

2 Piece Standard-250°F (121°C) Operating Temp. Hi-Temp - Extra Cost - 300°F (149°C) Operating

WORKING PRESSURE

175 PSI (1207kPa) in accordance with ASA B16.1 NOTE Flanges are tapped for gauges

TACO, INC. 1160 Cronstor TACO (Canada) Li




Submittal Data Information aCO 1600 Series Pumps 301-002

MODEL 1611

SUPERSEDES: SD300-1.2

Job BLD6	AS 3504	(B55548)	NEW RIVER	N. C.A.S
----------	---------	----------	-----------	----------

ITEM NO.	MODEL NO.	IMPELLER DIA.	G.P.M.	HEAD IN FT.	H.P.	ELECTRICAL CHARACTERISTICS
H.W.	16110	4.0	25	12	1/3	115/1/00




SIZES & DIMENSIONS:

(APPROXIMATE)

	MODEL	Flange Size	H.P. (W)	٨	В	C	D
>	1611	11/2	% (487)* 1/3 (249)* % (373)*	3 (76)*	16½ (419)* 16½ (419)* 17 (432)*	1014	12% (327)

*MREmeters



SPECIFICATIONS:

MOTORS

1750 RPM, Three Phase 200V or 230/460V 60C Sleeve Bearing

Also available in Single Phase with overload protection except 3 HP (2238W)

BODY

Cast Iron with flanged in-line connections. Companion tlanges are included.

IMPELLER

Cast Bronze, Closed, Dynamically Balanced

DRIVE COUPLING

Non-Metallic/Vibration Dampening

SHAFT

Alloy Steel with Cupro-Nickel Sleeve.

Sieeve Bearing, Disc Type, Oil lubricated. REMOVABLE BEARING CARTRIDGE FITS ALL MODELS. DID Stick to measure oll level

MECHANICAL SEAL


2 Piece Standard-250°F (121°C) Operating Temp. Hi-Temp-Extra Cost-300°F (149°C) Operating Temp.

WORKING PRESSURE

175 PSI (1207kPa) ... in accordance with ASA B16.1 NOTE: Flanges are tapped for gauges

Quality Through Design — COMPARE.

TÁGO, INC. 1:60 Chanston St., Cranston, R. p2926 (401) 912-8000. Telex, 92-7627. TAGO (Canado) Lid. 3090 Lenworth Dilve, Mississauga, Optano, Canada - Telex, 06-961179.






Submittal Data Information **aco** 1600 Series Pumps 301-004

MODEL 1619

SUPERSEDES: SD300-1.4

JOB: VARIOUS BLDGS (B55548) NEW RIVER, MC AS

ITEM NO.	MODEL NO.	IMPELLER DIA.	G.P.M.	HEAD IN FT.	H.P.	ELECTRICAL CHARACTERISTICS
H.W	16190	7.6	72	45	2	208/3/60




SIZES & DIMENSIONS:

(APPROXIMATE)

MODEL	Flange Size	H.P. (W)	A	В	С	D
1619	2	% (560). 1 (746). 1% (1119). 2 (1492).	3 (76)·	18½ (469)* 19 (483)* 21 (533)* 23 (584)*	14½ (368)*	17% (441)*

Millimeters



SPECIFICATIONS:

MOTORS

1750 RPM. Three Phase 200V or 230/460V 60C Sleeve Bearing

Also available in Single Phase with overload protection except 3 HP (2238W).

BODY

Cast Iron with flanged in-line connections. Companion flanges are included.

IMPELLER

Cast Branze, Closed, Dynamically Balanced.

DRIVE COUPLING

Non-Metallic/Vib: ation Dampening

SHAFT

Alloy Steel with Cupro-Nickel Sleeve.

FRAME

Sleeve Bearing, Disc Type, Oli lubricated. REMOVABLE BEARING CARTRIDGE FITS ALL MODELS. Dip Stick to measure oll level

MECHANICAL SEAL


2 Piece Standard-250°F (121°C) Operating Temp. Hi-Temp-Extra Cost-300°F (149°C) Operating

WORKING PRESSURE


175 PSI (1207kPa) ... In accordance with ASA 816.1 NOTE: Flanges are tapped for gauges

Quality Through Design — COMPARE.

TACO, INC. 1160 Cranston St. Cranston, Rt 02920 (401) 942-8000. Telex. 92-7627 TACO (Canada) Ud. 3090 Lenworth Drive, Mississauga, Ontario, Canada Telex. 06-961179



DESCRIPTION:



☐ Tab page did not contain hand written information



Tab page contained hand written information *Scanned as next image




Submittal Data Information U Tube Heat Exchangers

201-007

4" DIAMETER STEAM


SUPERSEDES: SD200-1

ob:	BLDG.	ASZ	05	NEW R	MER	MCAS		
Hem No.	Model No.	Pass	GPM Tubes	lemp.	lemp. Out	Steam Pressure Shell	Pressure Drop Tubes	Velocity Tubes
CONV.	4206	2	30	160	180	20	1.2	4.3
	S	PASS	GPM	7	F	PSIG	Fr.	St /SE










4 Inch Diameter



Model N	lumber	Ca	st Iron	Heads				Dim	ensio	ns (in	ches)						Heating	Shipping
2 Pess	4 Pass	2 P	U	4 PC	255 T	Y	v	2 cr	nd 4 P	CISS D	Ε	F	6	L	R	\$	Surface (sq.ft.)	Weight (ibs.)
G42045	G4404S	21/2	135T	24	11	₹4	2%	41/2	9	5	19%	4	4	241/2	4161	17	4.6	65
G4206S	G44065	21/2	11/27	24	11	₹6	2%	41/2	9	5	311/2	4	4	361/2	1547	11	7.0	75 _
G4208S	G4408S	214	1167	2%	11	%	2%	41/2	9	5	431/2	4	4	481/2	1%1	11	9.3	84
G4210S	G4410S	21/2	11/27	23%	11	3/8	2%	41/2	9	5	551/2	4	4	60%	1147	11	11.7	94
G42125	G4412S	21/2	11/27	21/6	41	%	2%	41/2	9	5	67%	4	31/6	7211	1951	11	14.1	104
G42145	G44145	21/2	11/27	2%	11	7∕4	23/3	41/2	9	5	7914	4	3¾	8412	11/21	11	16.4	114
G4216S	G4416S	21/2	11/61	2%	11	7∕8	2%	41/2	9	5	91%	4	33/4	9612	1127	11	18.8	124
G42185	G44185	215	1%T	23/4	11	7/8	21/6	41/2	9	5	103'2	4	33/4	1081/2	11/21	11	21.1	134
G42205	G4420S	212	1167	2%	11	36	2%	41/2	9	5	115'5	4	334	12012	1351	11	23.5	144

SADDLE DIMENSIONS: H-51/4, W-615/46; X-51/2; Hole Dia.-1/2.

MATERIALS OF CONSTRUCTION (Unless otherwise indicated, standard will be turnished.)

Shell Head

Head

Tubes
Tube Sheet
Separators
Working Pressure
Max. Temperature

Steel Steel

Cast iron 4-10' Fabricated Steel 12-30' 3/4 x 20 BWG Copper

Steel Steel

150 PSIG (ASME)

Optional

304ss. 316ss

Fabricated Steel, Cast Bronze, Fabricated 304ss/316ss

Cast Bronze, Fabricated 304ss/316ss


3/4 x 18 BWG Copper, Steel, 304ss, 316ss, 90/10 Cu Ni, Admiratly

Bronze, Brass. 304ss. 316ss, 90/10 Cu Ni. Bronze, Brass. 304ss. 316ss, 90/10 Cu Ni.

Consult Factory
Consult Factory

Quality Through Design — COMPARE

TACO, Inc., 1160 Grandles & Prometon RI 02920 (401) 942 8000 | felex 92,7827 TACO, (Canada) Ud., 1818 ferros Brail Mysissauga Ontario L4W 182 (418) 425-2160 | feléx 06-961179 Printed in USA Copyright 1994 DCC: HIC






Submittal Data Information aco U Tube Heat Exchangers

201-008

6" DIAMETER STEAM

SUPERSEDES: SD200-1


Job:	BLDG	AS 2	36	NEW	RIVER	P M.C.	A.S.	
tiem No.	Model No.	Poss	GPM Tubes	Temp.	Temp. Out	Steam Pressure Shell	Pressure Drop Tubes	Velocity Tubes
Cour.	Car	2	72	160	180	40	1.7	5.1
	S	PA SS	GPM	7	°F	PSIG	FT	Fr/SEC











DIMENSIONS

6 Inch Diameter

Model N	lumber	Car	st Iron	Heads				Dim	ensior	ns (in	ches)						Heating	Shipping
2 Pass	4 Pats	2 Po	uss U	4 Pr	265 T	Y	٧	2 CI	nd 4 Po	DSS D	E	F	G	ı	R	5	(sq.fl.)	Weight (lbs.)
G62045	G6404S	4	21	334	11/27	11/4	37/46	6%	11	5	181/2	4%	4%	25	1157	11	9.1	120
-G620c3	G6406S	4	27	334	1121	11/4	37/10	6%	11	5	301/2	4%	4%	37	21	11	13.8	148
G6208\$	G6408S	4	21	3%	134T	11/4	31/16	6%	11	5	421/2	41/2	5%	49	2%	11	18.5	182
G6210S	G6410S	14	21	3%	1151	11/4	37/16	648	11	5	541/2	47/6	53/4	6'	212	11	23.2	207
G6212S	G64125	4	21	334	1151	11/4	37/15	65%	11	5	661/2	43	5%16	3	31	41	27.9	235
G6214S	G64145	4	21	334	11/21	11/4	37/16	6%	11	5	78%	424	5%16	85	31	11	32.6	262
G62165	G64165	1 4	21	33/4	1327	11/4	37/10	65%	11	5	90%	4%	59/16	97	31	11	37.3	290
G6218S	G64185	4	21	34	1151	114	37/10	65%	11	5	102%	41/5	5%16	109	31	11	42.1	318
G6220S	G64205	4	21	334	11/41	114	37/16	6%	11	5	114%	4%	5%16	121	31	11	46.8	346

SADDLE DIMENSIONS: H-61/16; W-91/4; X-71/2; Hole Dia.-%.

MATERIALS OF CONSTRUCTION (Unless otherwise indicated, standard will be furnished.)

Shell

Head

Aubes **Rube Sheet** Separators Working Pressure Max. Temperature Standard

Stoet

Cast Iron 4-10° Fabricated Steel 12-30"

3/4 x 20 BWG Copper

150 PSIG (ASME)

375°F

Optional

304ss. 316ss

Fabricated Steel, Cast Bronze, Fabricated 304ss/316ss

Cast Bronze, Fabricated 304ss/31oss

3/4 x 18 BWG Copper, Steel, 304ss, 316ss, 90/10 Cu Ni, Admirally


Bronze, Bross, 304ss, 316ss, 90/10 Cu Ni

Bronze, Bross, 304ss, 316ss, 90, 10 Cu Ni

Consult Factory Consult Factory

Quality Through Design 👑 COMPARE.

TACO, Inc., 1160 Chanston St. Cranston, PT 02920 (401) 94 -8000 felex 92-7627 TACO, (Canada) Ltd., 1310 Amoo Bwd. Mississauga, Onlice o LAW 182 (416) 625-2160 felex 06-961179



DE	SCRIPTION:
	NA
	Tab page did not contain hand written information
	Tab page contained hand written information
	*Scanned as next image



submittal Data Information Taco "PS" Expansion Tanks

401-007

SUPERSEDES: 401-007 (dated 1/1/85)

JOB: VARIOUS BLDGS. (B55548) NEW RIVER, M.C.A.S.


BLD6. 452 05	LOCATION	PSO30	QUANTITY	30 GALLONS
PLD 6. 45: 010		P5.030	1	30
BLOG. 1/2 236		P5030	l f	30


(OPTIONAL) SADDLES

(For Horizontal Installation)

FIG. 1

Tank Dia.	×	Y	Weight In Lbs. Per Pair
14	8	2	8
16	8	21/8 11/16	8
20	145/8	11/16	14
20 24	145/8	13/4	13
30	14	21/2	13 121/2
36	151/2	13/4 21/2 27/10	131/2





SIZES & DIMENSIONS

Model	Capacity					-	r	Approx.	Wf. Lbs.
No.	Gal	A	В	C	D	E	West black	Painted	Galv.
PS015	15	14	27	10%	55/16	7	11/2	49	59
P\$030	30	14	461/2	10%	55/18	7	11/2	88	96
PS040	40	14	65%	10%	5%	7	11/2	114	124
PS060	60	16	751/2	12	6	71/2	11/2	118	132
PS080	80	20	667/8	151/4	7%	9	2	160	175
PS100	100	20	783/4	151/4	7%	9	2	196	215
PS120	120	24	671/8	183/4	93/6	10	2	213	233
PS135	135	24	75%	18¾	9%	10	2	235	255
PS180	180	30	64%	22	11	12	2	363	286
PS220	220	30	791/8	22	11	12	2	433	460
PS240	240	30	85¾	22	11	12	2	466	496
PS300	300	36	761/2	28	14	133%	2	676	706
PS400	400	36	993/4	28	14	133/8	2	858	899
PS500	500	36	126%	28	14	133/8	2	1069	1120


SPECIFICATIONS

- Manufactured in Accordance with ASME Section VIII.
- Max. Working Pressure 125 PSIG.
- Max. Operating Temperature 375°F.

ASME STAMPED

Quality Through Design — COMPARE.

TACO, Inc., 1160 Cranston St., Cranston, RI 02920 (401) 942-8000 Telex: 92-7627
TACO, (Canada) Ltd., 1310 Airneo Blvd., Mississauga, Ontario L4W 182 (416) 625-2160 Telex: 06-961179





SD 100-2.5

SUBMITTAL DATA

Effective: July 1, 1981 Supersedes: SD 100-2.5

dated 4/81

TACO-TROL TANK FITTINGS

Fignt ID 001-311

JOB! VARIOUS BLOGS. LE55548)
NEW RIVER, M.C.A.S.
PURPOSE


Designed to control the flow of air into the expansion tank while preventing free interchange of water between the expansion tank and the system.

HOW IT WORKS

As air enters the fitting, it is directed thru the outer tube to the tank. As the water in the tank or als during an off cycle period of the firing device, water will tend to flow back toward the boiler or system. Because a restriction is built into the fitting, gravity circulation between boiler and tank is virtually eliminated. An inner tube and manual vent are also provided to permit air to escape from the tank during the initial filling and venting of the system.

HOW USED


The Taco-Trol Tank Fitting is screwed directly into the expansion tank and may be piped to an Air-Scoop (air separator or purger) or directly to the boiler if a "dip tube" is used (See Sketch).



INSTALLATION WITH AIR SCOOP & HI-VENT

INSTALLATION WITH DIP TUBE

Canada an in Ontain Triesbon (416, 625 2160 "ries 06 961129



INSTALLATION AND FILLING PROCEDURE

INSTALLATION

- 1- Cut tubes to correct length per dimension table below.
- 2- Insert Tank Fitting into bottom of expansion tank, using close nipple supplied.
- 3— Connect Fitting to Air-Scoop Tank Connection or Boiler Dip Tube with ½" (15 mm) pipe: If vertical line is some distance from Fitting, pitch horizontal Line up to Fitting approximately 1/8" (5 mm) per foot (305 mm) of pipe length.

FILLING PROCEDURE

A- Open air vent screw on Taco-Trol Tank Fitting. Close all system vents and fill system. As soon as water flows freely from vent screw opening in Tank Fitting, close the screw tightly.

DO NOT RE-OPEN THIS VENT SCREW EXCEPT TO DRAIN TANK

- B- Open system vents and vent all high points.
- C- Adjust Pressure Reducing Valve (if required) to provide positive pressure at highest point in system.
- D— After system is filled, start circulator. Circulate cold water for several minutes to dislodge air bubbles from system.
- E- Stop circulator. Fire Boiler to High Limit state the temperature. After firing stops, wait a few minutes, then re-start circulator to permit separated air to enter expansion tank or leave system thru Taco Air-Scoop.
- F- Stop circulator and re-vent system high points. Reset all controls for automatic operation. System is now ready for normal operation.


If it is necessary to drain expansion tank for any reason, open air vent screw in Taco-Trol Tank Fitting and open Boiler drain to drain tank.

SIZE & SPECIFICATIONS

	Size Con	nections	Maximum			
Prod. No.	Boiler or Air-Scoop	Expansion Tank	Working Pressure	Approx. Wht. Lbs.		
439	3/4" (20 mm)	1/2" (15 mm)	125 PSI (862kPa)	1 (.5 kg)		
438	1" (25 mm)	1" (25 mm)	125 PSI (862kPa)	2.2 (1 kg)		

CUT-OFF TABLE

	Tank Diameter	Cut Off Both Tubes
	24" (610 mm)	None
	20" (508 mm)	2-1/8" (54 mm)
439	16" (406 mm)	4-1/4" (108 mm)
	14" (356 mm)	5-5/16" (135 mm)
	12" (305 mm)	6-3/8" (162 mm)
or expansi	on tanks larger than 24" thru 3	o" in diameter cut off both tubes as follows:
	distribution and the supplementaries	
	36" (915 mm)	None
438		None 3-3/46" (_80 mm)



□ Tab page did not contain hand written information Tab page contained hand written information *Scanned as next image



NUMBER

SD 100-2.6

SUBMITTAL DATA SHEET

Effective: November 15, 1982

Supersedes: SD100-2.6 dated 4/30/81

Customer		
in VA	RIDUS BLDGS:	
100. (12	55548) NEW RIVER	

M.C.A.S

TANK DRAINER

PURPOSE

Designed for fast draining of water from water-logged Expansion Tanks.

FEATURES

Low Cost

Quick Air Charging

Easily installed

All brass body

11" (280 mm) long copper tube


Air charging plug on side, preventing water from soaking installer


Adaptable to any style drain valve

Individually boxed for full protection

OPERATION


Removing the plug on side of Tank Drainer permits air to enter into top of Expansion Tank, breaking the vacuum for fast and full flow draining of the Expansion Tank and/or the Heating System.





* DIMENSIONS

	PRODUCT NO.		APPROX, SHIPPING WEIGHT							
		CONN. SIZE	EACH		12 PCS.		DIAMETER		LENGTH	
			Lb.	Kg.	Lb.	Kg.	₹n.	mm	In.	mm
	440	1/2" N.P.T.	.6	.5	8	3.6	1 - 1/8	29	13	330



DESCRIPTION: | Lectronic | | Air cleaner | | Tab page did not contain hand written information | | Tab page contained hand written information | | *Scanned as next image



MODEL 71 SERIES CERTIFIED SUBMITTAL DATA

TRION, INC.

P.O. BOX 760

SANFORD, N.C. 27330


Project	Location	
Architect/Engineer_CHEATHAM & Assoc.	Location Jacksonville, NC	
Purchaser Humphrey Heating	Location Jacksonville, NC	
Trion Representative Environmental Product Sales	Location Raleigh, NC	
	y Jerry L. Crotts	Date_Nov. 9, 1987


SYSTEM NUMBER	DESIGN CAPACITY (CFM)	%EFFICIENCY () ASHRAE DISCOLORATION () DOP	TRION MODEL NUMBER	*HAND LEFT OR RIGHT	DETERGENT TANK-SIZE (GAL)	DISTANCE BETWEEN POWER PACKS & UNIT (Ft.)	EXTERNAL STATIC "H ₂ O	OFFICER IN CH	FFICE OF THE HARGE OF CONSTRUCTION UNE, NORTH CAROLINA	
11000	12,000	90	71-206-02	*	16	*	N/A	AF	PROVED	
	12,000							SUBJECT TO CONTRACT PEQUIREMENTS CONTRACT N62470 - 86 - 6 - 5548		
								DATE	2-5-88	
			e S an San San						T. L. HUGUELET	
	190 U					2 00		CHEATHAM AND ASSOCIATES H AIR STRIKING ONE	CDR, CEC, USN Officer in Charge of Construction	


Options, Accessories &/ Or Special Requirements:


* To be determined


DRAWINGS INCLUDED System Number(s)	1					
Unit Outline	429360					13.00
Blower Outline	N/A		ar all			
Power Pack(s) Outline	427935					
Control Outline	427983					
Detergent System Outline	329445	The state of				
Piping Schematic	429488				100 3130	196
Field Wiring Diagram	429434				ni sayini sa	40
Wiring Schematic	429605					in the second
			The state of the s		1507	
	-	-				
	-	-		The state of the same	The second	1












































- 0 I SYSTEM COAST TIME ALLOW FAN TO STOP
- 1 3 WASH TIME CAM 3 ON 108TR FACTORY SET TO 2 MINUTES ADJUST 120TR FOR OPTIMUM DETERGENT USAGE
- 3 5 SOAK TIME ADJUSTABLE BY VARYING START OF DETENT OF CAM 4 ON 108 TR
- 5 8 RINGE TIME FACTORY SET FOR 3 MINUTES, ADJUST BY VARYING DETENT OF CAM 4 ON 108TR
- 8 15 DRIP DRY TIME ADJUSTABLE BY VARYING DETENT END OF CAM 5 ON 108 TR
- 15-80 FAN DRY TIME

SEQUENCE OF OPERATION

The wash cycle can be initiated either manually or automatically and requires 80 minutes for completion. Manual operation is initiated by depressing the Manual Start push-button switch 108PB. Automatic operation is initiated through the closing of the 7 day timer normally open switch 114TR and the one second time delay relay 104TR.

Once the wash sequence is initiated cam 1 (108TR1-2) closes twoning on the wash light llOLT, cam 2 (108TR2-1) opens decnergizing the power pack(s) and cam 5 (108TR5-1) opens to shut down the fan. After approximately one minute of fan coast time, cam 3 (108TR3-2) closes energizing the variable time delay relay 120TR.

120TR energizes the detergent pump relay 122CR, control relay 124CR, solenoid valve 130SOL and the manifold motors 126M and 128M. These remain energized for the amount of time set on 120TR (1.2-120 seconds). Typical field setting will be 30 to 60 seconds. After a soak time of up to two minutes, can 4 (108TR4-2) closes energizing the solenoid valve 130SOL and the manifold motors 126M and 128M for 3 minutes.

After this rinse period, the unit will drip dry for approximately 6 minutes before cam 5 (108TR5-1) closes turning the system fan back on. The system will force dry for approximately 60 minutes after which 108TR will complete its cycle, and return the system to its normal operating state.


CO - 3006 REVISIONS

NEXT ASS 'Y. USED ON DATE 1-51-80 DATE 2-13-80

UNLESS OTHERWISE SPECIFIED USE

SCHEMATIC "D" CONTROL


SCHEMATIC "



TRION

ELECTRONIC AIR CLEANERS

CUSTOM PACKAGED EQUIPMENT



Designed for heavy Commercial and Industrial Applications

Trion, Inc. the leader in the design, manufacture and distribution of Electronic Air Cleaners.

The Advantages of Trionized Air

Contaminated air is an undesirable by-product of progress. Contaminated air can be caused by the most simple movement as well as complex operations. In the relatively clean atmosphere of a modern office building, dust is created by foot steps on a carpet. In machine shops, oil mist is created when metals are shaped and formed. Welding shops create fume. The extrusion of plastics, the processing of tobacco, the operations in spinning and weaving mills, all create contamination. It becomes apparent that almost every move man makes fouls the air he breathes. In that these contaminates cannot be prevented from developing, they must be removed, both efficiently and economically. Trion Electronic Air Cleaners are designed to meet these two very basic requirements.

As we communicate in todays world, we use a select group of words. Energy conservation, recycle, low cost, governmental pressures . . . these terms of speech are synonymous with the Trion method of cleaning air.

ENERGY CONSERVATION:

The low pressure drop existing in Trion equipment means reduction in fan motor horsepower. By comparison to other means of filtration, the pressure drop created by Trion Electronic Air Cleaners is low. It is low initially when first installed and remains low in operation.

RECLAMATION:

Many substances, such as expensive lubricating oils, are useless and a menace in an airborne state. When collected, they coalesce, and are suitable for reuse. In addition to the benefit of the salvage, the nuisance has been eliminated.

SPECIFIC INTEREST:

Acceptable pollution levels by governmental and associated pressures have become a way of life. To continue to progress, pollution problems must be addressed or prevented. Trion Electronic Air Cleaners are recognized and accepted as an efficient practical solution.

GENERAL EXPENSES:

Dirty conditioning coils reduce efficiency and are costly to clean. Soiled finish on walls and furnishings are

expensive to clean or replace. Material in process or finished stock that is rejected due to soilage or contamination can be disastrous to profits. Trion Electronic Air Cleaners are a practical method to reduce operating costs as well as the enhancement of the general well being of those using ventilation air.

NEW INTEREST:


The new avenues stemming from today's research and technical development multiply rapidly. From this progress, situations are created that are untried and our industry is called upon daily to collect airborne contaminates to which there is no past reference. Tempered with application potential, this challenge is of interest and Trion invites the opportunity to investigate.

The Principle of Operation

As contaminated air enters the electronic air cleaner, it must pass by fine diameter tungsten wires suspended between flat grounded electrodes. The DC voltage supplied to the wires creates a high intensity field wherein the particulate matter in the air becomes electrically charged. The charged particles then pass into a collector plate section made up of a series of equally spaced parallel plates. Each alternate plate is charged with the same polarity as the particles, which repel, while the interleaving plates are grounded, which attract and collect.

Liquid contaminates, coalesce into droplets when collected and run off the collector plates in a self-cleaning action.

Solid contaminates, or more viscous substances, accumulate and are periodically washed away.



The Model 71 Packaged Line

Todays' industry demands a packaged precipitator capable of cleaning heavy commercial and industrial environments. To meet this need the Trion Model 71 was designed to provide twenty sizes ranging from 2000 to 27,000 CFM in capacity.

Stationary pre/after filtration and washing/detergent systems are available and may be added to the base unit to meet specific job requirements.

Most sizes are available with blower sections.

Access to the collecting elements (ionizing-collecting cells) and the pre/after filters is located on one end of the unit, perpendicular to the direction of air flow and may be specified on either side of the unit.

Two standard size ionizing-collecting cells are employed in the make-up of any given unit. The height and depth dimensions are identical; 24" high x 18" deep. Cell width dimensions vary: nominal 24" and 36". This provides increments of 1 foot widths and 2 foot heights.


The power pack is designed for remote mounting up to 250 feet away from the base unit.

When a washer/detergent system is required a control is furnished to actuate the washing cycle. It may be furnished either semi-automatic (push button initiated) or completely automatic (time clock initiated). An optional step-down transformer-is also available.

The control for the blower package includes a motor starter with fused disconnect switch and a step-down transformer for single power supply hook-up.

When control accessories are specified they are factory mounted and wired inside the control.

Model Number Designation



Specific Feature Designation

MODEL 71-XXX-	BASE UNIT	FRONT & REAR COLLARS	*STATIONARY FILTERS AND PERFORATED PLATE	WASHER W/DETERGENT SYSTEM	FAN SECTION
-00	YES	NO	NO	NO	NO
01	YES	YES	YES	NO	NO
-02	YES	YES	YES	YES	NO
-03	YES	YES	YES	NO	YES
-04	YES	YES	YES	YES	YES

*Stationary Filters-1" heavy duty metal

Perforated Plate—5/16" holes on 1/2" stag-


gered centers.
Stationary filters shipped as standard.
If perforated plate is desired front and/or rear it must be specified.

Refer to feature Designation Table to


Refer to Efficiency Resistance Graph for pressure drop.

Typical System Arrangements


The Model 71 readily adapts to the various air distribution systems utilized to deliver contaminate for collection. Air inlet and outlet collars on the unit contain predrilled flanges, as well as straight edges, for adjoining duct connections. Cabinetry legs employ wide, predrilled pads for mounting securement.



FUGITIVE CONTAMINATE - FREE STANDING UNIT




FUGITIVE CONTAMINATE - LOW SIDE WALL DUCTED DISCHARGE




FUGITIVE CONTAMINATE - MULTIPLE OVERHEAD DISCHARGE THROUGH CENTRAL TRUNK LINE



FUGITIVE CONTAMINATE - LOW COLUMN DUCTED DISCHARGE




MULTIPLE SOURCE CAPTURED CONTAMINATE HOODED TO MAIN TRUNK LINE




MULTIPLE SOURCE CAPTURED CONTAMINATE -HOODED TO COMMON MIXING PLENUM

Characteristics of Particles and Particle Dispersoids



Efficiency Resistance



AIR VELOCITY FEET PER MINUTE (VOLUME OF AIR FLOW CFM PER SQ. FT. OF FACE AREA)

EFFICIENCY—CURVES 1 AND 2


- ASHRAE Standard 52-76 Dust Spot Test Method Atmospheric Air.
- 2. DOP Dioctylphthalate Aerosol Using Penetration Meter.


PRESSURE DROP ACROSS UNIT-CURVES 3 AND 4


- 3. Cell with 40% open perforated plate front and rear.
- 4. Cell with 1" metal mesh filter front and rear.
- 5. Cell only.

Base Unit without Collars without Wash

Model Designation ends in -00







Size Capacity Data Chart


	CFM CAPACITIES CFM CAPACITIES EFFICIENCIES (1) EFFICIENCIES (2)				71-XXX-00 NOT AVAILABLE WITH A BLOWER SECTION						
MODEL					SQ. FT.	POWER	OPENING D	IMENSIONS	OVERALL DI	MENSIONS	
DESIGNATION NUMBER	95%	90%	95%	90%	CELL FACE AREA (3)	PACK TYPE	HEIGHT A	WIDTH B	HEIGHT C	WIDTH D	WT. LBS (4)
71-102-00	1,600	2,000	1,375	1,500	3.68	E	25"	217/8"	401/2"	26"	360
71-103-00	2,400	3,000	2,070	2,250	5.54	E	25"	33	401/2"	371/8"	410
71-104-00	3,200	4,000	2,750	3,000	7.36	E	25"	44	401/2"	481/8"	460
71-105-00	4,000	5,000	3,350	3,750	9.22	E	25"	551/8"	401/2"	591/4"	530
71-106-00	4,800	6,000	4,125	4,500	11.08	E	25"	663/8"	401/2"	701/2"	655
71-107-00	5,600	7,000	4,850	5,250	12.90	E	25"	771/4"	401/2"	813/8"	705
71-108-00	6,400	8,000	5,500	6,000	14.76	Е	25"	881/2"	401/2"	925/8"	750
71-109-00	7,200	9,000	6,200	6,750	16.62	E	25"	99¾"	401/2"	1037/8"	800
71-203-00	4,800	6,000	4,125	4,500	11.08	E	491/4"	33	64¾"	371/8"	655
71-204-00	6,400	8,000	5,500	6,000	14.72	E	491/4"	44	64¾"	481/6"	750
71-205-00	8,000	10,000	6,890	7,500	18.44	F	491/4"	551/8"	64¾′	591/4"	805
71-206-00	9,600	12,000	8,250	9,000	22.16	F	491/4"	663/8"	64¾"	701/2"	900
71-207-00	11,200	14,000	9,700	10,500	25.80	F	491/4"	771/4"	64¾"	813/8"	1,100
71-208-00	12,800	16,000	11,000	12,000	29.52	F	491/4"	881/2"	64¾"	925/8"	1,200
71-209-00	14,400	18,000	12,400	13,500	33.24	F	491/4"	99¾"	64¾"	103%"	1,300
71-303-00	7,200	9,000	6,200	6,750	16.62	E	737/8"	33	89¾"	371/8"	750
71-304-00	9,600	12,000	8,250	9,000	22.08	F	737/8"	44	893/8"	481/8"	900
71-305-00	12,000	15,000	10,300	11,200	27.66	F	737⁄8"	551/8"	893/8"	591⁄4"	1,050
71-306-00	14,400	18,000	12,400	13,500	33.24	F	737/8′	66¾"	893/8"	701/2"	1,200
71-307-00	16,800	21,000	14,400	15,700	38.70	Fx2	737/8"	771/4"	893/8"	813/8"	1,350
71-308-00	19,200	24,000	16,500	18,000	44.28	Fx2	737/8"	881/2"	893/8"	925/8"	1,500
71-309-00	21,600	27,000	18,600	20,200	49.86	Fx2	73%"	99¾"	89%"	1037/8"	1,650


⁽¹⁾ ASHRAE Standard 52-76 Dust Spot Test method.


⁽²⁾ DOP efficiency based on use of Dioctylphthalate Aerosol.

⁽³⁾ Total gross face area of ionizing-collecting cells in accordance with ASHRAE Standard 52-76.
(4) Total weight of unit with power pack(s).

Base Unit with Collars without Wash Model Designation Ends in -01








Size Capacity Data Chart


	CEM CA	DACITIES	CEM CA	DACITIES					71-XX	C-01 W/O WASH		
MODEL DESIGNATION	CFM CAPACITIES EFFICIENCIES (1)				SQ. FT. CELL FACE	POWER	COLLAR D	IMENSIONS	OVERALL D	IMENSIONS		AVAILABLE
NUMBER	95%	90%	95%	90%	AREA (3)	PACK TYPE	HEIGHT A	WIDTH B	HEIGHT C	WIDTH D	(4)	WITH FAN SECTION
71-102-01	1,600	2,000	1,375	1,500	3.68	E	25"	21¾"	401/2"	26"	410	YES
71-103-01	2,400	3,000	2,070	2,250	5.54	Е	25"	33"	401/2"	371/8"	460	YES
71-104-01	3,200	4,000	2,750	3,000	7.36	E	25"	44"	401/2"	481/8"	510	YES
71-105-01	4,000	5,000	3,350	3,750	9.22	Е	25"	551/8"	401/2"	591/4"	580	YES
71-106-01	4,800	6,000	4,125	4,500	11.08	E	25"	661/4"	401/2"	701/2"	705	YES
71-107-01	5,600	7,000	4,850	5,250	12.90	E	25"	771/4"	401/2"	813/8"	755	YES
71-108-01	6,400	8,000	5,500	6,000	14.76	E	25"	881/2"	401/2"	92%"	800	YES
71-109-01	7,200	9,000	6,200	6,750	16.62	Е	25"	99¾"	401/2"	103%"	850	YES
71-203-01	4,800	6,000	4,125	4,500	11.08	E	495%"	33"	64¾"	371/8"	705	YES
71-204-01	6,400	8,000	5,500	6,000	14.72	Е	495%"	44"	64¾"	481/8"	800	YES
71-205-01	8,000	10,000	6,890	7,500	18.44	F	495%"	551/8"	64¾"	591⁄4"	855	YES
71-206-01	9,600	12,000	8,250	9,000	22.16	F	49%"	661/4"	64¾"	701/2"	950	YES
71-207-01	11,200	14,000	9,700	10,500	25.80	F	495%"	771/4"	64¾"	81%"	1,150	YES
71-208-01	12,800	16,000	11,000	12,000	29.52	F	495%"	881/2"	64¾"	92%"	1,250	YES
71-209-01	14,400	18,000	12,400	13,500	33.24	F	495%"	99¾"	643/8"	1037/8"	1,350	YES
71-303-01	7,200	9,000	6,200	6,750	16.62	The Ethics	741/4"	33"	89%"	371/8"	800	YES
71-304-01	9,600	12,000	8,250	9,000	22.08	F	741/4"	44"	89%"	481/8"	950	YES
71-305-01	12,000	15,000	10,300	11,200	27.66	F	741/4"	551/8"	89%"	591/4"	1,100	YES
71-306-01	14,400	18,000	12,400	13,500	33.24	F	741/4"	661/4"	89¾"	701⁄2″	1,250	YES
71-307-01	16,800	21,000	14,400	15,700	38.70	Fx2	741/4"	771/4"	893/8"	813/8"	1,400	YES
71-308-01	19,200	24,000	16,500	18,000	44.28	Fx2	741/4"	881/2"	89¾"	92%"	1,550	YES
71-309-01	21,600	27,000	18,600	20,200	49.86	Fx2	741/4"	99¾"	89%"	1037/8"	1,700	YES


 ⁽¹⁾ ASHRAE Standard 52-76 Dust Spot Test method.
 (2) DOP efficiency based on use of Dioctylphthalate Aerosol.
 (3) Total gross face area of ionizing-collecting cells in accordance with ASHRAE Standard 52-76.
 (4) Total weight of unit with power pack(s).

Base Unit with Collars with Wash

Model Designation Ends in -02







Size Capacity Data Chart

					71-XXX-02 W/WASH									
MODEL	EFFICIENCIES (1) EFFICIE			CFM CAPACITIES EFFICIENCIES (2) S		POWER	COLLAR DIMENSIONS		OVERALL D	IMENSIONS		AVERAGE	DET.	AVAILABLE
DESIGNATION NUMBER	95%	90%	95%	90%	CELL FACE AREA (3)	PACK TYPE	HEIGHT A	WIDTH B	HEIGHT C	WIDTH D	WT. LBS.	H ₂ O REQ. GPM (5)	AV. GAL. PER WASH	WITH FAN SECTION
71-102-02	1,600	2,000	1,375	1,500	3.68	E	25"	21¾"	401/2"	26"	490	5	.25	YES
71-103-02	2,400	3,000	2,070	2,250	5.54	E	25"	33"	401/2"	371/8"	560	7	.35	YES
71-104-02	3,200	4,000	2,750	3,000	7.36	E	25"	44"	401/2"	481/8"	630	10	.50	YES
71-105-02	4,000	5,000	3,350	3,750	9.22	E	25"	551/8"	401/2"	591/4"	720	12	.60	YES
71-106-02	4,800	6,000	4,125	4,500	11.08	E	25"	661/4"	401/2"	701/2"	865	14	.70	YES
71-107-02	5,600	7,000	4,850	5,250	12.90	E	25"	771/4"	401/2"	81%"	910	17	.85	YES
71-108-02	6,400	8,000	5,500	6,000	14.76	E	25"	881/2"	401/2"	92%"	950	19	.95	YES
71-109-02	7,200	9,000	6,200	6,750	16.62	E	25"	99¾"	401/2"	103%"	1,020	22	1.10	YES
71-203-02	4,800	6,000	4,125	4,500	11.08	E	495%"	33"	64¾"	371/8"	780	14	.70	YES
71-204-02	6,400	8,000	5,500	6,000	14.72	E	495%"	44"	64¾"	481/8"	895	19	.95	YES
71-205-02	8,000	10,000	6,890	7,500	18.44	F	495%"	551/8"	64¾"	591/4"	1,025	24	1.20	YES
71-206-02	9,600	12,000	8,250	9,000	22.16	F	495%"	661/4"	64¾"	701/2"	1,225	29	1.45	YES
71-207-02	11,200	14,000	9,700	10,500	25.80	F	495%"	771/4"	64¾"	81%"	1,370	34	1.70	YES
71-208-02	12,800	16,000	11,000	12,000	29.52	F	495%"	881/2"	64¾"	92%"	1,465	38	1.90	YES
71-209-02	14,400	18,000	12,400	13,500	33.24	F	495%"	99¾"	64¾"	103%"	1,595	43	2.15	YES
71-303-02	7,200	9,000	6,200	6,750	16.62	E	741/4"	33"	89¾"	37%"	945	22	1.10	YES
71-304-02	9,600	12,000	8,250	9,000	22.08	F	741/4"	44"	89%"	481/8"	1,215	29	1.45	YES
71-305-02	12,000	15,000	10,300	11,200	27.66	F	741/4"	551/6"	89%"	591/4"	1,300	36	1.80	YES
71-306-02	14,400	18,000	12,400	13,500	33.24	F	741/4"	661/4"	89%"	701/2"	1,450	43	2.15	YES
71-307-02	16,800	21,000	14,400	15,700	38.70	Fx2	741/4"	771/4"	89%"	81%"	1,650	50	2.50	YES
71-308-02	19,200	24,000	16,500	18,000	44.28	Fx2	741/4"	881/2"	89%"	925%"	1,850	58	2.90	YES
71-309-02	21,600	27,000	18,600	20,200	49.86	Fx2	741/4"	99¾"	89%"	103%"	2,050	65	3.25	YES


⁽¹⁾ ASHRAE Standard 52-76 Dust Spot Test method.

(2) DOP efficiency based on use of Dioctylphthalate Aerosol.
(3) Total gross face area of ionizing-collecting cells in accordance with ASHRAE Standard 52-76.


(4) Total weight of unit with power pack(s), control, wash and 16 gal. detergent system without liquid detergent. Detergent wt. 9.25 lb./gallon. (5) Average wash cycle is 4 minutes. Multiply GPM × 4 for average maximum water volume.

Fan Transition Dimensional Data (inches):

Model Designation Ends In -03 or -04



TRANSITION (Connected to air cleaner discharge at factory)



FAN SIZE(1)	A & B	С	D	E	F	G	н	J	К	L	М
SL122-1		17	24	21/2	33/8	211/4	28	481/2	241/2	81/2	93/4
SL135-1		18¾	25	21/2	33/8	231/2	301/4	491/2	241/2	93/8	105/8
SL150-1		203/4	261/4	21/2	33/8	261/2	331/4	503/4	241/2	103/8	115/8
SL165-1		227/8	273/4	21/2	33/8	291/4	36	521/4	241/2	111/2	123/4
SL182-1		251/4	341/2	21/2	33/8	341/2	391/4	59	241/2	125/8	137/8
SL182-2	SAME AS	251/4	341/2	21/2	33/8	321/2	391/4	59	367/16	125/8	137/8
SL200-1	AIR CLEANER	275/8	36	21/2	33/8	355/8	423/8	601/2	241/2	137/8	151/8
SL200-2	OUTLET	275/8	36	21/2	33/8	355/8	423/8	727/16	367/16	137/8	151/8
SL222-1		307/8	38¾	31/2	47/8	381/4	48	631/4	241/2	151/2	163/4
SL222-2	REFER TO	307/s	383/4	31/2	47/8	381/4	48	753/16	367/16	151/2	163/4
SL222-3	MODEL	307/8	383/4	31/2	47/8	381/4	48	871/2	483/4	151/2	163/
SL245-1	71-XXX-01	34	411/2	31/2	47/8	43	523/4	66	241/2	17	181/4
SL245-2	OR	34	411/2	31/2	47/8	43	523/4	7715/16	367/16	17	181/4
SL245-3	71-XXX-02	34	411/2	31/2	47/8	43	523/4	901/4	483/4	17	181/
SL270-1	PAGE 5 & 6	371/2	433/4	31/2	47/8	481/4	58	681/4	241/2	183/4	20
SL270-2		371/2	433/4	31/2	47/8	481/4	58	803/16	367/16	183/4	20
SL270-3		371/2	433/4	31/2	47/8	481/4	58	921/8	483/4	183/4	20
SL300-2		415/8	453/4	31/2	47/8	533/4	631/2	823/16	367/16	207/8	221/8
SL300-3		415/8	453/4	31/2	47/8	533/4	631/2	941/2	483/4	207/8	221/
SL330-2		453/4	511/2	31/2	47/8	591/2	691/4	8715/16	367/16	227/8	241/8
SL330-3		453/4	511/2	31/2	47/8	591/2	691/4	1001/4	483/4	227/8	241/
SL365-2		501/2	53¾	31/2	47/8	621/4	72	903/16	367/16	251/4	271/
SL365-3		501/2	533/4	31/2	47/8	621/4	72	1021/2	48¾	251/4	271/
SL402-3		55 ⁵ /8	571/4	5	63/4	693/4	831/4	106	48¾	20 ⁷ / ₈	297/
SL445-3		611/2	601/4	5	63/4	771/4	903/4	109	483/4	303/4	323/

- (1) Refer to Fan Data Chart below for fan size.
- (2) 71-XXX-03 is the designation for a Model 71-XXX-01 Air Cleaner (less washer) coupled with a blower section.
- (3) 71-XXX-04 is the designation for a Model 71-XXX-02 Air Cleaner (with washer) coupled with a blower section.
- (4) Refer to 71-XXX-01 or 71-XXX-02 data for Air Cleaner dimensions.
- (5) Dimensions listed are nominal.
- (6) For total assembly weight, add Air Cleaner weight, pages 5 or 6, to Fan Transition weight listed below.

71-308-XX

71-309-XX

SL402-3

SL445-3

20 925

25 813

Engineering Specifications

THE FOLLOWING GUIDE COVERS FIVE MODEL VARIATIONS. SELECT THE SPECIFIC MODEL, THEN THE SPECIFICATION SECTION AS NOTED (A, B, ETC.) AND THE WORDING OPTIONS WITHIN THE SECTION THAT ARE APPLICABLE.

			COP	Y SE	CTIC	N		
MODEL	А	В	B-1	С	D	E	F	G
71-XXX-00	*	*		*	*			
71-XXX-01	*	*	*	*	*	mo iq		
71-XXX-02	*	*	*	*	*	*	*	
71-XXX-03	*	*	*	*	*			*
71-XXX-04	*	*	*	*	*	*	*	*

SECTION A—GENERAL

The electrostatic precipitator(s) shall be the two stage dual voltage plate type Electronic Air Cleaner(s) Model 71 packaged unit(s) utilizing industrial grade components and construction quality as manufactured by Trion, Inc. Furnish such equipment where shown on plans to clean the specified air volume at an air cleaning efficiency not less than % (determine % efficiency from the size-capacity-data chart) as determined by (select one) the ASHRAE Standard 52-76 Dust Spot Test Method using atmospheric air (or) the DOP Test Methods.

SECTION B-AIR CLEANER HOUSING

The housing shall be of steel construction protected against rust and corrosion with hinged access doors for component removal. All doors shall be gasketed to prevent air and water leakage and doors to charged high voltage components shall be equipped with electrical interlocks for interconnection into the primary power supply to prevent access to charged components. The housing shall be funished with predrilled, wide bearing mounting pads for mounting securement and the bottom pan pitched toward a threaded drain nipple. Finish shall be industrial gray, 3 mil minimal thickness textured epoxy ester.

SECTION B.1—AIR INLET AND OUTLET COLLARS

Air inlet and outlet collars shall contain (select one) nominal 1" thick metal mesh filters (or) 40% open perforated plate, accessible from outside of cabinet through hinged access doors. Doors shall be gasketed to prevent air and water leakage from cabinet. Collars shall be equipped with provision for slip joint and flange type connections for adjoining ducting.

SECTION C-IONIZING-COLLECTING CELLS

lonizing-collecting cell(s) shall be of single unit construction with an 18 inch minimum depth in direction of air flow. All support framing, end plates and ionizer ground electrodes shall be 0.090 inch minimum thick aluminum. Both repelling and collector plates shall be 0.032 inch minimum thick aluminum and rigidly retained in place with tubular spacers and cadmium plated steel tie rods. Spacing between plates shall be no less than 0.318 inch. Each plate shall be 12% inch minimum depth in direction of air flow. Ionizer ground electrodes shall be 0.090 inch minimum thickness and not less than 3% inch minimum depth in direction of air flow. Ionizing wire to ground spacing shall be 11/16 inch. lonizing wires shall be spiraled selftensioning 0.010 inch minimum diameter tungsten and rigidly supported both in a vertical and lateral plane with stainless steel supports. Total grounded collector surface shall not be less than 28 square feet per square foot of cell face area. High voltage support insulators shall be glass reinforced polyester and designed electrical creep distance surface shall be free from serrations to enhance cleaning. All high voltage electrical connections within each tier of cells shall be between cells and automatically made when cells are installed. High voltage connections between cell tiers and between power pack and cells shall be located on the access door end of the cabinet and manually connected for ease in service

SECTION D-POWER PACKS

Power packs shall be 100% solid state providing a dual high voltage of 14,000 VDC for the ionizer and 7,000 VDC for the collector. The power pack(s) shall be housed in NEMA 12 type enclosures, operate on 115 VAC, 60 HZ, 1 PH supply and fur-

nished with integrally mounted electrical interlock to prevent access to high voltage components without interrupting the primary power supply. The face panel of the power pack(s) shall contain an indicating light, milliammeter operated with a push-to-read switch to monitor total secondary current and a kilovoltmeter with a selector switch to monitor both ionizer and collector voltages. The circuit shall contain circuit breakers to protect the circuit and prevent nuisance trippage. The high voltage transformer will be equipped with a variable primary input to adjust for a supply voltage ranging from a constant 110 to 125 VDC. All high voltage secondary components shall be board mounted and both readily removable for ease in service. The high voltage capacitor shall be protected from rapid voltage change with a surge resistor. Bleed resistors shall be provided in both the ionizer and collector circuits.

SECTION E-WATER WASH/DETERGENT SYSTEM

Detergent wash and rinse water shall be applied by manifolds located on both the air entering and air leaving sides of each ionizing/collecting cell tier through spray nozzles delivering a positive fan shaped pattern. The manifolds shall contain clean out plugs and oscillate in a vertical plane through motor driven linkage. Drive motors shall be high torque, gear reduced, fan cooled permanently lubricated, 1/15 HP and located outside of the collars for ease in access. The detergent reservoir, pump, motor and by-pass valving, shall be provided as a pre-packaged assembly with an adjustable volume setting. The detergent pump shall be positive displacement self priming and delivery not less than 3.5 GPM to 40 PSIG outlet pressure. Pump motor shall be PSC with built-in overload protection. Main water line strainer, solenoid valve, and vacuum breaker shall be included with the system.

SECTION F-WASH CONTROL

(For Units with Washer and Without Blower Section)

The wash control shall be housed in a NEMA 12 type enclosure. Terminals shall be provided to interconnect the system fan and shall sequence the wash water, detergent, soak time, rinse time, dry time and return to operation cycles. All times shall be field adjustable. Control initiation shall be (select one) semi-automatic pushbutton initiated (or) completely automatic time clock initiated including semi-automatic manual pushbutton override.

(For Units without Washer and with Blower Section)

The wash control shall be housed in a NEMA 12 type enclosures. Terminals shall be provided to interconnect the system fan and shall incorporate a prewired stepdown transformer, motor starter and fused disconnect switch.


(For Units with Washer and Blower Section)

The wash control shall be housed in a NEMA 12 type enclosure. Terminals shall be provided to interconnect the system fan and shall sequence the wash water, detergent, soak time, rinse time, dry time and return to operation cycles. All times shall be field adjustable. Control initiation shall be (select one) semi-automatic pushbutton initiated (or) completely automatic time clock initiated including semi-automatic manual pushbutton override. The control shall incorporate a prewired stepdown transformer, motor starter and fused disconnect switch.

SECTION G-FAN SECTION

The fan/transition section shall mate with the air cleaner and provide for even distribution of air through the ionizing-collecting cells. The fan shall be in-line Tubular Centrifugal type with non-overloading horsepower characteristics designed to deliver ____ CFM at ____ inches external static pressure. Wheels shall be of all-welded construction with backwardly inclined blades. Wheels 27 inches in diameter and larger shall have double thickness air foil blades; smaller wheels shall have single thickness blades. All wheels shall be statically and dynamically balanced to commercial tolerances. Housings shall be of Tubular design, welded steel construction and shall incorporate curved die-formed conversion vanes and a tapered inner tube at the discharge side of the wheel to provide maximum static pressure regain and minimum noise levels. Finish shall be Industrial gray, textured epoxy ester at a minimum three mil thickness. Shafts shall be designed so that fans operate at speeds well below first critical speed. Bearings shall be heavy duty self-aligning grease lubricated and furnished with external lubrication fittings. The fan performance shall be based on tests conducted according to AMCA

Model 71 Major Components




IONIZING-COLLECTING CELL

Туре	2 Ft.	3 Ft.
Height	24"	24"
Width	221/8"	331/4"
Depth	18"	18"
Weight	75 Lbs.	115 Lbs.
Gross Face Area	3.68 Ft.2	5.54 Ft. ²
Plate Spacing	.318"	.318"
Plate Depth	127/8"	127/8"
Plate Thickness	.032	.032
Wire to Gnd Spacing	11/16"	11/16"
Ionizer Depth	4"	4"
Ionizer Wire Diameter	.010"	.010"
Wire Mtg. Arrangement	Rigid	Rigid
Ion-Gnd Electrode Thickness	.090	.090
Insulator Diameter Min	29/16"	29/16"
Ft ² Collector Surface	96	159
Operating Current Min	2.1MA	3.2MA
Operating Current Max	2.5MA	4.0MA
Operating Voltage		
Ionizer Nom. DC	14 KV	14 KV
Collector Nom. DC	7 KV	7 KV



POWER PACK (NEMA 12 ENCLOSURE)

Туре	08E	08F	
Height	20"	20"	
Width	16"	16"	
Depth	131/4"	131/4"	
7/16" MTG Hole to	10" x 211/4"	10" x 211/4"	
Min. Service Clearance	18"	18"	
Weight	80 Lbs.	110 Lbs.	
Input:	115V, 60 Hz, 1 Phase	115V, 60 Hz, 1 Phase	1
Output DC:			
Max Operating Current	12 MA	25 MA	
Ionizer Voltage	14 KV	14 KV	
Collector Voltage	7 KV	7 KV	
Circuit Breaker Max	3.5 AMP	7.5 AMP	
Max Input Power	290 W	400W	



DUAL OSCILLATING WASHERS WITH CYCLOMATIC ACTION

Line-35 PSI Min. at full flow Water Pressure See size chart for volume req. Drive Rigid Linkage Drive Motor 115V, 60 Hz, 1 Phase Input Qtv Type Split Phase Reversible TEFC 1/15 Max Input Current 2.6 AMP Strainer Size 11/4" Solenoid Valve Size 11/4" Vacuum Breaker Size 11/4"



DETERGENT SYSTEM

DETERGENT STST	EIVI		
TYPE	16 Gal	30 Gal	55 Gal
Height	42"	46"	52"
Width	17"	25"	27"
Depth	17"	25"	27"
13/32 MTG. Hole C to C	91/2" x 1	123/4" x 151/4"	151/2" x 18"
Weight Empty	50 lb.	50 lb.	115 lb.
Weight Full Pump:	200 lb.	275 lb.	585 lb.
Output @ max. head	3GPM	3GPM	6.5GPM
Max. Vert. Head			
@ 40 PSI wash water	46'	46'	46'
Motor:			
Input	115V 60 Hz	115V 60 Hz	115V 60 HZ
	1 phase	1 phase	1 phase
Overload Protection	thermal	thermal	thermal
HP	1/3	1/3	3/4
Max Input Current	7.2 AMP	7.2 AMP	13.8 AMP

10



CONTROLS

Control For	Air Cleaner With Washer Without Blower	Air Cleaner With Washer With Blower	Air Cleaner Without Washe With Blower
Туре	D	D1	D2
Comes Standard With:			Cart Chart
Step-Down Transformer	No	Yes	Yes
Motor Starter	No	Yes	Yes
Disconnect Switch	No	Yes	Yes
Options Available:			
Step-Down Transformer	Yes	Standard	Standard
Automatic Time Clock	Yes	Yes	No
Height	24"	46¾"	32"
Width	24"	46¾"	30¾"
Depth	10"	12"	12"
7/16" MTG Hole C to C	18 " x 251/4"	403/4 x 491/4"	26" x 331/4"
Min. Service Clearance	24"	44"	30"
Weight	60 Lbs.	120 Lbs.	90 Lbs.
		TO SHALL SHOW THE STATE OF THE	



UNIT CABINET

Hand - The unit hand identifies location of access doors, manifold drive motors, and wash water headers. Hand is optional—left or right—and must be specified. It is determined by standing in air stream facing unit with air flow striking back. Unit shown is left hand.

Dimensions—Refer to size—capacity—date chart Weight—Refer to size—capacity—data chart

Door Hinges-Located on left facing door

Door Swing-22 inches.

Service Access Required for Cell Removal—40 inches.

Cabinet Metal Thickness—18/16 Ga. Collar Metal Thickness—16 Ga.

Flange Stock-11/2 x 11/2 x 1/8

Finish-Industrial gray, textured epoxy ester, 3 mil thickness



FAN SECTION

External Static Pressure—as specified Dimensions—Refer to size—capacity—data chart Weight—Refer to size—capacity—data chart Motor:

H.P.: Refer to size-capacity-data chart

Input:

460 Volts 60 Hz, 3 Phase

Type: TEFC

Blower:

Backward Inclined

Heavy Duty

All Welded Construction

Extended Inlet Collars

Statically & Dynamically Balanced

External Lubrication Fittings

Finish—Industrial gray, textured epoxy ester, 3 mil thickness




TRI-DEX DETERGENT

TRI-DEX is a heavy duty alkaline liquid detergent formulation developed specifically for removal of stubborn airborne deposits which coat exposed ionizing-collecting elements of electronic air cleaners.

Deposits to be removed include tars from tobacco smoking, dirt, grease, dust and other tenacious particulate matter which ordinarily is difficult to penetrate and make soluble with other common commercial detergents.

An initial supply of TRI-DEX is supplied with each unit and is available in 6, 30, and 55 gallon containers.



MODEL 60 - FIELD ASSEMBLED PRECIPITATORS



MODEL 24 - VENT FOG PRECIPITATORS



MODEL 38 - INDUSTRIAL MIST PRECIPITATORS



MODEL 18 - OIL MIST PRECIPITATORS



MODEL 22 - OIL MIST PRECIPITATORS

AS A MATTER OF POLICY, TRION, INC. IS CONTINUALLY STRIVING TOWARD CONSTANT PRODUCT IMPROVEMENT. THEREFORE, ALL MODELS AND SPECIFICATIONS ARE SUBJECT TO CHANGE WITHOUT NOTICE OR OBLIGATION.



TRION, INC.

101 McNEILL ROAD • BOX 760 SANFORD, NORTH CAROLINA 27331-0760 AREA (919) 775-2201 TWX 510-920-0675

REPRESENTED IN YOUR AREA BY:



TRION Model Series 60 and 71 Features, Facts and Benefits

Like most devices, an Electronic Air Cleaner is formed into an air cleaning system by blending together major assemblies. Each assembly performs a separate function to achieve a total end result. The ultimate end result would be a unit with a collection efficiency of 100%, unlimited capacity, require no space, never need cleaning, consume no energy, never malfunction and cost nothing. We do not have a unit like this.

We do, however, keep the ultimate in mind in our design. We review each major assembly for its individual function. Then, and most important, each major assembly is reviewed for its working relationship with the other assemblies. By doing this, a blend is achieved that provides the very best a total electronic air cleaning system can offer.

Our product, like any product, has design features that are obviously clear as to the reason behind them, while other features are hidden and are sometimes questioned. If your position is to specify, or to purchase, or just of general interest, we take this opportunity to review some of our product features, their benefits and the reasoning behind the design.

IONIZING-COLLECTING CELLS

ELECTRICAL CONNECTIONS

POWER PACKS

CLEANING SYSTEM
CONTROLS

CABINETRY

IONIZING-COLLECTING CELLS

Face Area -

Trion uses the total gross face area of the cells to determine the face area of a unit. This excludes any framework that may support the cells. Neither is it to be confused with the net free effective area; the actual open space through the cell. Our reason for choice is based on the ASHRAE Standard 52-76 definition of face area.

Depth in Direction of Air Flow -

Some manufacturers point to shallow cell depth as a selling feature. Trion cells are 18 inches deep. When a particle of contaminate passes through a cell, the time the particle remains in the ionizer and collection sections is one of the functions of efficiency. We have purposely chosen a "relatively" deep cell in order to maintain efficiency at a high velocity and a reduced face area. Square feet of face area is normally much more critical than inches in direction of air flow.

Contaminated Air By-Pass -

Contaminants in the air stream that are not ionized (or electrically charged in the ionizer section) are not precipitated and pass through the collector section of the cell. Ionization is dependent upon the corona discharge created on the ionizing wires. The corona discharge diminishes at

the ends of each wire near their points of attachment and at their supports.

To force the contaminated air through the effective ionizing area, Trion blocks off the air flow in the ineffective areas at the top and bottom of each cell with wide horizontal air baffles.

In addition to the primary function of directing air flow, the angular shape of the baffles are designed to provide additional strength and protection without interfering in any way with ionizing wire replacement.

Weight -

Our cell Frame Bracing, End Plates and Ionizer Ground Electrodes are constructed from 0.090" aluminum. Both the Charged Plates and the Grounded Collector Plates are 0.032" aluminum. This thickness eliminates vibration and warpage often found when lighter material is used. The cells are designed for service in atmospheres found in industrial and heavy commercial application. They resist torque, shipping damage and the handling expected in the environment they serve.

Collector Plate Core Support -

It is rigid and it is positive. Our experience with Mil-Spec Design, led us to choose individual spacer and tie rods for support. The cell core is one of the vital components of any precipitator. This is where the task the precipitator is

intended to perform takes place. Other methods such as slotted tube/plate tab fold over, keyed twist cam, expanded tube and others were reviewed, experienced and rejected in lieu of the spacer and tie rod method. The close tolerance tubular spacers are used to provide positive spacing and plate alignment. The 3/8" steel tie rods provide support and positive securement.

Collector Plate Spacing -

Our plate spacing is 0.318" (over 5/16"); one of the widest in the industry. Proper plate spacing is determined by blending several considerations. Voltage gradient, contaminate loading depth, collection surface area, washability, and method of support are the main considerations. With proper design, very little, or none of the considerations need to be sacrificed.

High Voltage Insulators -

High voltage insulators in the cell not only separate the high voltage components from ground but must support the weight of the charged components. They must be "strong" electrically and physically. Trion is aware of "insulator strength". The "cookie" shaped insulator is also used in cells supplied to the U.S. Navy. In addition to the above, and just as important, the configuration of the insulator must lend itself readily to cleanability. Our insulators have smooth flat surfaces which are easy to clean. We incorporate no cost saving short cuts by adding serrations or tricky configurations to gain electrical creep distance. These features do provide creep distance but they also provide dirt traps.

Insulator Location -

The ideal location for insulators within a cell has been banted back and forth within the industry for years. To place them inside or outside of the airstream has been the question. We have chosen the best of two worlds and placed them in the end plate. The outboard portion is completely out of the airstream to minimize dirt accumulation. Our end plate area is vertically sealed as it contains no holes to provide electrical clearance. The electrically charged components go through a hole in the center of the insulator. The inboard portion is flush with the end plate, parallel with the airstream and exposed to the wash water stream. All surfaces are flat and smooth and designed to readily clean.

Ionizing Wires -

A vital component. Trion lonizing Wires are made of 0.010" diameter tungsten. Thickness within the industry varies slightly but a mil or two in diameter is an important factor in strength. A wire of 0.010" diameter has 56% more cross sectional area than a wire 0.008" diameter. In addition to strength, wire location with respect to adjacent

components is important (wire to ground spacing). Our wires are positively located on fixed rigid, stainless steel supports which totally eliminate misalignment, either horizontally or vertically, which is often a problem with support pins, springs and external tensioning means. We supply tension within the wire itself by the unique coil design.

ELECTRICAL CONNECTIONS MODEL 71

Packaged Equipment -

Cells load from the cabinet end perpendicular to air flow. All electrical high voltage electrical connections between cells are automatically made when the cells slide into the cabinet. A broad, stainless steel, spring brush connector is secured to the ionizer and collector tie rod ends of each cell to mate with the adjoining cell. The high voltage leads from the power pack and the jumpers between cell tiers on units more than one tier high are connected on the access panel side for ease in service.

ELECTRICAL CONNECTIONS MODEL 60

Field Assembled Equipment -

Cells load from inside duct parallel with air flow. Cells are interconnected with rigid bus bars located on the clean air side of the cells. The bus bars are secured to both the ionizing and collecting section of each cell with threaded, insulated rods to insure positive connection. This arrangement also lends its self well in trouble shooting the large multi-section field assembled installations.

POWER SUPPLY

Trion Designed - Trion Built -

Most precipitator manufacturers purchase power supplies from outside sources. We insist on building our own supply, to our design specifications and our own quality assurance standards. After years of experience we are confident; through proof, that our expertise in this area is second to none. We have to be, it's our bread and butter. The 08E power pack is rated at 12 MA and the 08F pack is rated at 25 MA. The voltage output on both is a nominal 14,000 VDC to the ionizer and 7,000 VDC to the collector. Each component is source inspected for quality, and is selected on the basis of reliability testing in our laboratory under extremely harsh operating conditions. Coil winding and insulation is monitored every step of the way. Final testing and batch life testing is on a continuous basis.

Tapped Primary Transformer -

The heart of any power supply is its high voltage transformer. We have selected the tapped primary design, in order to maximize both flexibility and reliability. Voltage

adjustment is available in 5% increments (to a maximum of 45%) by moving the input leads to various positions to meet the normal supply line variations normally encountered in the field, as well as to adjust for specific unit loading.

High Voltage Component Board -

All high voltage components are mounted conveniently on a single, easily removable, component board for ease in servicing the power supply. A spare board in stock minimizes system down-time and allows actual repair to be accomplished at a more convenient time and location. Factory mounted components include two 30 KV, 350 MA silicon high voltage rectifiers, arc tested capacitor, bleed resistors, surge resistor, and high voltage lead connecting posts.

Enclosure -

The power supply is housed in a NEMA-12 cabinet with hinged access door, that provides the maximum protection against contaminant buildup on power supply components.

Circuit Protection -

During the normal course of operation, periodic electrical arc-over is an inherent characteristic in electrostatic precipitators. Arc-over usually stems from a very large piece of particulate matter in the air stream and may become more prevalent when changes occur in humidity and/or fluxuation in supply line voltage.

In form, the arc-over may be momentary or prolonged and of a magnitude that is light or heavy with respect to current draw on the electrical circuit. In the case of a malfunction, such as a broken ionizing wire coming in contact with a grounded component, a dead short takes place. Good circuitry design takes all of these conditions into consideration and provides for maximum component protection with a minimum amount of attention.

In addition to a surge resistor to protect the high voltage DC capacitor from the detrimental effect of rapid changes in secondary voltage, two circuit breakers are employed in the power pack primary. The main breaker is a manual reset, hydraulically damped, magnetic breaker and operates under dead shorts or prolonged arc-over. To prevent nuisance trip out of this main breaker which requires manual reset, an automatic reset, thermal breaker is wired in series with it to protect the circuit under arc-over of a smaller magnitude.

Milliammeter -

A milliammeter is provided on each power supply to indicate total operating current. A "Press to Read" push-button is provided. This feature is an extra that saves the meter by removing it from the circuit until it is actually needed.

Power Indicator -

A red indicating light is mounted on the front of the enclosure to show at a glance that line voltage is being applied to the unit.

Kilovoltmeter -

A kilovoltmeter is provided with constant indication. A selector switch is used for reading either the ionizer or the collector voltage. The kilovoltmeter coupled with the milliammeter provides complete operation and service instrumentation.

Safety Switch -

A time delay screw and switch make-up the electrical interlock that interrupts the primary input when the enclosure is opened for inspection or service. The time delay, is accomplished by the screw which allows any residual capacitive charge to drain to ground through the bleeder resistors.

CLEANING SYSTEM

The Trion Electronic Air Cleaner is a high efficiency dirt collector. The collecting elements, the largest in the industry, enable it to efficiently compile and retain large quantities of particulate with a prolonged cleaning frequency. This is its given task. Once collected, however, the particulate has to be effectively removed or the efficiency of the collector will be lowered. Therefore, the cleaning system becomes just as important as the collector.

Cleaning is accomplished with an oscillating wash manifold located in the front and in the rear of each tier of cells. As highest impact and wash water efficiency is produced by nozzles with solid stream or unbroken spray, our manifolds are fitted with nozzles producing a flat solid spray pattern. This simultaneous flooding, from the front and rear, requires a higher initial volume of water than that required by our single manifold residential and light commercial units, but it shortens the wash time, enabling fast return of the unit to cleaning air - - its primary function. All things being equal, it takes a given amount of water to remove a given amount of dirt.

The movement causing the manifolds to oscillate is direct, smooth and uncomplicated. The manifolds are connected to a single drive bar, which in turn is connected to a motor. Chains, cables, sprockets, slide mechanisms limit switches and the adjustments they require are not necessary.

Detergent System -

To augment the wash water, detergent is injected into the water supply prior to entering the manifold headers. The volume (Detergent Water Ratio) is adjustable so that it can be "tailored" in the field for the specific application. The system consists of a detergent reservoir with gravity feed, a positive displacement pump, by-pass piping with adjustment and a flow check valve. The Detergent Feeder is completely preassembled and is furnished with a 16, 30 or 55 gallon storage tank. Standard accessories include a main water solenoid valve, strainer and vacuum breaker.

Tri-Dex MSP-21 -

The choice of detergent for washing a precipitator is important. Since no commercially available product was satisfactory in all respects, Trion developed Tri-Dex MSP-21. In addition to its excellent affinity for grease and dirt, it is low foaming, freeze-thaw stable, biodegradable, and contains various surface active agents and aluminum corrosion inhibitors. It's specifically designed for cleaning electrostatic precipitators.

WASH CONTROLS

The efficient removal of the precipitated contaminant from the ionizing-collecting cells is as important to the total performance of the equipment as the collecting efficiency. The close control of wash water, especially if it is heated, and the close control of detergent are important considerations. The many types of contaminants and the various loading conditions call for a control that is adjustable to the specific conditions encountered on each specific job. Proper detergent concentration and cycle timing are prerequisite for effective washing from the standpoints of cost and cleaning efficiency. All cycle times are readily adjustable in the field in Trion Controls. On large multi-section controls all times are simply dialed in, right down to the second. The controls sequence the system fan, including coast down, power packs, manifold drive motors, water valves, detergent pump motor and drying cycles.

CABINETRY - MODEL 71

Packaged Equipment -

The Model 71 is packaged up to a nominal volume including 27,000 CFM. Hinged doors, gasketed against air and water leakage, with vault type latching are provided for

all component access. The main door to high voltage components is electrically interlocked to prevent entry without first de-energizing the electrical circuit. The collars for the connection of adjoining equipment or duct work employ a standard design to provide for several methods of attachment. A straight single edge is provided as well as a predrilled flange. Mounting legs are sturdy three inch angles with wide bearing pads. Each pad is predrilled so that the cabinet may be either bolted or welded into place. The manifold drive motors are outboard and located on the access side for accessibility. The bottom of adjoining collars and the drain pan are pitched toward a common center drain and all metal is finished and protected against rust and corrosion. The cabinetry is rugged and uncomplicated.

CABINETRY - MODEL 60 -

Field Assembled Equipment -

The Model 60 is designed for and readily adaptable to handle large volumes of air, up to a nominal 180,000 CFM in a single system in standard equipment. Larger systems are readily available when required. It will also handle the small job too, 12,000 CFM.

Sectional Design -

The sectional design allows maximum flexibility. Each section is independent in terms of power supplies and washing systems, but all sections utilize the same detergent system and automatic wash controls. Up to and including five sections may be operated through a single control.

Internal Framing -


Top frame, base and intermediate cell support framework is of welded, galvanized, "Uni-Strut" construction, and is attached to the end support structure with heavy steel angle and bolts. The individual cell support rails allow removal of the ionizing-collecting cells from either the front or rear of the unit. All cabinetry components are match-marked at the factory for ease in assembly. Baffle strips are provided to seal off air by-pass and all metal finish is protected against rust and corrosion.



101 McNEILL ROAD · P.O. BOX 760 SANFORD, NORTH CAROLINA 27331-0760 AREA (919) 775-2201 · TWX 510-920-0675

TAB PLACEMENT HERE

DESCRIPTION:



- ☐ Tab page did not contain hand written information
- Tab page contained hand written information
 *Scanned as next image

Confidential Records Management, Inc. New Bern, NC 1-888-622-4425 9/08

Chet Adams Company

Sales Engineers

AIR CONDITIONING EQUIPMENT

VENTILATING

AIR POLLUTION SYSTEMS

ENERGY CONSERVATION

February 16, 1988

MAINTENANCE AND OPERATING INSTRUCTIONS

Project:

A/C Building AS-205

Camp Lejeune, NC

Contractor:

Humphrey Htg. & Roofing, Inc.

Jacksonville, NC

P.O.#

107-284

Engineer:

Cheatham and Associates

Sales Rep:

Chet Adams Company

Cary, NC

Manufacturer:


Governair Corporation

AIR HANDLER

1 - Model RSA-02 custom built exterior air handler as per attached data.

AIR COOLED CONDENSING UNIT

1 - Model ACU-302 air cooled condensing unit as per attached data.



SUBMITTAL DATA

PROJECT: A/C BUILDING AS-205

CAMP LEJEUNE, NC

DATE: 12/11/87

SERIAL NO.: 25997

SOLD TO: HUMPHREY HEATING

& ROOFING, INC. P.O. BOX 1268

JACKSONVILLE, NC 28540

REF. DWG.: 32636

TAG: AC-1

MODEL NO.: ACU-302

NO. UNITS: 1

AIR COOLED CONDENSERS

UNIT CAPACITY:

CAPACITY BALANCED WITH RSA-01 REFERENCE DRAWING NUMBER 32637 27,900 CFM THRU CONDENSER

CONSTRUCTION:

BASE FRAME - Structural formed steel base,

CABINET - FLOOR - 14 gauge galvanized steel single wall,

WALLS - 20 gauge galvanized steel single wall

ROOF - 20 gauge galvanized steel single wall,

PAINT - "Landmark Beige" enamel finish inside & out,

ACCESS DOORS - Single wall construction with hinges,

DOOR LATCHES - Ventlok 333,

COMPRESSOR SECTION:

COMPRESSOR - Semi-hermetic model 3DB1-1000,

(1 REQ'D) Spring isolated,


Suction and discharge line vibrasorbers, 1/2" armaflex suction line insulation,

COMPRESSOR - Semi-hermetic model 3D51-1500,

(1 REQ'D) Spring isolated,

Suction and discharge line vibrasorbers,

1/2" armaflex suction line insulation,



CONDENSER SECTION:

CONDENSER COIL: - 3 row, 1/2" copper tubes,

10 aluminum fins per inch, 35" fin width,

84" fin length, 12 pass with sub-cool

circuit, 1 req'd,

3 row, 1/2" copper tubes, 10 aluminum CONDENSER COIL -

fins per inch, 30" fin width, 66" fin length, 12 pass with sub-cool circuit,

- 27 1/4" dia, (3 req'd), direct drive, PROP FANS

setup 27/2,

- 2 horsepower, 208/3/60 TEFC, 1140 RPM, MOTORS

56 frame,

LOW AMBIENT - Adjustable to 0 F degrees with flooded OPERATION

condenser head pressure control valves,

REFRIGERANT CIRCUIT (EACH COMPRESSOR):

RECEIVER - ASME full charge with relief,

Inlet and outlet valves,

FILTER DRIER - Sealed,

- One per circuit, SIGHT GLASS


SOLENOID VALVE - Liquid line,

ELECTRICAL REQUIREMENTS:

208/3/60 power with 120 volt control, 120 volt transformer furnished and installed,

ELECTRICAL CONTROLS:

See Wiring Diagram WD-32636



DATA SUBMITTAL ISSUE (A)

PROJECT: A/C BUILDING AS-205

CAMP LEJUENE, NC

DATE: 12/11/87

12/30/87

SERIAL NO.: 25998

REF. DWG.: 32637-A

SOLD TO: HUMPHREY HEATING

& ROOFING, INC. P.O. BOX 1268

JACKSONVILLE, NC 28540

TAG: AH-1

MODEL NO .: RSA-02

NO. UNITS: 1

ETL LABEL

DRAWINGS MUST BE RETURNED PRIOR TO FABRICATION,

NOTE: ONE SET OF APPROVED

AIR FLOW DATA:

.10" Electronic Air Cleaner-Future SUPPLY AIR: 9,000 CFM at

.15" Damper/Hood

.25" Filters

.88" Coil - DX

.07" Coil - HW

.25" Unit

.50" External Static - Available

2.20" Total Static Design

COOLING CAPACITY - R-22

- 358,500 BTU/HR TOTAL

BTU/HR SENSIBLE - 125,969

- 79.1 deg. DB, 66.2 deg. WB, ENTERING AIR

- 60 deg. DB, 57.0 deg. WB, LEAVING AIR LEAVING AIR - 60 deg. D SUCTION TEMP. - 45.5 deg.

AMBIENT TEMP. - 90 deg.

- 0.88 A.P.D.

HEATING CAPACITY - Water

-388,124BTU/HR TOTAL

- 20 deg. DB, ENTERING AIR


- 59.8 deg. DB, LEAVING AIR

ENT./LVG. WATER - 180.0 deg./160 deg.

- 40

- 1.6 FEET P.D.

- 0.07 A.P.D.



CONSTRUCTION:

BASE FRAME - Structural steel tube electrically welded,

LUGS. LIFTING - Fixed,

CABINET - FLOOR - 18 gauge galvanized steel single wall,

WALLS - 18 gauge galvanized steel single wall

ROOF - 18 gauge galvanized steel single wall,

PAINT - "Landmark Beige" enamel finish inside & out,

INSULATION - 1" fiberglass, 1 1/2 lb. density,

ACCESS DOORS - Double wall construction with standard

galvanized steel hinges,

DOOR LATCHES - Ventlok 333,

CONDITIONER SECTION:

COOLING COIL - DX 5 row, 5/8" copper tubes, 12 aluminum fins per inch, 19.38 sq. ft. total, 45" fin width, 62" fin length, 10 pass, 1 req'd,

EXPANSION VALVE - One per compressor with distributor,

BLOWER ASSEMBLY - One - 20" forward curve, class I, DWDI,

778 RPM, 2118 outlet velocity, 5.32 B.H.P.

Isolators - spring,

Relubrication lines extended to drive side,

Variable pitch sheaves,

MOTOR - 7 1/2 horsepower, 208/3/60 ODP, 1750 R.P.M.,

213T frame, pivot base,

DRAIN PAN - Insulated with drain connection,

mastic coated, traps furnished and installed

"By Others",

FILTER RACK - Angle with 2" throwaway filters,

HEATING COIL RE - 1 row, hot water,

5/8" copper tubes, 8 aluminum fins per inch,

19.38 sq. ft. total, 45" fin width,


62" fin length, 2 pass,

OA-RA DAMPERS - Outside air rainhood,

Opposed blade,

Damper motor and controls furnished and

installed "By Others",




ECTRICAL REQUIREMENTS:

208/3/60 power with 24 and 120 volt control, 24 volt transformer furnished and installed, 120 volt transformer furnished and installed,


ELECTRICAL CONTROLS:

See Wiring Diagram WD-32637





INSTRUCTION MANUAL



Air Handling Units

Installation Operation <u>Mainte</u>nance

General

This manual has been prepared as a guide when installing, operating and maintaining Governair Air Handling equipment. This is high quality equipment and by following the instructions listed in this manual, years of economical and satisfactory operation will be obtained from your Governair equipment.

It is not possible to cover every item in detail and where an item is listed as typical you should contact your local Governair sales representative or the Governair factory in Oklahoma City for the specific information required.

AH-1 SERIAL # 25998 MODEL # RSA-02

Table of Contents

General
Receiving Instructions
Rigging Instructions
Ship Loose Parts 7 Demounted Units — Assembly 9 Weights 10
Storage
Electrical11
Static Pressure Limits
Coils 13 Direct Expansion 13 Chilled Water 13 Hot Water 13 Steam 13
Piping & Control
Coil Freeze Protection of Water & Steam
Parts Replacement
Pre-Start Up Check
Blowers
Motors
Belts18Belt Adjustment — See Trouble Shooting32Pulleys & Drives18-21
Lubrication — Motor Bearings
Lubrication — Bearings Blowers
Filters
Door Latches
Door Gaskets
Caulking
Paint
Drain Traps for Condensate
Dampers — Multizone
Dampers — Fresh Air — Exhaust Air — Return Air
Minimum Position Potentiometer
Enthalpy Control or Economizer Change over Thermostat
Electrical Heat
Troubleshooting

Receiving

Inspect the complete unit for shipping damage. If damage is present, you have the right to either accept or reject the shipment. If the receiving contractor or the receiving agent for the contractor elects to receive the equipment in a damaged condition, it then becomes the contractor's responsibility to note the extent of the damage on the delivering freight bill of lading in the presence of the delivering agent (driver) of the delivering freight carrier. It then becomes the contractor's responsibility to file a freight claim with the delivering freight carrier in accordance with the ICC regulations. It also then becomes the responsibility of the receiving contractor to work with the delivering carrier to have the equipment repaired to the satisfaction of Governair Corporation so the warranty may remain valid. Governair must also be notified of shipping damage.

Note: Governair reserves the right to cancel the warranty on any equipment that is not repaired to Governair's satisfaction.

See section Ship Loose Parts.

Inspection of Equipment - Visual

The equipment type and arrangement should be verified as ordered at once when it arrives at the jobsite. When a discrepancy is found, the local Governair Sales Representative must be notified immediately so that corrective action may be instigated, also verify electrical conformance to specifications. Unauthorized alterations and unauthorized backcharges will not be recognized by Governair Corporation.

Curb Installation

Note: If the unit is to be installed on grillage, this section will not apply.

The curb will be shipped unassembled. It is necessary to assemble it on the jobsite. Each part of the curb is identified with the proper tags and/or markings. Complete assembly instructions are shipped with and attached to each curb package. Where more than one curb is shipped to one location, there will be assembly instructions with and attached to each curb package. It is important the curb be installed level and square.

Note: See section under receiving instructions when receiving curbs and inspecting for freight damage and filing of freight damage claims. Any freight damage is the responsibility of the receiving contractor and/or his authorized receiving agent and the delivering carrier.

See pages 5 & 6 for typical curb installation and parts list. When installing curb, obtain a copy of the approved submittal, as each unit and actual curb installation may not be identical. Do not use this typical curb to install your curb.

Note: Should there be any questions as to the number of pieces of curb parts or assembling of the curb, notify Governair Corporation at once.



ITEM	OTV	DESCRIPTION	
ITEM	QTY.	DESCRIPTION	
a or e lander the			
		Typical actual parts list	
		will be supplied with your curb	
9			

Curb Assembly/Installation Instructions.

- 1. Match parts received to parts list above and notify factory immediately regarding any discrepancy.
- 2. Each curb section bears a part number as shown on attached assembly drawing.
- 3. Referring to the attached submittal and assembly drawings, assemble curb sections using hardware furnished. Curb must be installed square and level with maximum of 48" between supports and 18" overhang at ends.
- 4. Curb may now be insulated and roofed in as required.


NOTE: ½" x 1½" curb gasket shipped with unit.






CAUTION

CURB MUST BE INSTALLED SQUARE AND LEVEL WITH MAXIMUM OF 48" BETWEEN SUPPORTS AND 18" OVERHANG AT ENDS.



NOTES:

- (1) SEE ATTACHED PARTS LIST AND ASSEMBLY/INSTALLATION INSTRUCTIONS, AND CURB DIMENSIONAL DRAWING.
- (2) NOT ALL CURB & CROSS BRACE SECTIONS SHOWN ON THIS DRAWING.
- (3) CURB MAY BE SHIPPED PARTIALLY ASSEMBLED.



The curb installation shows a curb gasket that is mounted between the curb and the unit. When this gasket is supplied by Governair Corporation it is not shipped with the curb, but is shipped with the completed unit "ship loose parts" and is so noted on unit packing list. It is necessary to check the unit packing list for location of the section of the unit in which the curb gasket is located. It is necessary to install the curb gasket before setting the unit on the curb. This is necessary for an air seal between the unit and the curb and also serves as a dampener, preventing metal to metal contact between the unit and curb. However, this should not be used as a vibration isolator where the prevention of noise and vibration transmission into the building is critical.

Rigging Instructions

Proper handling of the equipment is mandatory during unloading and setting it into position.

NOTE: If equipment is not set in its permanent position and is stored on the ground or other unlevel area, proper provisions must be taken for supporting and protecting the equipment. See section for both short and long-term storage.

It is mandatory that the proper spreader bars and hoisting straps be used when rigging. See page 8 for recommendations. It is also mandatory that an experienced and reliable rigger be selected to handle unloading and final placement of the equipment. Your rigger must be advised that unit contains delicate components and that it be handled in an upright position. Care must be exercised to avoid twisting the structure.

When the equipment has been set in final placement, the following must be done:

- 1. Check all caulked seams and air seals. Recaulk if and where caulking has been broken.
- 2. Check all door latches and readjust if necessary to maintain a good tight seal.


NOTE: Remove shipping screws in body of door handle. These screws are installed prior to shipment to prevent doors from accidentally working open during transit and handling.

Shipped Loose Parts

- 1. Check the packing list for the list of ship loose parts.
- 2. Packing list will note how many and type of parts.
- 3. Packing list will note in what section of the unit each shipped loose part is located.
- 4. All air filters are shipped as loose parts.
- 5. Rainhoods are shipped as loose parts. Small rainhoods will be inside the units, and large rainhoods will be outside the unit and so noted on packing list.



Rigging Instructions



Units will have lifting lugs welded and/or bolted to the base when specified.

Avoid damage to the curb and curb gasket when rigging onto a curb. See curb instruction pages 6 and 7.


Spreader bars must be used to prevent damage to the unit casing.

Care must be taken to keep the unit in the upright position during rigging.

Avoid unnecessary jarring or rough handling.

Care must be taken to not damage the water-tight seams in the unit casing.





Weights of Units

Due to the gross latitude in each unit design, it is not possible to list unit weights in this manual. Unit weights are listed with each unit submittal drawing. These drawings must be referred to when selecting a crane for rigging and figuring roof weight loads.

Contact your Governair Sales Representative should you have any questions.

Storage

Short-Term Storage:

Short-term storage is considered six (6) months or less from date of shipment. Storage maintenance during this time period is usually, but not necessarily, limited to the following:

- 1. Make sure the equipment is received and unloaded and set in position per guidelines listed under "Rigging".
- 2. Make sure all access doors are tightly closed and that all access openings into the unit are sealed, such as air supply and air return openings, pipe chase openings, fresh air openings, exhaust air openings, electrical connection openings and other access openings of the unit cabinet that may permit entry of snow, ice, rain water, dust, dirt, mud and other construction debris, or birds and rodents that may enter the interior of the unit.
- 3. The unit must also be protected when setting on the ground level to prevent damage to the exterior of the cabinet by construction vehicles and personnel.

Long-Term Storage:

Long-term storage is considered to be any period beyond six (6) months from date of shipment. If long-term storage is anticipated, contact the Governair Sales Office at time of order entry for the proper instructions for long-term storage, as it is mandatory that a detailed record be maintained during this long-term storage period, such as, but not limited to, proper sealing of the cabinet, rotation of the blowers and bearings and protection of all motors from moisture. Note: Under certain conditions, it may be necessary to remove the motors from the unit and/or add heat to the motor. This record must be available to Governair should a failure occur during the warranty period. There is a time limit of one year from date of shipment that any unit may be kept in long-term storage. At the end of the one year period, the unit must be in operation.

NOTE: Failure to perform the long-term storage requirements and properly log these required procedures will void the warranty.



Electrical Information

NOTE: All wiring must conform to the National Electrical Code (NEC) and possibly local codes that may be in addition to the NEC.

The current characteristics, phase, cycle and voltage are stamped on the nameplate of each Governair unit. The "As Built" wiring and control schematic contained in the instruction envelope enclosed in the control panel box also calls out these requirements. Before attempting to energize any portion of the system, be certain to check the electrical characteristics of the supply current. Even though you may not energize the major components, the voltage reducing transformer, normally applied to the control circuits, will be subjected to the line voltage.

Good practice dictates that all exposed electrical connections in the area of starters, contactors, relays, buss sections and terminals should be checked for tightness prior to the actual startup. Many of the connections contain several wires and while they were tightened at the factory at the time of assembly, and checked at the time of run-in, they may have developed a "set" and will concede to retightening. The danger of a poor connection causing overheating and component failure through inadequate current handling capacity cannot be over emphasized. Cartridge fuses should always be of the fusetron type. Ordinary cartridge fuses, not designed for limited short period overloads, will cause nuisance failures. The amperage value of the fusetron to be applied on a given unit will be clearly called out on the wiring diagram contained in the control panel.

The wiring diagram supplied with each unit will be the "As Built" factory wiring. This wiring diagram must be referred to when bringing field wiring to the unit. This is necessary, as during manufacturing assembly of each unit a terminal number could change. This possible terminal number change will not alter the original approved design and/or operation of the unit.



Static Pressure Limits of Cabinet

TABLE 4

CABINET SIZE					MAX	STAT	C PRES	SS. (+ O	R -)				
CABINET SIZE	0.50"	1.00"	1.50"	2.00"	2.50"	3.00"	3.50"	4.00"	4.50"	5.00"	5.50"	6.00"	6 + "
01													
02													
03		2											
04		, O				A.							
05					KUIN	A. S.			APRES	RE			
06					FOILM				ARKS				
07								'AIC	31				To the
08							n (g) 44					4 PC	S
09											ONS	STARCO	
10											6-		

LOW PRESSURE PACKAGE

A. Cabinet construction:

20 gauge single wall (or double wall 20 gauge exterior with 20 gauge solid or perforated liner.) All joints are sealed with latex caulking.

B. All access doors are double wall 20 ga/24 ga and open to the outside with door latches, standard flat gasket and standard galvanized hinges. **Maximum** door size 66" H x 30" W.

MEDIUM PRESSURE PACKAGE

A. Cabinet construction:

16 Gauge single wall (or double wall 18 gauge exterior with solid 20 gauge liner, or double wall 16 gauge exterior with 20 gauge perforated liner.) All joints sealed with latex caulking.

B. All access doors are double wall 18 ga/24 ga with maxi-

mum door size 66" H x 30" W. All doors open out with door latches and full height hinges.

HIGH PRESSURE PACKAGE

A. Cabinet construction:

16 gauge single wall (or double wall 16 gauge exterior with solid or perforated 20 gauge liner). All joints are sealed with high pressure sealant or continuously welded.

B. All access doors are double wall 16 ga/24 ga with maximum door size 66" H x 30" W. Doors open against pressure with full height hinges, door latches, and seal against bulb-type gasket.

NOTE:

(1) Some units may require special construction considerations. The manufacturer reserves the right to modify construction of any unit as deemed necessary.



Coils

Chilled Water and Direct Expansion Coils:

Chilled water and direct expansion coils must not exceed 600 feet per minute to prevent condensate water from being pulled off the coil and outside the condensate drain pan. Air velocity of 500 feet per minute is more desirable.

The static pressure drop across each coil will change with the number of rows deep and other design conditions. Consult the written submittal for each unit on each job.

- NOTE: 1. For condensate drain traps, see Table of Contents under "Drain Traps".
 - 2. For winterizing see Table of Contents, "Winterizing Coils".

Hot Water Coils

The static pressure across hot water coils will change with the number of rows deep and fins per inch. This also is closely related with the temperature rise desired leaving the coil.

The temperature rise of the air leaving the coil is also dependent on the airflow across the coil, the gallons of water flow through the coil and the entering water temperature into the coil. Consult the submittal for each specific job for the above information.

NOTE: When using ethylene glycol or other antifreeze solutions, consult Governair for the required derating of each coil. It will be necessary to give the percentage of ethylene glycol required.

Winterizing - See Table of Contents - "Winterizing Coils"

Steam Coils

The static pressure drop across steam coils will change with the number of rows deep and fins per inch. Consult the submittal issued for each specific unit for above information.

DTH Steam Coils are commonly called non freeze coils. Caution: There is no coil that is absolutely free from freezing.

Winterizing - See Table of Contents "Winterizing Coils".

Piping & Control

Consult the job specification for the specific piping requirements for each unit.



Freeze Protection of Coils

All chilled water, hot water and steam coils can be damaged during freezing weather. Pre-cautionary measures must be taken to prevent freezing such as:

- 1. Draining each coil and related piping, making sure that all low areas also drain.
- 2. After draining, flush coils with an antifreeze solution such as ethylene glycol. A solution of 50% ethylene glycol and 50% water will protect from freezing to approximately 35° F. below zero at sea level.
- 3. In case of unit shutdown during winter operation, such as power failure, night shutdown and weekend shutdown, the controls must be installed so the valves will go to the full heat position, and all fresh air dampers and exhaust dampers go to the full closed position. The water circulation pumps must keep circulating water through the coils and/or auxiliary heat must be maintained within the unit cabinet.

Parts Replacement Ordering

Due to the variation of components supplied with this type of equipment, it is not possible to publish a generalized parts list. When requesting replacement parts, the following information must be given:

- 1. Complete Governair nameplate data such as model and serial number.
- 2. Name of part, giving full description, including model and serial number, if available.

Pre-Start Up Check

All Governair units are carefully checked at the factory and are operated by factory test technicians to determine satisfactory operation and verify conformance to the specifications. However the check-test and start up procedure supplied as a part of this manual page 15 must be closely adhered to when putting the unit into operation. A copy of the check-test and start up form must be presented to Governair to verify start up date of the unit.



Start Up Check List

Date	
Model	
Serial #	5075 April 1

Pre-start Check		
Unit received undamaged		an Lea
Equipment received as ordered		
Unit located properly for service		
Vibration isolators used	5.75	
Spring isolation properly adjusted		
Rubber in shear isolators properly shimmed		
Check electrical supply voltage		
Check electrical connections for tightness		
Check fusetron amperage against schematic		
Remove shipping blocks		
Check fan wheel set screw, drive sheaves		
Check bearings for alignment and locking collars		
Rotate wheels and motors to assure freedom of movement		
Check condensate drain traps		
Check to see that proper air filters are installed	da na	
Operational check		
Momentarily start fan motor and assure correct rotation		
Check belts for tightness	ed heredon	
Check fan motorRPMAMPS		
Check Return fan motorRPMAMPS		
Check damper operation		
Check cabinet for air leaks		
Check cabinet for possible water leaks		
Latch/tighten all panels	Carrier 1	T-m & ,50



Blowers

All blower wheels should rotate freely and should be rotated by hand and the blower hub set screws retightened prior to actually starting the blower. If the blower wheel has shifted in shipment, it may be corrected by:

1. Loosening the bearing collar set screws and moving the blower and shaft to correct. Then retighten bearing collar set screws.

CAUTION: This may cause the belts to be misaligned which will require realignment.

2. Loosen the blower hub set screws and move blower wheel to correct.

CAUTION: Do not operate the blower if there is undue vibration. Such operation can result in bearing failure, sprung shaft, or other serious damage.

Forward curved and backward curved blowers having either spring or rubber-in shear isolation, will have wood shipping blocks between the blower frame and the unit base.

The shipping blocks must be removed and the locking nuts on the spring isolators adjusted so that the assembly rides free and properly absorbs the vibration of the fan assembly.

Bearings may be replaced on either assembly by removing two pillow block bearing bolts, loosening two Allen set screws in the concentric locking collar and sliding the bearing off of the shaft. Bearings are self aligning.


Blower wheels are removed from the forward curved scroll by removing the cutoff in the blower outlet, loosening the bearing and blower wheel set screws to remove the shaft. Remove the wheel through the blower outlet.

Blower wheels are removed from the backward curved blowers through the side of the blower scroll.


- 1. Remove the bearing and bearing support.
- 2. Remove the inlet cone.
- 3. Remove the wheel through the side of the scroll. See page 17.

Motors

All motors contained in Governair units have been phased at the time of inspection and testing. Should you find the fans or blower wheels operating in a reverse direction, interchange two main supply lines (3 PH.). Do not interchange leads on the motor starters.



Forward Curved Fan Without Spring Isolators



Backward Curved Fan With Belt Guard and Spring Isolators





BACKWARD INCLINED AND AIRFOIL FANS

INSTRUCTIONS TO DISASSEMBLE AND REASSEMBLE LARGE SIZE FANS 1. Remove funnel bolts (A), split housing bolts (B), nuts (C) and flat stock (D) Covering housing split 2. Remove top half of housing (E) 3. Remove vane linkage bolts (F) 4. Remove bearing caps (G) CAUTION: Bearing caps (G) MUST be marked and placed back onto the exact bearing. Caps ARE NOT interchangeable or reversible. DO NOT remove bearing base Q from bearing bars (K) CLOSELY follow bearing manufacturers instructions included with 5. Lift wheel (H) and shaft (M) assembly. Support assembly while bearing bars (K) are being removed. 6. Remove bolts (J) and bearing bars (K) 7. Remove bearing races (L) from shaft (M) CAUTION: Bearing race (L) must be marked and placed back onto the shaft (M) exactly as it came off. Use spanner wrench or steel drift to remove inner locking nut. 8. Remove nuts P and pull funnels N from fan. 9. Lift wheel (H) and shaft (M) assembly out of unit. TO REASSEMBLE UNIT REVERSE ABOVE PROCEDURE. NOTE: When assembling bearings inner clearances must be feeler guage set to exact tolerances (see bearing instruction sheet.) It is recommended that a representative of bearing company be present for bearing re-assembly. Bearing warranty is void if this is not done.

Backward Inclined and Airfoil Fans

Motor amperage should be checked after the connecting duct work is installed and an air check made on the air distribution system. Only in those cases where the air flow at the outlets is insufficient to meet specifications should the blower speed be changed. The proof of proper motor amperage draw lies not within the motor amp reading, but rather with the effect produced. If the air flow is sufficient at the outlets, do not alter blower speed to bring the motor HP up to nameplate rating. Quite often the motor sizing may fall on the liberal side of the actual requirement and to change speed merely to utilize the HP capacity of the motor may introduce air circulation problems in the conditioned area as well as in the unit. Be certain to check the motor nameplate for the maximum amperage draw.

Belts

Belts should be checked for correct tension at start up and should be checked again after one week of operation. On multiple drive adjustable pulleys, the pitch depth should be checked and equated to insure identical belt travel, power transfer and wear. Adjustable motor bases, either hinged or sliding type, are provided for easy belt adjustment. See section "Belt Adjustment".

Pulley and Drives

Motor pulleys both adjustable pitch, fixed pitch, and blower shaft pulleys are locked in position with either set screws or split taper lock bushings. It is mandatory that all set screws and/or taper lock bolts be checked for tightness and alignment before putting equipment into operation.


All drive belts must also be checked for proper tension. See section "Belt Adjustment."

NOTE: An incorrectly aligned and tensioned belt can substantially shorten belt life, overload blower and motor bearings shortening their life expectancy and a belt tensioned too tight can overload the motor electrically causing nuisance tripping of the motor overloads and/or motor failure.

For pulley adjustment, removal and installation see page 19, 20 and 21.




Sheaves With Split Taper Malleable Bushings



- A. This key guides bushing into sheave. It provides extra safety and a positive drive.
- B. Bushing barrel and bore of sheave are tapered. This assures concentric mounting and a true running sheave.
- C. Three cap screws, when tightened, lock bushing in sheave.
- D. Bushing is split so that when the locking cap screws force bushing in tapered bore, the bushing grips the shaft with a positive clamping fit. This will withstand vibration and punishing loads without being loosened.
- E. Sheave and bushing assembly is keyed to shaft and held in place by compression. This gives added driving strength.
- F. Sheave is easily removed from shaft by inserting and tightening two of the cap screws in the tapped holes in the bushing flange. This forces the bushing loose from the sheave and releases the compression so that the entire assembly will slide from the shaft.

WARNING — Do not attempt to pull bushing flange flush with hub end. There should be ½" to ½" clearance when tightened.

MVP* Variable Speed Sheaves Adjustment and Cleaning Instructions



Pitch Diameter Adjustment Instructions

1. Slack off all Belt Tension by moving motor towards driven shaft until Belts are free of grooves. For easiest adjustment, remove the Belts from the grooves.



2. Loosen both Locking Screws "A" in Outer Locking Ring, but **Do Not Remove Them From The Sheave.**

(There is a gap of approximately 1/32" between Inner and Outer Locking Rings. This gap must be maintained for satisfactory locking of the Sheave. If the Locking Screws "A" are removed by accident and gap is lost, screw the Outer Locking Ring down until it touches the Inner Locking Ring. Then back off the Outer Ring ½ to ¾ turn until the screw holes are lined up in the Inner and Outer Locking Rings. Reinsert Locking Screws "A" but do not tighten them until after adjustment is made.)

3. Adjust Sheave to desired Pitch Diameter by turning Outer Locking Ring.

(Any Pitch Diameter can be obtained within the Sheave range. One complete turn of the Outer Locking Ring will result in .233" change in Pitch Diameter.)

DO NOT OPEN "B" SHEAVES MORE THAN 4¾ TURNS FOR "A" BELTS OR 6 TURNS FOR "B" BELTS. DO NOT OPEN "C" SHEAVES MORE THAN 9½ TURNS. DO NOT OPEN "D" SHEAVES MORE THAN 13 TURNS. DO NOT OPEN "5V" SHEAVES MORE THAN 6 TURNS. DO NOT OPEN "8V" SHEAVES MORE THAN 8½ TURNS.

CAUTION:

SHEAVES SHOULD $\underline{\text{NOT}}$ BE ADJUSTED IN EITHER DIRECTION TO THE POINT WHERE MOVABLE AND STATIONARY FLANGES ARE IN CONTACT.

- 4. Tighten BOTH Locking Screws "A" in the Outer Locking Ring.
- 5. Replace Belts and move motor away from driven shaft to apply sufficient Belt Tension to prevent slippage. Check speed. If further adjustment is needed, repeat the steps above.

Caution: Do not loosen any screws other than the two LOCKING Screws "A" in the Outer Locking Ring. These screws should be loosened only while the drive is at rest and adjustment is being made. They must be tightened securely before drive is operated.

To Strip Sheave for Cleaning

- 1. If it becomes necessary to clean dirt, lint, etc from the Sheave, it can be disassembled by removing the three Capscrews "B" in the Stationary End Flange of the Sheave (opposite the Locking Rings). After this is done, the Center Flange Assembly can be removed as a unit by loosening Locking Screws "A" and backing off the Locking Rings until they are disengaged from the threaded end of the Barrel.
- 2. Clean Sheave Barrel and bore of Center Flange Assembly. If it is necessary to use an abrasive, use only fine grit emery cloth. Do not use a file. If Stationary End Flange or Keys are removed from Barrel, be sure they are reassembled as shown below:




Fig. 2


- 3. After cleaning, wipe a thin film of high quality rust inhibiting grease, such as TEXACO THREAD-TEX over the Barrel.
- 4. To reassemble, line up keyways of the Center Flange Assembly so that the keyway extending through the Adjustable End Flange goes over the long key. Place the Center Flange Assembly over the Barrel. It may be necessary to move each flange slightly to line up the keyway with the key in the Barrel.
- 5. When Center Flange Assembly has been placed over Barrel, turn Locking Rings to engage thread on Barrel. Screw Locking Rings onto Barrel thread until Center Flange Assembly is tight against Stationary End flange, then back off ¼ turn.



6. After Sheave is assembled in this position, reinsert Capscrews "B" with lock washers and tighten. Sheave is now ready to readjust for operation.

Caution: Do not remove any screws other than those marked in sketches. This Sheave has been finished grooved and balanced after assembly for true running and quiet operation. Further disassembly offers possibility of Center Flanges being mixed up, which will create unbalance and groove run-out.

Instructions for Mounting and Adjusting VARIABLE PITCH KEY TYPE SHEAVES



Mounting:

- 1. All sheaves should be mounted on the motor or driving shaft with the end containing the setscrew "A" toward the motor.
- 2. Be sure both driving and driven sheaves are in alignment and that shafts are parallel.
- 3. Fit internal key "D" between sheave and shaft, and lock setscrew "A" in place. Wrench Torque 110'' lbs. min. -130'' lbs. max.

Adjusting:

- 1. Loosen setscrews "B" and "C" in moving parts of sheave and pull out external key "E". (This key projects a small amount to provide a grip for removing.)
- Adjust sheave pitch diameter for desired speed by opening moving parts by half or full turns from closed position. DO NOT OPEN MORE THAN FIVE FULL TURNS FOR "A" BELTS OR SIX FULL TURNS FOR "B" BELTS.
- 3. Replace external key "E" and tighten setscrews "B" over key and setscrews "C" into keyway in fixed half of the sheave. Wrench Torque 110" lbs. min. -130" lbs. max.
- 4. Put on belts and adjust belt tension (Do not force belts over grooves.)
- 5. Future adjustments should be made by loosening the belt tension and increasing or decreasing the pitch diameter of the sheave by half or full turns as required. Readjust belt tension before starting drive.
- 6. Two groove sheaves must have both halves adjusted by the same number of turns from closed position to insure the same pitch diameter.
- 7. Be sure that ALL keys are in place and that ALL setscrews are torqued properly before starting drive. Check setscrews and belt tension after 24 hours service.
- 8. Recheck motor running load amps with motor name plate R.L.P.

Lubrication

Motors: check the name plate of each for proper lubricant to use. If no lubrication instructions are on the motor name plate the following lubricating instructions are to be followed.

Motors are equipped with double-shield ballbearings* having sufficient grease to last indefinitely under normal service. Where the motor is used constantly in dirty, wet or corrosive atmospheres, it is advisable to add one quarter ounce of grease per bearing every three months. Use a good quality rust inhibited polyurea based grease, such as Chevron SR1.

When greasing the bearings, keep all dirt out of the area. Wipe the fittings completely clean and use clean equipment. More bearing failures are caused by dirt introduced during greasing than from insufficient grease.

*The blower end bearings of 143T and 145T motors are sealed bearings and need no greasing.

CENTRIFUGAL FAN MAINTENANCE AND LUBRICATION

BEARING LUBRICATION INSTRUCTIONS

Bearing Types

Governair typically furnishes one of three basic bearing types for centrifugal fans - ball bearing, spherical roller bearing, spherical roller bearing with split housing. The bearing type and manufacturer are indicated on each bearing.

Operating Conditions

Bearings should not be located in the airstream or an environment with a heavy concentration of abrasive elements. Governair does NOT recommend grease lubricated bearings for ambient temperatures above 200° F. For information on water, or oil cooled bearings contact the factory.

Grease Selection

Various types and brands of grease are suggested below and on the following pages. The brands suggested for your specific bearing type and application can be used. In all cases one should avoid mixing different brands of grease.

Initial Greasing

All standard bearings provided by Governair should be purged and relubricated before operation. Using the approved grease or an equivalent, lubricate the bearing and housing reservoir through the pressure lubrication fitting. Complete greasing is assured if grease is worked in on one side of the bearing until grease appears on both sides. If the bearing will be operated at less than 150 RPM, and in dirty conditions, more grease is desirable. The bearing will discharge excess grease through seals after a short period of operation. It is not necessary to replace this initial discharge because leakage will cease when the excess grease is worked out.

Relubrication

The initial greasing interval can be determined by the conditions or bearing instructions which follow. By carefully observing the condition of the grease expelled from bearings at the time of relubrication, it can be determined whether the maintenance schedule should be altered. When regreasing, avoid mixing different brands of grease.



Grease Lubrication Chart

	rating lition	Bearing operating	Greasing interval	Use grease equivalent	Remarks
Dirt	Moisture	temperature		to these grades	
Fairly clean	None	32°F. to 120°F. 120°F. to 160°F. 160°F. to 200°F.	6 to 12 months 1 to 2 months 1 to 4 weeks	Phillips Petroleum Co. Philube L #1	
Moderate to extremely dirty	None	32°F. to 160°F. 160°F. to 200°F.	1 to 4 weeks	Master Lubricants Co. Lubrike M-3 Spec. Atlantic Refining Co. Atlantic 62 Imperial Oil Ltd. Andok 280	
	Heavy moisture and direct water splash	32°F. to 200°F.	1 week	Standard Oil Co. (Ind.) Amelith #1 Sun Oil Co. Sunoco 844-X New York & New Jersey Lubricant Co. F-925 Mobil Oil Co. Mobilux #1	Customer should provide flinger or place a hood over bearing housing and fasten a disc to shaft just inside of hood shaft opening. Consult Link-Belt.
Fairly clean		32°F. to 200°F.	Determined by fre- quent inspection of installation.	Shell Oil Co. Alvania EP2 Mobil Oil Co. Sovarex grease L-1	e englese al
	None	32°F. to -40°F.	Consult Link-Belt Application Engineering	Mobil Oil Co. Mobilgrease BRB Zero Texas Co. 2324 Uni Temp. Ep	Cold storage room
	None	Over 200°F. or below -40°F.	Consult Link-Belt Application Engineering	Special labrication may be required. Consult Link-Belt.	A different Link-Belt bearing may be re- quired using oil as a lubricant, etc.

[☐] Frequency of regreasing will vary, depending on the hours of operation, temperature and surrounding conditions.

Storage

Bearings which are to be stored or idle for an extended period of time should be wrapped in a neutral grease-proof paper, foil or plastic film. Compounds can be recommended by the bearing manufacturer to provide protection for several months to several years. During storage the bearings should be rotated monthly to prevent corrosion. After long-term storage, grease should be purged from the bearings and fresh grease injected prior

SEAL MASTER BALL BEARING UNITS prelubricated . . . ready for immediate use

RELUBRICATE WHILE RUNNING IF POSSIBLE, IF RELUBRICATING WHILE IDLE, ADD ONLY 4 to 5 SHOTS WITH HAND GUN USE GREASE, NOT OIL

SUGGESTED INTERVAL

Speed	Temperature	Cleanliness	Greasing Interval
0-100 RPM	TO 140°F.	CLEAN	6-12 MONTHS
101-1500 PRM	TO 140°F.	CLEAN	2-6 MONTHS
ANY SPEED	TO 140°F.	DIRTY	1 WK 1 MO.
ANY SPEED	TO 200°F.	DIRTY	DAILY - 2 WK.

IF ABNORMAL CONDITIONS EXIST CONSULT SEALMASTER ENGINEERS FOR RECOMMENDATIONS.

SEALMASTER BEARING DIVISION STEPHENS-ADAMSON MFG. CO.

AURORA, ILL. LOS ANGELES, CAL. BELLEVILLE, ONT.


Instructions for Specific Bearings

Below and on the following pages are copies of the lubrication instruction labels similar to those for the standard bearings provided by Governair. If additional information is required for these or other bearings provided by Governair, contact the bearing manufacturer directly.

ASSEMBLY AND LUBRICATION INSTRUCTIONS FOR FAFNIR RELUBRICATABLE MECHANISEAL & PLYASEAL TRANSMISSION UNITS

INSTALLATION

LOCATE ASSEMBLED UNIT TO LOCA IE ASSEMBLED UNIT TO POSITION AND LINE-UP SHAFT CAREFULLY. FAFNIR SELF-ALIGNING UNITS WILL AUTOMAT-ICALLY COMPENSATE FOR MIS-ALIGNMENT, BUT SHAFT MUST BE STRAIGHT. BOLT UNIT SECURELY TO SUPPORTING STRUCTURE.



SLIDE COLLAR AGAINST CAM END OF INNER RING. ENGAGE CAMS BY ROTATING COLLAR UNTIL IT SLIDES OVER CAMMED END OF INNER RING. LOCK COLLAR BY TAPPING LIGHTLY
IN DIRECTION OF SHAFT ROTATION.
TIGHTEN SET SCREW TO DISASSEMBLE.
LOOSEN SET SCREW AND TAP COLLAR
IN DIRECTION OPPOSITE SHAFT ROTATION

<u>LUBRICATION</u>
BEARINGS HAVE BEEN FACTORY PRELUBRICATED WITH HIGH QUALITY GREASE AND FOR NORMAL CONDITIONS OF SERVICE REQUIRE NO FURTHER LUBRICATION.

NORMAL SERVICE IS CONSIDERED AS OPERATION IN A CLEAN DRY ATMOSPHERE AT TEMPERATURES BETWEEN -20°F and 180°F AND AT SHAFT SPEEDS UP TO 2100 FT. PER MIN

WHERE SERVICE IS ABNORMAL WITH RESPECT TO SPEED, TEMPERATURE OR EXPOSURE TO CONTAMINATION, OR EXTREMELY LONG LIFE IS REQUIRED, PERIODIC RELUBRI-CATION MAY BE ADVISABLE.



LUBRICATION SCHEDULE FOR HORIZONTAL MOUNTED FAN WITH FMC/LINK BELT **SERIES 200 BALL BEARING UNITS**

LINK-BELT BEARING DIVISION

CONSULT MANUFACTURER FOR SPECIFIC RECOMMENDATIONS

SHAFT SIZE	OPERATING SPEED (RPM)												
INCHES	500	1000	1500	2000	2500	3000	3500	4000	4500	5000			
IIVETIES	RELUBRICATION CYCLE (MONTHS)												
1/2 thru 1	6	6	6	6	6	6	4	4	2	2			
1-1/16 thru 1-7/16	6	6	6	6	6	6	4	4	2	1			
1-1/2 thru 1-3/4	6	6	6	4	4	2	2	2	1	1			
7-7/8 thru 2-3/16	6	6	4	4	2	2	1	1	1				
2-1/4 thru 2-7/16	6	4	4	2	2	1	1	1					
2-1/2 thru 3	6	4	4	2	1	1	1						
3-7/16 thru 3-1/2	6	4	2	1	1	1							
3-15/16 thru 4	6	4	2	1	1								

Lubricate with or equivalent to:

Shell - Alvania EP Grease No. 2 - Molytex Grease No. 2 Texaco

- Gulfcrown Grease No. 2

Mobil - Mobilux EP2

American - Amolith Grease No. 2

For operating temperatures below 32°F or above 300°F consult manufacturer.

Condition of temperature, moisture, or dirt will require more frequent lubrication cycle. Use sufficient volume of grease to purge the seals. Rotate bearings during relubrication where good safety practice permits. For corrosion protection, lubricate upon shutdown. Rotate bearings monthly during fan storage.

RECOMMENDED LUBRICATION SCHEDULE FOR FMC/LINK-BELT SERIES 300 BALL BEARINGS USED ON HORIZONTAL MOUNTED FANS

MANUFACTURER FOR SPECIFIC RECOMMENDATIONS

SHAFT SIZE	OPERATING SPEED (RPM)											
INCHES	500	1000	1500	2000	2500	3000	3500	4000	4500	5000		
HVGHES	LUBRICATION CYCLE (MONTHS)											
5/8 thru 1	6	6	6	6	4	4	4	4	2	2		
1-1/8 thru 1-1/2	6	6	6	4	4	4	2	2	2	1		
1-5/8 thru 1-15/16	6	6	6	4	4	2	2	1	1			
2 thru 2-1/2	6	6	4	4	2	1	1			•		
2-11/16 thru 3-3/16	6	4	2	2	1	1	1/2					
3-7/16 thru 3-15/16	6	4	2	1	PARTICIPATION	ON OF YOUR	niesiky (s.	See park				

Lubricate with the following greases or their equivalent:

- Alvania EP Grease No. 2 Shell Texaco - Molytex Grease No. 2

Gulf - Gulfcrown Grease No. 2 American - Amolith Grease No. 2

- Mobilux EP2

If bearings are subjected to temperatures below 32° or above 200°F, consult fan manufacturer for proper

Apply sufficient grease when relubricating to cause some purging of grease at seals.

Increase the frequency of relubrication in conditions of abnormal moisture or dirt.

Lubricate for extended shutdown or storage and rotate shaft monthly for corrosion protection.

601-64 272 FMC CORPORATION • LINK-BELT BEARING DIVISION • INDIANAPOLIS, INDIANA



Grease lubrication schedule

Link-Belt® spherical roller bearings — Series B22400 and B22500

For use on horizontal shaft equipment

		Amount of		Operating speed (rpm)										
Shaft sizes		grease		500	1000	1500	2000	2200	2700	3000	3500	4000	4500	
Inches	MM	IN ³	CM ³	Lubri	cation c	ycle (m	onths)	The state						
3/4 - 1	25	0.39	6.4	6	6	6	4	4	4	2	2	1	1	
1-1/8 - 1-1/4	30	0.47	7.7	6	6	4	4	2	2	1	1	1	1	
1-7/16 - 1-1/2	35	0.56	9.2	6	4	4	2	2	1	1	1	1	1/2	
1-5/8 - 1-3/4	40	0.80	13.1	6	4	2	2	1	1	1	1	1/2		
1-15/16 - 2	45-50	0.89	14.6	6	4	2	1	1	1	1	1/2			
2-3/16 - 2-1/4	55	1.09	17.9	6	4	2	1	1	1	1/2				
2-7/16 - 2-1/2	60	1.30	21.3	4	2	1	1	1	1/2					
2-11/16 - 3	65-75	2.42	39.7	4	2	1	1	1/2						
3-3/16 - 3-1/2	80-85	3.92	64.2	4	2	1	1/2	1.0	1					
3-11/16 - 4	90-100	5.71	93.6	4	1	1/2								
4-3/16 - 4-1/2	100-115	6.50	106.5	4	1	1/2								
4-15/16 - 5	125	10.00	163.9	2	1	1/2								

These guidelines are for usage on applications approved by FMC.

Lubricate with a multi-purpose roller bearing NLGI Grade 1 or 2 grease having rust inhibitors, anti-oxidant additives, and a minimum oil viscosity of 400 SSU at 100°F. For operation requiring a monthly or less cycle the grease should also be suitable for temperatures up to 250°F continuous, dynamically stable and must not churn or whip.

Some greases having the desired properties are:

American − Rykon Grease No. 2 EP, Mobil − Mobilgrease® 28, Texaco − Molytex EP2 grease.

If bearings are subjected to temperatures below 32° or above 200°F, consult equipment manufacturer for proper lubrication

Conditions of vibration exceeding 1 to 2 mils, moisture or dirt will require a more frequent lubrication cycle or special lubricant selection. Rotate bearings during relubrication where good safety practice permits.

Lubricate bearing prior to extended shutdown or storage and rotate shaft monthly to aid corrosion protection.

601-65-084

FMC Corporation • Bearing Division • Indianapolis, Indiana 46206



SKF SPHERICAL ROLLER BEARINGS

RELUBRICATE ON THIS SCHEDULE UNDER NORMAL OPERATING CONDITIONS

SHAFT DIA.		SPEED IN R.P.M.												
(IN.)	RS	300	500	700	900	1100	1300	1500	1800	2400	2700	3000		
2-3/16 2-7/16 2-11/16 2-15/16 3-7/16 3-15/16 4-7/16 4-15/16 5-7/16 5-15/16	LUBRICATION IN HOUI	6060 5520 5090 5090 4560 4270 3580 3380 3050 2900	3550 3220 2930 2930 2590 2400 1940 1800 1570 1470	2470 2220 2010 2010 1745 1600 1240 1125 940 850	1875 1670 1495 1495 1280 1155 845 750 590 510	1490 1320 1170 1170 985 875 600 515 370	1230 1070 940 940 770 675 425	1035 900 780 780 625 535	825 700 600 600 460 375	565 465 375 375	475 380	410		

LUBRICATION NOTES

The upper half of the housing has two tapped holes 30° from the vertical center line. One hole is in the center of the housing; the other is to the side. Lubricate through the center hole for spherical roller bearings with W33 feature (with groove around the outer ring) and lubricate through the side hole for self-aligning ball bearings and spherical roller bearings without W33 feature (without groove around outer ring). This is important! The lubricant will not get to the bearing if it is applied through the center hole when a bearing without the grooved outer ring is used.

GREASE LUBRICATION: If grease is used as a lubricant it should be smeared between the rolling elements and worked in. The lower half of the housing should be packed 1/3 to 1/2 full.

BALL BEARINGS: An apparent channeling grease with a ASTM penetration of 190 minimum should be used.

ROLLER BEARINGS: Greases to be used should have an ASTM penetration above 300 and should not channel.

GREASE CLASSIFICATION

CLASS	TYPE O	F B	ASE (1)	OIL VIS SAYBOLT SECON	NLGI (2)	
CLITOO	11120		IOL (I)	@ 100°F.	@ 210°F.	GRADE
Α	Lithium	or	Equal	200-500	48-55	0
В	**	**	**	400-600	58-68	1
С	**	**	**	800-1000	75-82	1
D	Lithiu	ım (Only	800-1000	75-82	2

TYPE OF GREASE & RELUBE CYCLE RECOMMENDED

Operating Temp.	Grease Class Chart) fo	Suggested (8 Relube Cycle				
of Brg. (4)	Low (5)	Medium	High			
0-70	A or B	A or B		6-12 months		
70-120	B or C (6)	B or C		6-12 months		
120-160	B or C (6)	C or D	D (7)	2-3 weeks		
160-200	С	C or D	D (7)	1-4 weeks		

- (1) Calcium Complex Greases Not Recommended For Spherical Roller Bearings.
- (2) National Lubricating Grease Institute Consistency Code.
- (3) Definition of speed categories:

 Low Up to ¼ of catalog speed limit for static oil lubication.

 Medium ¼ to ½ catalog speed limit for static oil lubication.

 High ½ to full catalog speed limit for static oil lubrication.
- (4) Consult SKF Engineering if temperature is below 0° or above 200°F.
- (5) Extremely slow speed, will require special consideration if loads are high.*
 (6) Use type "C" where load is heavy, 15,000 hours bating life or less and/or
- speeds are less than 100 RPM.

 (7) Consult SFK Engineering Grease lube not normally recommended under this combination of operating conditions.
- (8) Clean Dry applications only For moderate conditions of dirt and /or moisture, use cycle of 1 to 2 months. For extreme conditions of dirt and/or moisture use cycle of 1 week. Vertical applications normally require shorter than normal relube cycle.
- (9) Never mix greases with unlike bases.
- (10) Remove old grease at least once a year.
- *Under all conditions, application should be checked using the SKF lubricant film parameter found in the Engineer Date Catalog.



SAF 225/226 SPIT HOUSING PILLOW BLOCKS WITH SKF SPHERICAL ROLLER BEARINGS

RELUBRICATE ON THIS SCHEDULE

				SPEED (R.P.M.)										GREASE ADDED AT EACH INTERVAL (OUNCES)				
I N	PILLOW BLOCK NUMBER 225/226	SHAFT DIA.				300	500	700	900	1100	1300	1500	1800	2400	2700	3000		V BLOCK RIES 226
	09	1-7/16	S)	6775	3995	2800	2140	1715	1425	1210	980	690	595	515	0.35	0.52		
	10	1-11/16	JRS	6400	3760	2630	2000	1600	1325	1120	900	625	535	515	0.37	0.79		
	11	1-15/16	OUR	6070	3555	2475	1880	1495	1230	1040	830	565	480	410	0.45	0.93		
	13	2-3/16	H	5530	3215	2220	1670	1320	1075	900	705	465	385	320	0.67	1.21		
	15	2-7/16	AL	5090	2935	2010	1495	1170	945	780	600	375	300		0.72	1.58		
	16	2-11/16	>	4900	2810	1915	1420	1105	885	725	550	330	260		0.83	1.77		
	17	2-15/16	ER	4720	2700	1830	1345	1040	830	670	505	295			0.97	1.94		
	18	3-3/16	IN	4560	2590	1750	1280	980	775	625	460				1.15	2.19		
	20	3-7/16		4265	2400	1600	1155	875	675	535	380				1.49	2.82		
	22	3-15/16	TION	4010	2230	1465	1045	775	585	450	300				1.91	3.45		
	24	4-3/16		3780	2075	1385	940	680	505	370					2.24	4.02		
	26	4-7/16	CA	3575	1935	1235	845	595	425	300					2.65	4.68		
	28	4-15/16	Z.	3385	1805	1130	755	515	350						3.06	5.50		
	30	5-3/16	UBRICA	3210	1685	1035	670	440	280						3.54	6.21		
	32	5-7/16	ELI	3050	1575	940	590	365							4.17	6.97		
	34	5-15/16	8	2900	1470	855	515	295							4.79	7.77		

- Notes: 1. Lubricate with a Grade 2 lithium or non-soap base grease having an oil viscosity of 500-1000 SUS at 100°F.
 - 2. Should bearing operating temperature be below 32°F. or above 200°F. consult fan manufacturer for lubrication recommendations.
 - 3. Clean and repack annually.
 - 4. If fans are to be stored after arrival at job site, bearings should be immediately relubricated and shaft rotated monthly for corrosion protection.

Air Filters


All filters are shipped loose in boxes inside of unit. See packing list received with each unit showing what section of unit filters are shipped in. It is mandatory that filters be installed in the filter frames of each unit before putting the unit into operation to protect the coils and keep them clean.

Upstream access filter frames have a removable section of the frame secured in place with sheet metal screws. It is necessary to remove this section for each horizontal row of filters, install the filters and secure the removable frame section back in place.

Side access slide filters have a side plate to the filter frame secured on with sheet metal fasteners. The opposite side is hinged. Remove the fasteners, swing open side plate, slide filters into filter frame, close side plate and re-install sheet metal fasteners.

Due to the wide variety of bag filters, hepa filters, roll filters and odor removing filters it is not possible to cover all of them in this manual. However, when these filters are supplied installation instructions are shipped with each type.





VENTLOCK # 333 DOOR LATCH

Door Latch

Remove shipping set screw before attempting to open door.

The first quarter turn of the latch handle engages the flange, and during the next quarter turn not only does the bevel on the flange impart compression amounting to 5/32", but a stud on the latch handle works against a cam in the latch barrel pulling in the striker another 1/8". In other words, total compression of over 1/4" is provided by this latch.

The door handle should be checked for proper adjustment so that the door makes a positive seal against the door gasket. To adjust door handle, loosen locking set screws, move flange to desired position on latch shaft, retighten locking set screws.

Door Gaskets

3/16" x 3/4" closed cell door gasketing is applied to the door frame opening. At time of startup, the door frame and gasketing should be inspected for possible damage by workmen during the hookup of the equipment.

Caulking

There is always the possibility that external caulked seams may be loosened during the shipping and rigging process. Any seam that appears to be a possible leak source should be recaulked, with acrylic or silicone sealant.

Paint Standard

Units are painted with an industrial enamel which will meet or exceed the exposure requirements of TTP 636 Federal Specifications. This finish lends itself to repainting with other enamels; however, it is not recommended that epoxies be used over this paint.


Note: Some units may have special paint. Check each submittal for each unit for special paint.



Condensate Drain

The majority of evaporator coils are located in the units so that the supply air is drawn through them. This results in the condensate being induced to the area of low static pressure. Unless some means of pressure equalization is provided in the condensate drain, the air rushing through the drain pan pipe flange will cause the condensate to pile up in the drain pan. As the unit continues to operate, the accumulated water will be picked up by the in-rushing air and carried with the air over the side of the drain pan causing possible water leaks into the supply duct and/or through the bottom of the unit causing water damage in the building. A minimum trap should be installed to prevent this condensate water buildup. See illustration below. On initial startup, it may be necessary to fill the trap manually or, after the unit has operated sufficiently for a small amount of condensate to collect in the drain pan, turn off the unit, and the trap will automatically fill.

During the winter months when the cooling system is turned off and the unit is exposed to freezing conditions, an antifreeze solution should be poured into the condensate drain trap to prevent freezing and possible damage. The condensate drain trap may also be drained and capped, but be sure to remove the cap when starting the cooling for the next season.



Dampers

CAUTION: Dampers, operators, controls and linkage must be checked prior to applying power to the operators making sure nothing will obstruct the operation of the dampers. Do not over-drive damper operators as this may cause damage to the dampers.

Multizone Dampers

FUNCTION: Position zone dampers in response to zone thermostat. One end switch from each motor should be connected in series to prevent heating source from operating until at least one zone is calling for heat.

LOCATION: Discharge end of unit above or below dampers.



Fresh Air - Return Air and Exhaust Air Damper Motors

FUNCTION: One or more damper motors operate outside air, return air and exhaust air dampers, which function in response to mixed air thermostat or through mixed air lock out to minimum position. Spring return on damper motors close outside air dampers, close exhaust dampers and opens return air dampers when there is no power to the motors.

LOCATION: Mixed air section, return air section and/or exhaust air section.

Minimum Position Potentiometer (If Supplied)

FUNCTION: To maintain minimum outside air setting when energized. Position may be tailored to suit individual job.

LOCATION: Inside of damper motor in mixed air section or in remote control panel.

A good check-out should guarantee that:

- 1. The motor operates the load properly.
- 2. The motor responds properly to a controller.
- 3. The motor returns the damper to the starting position whenever power to the motor is interrupted.
- 4. There is no binding or stalling of the motor as the motor travels through its entire range.

NOTE: To simplify checkout procedure, it is suggested that an auxiliary potentiometer be substituted for the controller. This may be obtained through your local controls supplier.

Enthalpy Control or Economizer Change Over Thermostat

Function: To drive fresh air dampers and exhaust air dampers to the minimum or closed position and the return air dampers to full open position. When the outside air temperature is below the setting of the control the fresh air dampers, return air dampers and exhaust air dampers are in full economizer cycle operation.

LOCATION: Return air section with the sensing element extending into the fresh air section.





ELECTRIC HEATER TYPICAL

NOTE: When ordering replacement parts give the complete model and serial number of both the electric heater and the Governair unit.


Air Pressure Switch sensing tube removable inside the heater control panel.


Automatic primary hi-limit












Secondary hi-limit safety device. Without removing heater from duct, the heat limiter, or fuse link is manually replaceable in the control panel by removing one screw.





BELT TENSIONING GAUGE

Troubleshooting

An air moving system consists of the entire air circuitry through which air flows. Included in the system are such components as duct work, fittings, branch ducts, dampers, heat exchangers, filters, coils, elbows, registers, grilles, and other items through which air flows or which offer obstruction to air flow.

While differences in temperature and humidity may cause air movement, it may be considered very slight in comparison to the positive circulation required in an air conditioning system. To accomplish this air movement, a fan has two functions to perform.

- 1. To produce sufficient pressure or head to accelerate the mass of air from a state of rest to the required velocity, and
- 2. To produce sufficient pressure to overcome any resistances to the flow of air

The determination of these pressures is a very important part of troubleshooting an air conditioning system. The generally accepted standard instrument for measuring these unit pressures is the Pitot Tube (see Figure 31). The Pitot Tube is used in conjunction with an Inclined Manometer, Magnehelic Gauge, or a Tube Manometer.

When the Pitot Tube is used in conjunction with these instruments, one is able to read velocity pressure (Vp), static pressure (Sp), and total pressure (Tp) within the system.




FIG. 31 — CONSTRUCTION OF PITOT TUBE

Pitot Tube

The pitot consists of an impact tube within a larger static tube. When the impact tube is pointed directly into the air stream, the small static pressure holes are perpendicular to the air stream and are not affected by air velocity.

To read velocity pressure, the total pressure tap at the end of the pitot tube is connected to one leg of a manometer and the static pressure tap at the side of the pitot tube is connected to the other leg of the manometer. Refer to Figure 32.




FIG. 32 - PITOT TUBE CONNECTIONS

Inclined Manometer

This instrument, also known as a draft gauge, is a simple, foolproof device, which responds directly to the air pressure exerted against it (transmitted from the Pitot tube), and reads directly in inches of water. Ranges for these instruments vary, and the technician should have one or more instruments to cover the range of 0 to 8 inches of water. Refer to Figure 33.

Magnahelic Pressure Gauge

"Magnahelic" is not a generic term but is registered by Dwyer Instrument Company. The magnahelic gauge is a diaphragmoperated gauge that has several advantages over a liquid
manometer; (1) It need not be leveled to 0 and can be used
easily on a ladder or unlevel surface. (2) When hooked up to
the Pitot tube it need not be purged of air bubbles as the
liquid manometer may. (3) There is less chance of parallax
error in reading the dial face. (4) It is easily transported
without the chance of losing the liquid charge. Unless extreme accuracy is required, this instrument may replace the
manometer for average air conditioning work, and like the
manometer, is available in a variety of ranges. The dial is only
4 inches in diameter and therefore has a limited scale; several
instruments are required to cover the normal ranges encountered in average air conditioning jobs. Refer to Figure 34.




FIG. 33 - INCLINED MANOMETER

"U" Tube Manometer

Pressure is defined as force per unit area — and the best way to measure air pressure is to balance a column of liquid of known weight against the air pressure and measure the height of liquid columns so balanced. The units of measure commonly used are, inches of mercury (in Hg.), using mercury as the fluid and inches of water (in. WG.) using water or oil as the fluid.

Instruments employing this principle are called manometers. The simplest form is the basic well known U-tube manometers (see Figure 35). This device indicates the difference between two pressures or between a single pressure and atmosphere, when one side is open to atmosphere.




FIG. 34 - MAGNAHELIC PRESSURE GAUGE

If a U-tube is filled to the half way point with water and air pressure exerted on one of the columns, the fluid will be displaced. Thus one leg of water column will rise and the other falls. The difference in height "h" which is the sum of the readings above and below the half way point, indicates the pressure in inches of water column.

The U-tube manometer is a primary standard because the difference in height between the two columns is always a true indication of the pressure regardless of variations in the internal diameter of the tubing.




FIG. 35 - "U" TUBE MANOMETERS



FIG. 36 - TUBE MANOMETER



The Dwyer Slack Tube Manometers are as accurate as the finest laboratory "U" gauges and they are made to roll up compactly for easy carrying and to withstand rough usage. For use on all Governair units the manometers should cover at least a 16 inch range. See Figure 36.

Duct Pressures and How They Work

Velocity — When air moves at a given velocity in a duct it creates a pressure corresponding to the velocity; this is a measure of the kinetic energy in the fluid and it is known as the *velocity pressure* (Vp). Velocity pressure is always exerted in the direction of air flow. The relationship between the velocity and the velocity pressure may be expressed by the following formulas:

$$V_p = \frac{V}{4005}$$

$$V = 4005$$
 Vp

It is therefore a simple matter to determine the velocity (fpm) of an airstream if the Vp can be measured. For example, if a Pitot tube manometer hook-up reads 0.250 in. water, we substitute for the above equation:

$$4005$$
 0.250 = 2002 fpm

Static Pressure — Independent of its velocity, air, when confined within an enclosure such as a duct or tank, will exert itself perpendicularly to the walls of the enclosure. This is the compressive pressure existing in a fluid, and it is known as the static pressure (Sp). Unlike velocity pressure) which is always positive, static pressure when it is above atmospheric pressure will be positive, but when below atomospheric pressure it will be negative. The discharge side of a fan in a supply system will read a positive pressure, the inlet side of the fan in an exhaust system will read a negative or minus pressure.

Total Pressure — Static pressure is exerted whether air is at rest or in motion. The algebraic sum of static pressure and velocity pressure gives the *total pressure* (Tp). Therefore:

$$Vp = Tp - Sp$$

The manometer does not sense the actual velocity pressure directly but by using the Pitot tube hook-up with the static opening connected to the low pressure side of the gauge, and the total pressure opening connected to the high pressure side of the gauge, the manometer will read the difference between the two, or the *velocity pressure*.

Velocity pressure and static pressure change in the duct work with every change in the duct configuration, but the total pressure, on the other hand, remains constant. Hence, as the velocity pressures decreases, the static pressure increases and vice versa, because the static pressure is always the difference between the total pressure and the velocity pressure. It should be remembered, however, that in an actual duct system, the internal friction will cause a loss of total pressure.

The static pressure in an exhaust system is always below atmospheric pressure, and it is customary among ventilation engineers to omit the minus sign affecting the static (gauge pressure). These men know, of course, that the total pressure is higher than the static pressure by the amount of the velocity pressure.

When the unit is designed for connection to a duct system and the installing contractor assembles ducts, elbows, registers, grilles, etc. to the outlet and/or inlet of the unit, the static pressure drop through this external duct work is called external static pressure. See Figure 37.




FIG. 37 - AIR MOVING SYSTEM

Fans selected must be capable of moving the desired air flow through the entire air moving system including the unit (internal SP) and also the duct system (external SP).

At a given flow rate the internal static pressure losses plus the external static pressure losses equal the system static pressure or the summation static pressure. These pressures are of great importance when troubleshooting for causes of reduced capacity, vibration, and noise.

Changes in the cross sectional area of duct (contractions or enlargements) cause changes in the velocity of the air flowing through the duct.

When the velocity decreases, the velocity pressure also decreases. Some of the velocity energy is lost as a result of the design of the duct where the area changes. Some of the velocity energy is converted into static pressure energy in the continuing duct work. This conversion of velocity energy to static pressure is called static regain.

When contacting Governair for assistance the following information will be required:

- 1. Unit Model No.
- 2. Job Name (Not Contractor)
- 3. Unit Model No.
- 4. Customer's Unit Identification
- 5. Design Data and Actual Data.
 - A. Fan RPM
 - B. Unit SP (Across Fan)
 - C. Unit CFM
 - D. Pressure Drop of Water Across Cooling Coil (PSIG)
 - E. Air Pressure Drop Across Coil (In. of Water)
 - F. Temperature Differential Across Cooling Coil (°F)
 - G. Voltage
 - H. Amperes
- For Fan or Motor RPM (Use a Tachometer, Stroboscope or Revolution Counter).

- 7. The Voltage and Amperes can be obtained by using a separate meter or a clamp-on type AMP meter.
- 8. A sketch of the Duct Configuration would assist us in trying to resolve the problem.
- 9. The most important item is to provide a detailed explanation of the problem.
- 10. Most of us recognize that an orifice is the best method of measuring flow in piping. This is also true in an air system and is the reason for reading step 5D.

For further assistance in troubeshooting the air unit refer to the troubleshooting chart which follows:

TROUBLESHOOTING CHART

SYMPTOM		SOURCE	PROBABLE CAUSE
	1.	IMPELLER HITTING INLET RING	Impeller not centered (check shaft clamp.) Inlet ring damaged or not adjusted. Shaft loose in bearing (check locking Collar.) Impeller loose on shaft (check shaft clamp.) Bearing loose in bearing support (check mounting bolts.)
	2.	DRIVE	Sheave not tight on shaft (motor or fan.) Belts hitting belt guard. Belts loose. Adjust after 48 hours operation. Belts too tight.
			Belts wrong cross section. Belts not "matched" in length on multi-belt drive. Variable pitch sheaves not adjusted so each groove has same pitch diameter (multi-belt drives.) Misaligned sheaves. Belts worn. Motor, motor base or fan not securely anchored. Belts oily or dirty.
	3.	BEARING	Defective bearing. Needs lubrication. Loose on bearing support. Loose on shaft (check locking collar.) Misaligned (check alignment binding.) Foreign material inside bearing. Worn bearing. Fretting corrosion between inner race and shaft.
NOISE	4.	Loose on shaft (check shaft clamp.)	Defective impeller. Do not run fan. Contact manufacturer. Unbalance. Foreign material on fan blades.
	5.	HOUSING	Foreign material in housing. Inlet cones loose or not adjusted.
الماسي	6.	ELECTRICAL	Lead-in cable not secure or is too rigid. AC hum in motor or relay. Starting relay chatter. Motor bearings. Single phasing a 3-phase motor.
	7.	SHAFT	Bent. Undersized. May cause noise at impeller, bearings or sheave. Loose internal balance weights. Bearing alignment.
	8.	HIGH AIR VELOCITY	Duct work too small. Fan running too fast. Fan selection too small. Static pressure lower than expected. Registers and grilles too small. Insufficient fade area of heating or cooling coil.
	9.	OBSTRUCTION IN HIGH VELOCITY AIR STREAM MAY CAUSE RATTLE, OR PURE TONE WHISTLE	Dampers. Registers. Loose dampers or splitters. Grilles. Sharp elbows. Sudden expansion of duct work. Sudden contraction of duct work. Turning vanes.



	SYMPTO	OM SOURCE	E PROBABLE CAUSE
	10.	PULSATION OR SURGE	Oversized duct work. Parallel fan operation. Loose dampers or splitters. System instability. Ducts vibrate at same frequency as fan pulsations. Organ pipe action on long duct.
	11.	HIGH VELOCITY THROUGH CRACKS, HOLES OR PAST OBSTRUCTIONS	Leaks in duct work. Registers or grilles.
NOISE	12.	RATTLES AND/OR RUMBLES	Excessive duct velocities. Vibrating ductwork. Flex connector too tight or touching. Vibrating parts not isolated from building.
	13.	FAN	Forward curve impeller installed backwards. Fan running backwards. Impeller not centered with inlet cones. Fan speed too slow.
	14.	DUCT SYSTEM	Actual system is more restrictive (more resistance to flow) than expected. Dampers closed. Splitter rod disconnected. Registers closed. Leaks in supply ducts. Open duct seams. Insulating duct liner loose. Fire dampers closed.
	15.	FILTERS	Dirty or clogged (dirt, lint, snow, grass.)
	16.	COILS	Dirty or clogged (construction trash.)
CFM — LOW	17.	RECIRCULATION	Internal cabinet leaks in bulkhead separating fan outlet (pressure zone) from fan inlets (suction zone.) Leaks around fan outlet at connection through cabinet bulkhead.
	18.	OBSTRUCTED FAN INLETS	Elbows, cabinet walls or other obstructions restrict air flow. Inlet obstructions cause restrictive systems but do not cause increased negative pressure readings near the fan inlet(s). Fan speed may be increased to counteract the effect of restricted fan inlet(s). (Observe fan RPM limits).
	19.	NO STRAIGHT DUCT AT FAN OUTLET	Fans which are normally used in duct systems are tested with a length of straigh duct at the fan outlet. If there is no straight duct at the fan outlet, decreased performance will result. If it is not practical to install a straight section of duct at the fan outlet the fan speed may be increased to overcome this pressure loss. Observe fan RPM limits.
	20.	OBSTRUCTIONS IN HIGH VELOCITY AIR STREAM	Obstruction near fan outlet. Sharp elbows near fan outlet. Improperty designed or no turning vanes.
CFM — HIGH	21.	SYSTEM	Oversized duct work. Access door open. System not balanced. Resistance less than specified. Registers or grilles not installed. Dampers set to by-pass coils. Filter(s) not in place.
	22.	FAN	Backward inclined impeller installed backwards (HP will be high.) Variable motor sheave not adjusted. Fanspeed too fast.
STATIC PRESSURE INCORRECT	23.	SYSTEM FAN OR INTERPRETATION OF MEASUREMENTS	GENERAL DISCUSSION The velocity at any point of measurement is a function of the velocity of the air and its density. The static pressure at a point of measurement in the system is a function of system design (resistance to flow), air density and the amount of air flowing through the system. The static pressure measured in a "loose" or oversized system will be less than the static pressure in a "tight" or undersized system for the same airflow rate. In most systems, pressure measurements are indicators of how the installation is operating. These measurements are the result of air flow and as such are useful indicators in defining system characteristics.

REFER TO THE TROUBLESHOOTING SECTION FOR THE PROPER METHODS OF OBTAINING CORRECT READINGS



SYMPTOM		SOURCE	PROBABLE CAUSE				
STATIC PRESSURE	24.	SYSTEM	System has less resistance to flow than expected. This is a common occurrence Fan speed may be reduced to obtain desired flow rate. This will reduce HP, conserve energy, and save operating costs.				
LOW	25.	AIR DENSITY	Pressures will be less with high temperature air or at high altitudes.				
CFM HIGH -	26.	FAN	Backward inclined impeller installed backwards, HP will be high. System resistance less than specified. Fan speed too high.				
STATIC PRESSURE LOW, CFM LOW	27.	SYSTEM	Fan inlet and/or outlet conditions not same as tested. See general discussion (23). Also see 13 thru 20.				
STATIC PRESSURE HIGH, CFM LOW	28.	SYSTEM	Obstruction in system. Dirty Filters. Dirty coil. Closed fire damper. System too restricted. Also see 13 through 20.				
SYMPTOM		SOURCE	PROBABLE CAUSE				
SYMPTOM		SOURCE	PROBABLE CAUSE				

Motor Trouble Shooting Guide

Apparent Trouble	Possible Causes	Correction
High Current Draw	First check accuracy of ammeter reading on all three phases	
Running Idle	High Line Voltage 5 to 10% over nameplate. Smaller motors (140-213 frames) may increase current at a faster rate.	Consult power company – possibly reduce by using lower transformer tap.
Running Under Load	Motor Overloaded	Reduce load or use larger motor
	High Line Voltage 5 to 10% over motor nameplate voltage on small motors (140-213 frames only)	Consult power company — possibly reduce by using lower transformer tap.
	200 volt motor on 230 or 240 volt system	Change to 230 volt motor.
	Low Line Voltage 5 to 10% lower than nameplate voltage on any size	Consult power company — possibly increase by using high transformer tap.
	230 volt motor on 208 volt system	Change to 200 volt motor.
Unbalanced Current Draw (5% or more of the average current draw)	Unbalanced Line Voltage due to:	Carefully check voltage across each phase at the motor terminals with a good, properly
(s) of more of the average carrent arms,	a. Power Supply	calibrated voltmeter.
	b. Unbalanced System Loading	If the voltage per phase is more than 1% out of balance, the current will be out of balance by an
	c. High Resistance Connection	even greater percentage.
	d. Undersized Supply Lines	If there is doubt as to whether the trouble lies with the power supply or the motor, check per the following:



PPARENT TROUBLE	POSSIBLE CAUSE	CORRECTION
	Defective Motor	
		Rotate all three input power lines to the motor by one position — i.e., move line #1 to #2 motor lead, line #2 to #3 motor lead and line #3 to #1 motor lead.
		a. If the unbalanced current draw pattern follows the input power lines, the problem is in the power supply.
		 b. If the unbalanced current draw pattern follows the motor leads, the problem is in the motor.
		Correct the voltage balance of the power suppl or replace the motor, depending on answer to a. & b. above.
Excessive Voltage Drop (more than 2 or 3% of nominal supply voltage)	Excessive Starting or Running Load	Reduce load or install larger motor.
	Inadequate Power Supply	Consult power company
	Undersized Supply Lines	Increase Line sizes
	High Resistance Connections	Check motor leads and eliminate poor connection
Overload Relays Tripping		
Upon Starting	Slow Starting (10 - 15 seconds or more) due to High Inertia Load	Reduce starting load. Increase motor size if necessary.
	Low voltage at motor terminals	Improve power supply and/or increase line size.
Under Load	Overload	Reduce load or increase motor size.
	Unbalanced Current Draw Single Phasing	Balance supply voltage. Eliminate.
	Excessive Voltage Drop	Eliminate.
	Too frequent starting or intermittent overloading	Reduce frequency of starts and overloading or increase motor size.
	High Ambient Starter Temperatures	Reduce.
	Wrong Size Relays	Correct size per nameplate amperes of motor. Relays have built in allowance for service factor ampere draw.
Motor Runs Excessively Hot	Overloaded	Reduce load or load peaks and number of starts in cycle or increase motor size.
	Blocked Ventilation a. TEFC's	Clean External ventilation system — check fan.
	b.O.D.P.'s	Blow out internal ventilation passages.
		Eliminate external interference to motor ventilation.
	High Ambient Temperature over 40° or 105° F	Reduce ambient temperature or provide outside source of cooler air.
	Unbalanced Current Draw	Balance supply voltage. Check motor leads for tightness.
	Single Phased	Eliminate.
Won't Start (just hums and heats up)	Single Phased	Shut power off. Eliminate single phasing. Check motor leads for tightness.
	Rotor or bearings locked	Shut power off. Check shaft for freeness of rotation.
		Be sure proper sized overload relays are in each of the 3 phases of starter
Runs Noisy Under Load (excessive electrical noise or chatter under load)	Single Phased	Shut power off. If motor cannot be restarted, it i single phased. Eliminate single phasing.
		Be sure proper sized overload relays are in each of the 3 phases of the starter.

Slow Starting

PWS

Auto. Transformer

(10 or more seconds on small motors - 15 or

more seconds on large motors)

Across the Line Start Excessive Voltage Drop (5 - 10% voltage drop

causes 10 - 20% or more drop in starting torque)

Consult power company - Check system.

Eliminate voltage drop.

High Inertia Load Reduce starting load or increase motor size.

Reduced Voltage Start Excessive Voltage Drop. Loss of Starting Torque.

Y-Delta Starting Torque Reduced to 1/3

Starting Torque Reduced to 1/2

Reduce starting load or increase motor size, or

Choose type of starter with higher starting

torque, or

Starting Torque Reduced to 1/4 to 5/8 Reduce time delay between 1st and 2nd step of

starter - get motor across the line sooner.

Load Speed Appreciably Below Nameplate Speed

Excessive Vibration (mechanical)

Overload

Reduce load or increase voltage

Check and eliminate per above.

Excessively Low Voltage

NOTE: A reasonable overload or voltage drop of 10 - 15% will reduce speed only 1-2%

> A report of any greater drop would be questionable.

Wrong Nameplate

If speed is off appreciably, i.e., from 1800 to 1200 RPM, check Lincoln code stamp on stator with nameplate. If codes do not agree, replace

Check meter using another device or method.

with motor of proper speed.

Inaccurate method of measuring RPM.

Out of Balance

a. Motor Mounting

Be sure motor mounting is tight and solid.

Disconnect belt or coupling - restart motor - if vibration stops, the unbalance was in load.

c. Sheaves or Coupling

Remove sheave or coupling - tape 1/2 key in shaft keyway and restart motor - if vibration stops, the unbalance was in the sheave or coupling.

d. Motor

b. Load

If the vibration does not stop after checking a, b and c above, the unbalance is in the motor -

replace the motor.

Bearing OK

e. Misalignment on Close Coupled Application

Check and realign motor to the driven machine.

Noisy Bearings (listen to bearings)

Smooth Mid Range Hum

High Whine

Low Runble Rough Clatter Normal fit

Internal fit of bearing too tight

Internal fit of bearings too loose

Bearing Destroyed

Replace bearing - check fits

Replace bearing - check fits

Replace bearing - Avoid: a. Mechanical Damage

b. Excess Greasing

c. Wrong Grease d. Solid Contaminants

e. Water running into motor

f. Misalignment on close coupled application

Mechanical Noise

Driven Machine or Motor Noise?

Isolate motor from driven machine - check difference in noise level.

Cushion motor mounting or dampen source

Motor Noise Amplified by resonant mounting

Driven Machine Noise transmitted to motor through drive

of resonance. Reduce noise of driven machine or dampen

transmission to motor. Improve alignment.

Misalignment on close coupled application


GOVERNAIR

Manufacturers of Air Conditioning and Refrigeration Equipment

4841 N. Sewell Street • Oklahoma City, Oklahoma 73118 • (405) 525-6546 • Telex 747-194



INSTRUCTION MANUAL



SELF CONTAINED and SPLIT SYSTEM AIR CONDITIONING UNITS

Installation
Operation
Maintenance

General

This manual has been prepared as a guide for installing, operating and maintaining Governair heating and cooling equipment. This is high quality equipment and by following the instructions listed in this manual, years of economical and satisfactory operation will be obtained.

It is not possible to cover every item in detail and where an item is listed as typical you should contact your local Governair sales representative or the Governair factory in Oklahoma City for the specific information required.

AC-1 SERIAL # 25997 MODEL # ACU-302

Table of Contents

	rage
Receiving	2
Inspection of Equipment	2
Shipped Loose Parts	2
Caulking	2
Paint Standard	2
Weights of Units	2
Curb Installation	3-6
Storage	3
Rigging	7-8
Demount Assembly Instructions	9
Condensate Drain	10
Electrical Information	10-11
Pre-Startup Check — Cooling	11
Static Pressure Limits of Cabinet	12
Check Test and Startup Form	13
Superheat	14
Thermostats	15
Head Pressure Control	16
Capacity Control	17-18
Pressure Control Settings	18-19
Compressor — Oil Safety	19
Overload Protection (Solid State)	20
Condenser Fans	21
Blowers	22-23
Belts	24
Pulleys and Drives	24-27
Lubrication	28-33
Filters	33
Door Latch	34
Door Gaskets	34
Dampers	34
Damper Motors	34
Enthalpy Control	35
Parts — Replacement Ordering	35
Coils	35-36
Electric Heat	37
Gas Heat	38-42
Preventative Maintenance	43
Trouble Shooting — Air Side	44-49
Trouble Shooting Guide	49-56
	49-51
Cooling Cycle	52 - 54 54 - 55
Dampers & Damper Actuators	56

Receiving

Inspect the complete unit for shipping damage. If damage is present, you have the right to either accept or reject the shipment. If the receiving contractor or the receiving agent for the contractor elects to receive the equipment in a damaged condition, it then becomes the contractor's responsibility to note the extent of the damage on the delivering freight bill of lading in the presence of the delivering agent (driver) of the delivering freight carrier. It then becomes the contractor's responsibility to file a freight claim with the delivering freight carrier in accordance with the ICC regulations. It also then becomes the responsibility of the receiving contractor to work with the delivering carrier to have the equipment repaired to the satisfaction of Governair Corporation so the warranty may remain valid. Governair must also be notified of shipping damage.

Note: Governair reserves the right to cancel the warranty on any equipment that is not repaired to Governair's satisfaction.

See section Shipped Loose Parts

Inspection of Equipment - Visual

The equipment type and arrangement should be verified as ordered at once when it arrives at the jobsite. When a discrepancy is found, the local Governair Sales Representative, or the Governair factory, must be notified immediately so that corrective action may be initiated, also verify electrical conformance to specifications. Unauthorized alterations and unauthorized backcharges will not be recognized by Governair Corporation.

Shipped Loose Parts

- 1. Check the packing list for the list of shipped loose parts.
- 2. Packing list will note how many and type of parts.
- 3. Packing list will note in what section of the unit each shipped loose part is located.
- 4. All air filters are shipped as loose parts.
- 5. Rainhoods are shipped as loose parts. Small rainhoods will be inside the units, and large rainhoods will be outside the unit and so noted on packing list.

Caulking

There is always the possibility that external caulked seams may be loosened during the shipping and rigging process. Any seam that appears to be a possible leak source should be recaulked with acrylic or silicone sealant.

Paint Standard

Units are painted with an industrial enamel which will meet or exceed the exposure requirements of TTP 636 Federal Specifications. This finish lends itself to repainting with other enamels; however, it is not recommended that epoxies be used over this paint.

Note: Some units may have special paint. Check the submittal of each unit for special paint.

Weights of Units

Due to the gross latitude in each unit design, it is not possible to list unit weights in this manual. Unit weights are listed with each unit submittal drawing. These drawings must be referred to when selecting a crane for rigging and figuring roof weight loads.

Contact your Governair Sales Representative should you have any questions.



Curb Installation

Note: If the unit is to be installed on grillage, this section will not apply.

The curb will be shipped unassembled. It is necessary to assemble it on the jobsite. Each part of the curb is identified with the proper tags and/or markings. Complete assembly instructions are shipped with and attached to each curb package. Where more than one curb is shipped to one location, there will be assembly instructions with and attached to each curb package. It is important the curb be installed level and square. Each curb is marked with matching serial numbers for each unit.

The curb installation shows a curb gasket that is mounted between the curb and the unit. When this gasket is supplied by Governair Corporation it is not shipped with the curb, but is shipped with the completed unit "shipped loose parts" and is so noted on unit packing list. It is necessary to check the unit packing list for location of the section of the unit in which the curb gasket is located. It is necessary to install the curb gasket before setting the unit on the curb. This is necessary for an air seal between the unit and the curb and also serves as a dampener, preventing metal to metal contact between the unit and curb. However, this should not be used as a vibration isolator where the prevention of noise and vibration transmission into the building is critical.

Note: See section under receiving instructions when receiving curbs and inspecting for freight damage and filing of freight damage claims. Any freight damage is the responsibility of the receiving contractor and/or his authorized receiving agent and the delivering carrier.

See pages 4, 5 and 6 for typical curb drawings. When installing curb, obtain a copy of the approved submittal, as each unit and actual curb installation may not be identical. Do not use this typical curb to install your curb.

Note: Should there by any questions as to the number of pieces of curb parts or assembling of the curb, notify Governair Corporation at once.

Storage

Short-Term Storage:


Short-term storage is considered six (6) months or less from date of shipment. Storage maintenance during this time period is usually, but not necessarily, limited to the following:

- 1. Make sure the equipment is received and unloaded and set in position per guidelines listed under "Rigging."
- 2. Make sure all access doors are tightly closed and that all access openings into the unit are sealed, such as air supply and air return openings, pipe chase openings, fresh air openings, exhaust air openings, electrical connection openings and other access openings of the unit cabinet that may permit entry of snow, ice, rain water, dust, dirt, mud and other construction debris, or birds and rodents that may enter the interior of the unit.
- 3. The unit must also be protected when setting on the ground level to prevent damage to the exterior of the cabinet by construction vehicles and personnel.

Long-Term Storage:

Long-term storage is considered to be any period beyond six (6) months from date of shipment. If long-term storage is anticipated, contact the Governair Sales Office at time of order entry for the proper instructions for long-term storage, as it is mandatory that a detailed record be maintained during this long-term storage period, such as, but not limited to, proper sealing of the cabinet, rotation of the blowers and bearings and protection of all motors from moisture. Note: Under certain conditions, it may be necessary to remove the motors from the unit and/or add heat to the motor. This record must be available to Governair should a failure occur during the warranty

SUGGESTED ROOF CURB INSTALLATIONS




METHOD NO. I


UNIFORMLY SUPPORTED OVER STRUCTURAL STEEL

NOTES

- It is recommended that the entire curb be supported across the full width of the curb base plate.
- (2) The upper surface of the wood nailer and the counterflashing must be kept smooth and free of nail and screw heads to insure uniform curb loading and a proper unit-to-curb seal.




METHOD NO. 20 UNIFORMLY SUPPORTED OVER SHIMMED ROOF DECKING




METHOD NO. 2b
NON-UNIFORMLY SUPPORTED OVER
SHIMMED ROOF DECKING

(3	ic	VE	H	11	1	a	11	R
C	0	P	PO			+		0	N
			WELL						
OKL	AH		CITY	. 0	KLA	HO	M	, "	1118

MODEL	DATE	PAGE	OF	
SEH NO	DRAWING NO			



SUGGESTED ROOF CURB INSTALLATIONS



period. There is a time limit of one year from date of shipment that any unit may be kept in long-term storage. At the end of the one year period, the unit must be in operation.

Note: Failure to perform the long-term storage requirements and properly log these required procedures will void the warranty.

Rigging

Proper handling of the equipment is mandatory during unloading and setting it into position. See Rigging Instructions page 8.

Note: If equipment is not set in its permanent position and is stored on the ground or other unlevel area, proper provisions must be taken for supporting and protecting the equipment. See section for both Short- and Long-Term storage.

It is mandatory that the proper spreader bars and hoisting straps be used when rigging. See page 8 for recommendations. It is also mandatory that an experienced and reliable rigger be selected to handle unloading and final placement of the equipment. Your rigger must be advised that the unit contains delicate components and that it be handled in an upright position. Care must be exercised to avoid twisting the structure.


When the equipment has been set in final placement, the following must be done:

- 1. Check all caulked seams and air seals. Recaulk if and where caulking has been broken.
- 2. Check all door latches and readjust if necessary to maintain a good tight seal.

Note: Remove shipping screws in body of door handle. These screws are installed prior to shipment to prevent doors from accidentally working open during transit and handling.




Rigging Instructions



- 1. Units will have lifting lugs welded and/or bolted to the base when specified.
- 2. Avoid damage to the curb and curb gasket when rigging onto a curb. See Curb Instruction pages 4, 5 and 6.
- 3. Spreader bars must be used to prevent damage to the unit casing.
- 4. Care must be taken to keep the unit in the upright position during rigging.
- 5. Avoid unnecessary jarring or rough handling.
- 6. Care must be taken to not damage the water-tight seams in the unit casing.



Demount Assembly Instructions




Condensate Drain

The majority of evaporator coils are located in the units so that the supply air is drawn through them. This results in the condensate being induced to the area of low static pressure. Unless some means of pressure equalization is provided in the condensate drain, the air rushing through the drain will cause the condensate to accumulate in the drain pan. As the unit continues to operate, the accumulated water will be picked up by the in-rushing air and carried with the air over the side of the drain pan causing possible water leaks into the supply duct and/or through the bottom of the unit causing water damage in the building. A minimum trap should be installed to prevent this condensate water buildup. See illustration below. On initial startup, it may be necessary to fill the trap manually or, after the unit has operated sufficiently for a small amount of condensate to collect in the drain pan, turn off the unit and the trap will automatically fill.

During the winter months when the cooling system is turned off and the unit is exposed to freezing conditions, an antifreeze solution should be poured into the condensate pan trap to prevent freezing and possible damage. The condensate drain trap may also be drained and capped, but be sure to remove the cap when starting the cooling for the next season.

Note: If lengthy drain lines are used to drain the condensation into roof drains, it may be necessary to use anti-slime tablets in drain pan to prevent clogging.



Electrical Information

Note: All wiring must conform to the National Electrical Code (NEC) and possibly local codes that may be in addition to the NEC.

It is not possible to list all the wiring diagrams that may be supplied with Governair custom manufactured equipment in this manual.

The current characteristics, phase, hertz and voltage are stamped on the nameplate of each Governair unit. The "As Built" wiring and control schematic contained in the instruction envelope enclosed in the control panel box also calls out these requirements. Before attempting to energize any portion of the system, be certain to check the electrical characteristics of the supply current. Even though you may not energize the major components, the voltage reducing transformer normally applied to the control circuits will be subjected to the line voltage.

Good practice dictates that all exposed electrical connections in the area of starters, contactors, relays, buss sections and terminals should be checked for tightness prior to the actual startup.

Many of the connections contain several wires; and while they were tightened at the factory at the time of assembly and checked at the time of run-in, they may have developed a "set" and will concede to retightening. The danger of a poor connection causing overheating and component failure through inadequate current handling capacity cannot be overemphasized. Cartridge fuses should always be of the fusetron type. Ordinary cartridge fuses, not designed for limited short period overloads, will cause nuisance failures. The amperage value of the fusetron to be applied on a given unit will be clearly called out on the wiring diagram contained in the control panel.

The wiring diagram supplied with each unit will be the "As Built" factory wiring. This wiring diagram must be referred to when bringing field wiring to the unit. This is necessary, as during manufacturing assembly of each unit a terminal number could change. This possible terminal number change will not alter the original approved design and/or operation of the unit.

"Caution" & "Note"

All compressors are shipped with the fuses removed from the fuse holders and stored in the control cabinet. These must not be installed until the control circuit power of the control panel has been turned on for twenty-four (24) hours. This is necessary so the compressor crankcase heater may warm the oil in the crankcase of the compressor to drive out any refrigerant that may have migrated to the crankcase of the compressor. The compressor warranty is void if this procedure is not followed.

Note: Starting the compressor with liquid refrigerant in the crankcase will cause damage to the compressor by breaking valve plates, pistons, connecting rods, main bearings and/or the oil pump.

Pre-Start Up Check - Cooling

All Governair units are shipped with all compressor, liquid line receiver and hot gas bypass valves in the closed position. These are to be opened just before startup of the unit and/or before compressor fuses are installed. A leak check should be made at this time.

ALL GOVERNAIR UNITS ARE SHIPPED WITH THE FUSES FOR THE COMPRESSOR REMOVED FROM THE FUSE BLOCKS, TAPED TOGETHER AND STORED IN THE MAIN CONTROL CABINET. THE FUSE BLOCK IS TAGGED "DO NOT INSTALL FUSES UNTIL THE COMPRESSOR CRANKCASE HEATERS HAVE BEEN TURNED ON FOR A PERIOD OF 24 HOURS TO WARM THE CRANKCASE OIL IN THE COMPRESSOR."

All Governair units are carefully checked and tested at the factory. They are operated by factory test technicians to determine satisfactory operation and verify comformance to specifications. However, the check-test and startup procedure supplied as a part of this manual, on page 13, must be closely followed when putting the unit into operation. A copy of the check-test and startup form must be forwarded to Governair to verify startup date of the unit.

Note: On some split systems (demount) it may not be possible to operate the compressors with a charge of refrigerant prior to shipping from Governair. These units will have a vapor holding charge only and it will be so noted by tagging each circuit (compressor).

Caution: Use Sil-Fos, Easy-Flow or silver solder when connecting the refrigerant piping on split (demount) units. A good high vacuum of 500 microns or less must be pulled on each refrigerant circuit to remove any air and/or moisture that may have entered the system while the tubing was open to the atmosphere during installation.

Caution: BEFORE OPERATING UNIT, BE CERTAIN THAT YOU ARE THOROUGHLY FAMILIAR WITH THE SEQUENCE OF OPERATION.



Static Pressure Limits of Cabinet

CABINET	MAX STATIC PRESS. (+ OR -)												
SIZE	0.50"	1.00"	1.50"	2.00"	2.50"	3.00"	3.50"	4.00"	4.50"	5.00"	5.50"	6.00"	6+"
01													
02			12.7				75			3.			Edge Vill Derrie Ti Berne Ti
03			de			PRESCO	00			,			
04		200	9			PRE				SUR			,
05						an			700	CSSURE			TOR
06	0	,			ME	Mala		tropal	45				FACTOR
07									HICH				17/
08													CONSULT
09													25
10					·						100		

LOW PRESSURE PACKAGE:

- (A) 20 gauge exterior casing, single or double wall. All joints are sealed with latex caulking.
- (B) All access doors are double wall 20 ga./24 ga. with maximum door size 66" H x 30" W. All doors open to the outside with door latches, standard gasket, and standard hinges.

MEDIUM PRESSURE PACKAGE:

- (A) Cabinet construction is 18 gauge exterior on double wall with solid 20 gauge liner and 16 gauge on single wall or double wall with perforated liner. All joints are sealed with latex caulking.
- (B) All access doors are double wall 18 ga./24 ga. with maximum door size 66" H x 30" W. All doors open out with door latches and full height hinges.

HIGH PRESSURE PACKAGE:

- (A) Cabinet construction is 16 gauge exterior on double wall with solid 20 gauge liner and 16 gauge on single wall or double wall with perforated liner. All joints are sealed with high pressure sealant or continuously welded.
- (B) All access doors are double wall 16 ga./24 ga. with maximum door size 66" H x 30" W. Doors open against pressure with full height hinges, door latches, and seal against bulb type gasket.

NOTE:

(1) Some units may require special construction considerations. The manufacturer reserves the right to modify construction of any unit as deemed necessary.

FORM NO. 6100A-G401-482






START UP PROCEDURE ROOF TOP CHECK — TEST — START

		mataming contractor
	OWNER	Controls By
NAME		Governair Johnson Service Powers
STREE	п	Barber ColemanRobert Shaw Honeywell
	STATE ZIP CODE	TYPE: Electric Pneumatic
OIII	PRE-OPERATION CHECK LIST	[27] Check compressor unloading
[1]	Unit received damaged. YESNO If yes attach full report.	[28] Check compressor 1. Opens PSI Closes PSI Hot gas bypass 2. Opens PSI Closes PSI [29] Expansion valve superheat: Taking temperature reading
[2]	Equipment received as ordered.	at expansion valve bulb record temperature and suction pressure of compressor.
[3]	Adequate clearance for servicing.	1. SuctPSI 2. SuctPSI 3. SuctPSI 4. SuctPSI 1. TempF 2. TempF 3. TempPSI 4. TempF
[4]	Record system voltagev	[30] Condenser entering air tempF D.B.
[5]	Check all electrical terminals for tightness.	[31] Check compressor high pressure switch
14		The state of the s
[6]	Retighten all set screws and bolts in fan wheels, bearing collars and pulleys.	[32] Check oil safety switch. [33] Check compressor low pressure switch. CUT OUT CUT IN
[7]	Check blower belt adjustment.	1PSI 3PSI 1PSI 3PSI 2PSI 4PSI
[8]	NOTE: All units shipped with compressor	[34] Check condenser fans. 1 AMPS 3 AMPS 2 AMPS 4 AMPS
	fuses removed. Do not install these fuses before crankcase heaters have compressor oil warm.	[35] Check gas burner exhaust motors.
,	And the second s	[36] Check combustion inlet air motors.
[9]	Open compressor service valves and install gauges.	[37] Check burner gas pressure. Note: Set gas pressure high fire 3½" w.c. low 1¾" w.c.
[10]	Record ambient air temperatureF	Left High "w.c. Center High "w.c. Right High "w.c. Burner Low "w.c. Burner Low "w.c. Burner Low "w.c.
[11]	Through charging and gauge manifold build up low side pressure to 30 PSI.	[38] Check burner operation.
[12]	Check complete refrigeration system for leaks.	[39] Check high limit switches.
[13]	External spring mounted only: Loosen compressor -hold down shipping nuts.	[40] Check fresh air and return air damper operation and linkage.
[14]	Remove supply and return air blower shipping brackets.	[41] Check exhaust air damper operation and linkage.
[15]	Check gas burner for teaks.	[42] Check zone damper operation and linkage.
[16]	Check incoming gas pressure"w.c.	[43] Check all zone thermostats. Are they wired correctly to zone dampers?
[17]	Check wiring diagram supplied with unit.	[44] Check remote monitoring panel.
	Is all field wiring correct?YESNO NOTE: Wiring diagram indicates correct setting of all controls.	[45] Check night setback stat operation.
[18]	Check all controls for correct setting.	[46] Check and set all Thermostats.
[19]	Become fully oriented with the sequence of operation of	Cold deck 55 F Hot deck 70 F Mixed air 55 F Mixed air over ride 70 F Cooling ambient lockout 55 F heating ambient lock out 70
[00]	the complete unit.	[47] Recheck refrigeration system for R-22 leaks.
[20]	Is condenser drain trap installed YES (NOTE: This is to be field supplied) NO	[48] Check compressor oil level.
[21]	Are air filters cleanYESNO	[49] Check piping for vibration.
		[50] Tighten all service valve packing nuts and replace valve caps.
	OPERATIONAL CHECK LIST	[51] Replace all control covers.
[22]	Check rotation of blowers. Note: If rotation is wrong change only main power leads.	[52] Record final voltages. Main Control Primary Secondary
[23]	Supply BlowerRPMAMPS Return BlowerRPMAMPS	[53] Check all panels for water and air leaks.
[24]	Check compressor crankcase heaters.	
[25]	Install compressor fuses.	[54] AS INSTALLING CONTRACTOR AND/OR REPRESENTATIVE THEREOF, I certify the check-test and start of this unit completed this date.
[26]	Record compressor operation	Date
	1AMPS 1disc. PSI 1suct. PSI 2AMPS 2disc. PSI 2suct. PSI	Company
	3AMPS 3disc. PSI 3suct. PSI 4AMPS 4disc. PSI 4suct. PSI	Signature
		1

Crankcase Heaters

When the main power is on and compressor is not operating, the crankcase heater should be heating the compressor oil to vaporize any liquid refrigerant in the compressor crankcase. When the compressor starts the interlock on the compressor starter opens and the crankcase heater is taken out of the line. Failure of the crankcase heater to operate when the compressor is off could result in compressor slugging or bearing failure. Crankcase heaters should be energized 24 hours before compressor starts.

Superheat



	1	APOR	PRES	SURE	E, PSI	G	
100			That Yes				Degrees F
Temp.	11	12	22	113	114	500	502
_50	28.9	15.4	6.2		27.1		0.0
45	28.7	13.3	2.7	1	26.6	1	2.1
40	28.4	11.0	0.5		26.0	7.6	4.3
-35	28.1	8.4	2.6		25.4	4.6	6.7
_30	27.8	5.5	4.9	29.3	24.6	1.2	9.4
-25	27.4	2.3	7.4	29.2	23.8	1.2	12.3
-20	27.0	0.6	10.1	29.1	22.9	3.2	15.5
-15	26.5	2.4	13.2	28.9	21.8	5.4	19.0
-10	26.0	4.5	16.5	28.7	20.6	7.8	22.8
- 5	25.4	6.7	20.1	28.5	19.3	10.4	26.8
0	24.7	9.2	24.0	28.2	17.8	13.3	31.2
5	23.9	11.8	28.2	27.9	16.2	16.4	36.0
10	23.1	14.6	32.8	27.6	14.4	19.7	41.1
15	22.1	17.7	37.7	27.2	12.4	23.4	46.6
20	21.1	21.0	43.0	26.8	10.2	27.3	52.5
25	19.9	24.6	48.8	26.3	7.8	31.5	58.7
30	18.6	28.5	54.9	25.8	5.2	36.0	65.4
35	17.2	32.6	61.5	25.2	2.3	40.9	72.6
40	15.6	37.0	68.5	24.5	0.4	46.1	80.2
45	13.9	41.7	76.0	23.8	2.0	51.6	88.3
50	12.0	46.7	84.0	22.9	3.8	57.6	96.9
55	10.0	52.0	92.6	22.2	5.8	63.9	106.0
60	7.8	57.7	101.6	21.0	7.9	70.6	115.6
65	5.4	63.8	111.2	19.9	10.1	77.8	125.8
70	2.8	70.2	121.4	18.7		85.4	136.6
75	0.0	77.0	132.2	17.3	15.2	93.5	148.0
80	1.5	84.2	143.6	15.9	18.0	102.0	159.9
85 90	3.2	91.8	155.7 168.4	14.3	20.9	111.0	172.5
95	6.8	99.8 108.3	181.8	12.5	27.5	120.6	185.8
100							
105	10.9	117.2	195.9	8.6 6.4	31.2	141.2	214.4
110	13.2	126.6	210.8 226.4	4.0	39.1	152.4	229.7
115	15.6	136.4 146.8	242.7	1.4	43.4	164.1 176.5	245.8 262.6
120	18.2	157.7	259.9	0.7	48.0	189.4	280.3
125				2.2	52.8		
130	21.0	169.1	277.9	3.7	58.0	203.0	298.7
135	24.0	181.0	296.8 316.6	5.4	63.4	217.2	318.0
140	30.4	206.6	316.6	7.2	69.1	232.1	359.1
145	34.0	220.3	358.9	9.2	75.1	247.7	381.1
150	37.7	234.6	381.5	11.2	81.4	1 10	403.9

Figure-1 To Find Superheat

Figure-2 Example (Refrigerant-22)

1.	Measure temperature of suction line at compressor as shown in Figure-1.	60°
2.	Measure suction pressure	70 PSIG
3.	Convert suction pressure to temperature 70 PSIG = See Figure-2	41° F

4. Subtract the two temperatures obtained in (#1 & #3) minus the difference is superheat

Note: Ideal superheat for close piping of suction line between evaporator and compressor on packaged air conditioning units is 18° to 20° fahrenheit. This does not apply to medium and low temperature equipment.

Caution: Temperature probe should be attached to the suction line approximately six (6) to eighteen (18) inches from the compressor and insulated as shown to prevent heat transfer from the compressor and surrounding ambient air causing an incorrect temperature reading.



Thermostats

Low Ambient Condenser Fan Lockout Thermostat

Function: Set at 70° F to lockout the number one condenser fan on multiple fan units to help control head pressure and prevent short cycling of condenser fans.

Location: Normally behind control box with bulb in ambient air to the condenser coil.

Variable Air Volume, Dual Duct and Multizone Systems

Cooling Air Sensor

Function: Controls signal to master controller that makes and breaks refrigeration solenoid circuit.

Location: Refrigeration panel with sensing element located in the leaving air side of cooling coil.

Heat Air Sensor

Function: Maintains leaving air temperature by cycling the heat source to maintain hot deck temperature as required. Check wiring diagram for sequence of operation.

Location: Sensing element in leaving air of furnace discharge.

Note: VAV systems have the same sensor controlling both heating and cooling.

Single Zone Constant Air Volume Systems

Cooling Sensor

Function: Controls signal to the master controller that makes and breaks the refrigeration solenoid circuit.

Location: In the conditioned space.

Heating Sensor

Function: Controls signal to the master controller that cycles heating on and off.

Location: In the conditioned space.

Note: Usually the same sensor controls both the heating and cooling.

Outside Air and Mixed Air Thermostats

The economizer system is designed to meet cooling requirements with outside air whenever possible.

When the outside air is below the setting of the changeover thermostat, the refrigeration is locked out and the outside air dampers are under control of the mixed air thermostat. As the mixed air temperature increases, the outside air damper is driven toward the open position from the minimum position.

When the outside air is above the setting of the changeover thermostat, the outside air damper is positioned to the minimum position as set by the minimum position switch. The refrigeration is allowed to operate under control of the room thermostat.



The outside air damper is positioned to full closed position on fan shut down.

Common settings are 60° F on the changeover thermostat, and 55° F on the mixed air thermostat. Sometimes job conditions necessitate different settings.

NOTE: CONSULT WIRING DIAGRAM FOR SEQUENCE OF OPERATION AND PROPER WIRING OF THERMOSTATS.

Head Pressure Control

Fan Cycle

Head pressure may be controlled by cycling condenser fans down to approximately 55° F. Below this setting the compressors must be turned off by a thermostat sensing outside air, and cooling should be done with outside air with the economizer cycle. See Figure 1.




Figure-1 (Typical Illustration)

Flooded Condenser

Head pressure control by flooding condenser is used when operation of the compressors are required below 55° fahrenheit ambient temperature. A flooded condenser is when the flow of refrigerant is restricted from the condenser. This flow of refrigerant is automatically controlled by a specially designed control valve. The valve essentially makes the condenser smaller by holding liquid refrigerant in the coil to maintain a pre-set head pressure. (See Figures 1, 2, and 3) This control requires a greater amount of refrigerant charge. Therefore, a receiver large enough to hold this greater amount of refrigerant is required.

Adjustable ORI/ORD System Operation

As shown in Figure-2, the ORI is located in the liquid drain line between the condenser and the receiver. And the ORD is located in a hot gas line bypassing the condenser. During periods of low ambient temperature, the condensing pressure falls until it approaches the setting of the ORI valve. The ORI then throttles, restricting the flow of liquid from the condenser. This causes refrigerant to back up in the condenser thus reducing the active condenser surface. This raises the condensing pressure. Since it is really receiver pressure that needs to be maintained, the bypass line with the ORD is required.





Figure-2

(Illustration courtesy of Sporlan Valve Co.)

The ORD opens after the ORI has offered enough restriction to cause the differential between condensing pressure and receiver pressure to exceed 20 psi. The hot gas flowing through the ORD serves to heat up the cold liquid being passed by the ORI. Thus the liquid reaches the receiver warm and with sufficient pressure to assure proper expansion valve operation. As long as sufficient refrigerant charge is in the system, the two valves modulate the flow automatically to maintain proper receiver pressure regardless of outside ambient.

Non-Adjustable OROA System Operation

As shown in Figure-3, the OROA main port is located in the liquid drain line between the condenser and the receiver while the ORD portion of the valve is located in a hot gas line bypassing the condenser. Other than the fact that the main orifice of the OROA operates in response to its outlet pressure (receiver pressure), the OROA operates in the same basic manner as the ORI/ORD system. During periods of low ambient temperature, the receiver pressure falls until it approaches the setting of the



(Illustration courtesy of Sporlan Valve Co.)

control point of the OROA main orifice. The main orifice then throttles, restricting the flow of liquid from the condenser. This causes refrigerant to back up in the condenser thus reducing the active condenser surface. This raises the condenser pressure. Since it is receiver pressure that is being maintained, the function of the ORD valve which is located in the bypass fitting of the OROA, is required. The ORD valve opens after the main orifice of the OROA valve has throttled and offered enough restriction to cause the differential between the condensing pressure and the receiver pressure to exceed 20 psi. The hot gas flowing through the bypass line of the OROA and through the ORD serves to heat up the cold liquid being passed through the main orifice of the OROA. Thus the liquid reaches the receiver warm and with sufficient pressure to assure proper expansion valve operation. As long as sufficient refrigerant charge is in the system, the two valves comprising the OROA modulate the flow automatically to maintain proper receiver pressure regardless of outside ambient temperature.

Capacity Control

Compressor Unloading

Capacity control by compressor cylinder unloading is when one or more cylinders of the compressor is de-activated. (See chart D for compressor unloading.)

Hot Gas Bypass

Discharge bypass valves respond to changes in downstream or suction pressure. When the evaporating pressure is above the valve setting, the valve remains closed. As the suction pressure drops below the valve setting, the valve responds and begins to open. As the suction pressure continues to drop, the valve continues to open farther until the limit of the valve stroke is reached. As the suction pressure rises, the valve begins to close.


Without Remote Bulb

To adjust the HGBP valve (without remote bulb), remove the cap and turn the adjustment screw with a 5/16" hex wrench. A clockwise rotation increases the valve setting while a counter-clockwise rotation decreases the setting. When the refrigerant solenoid de-energizes for pumpdown, the HGBP solenoid also de-energizes closing the valve and allowing the system to pumpdown. (See Figure 4)



With Remote Bulb

To adjust the Remote Bulb valve, remove the protective cap from the remote bulb and turn the adjustment screw with a ³/16" hex wrench. A clockwise rotation increases the valve setting while a counter-clockwise rotation decreases the setting. (See Figure 5)



(Illustrations courtesy of Sporlan Valve Co.)

Caution: See Head Pressure Control page 19.

It is necessary to maintain the head pressure high enough to have sufficient heat to maintain evaporator temperature above freezing.

Note: Some applications require both compressor unloading and HGBP capacity control.

High Pressure Cut-Out

The high pressure cut out is pre-set in accordance with the type of condenser, water cooled or air cooled. The recommended hi-pressure cut out settings take into consideration the spring loaded high pressure relief valve settings which are as follows: Chart (A)

CHART (A) HIGH PF	RESSURE CUT-OUT PR	ESSURES	
CONTOC	CUT-OUT PRESSURE SETTINGS (psig)-R-22		
CONTROL	Water Cooled	Air Cooled	
High Pressure Cut - Out	275	350	
Pressure Relief Valve	300	400	

Low Pressure Cut-Out

The operational scheme of the equipment determines the cut in and cut out settings of the low pressure switch. Chart (B)

CHART (B) LOW PRES	SURE CUT-OUT PRE	SSURES
EVAPORATOR TYPE	PRESSURE SETTINGS (psig) - R-22	
	Cut - Out	Cut - In
Shell & Tube Types	30	60
Direct Expansion Type	30	60

Head Pressure Control

Where provided on the unit, the fan switch is used to delay condenser fan operation until adequate condensing pressure is reached. In low ambient conditions inadequate condensing pressure may contribute toward poor overall unit performance since the drive on the refrigerant at the expansion valve is dependent upon the condensing pressure. Chart (C)

CHART (C)	HEAD PRESSURE C	ONTROL	
TYPE	CONDENSER FAN OPERATION PRESSURES (psig) - R - 22		
TIPE	Out	In	
Air Cooled (w/Conn. On Comp.)	175	265	
Air Cooled (w/Conn. On Rec.)	170	225	
Water Cooled	175	215	

CHART (D) COMPRESSOR UNLOADING & HOT GAS BYPASS				
CONTROL	PRESSURE SETTINGS (psig)			
COMBINATIONS	Ist Step	2nd Step	HGBP	
I Step	63 to 75			
2 Step	67 to 79	62 to 74		


Compressors

Most all Governair units have semi-hermetic and/or direct drive compressors. These are equipped with oil pumps giving a positive lubrication. An oil safety switch is installed with each compressor. If the oil pump loses pressure, the oil safety switch senses the loss of the pressure and shuts the compressor off. The oil safety switch is a manual re-set. Should the oil safety switch shut the compressor off for any reason, check the complete system for the reason it tripped.

Caution: All Governair equipment has a continuous pump down cycle during normal operation. When the oil safety switch trips, the compressor stops immediately and does not pump down. Therefore, extreme caution must be taken in re-setting the oil safety switch to prevent liquid slugging of the compressor.

Note: See Trouble Shooting Guide for possible causes of oil safety switch tripping.





Overload Protection

Solid State Module (Compressor)

The Solid State Sensor Motor overload protection applies only to Copeland compressors. This system gives the Quick Response Temperature Sensing and, in addition, gives low voltage and short cycling protection. It also provides a major improvement in motor protection under single phase conditions.

Warning: See Trouble Shooting Guide for checking compressor for suspected defective solid state sensors.

Overload Relays (Motors)

Thermal overload relays are used to protect motors from excessive heat resulting from sustained motor overload, too rapid cycling and stalled rotor. The percentage of overload determines the length of time required to open the circuit.

Manual reset relays are the recommended method of positive motor protection devices.

The ambient compensated overload relay is used because the motor is in a constant ambient temperature and the control is in a varying ambient temperature. The relay responds to the motor current only and compensates for the ambient variation at the control. The compensated bimetal overload relay provides a constant trip time in ambient temperatures from -20° F to $+170^{\circ}$ F for a given heater rating.

The overloads have a visual trip indicator to help inform the maintenance personnel that an overload has occurred. A manual test button is provided to test the operation of the 3 pole overload relay control contacts. They also are provided with a plus and minus 15% nominal trip current adjustment.



Normal temperature rise inside the enclosure has been taken into account in selecting the NEMA Class 10 Dual Element heater.

Condenser Fans:

Most all fans supplied by Governair are of the propeller blade type. However, at times squirrel cage type fans will be supplied.

It is mandatory that all belts be maintained at the correct tension. See page 44 for setting correct belt tension.

Note: For lubrication - See Lubrication Section.

Condenser Fan Motors

See Motor Section, also Lubrication.



Blowers

All blower wheels should rotate freely and should be rotated by hand and the blower hub set screws retightened prior to actually starting the blower. If the blower wheel has shifted in shipment, it may be corrected by:

1. Loosening the bearing collar set screws and moving the blower and shaft to correct. Then retighten bearing collar set screws.

CAUTION: This may cause the belts to be misaligned which will require realignment.

2. Loosen the blower hub set screws and move blower wheel to correct.

CAUTION: Do not operate the blower if there is undue vibration. Such operation can result in bearing failure, sprung shaft, or other serious damage.

Forward curved and backward curved blowers having either spring or rubber-in shear isolation, will have wood shipping blocks between the blower frame and the unit base.

The shipping blocks must be removed and the locking nuts on the spring isolators adjusted so that the assembly rides free and properly absorbs the vibration of the fan assembly.

Bearings may be replaced on either assembly by removing two pillow block bearing bolts, loosening two Allen set screws in the concentric locking collar and sliding the bearing off of the shaft. Bearings are self aligning.


Blower wheels are removed from the forward curved scroll by removing the cutoff in the blower outlet, loosening the bearing and blower wheel set screws to remove the shaft. Remove the wheel through the blower outlet.

Blower wheels are removed from the backward curved blowers through the side of the blower scroll.


- 1. Remove the bearing and bearing support.
- 2. Remove the inlet cone.
- 3. Remove the wheel through the side of the scroll. See page 23.

Motors

All motors contained in Governair units have been phased at the time of inspection and testing. Should you find the fans or blower wheels operating in a reverse direction, interchange two main supply lines (3 PH.). Do not interchange leads on the motor starters.




Forward Curved Fan Without Spring Isolators



Backward Curved Fan With Spring Isolators

GOVERNAIR

BACKWARD INCLINED AND AIRFOIL FANS



Backward Inclined and Airfoil Fans

Motor amperage should be checked after the connecting duct work is installed and an air check made on the air distribution system. Only in those cases where the air flow at the outlets is insufficient to meet specifications should the blower speed be changed. The proof of proper motor amperage draw lies not within the motor amp reading, but rather with the effect produced. If the air flow is sufficient at the outlets, do not alter blower speed to bring the motor HP up to nameplate rating. Quite often the motor sizing may fall on the liberal side of the actual requirement and to change speed merely to utilize the HP capacity of the motor may introduce air circulation problems in the conditioned area as well as in the unit. Be certain to check the motor nameplate for the maximum amperage draw.

Belts

Belts should be checked for correct tension at start up and should be checked again after one week of operation. On multiple drive adjustable pulleys, the pitch depth should be checked and equated to insure identical belt travel, power transfer and wear. Adjustable motor bases, either hinged or sliding type, are provided for easy belt adjustment. See section "Belt Adjustment".

Pulley and Drives

Motor pulleys both adjustable pitch, fixed pitch, and blower shaft pulleys are locked in position with either set screws or split taper lock bushings. It is mandatory that all set screws and/or taper lock bolts be checked for tightness and alignment before putting equipment into operation.


All drive belts must also be checked for proper tension. See section "Belt Adjustment."

NOTE: An incorrectly aligned and tensioned belt can substantially shorten belt life, overload blower and motor bearings shortening their life expectancy and a belt tensioned too tight can overload the motor electrically causing nuisance tripping of the motor overloads and/or motor failure.

For pulley adjustment, removal and installation see page 25, 26 and 27.




Sheaves With Split Taper Malleable Bushings



- A. This key guides bushing into sheave. It provides extra safety and a positive drive.
- B. Bushing barrel and bore of sheave are tapered. This assures concentric mounting and a true running sheave.
- C. Three cap screws, when tightened, lock bushing in sheave.
- D. Bushing is split so that when the locking cap screws force bushing in tapered bore, the bushing grips the shaft with a positive clamping fit. This will withstand vibration and punishing loads without being loosened.
- E. Sheave and bushing assembly is keyed to shaft and held in place by compression. This gives added driving strength.
- F. Sheave is easily removed from shaft by inserting and tightening two of the cap screws in the tapped holes in the bushing flange. This forces the bushing loose from the sheave and releases the compression so that the entire assembly will slide from the shaft.

WARNING – Do not attempt to pull bushing flange flush with hub end. There should be ½" to ½" clearance when tightened.

MVP* Variable Speed Sheaves Adjustment and Cleaning Instructions



Pitch Diameter Adjustment Instructions

1. Slack off all Belt Tension by moving motor towards driven shaft until Belts are free of grooves. For easiest adjustment, remove the Belts from the grooves.

2. Loosen both Locking Screws "A" in Outer Locking Ring, but Do Not Remove Them From The Sheave.

(There is a gap of approximately 1/32" between Inner and Outer Locking Rings. This gap must be maintained for satisfactory locking of the Sheave. If the Locking Screws "A" are removed by accident and gap is lost, screw the Outer Locking Ring down until it touches the Inner Locking Ring. Then back off the Outer Ring ½ to ¾ turn until the screw holes are lined up in the Inner and Outer Locking Rings. Reinsert Locking Screws "A" but do not tighten them until after adjustment is made.)

3. Adjust Sheave to desired Pitch Diameter by turning Outer Locking Ring.

(Any Pitch Diameter can be obtained within the Sheave range. One complete turn of the Outer Locking Ring will result in .233" change in Pitch Diameter.)

DO NOT OPEN "B" SHEAVES MORE THAN 4¾ TURNS FOR "A" BELTS OR 6 TURNS FOR "B" BELTS. DO NOT OPEN "C" SHEAVES MORE THAN 9½ TURNS. DO NOT OPEN "D" SHEAVES MORE THAN 13 TURNS. DO NOT OPEN "5V" SHEAVES MORE THAN 6 TURNS. DO NOT OPEN "8V" SHEAVES MORE THAN 8½ TURNS.

CAUTION:


SHEAVES SHOULD <u>NOT</u> BE ADJUSTED IN EITHER DIRECTION TO THE POINT WHERE MOVABLE AND STATIONARY FLANGES ARE IN CONTACT.

- 4. Tighten BOTH Locking Screws "A" in the Outer Locking Ring.
- 5. Replace Belts and move motor away from driven shaft to apply sufficient Belt Tension to prevent slippage. Check speed. If further adjustment is needed, repeat the steps above.

Caution: Do not loosen any screws other than the two LOCKING Screws "A" in the Outer Locking Ring. These screws should be loosened only while the drive is at rest and adjustment is being made. They must be tightened securely before drive is operated.

To Strip Sheave for Cleaning

- 1. If it becomes necessary to clean dirt, lint, etc from the Sheave, it can be disassembled by removing the three Capscrews "B" in the Stationary End Flange of the Sheave (opposite the Locking Rings). After this is done, the Center Flange Assembly can be removed as a unit by loosening Locking Screws "A" and backing off the Locking Rings until they are disengaged from the threaded end of the Barrel.
- 2. Clean Sheave Barrel and bore of Center Flange Assembly. If it is necessary to use an abrasive, use only fine grit emery cloth. Do not use a file. If Stationary End Flange or Keys are removed from Barrel, be sure they are reassembled as shown below:




- 3. After cleaning, wipe a thin film of high quality rust inhibiting grease, such as TEXACO THREAD-TEX over the Barrel.
- 4. To reassemble, line up keyways of the Center Flange Assembly so that the keyway extending through the Adjustable End Flange goes over the long key. Place the Center Flange Assembly over the Barrel. It may be necessary to move each flange slightly to line up the keyway with the key in the Barrel.
- 5. When Center Flange Assembly has been placed over Barrel, turn Locking Rings to engage thread on Barrel. Screw Locking Rings onto Barrel thread until Center Flange Assembly is tight against Stationary End flange, then back off ¼ turn.



6. After Sheave is assembled in this position, reinsert Capscrews "B" with lock washers and tighten. Sheave is now ready to readjust for operation.

Caution: Do not remove any screws other than those marked in sketches. This Sheave has been finished grooved and balanced after assembly for true running and quiet operation. Further disassembly offers possibility of Center Flanges being mixed up, which will create unbalance and groove run-out.

Instructions for Mounting and Adjusting VARIABLE PITCH KEY TYPE SHEAVES



Mounting:

- 1. All sheaves should be mounted on the motor or driving shaft with the end containing the setscrew "A" toward the motor.
- 2. Be sure both driving and driven sheaves are in alignment and that shafts are parallel.
- 3. Fit internal key "D" between sheave and shaft, and lock setscrew "A" in place. Wrench Torque 110'' lbs. min. -130'' lbs. max.

Adjusting:

- 1. Loosen setscrews "B" and "C" in moving parts of sheave and pull out external key "E". (This key projects a small amount to provide a grip for removing.)
- 2. Adjust sheave pitch diameter for desired speed by opening moving parts by half or full turns from closed position. DO NOT OPEN MORE THAN FIVE FULL TURNS FOR "A" BELTS OR SIX FULL TURNS FOR "B" BELTS.
- 3. Replace external key "E" and tighten setscrews "B" over key and setscrews "C" into keyway in fixed half of the sheave. Wrench Torque 110" lbs. min. -130" lbs. max.
- 4. Put on belts and adjust belt tension (Do not force belts over grooves.)
- 5. Future adjustments should be made by loosening the belt tension and increasing or decreasing the pitch diameter of the sheave by half or full turns as required. Readjust belt tension before starting drive.
- 6. Two groove sheaves must have both halves adjusted by the same number of turns from closed position to insure the same pitch diameter.
- 7. Be sure that ALL keys are in place and that ALL setscrews are torqued properly before starting drive. Check setscrews and belt tension after 24 hours service.
- 8. Recheck motor running load amps with motor name plate R.L.P.

Lubrication

Motors: check the name plate of each for proper lubricant to use. If no lubrication instructions are on the motor name plate the following lubricating instructions are to be followed.

Motors are equipped with double-shield ballbearings* having sufficient grease to last indefinitely under normal service. Where the motor is used constantly in dirty, wet or corrosive atmospheres, it is advisable to add one quarter ounce of grease per bearing every three months. Use a good quality rust inhibited polyurea based grease, such as Chevron SR1.

When greasing the bearings, keep all dirt out of the area. Wipe the fittings completely clean and use clean equipment. More bearing failures are caused by dirt introduced during greasing than from insufficient grease.

*The blower end bearings of 143T and 145T motors are sealed bearings and need no greasing.

CENTRIFUGAL FAN MAINTENANCE AND LUBRICATION

BEARING LUBRICATION INSTRUCTIONS

Bearing Types

Governair typically furnishes one of three basic bearing types for centrifugal fans — ball bearing, spherical roller bearing, spherical roller bearing with split housing. The bearing type and manufacturer are indicated on each bearing.

Operating Conditions

Bearings should not be located in the airstream or an environment with a heavy concentration of abrasive elements. Governair does NOT recommend grease lubricated bearings for ambient temperatures above 200° F. For information on water, or oil cooled bearings contact the factory.

Grease Selection


Various types and brands of grease are suggested below and on the following pages. The brands suggested for your specific bearing type and application can be used. In all cases one should avoid mixing different brands of grease.

Initial Greasing

All standard bearings provided by Governair should be purged and relubricated before operation. Using the approved grease or an equivalent, lubricate the bearing and housing reservoir through the pressure lubrication fitting. Complete greasing is assured if grease is worked in on one side of the bearing until grease appears on both sides. If the bearing will be operated at less than 150 RPM, and in dirty conditions, more grease is desirable. The bearing will discharge excess grease through seals after a short period of operation. It is not necessary to replace this initial discharge because leakage will cease when the excess grease is worked out.

Relubrication

The initial greasing interval can be determined by the conditions or bearing instructions which follow. By carefully observing the condition of the grease expelled from bearings at the time of relubrication, it can be determined whether the maintenance schedule should be altered. When regreasing, avoid mixing different brands of grease.



Grease Lubrication Chart

	rating dition	Bearing operating	Greasing interval	Use grease equivalent	Remarks
Dirt	Moisture	temperature		to these grades	
Fairly clean	None	32°F. to 120°F. 120°F. to 160°F. 160°F. to 200°F.	6 to 12 months 1 to 2 months 1 to 4 weeks	Phillips Petroleum Co. Philube L #1	
Moderate to extremely dirty	None	32°F. to 160°F. 160°F. to 200°F.	1 to 4 weeks	Master Lubricants Co. Lubrike M-3 Spec. Atlantic Refining Co. Atlantic 62 Imperial Oil Ltd. Andok 280	
	Heavy moisture and direct water splash	32°F. to 200°F.	1 week	Standard Oil Co. (Ind.) Amelith #1 Sun Oil Co. Sunoco 844-X New York & New Jersey Lubricant Co. F-925 Mobil Oil Co. Mobilux #1	Customer should provide flinger or place a hood over bearing housing and fasten a disc to shaft just inside of hood shaft opening. Consult Link-Belt.
Fairly clean		32°F. to 200°F.	Determined by fre- quent inspection of installation.	Shell Oil Co. Alvania EP2 Mobil Oil Co. Sovarex grease L-1	The part of the pa
	None	32°F. to -40°F.	Consult Link-Belt Application Engineering	Mobil Oil Co. Mobilgrease BRB Zero Texas Co. 2324 Uni Temp. Ep	Cold storage room
	None	Over 200°F. or below – 40°F.	Consult Link-Belt Application Engineering	Special lubrication may be required. Consult Link-Belt.	A different Link-Belt bearing may be re- quired using oil as a lubricant, etc.

[☐] Frequency of regreasing will vary, depending on the hours of operation, temperature and surrounding conditions

Storage

Bearings which are to be stored or idle for an extended period of time should be wrapped in a neutral grease-proof paper, foil or plastic film. Compounds can be recommended by the bearing manufacturer to provide protection for several months to several years. During storage the bearings should be rotated monthly to prevent corrosion. After long-term storage, grease should be purged from the bearings and fresh grease injected prior to start up.

SEAL MASTER BALL BEARING UNITS prelubricated . . . ready for immediate use

RELUBRICATE WHILE RUNNING IF POSSIBLE, IF RELUBRICATING WHILE IDLE, ADD ONLY 4 to 5 SHOTS WITH HAND GUN USE GREASE, NOT OIL

SUGGESTED INTERVAL

Speed	Temperature	Cleanliness	Greasing Interval
0-100 RPM	TO 140°F.	CLEAN	6-12 MONTHS
101-1500 PRM			2-6 MONTHS
ANY SPEED	TO 140°F.	DIRTY	1 WK 1 MO.
ANY SPEED	TO 200°F.	DIRTY	DAILY - 2 WK.

IF ABNORMAL CONDITIONS EXIST CONSULT SEALMASTER ENGINEERS FOR RECOMMENDATIONS

SEALMASTER BEARING DIVISION STEPHENS-ADAMSON MFG. CO.

AURORA, ILL. LOS ANGELES, CAL. BELLEVILLE, ONT.


Instructions for Specific Bearings

Below and on the following pages are copies of the lubrication instruction labels similar to those for the standard bearings provided by Governair. If additional information is required for these or other bearings provided by Governair, contact the bearing manufacturer directly.

ASSEMBLY AND LUBRICATION INSTRUCTIONS FOR FAFNIR RELUBRICATABLE MECHANISEAL & PLYASEAL TRANSMISSION UNITS

INSTALLATION

LOCATE ASSEMBLED UNIT TO POSITION AND LINE-UP SHAFT CAREFULLY. FAFNIR SELF-ALIGNING UNITS WILL AUTOMATICALLY COMPENSATE FOR MISALIGNMENT, BUT SHAFT MUST BE STRAIGHT. BOLT UNIT SECURELY TO SUPPORTING STRUCTURE.



SLIDE COLLAR AGAINST CAM END OF INNER RING. ENGAGE CAMS BY ROTATING COLLAR UNTIL IT SLIDES OVER CAMMED END OF INNER RING. LOCK COLLAR BY TAPPING LIGHTLY IN DIRECTION OF SHAFT ROTATION. TIGHTEN SET SCREW TO DISASSEMBLE LOOSEN SET SCREW AND TAP COLLAR IN DIRECTION OPPOSITE SHAFT

<u>LUBRICATION</u>
BEARINGS HAVE BEEN FACTORY PRELUBRICATED WITH HIGH QUALITY GREASE AND FOR NORMAL CONDITIONS OF SERVICE REQUIRE NO FURTHER LUBRICATION.

NORMAL SERVICE IS CONSIDERED AS OPERATION IN A CLEAN DRY ATMOSPHERE AT TEMPERATURES BETWEEN -20°F and 180°F AND AT SHAFT SPEEDS UP TO 2100 FT. PER MIN

WHERE SERVICE IS ABNORMAL WITH RESPECT TO SPEED, TEMPERATURE OR EXPOSURE TO CONTAMINATION, OR EXTREMELY LONG LIFE IS REQUIRED, PERIODIC RELUBRI-CATION MAY BE ADVISABLE.



LUBRICATION SCHEDULE FOR HORIZONTAL MOUNTED FAN WITH FMC/LINK BELT SERIES 200 BALL BEARING UNITS

LINK-BELT BEARING DIVISION

CONSULT MANUFACTURER FOR SPECIFIC RECOMMENDATIONS

SHAFT SIZE	OPERATING SPEED (RPM)											
INCHES	500	1000	1500	2000	2500	3000	3500	4000	4500	5000		
INCITED	RELUBRICATION CYCLE (MONTHS)											
1/2 thru 1	6	6	6	6	6	6	4	4	2	2		
1-1/16 thru 1-7/16	6	6	6	6	6	6	4	4	2	1		
1-1/2 thru 1-3/4	6	6	6	4	4	2	2	2	1	1		
7-7/8 thru 2-3/16	6	6	4	4	2	2	1	1	1	7.00		
2-1/4 thru 2-7/16	6	4	4	2	2	1	1	1		1, 1		
2-1/2 thru 3	6	4	4	2	1	1	1	Sept.				
3-7/16 thru 3-1/2	6	4	2	1	1	1						
3-15/16 thru 4	6	4	2	1	1							

Lubricate with or equivalent to:

Shell — Alvania EP Grease No. 2 Texaco — Molytex Grease No. 2

Mobil – Mobilux EP2

Gulf - Gulfcrown Grease No. 2

American - Amolith Grease No. 2

For operating temperatures below 32°F or above 300°F consult manufacturer.

Condition of temperature, moisture, or dirt will require more frequent lubrication cycle. Use sufficient volume of grease to purge the seals. Rotate bearings during relubrication where good safety practice permits. For corrosion protection, lubricate upon shutdown. Rotate bearings monthly during fan storage.

RECOMMENDED LUBRICATION SCHEDULE FOR FMC/LINK-BELT SERIES 300 BALL BEARINGS USED ON HORIZONTAL MOUNTED FANS

CONSULT MANUFACTURER

FOR SPECIFIC RECOMMENDATIONS

SHAFT SIZE				OPER	RATING	SPEED	(RPM)					
INCHES	500	1000	1500	2000	2500	3000	3500	4000	4500	5000		
HVCHES	LUBRICATION CYCLE (MONTHS)											
5/8 thru 1	6	6	6	6	4	4	4	4	2	2		
1-1/8 thru 1-1/2	6	6	6	4	4	4	2	2	2	1		
1-5/8 thru 1-15/16	6	6	6	4	4	2	2	1	1			
2 thru 2-1/2	6	6	4	4	2	1	1		MILITARY OF	a ferrage		
2-11/16 thru 3-3/16	6	4	2	2	1	1	1/2					
3-7/16 thru 3-15/16	6	4	2	1								

Lubricate with the following greases or their equivalent:

Shell — Alvania EP Grease No. 2

Gulf - Gulfcrown Grease No. 2

Texaco - Molytex Grease No. 2

American - Amolith Grease No. 2

Mobil - Mobilux EP2

If bearings are subjected to temperatures below 32° or above 200°F, consult fan manufacturer for proper lubrication.

Apply sufficient grease when relubricating to cause some purging of grease at seals.

Increase the frequency of relubrication in conditions of abnormal moisture or dirt.

Lubricate for extended shutdown or storage and rotate shaft monthly for corrosion protection.

601-64 272 FMC CORPORATION • LINK-BELT BEARING DIVISION • INDIANAPOLIS, INDIANA



Grease lubrication schedule Link-Belt® spherical roller bearings — Series B22400 and B22500 For use on horizontal shaft equipment

		Amou	nt of	Opera	ting spe	ed (rpn	1)						
Shaft sizes		grease		500	1000	1500	2000	2200	2700	3000	3500	4000	4500
Inches	MM	IN ³	CM ³	Lubri	cation c	ycle (m	onths)						
3/4 - 1	25	0.39	6.4	6	6	6	4	4	4	2	2	1	1
1-1/8 - 1-1/4	30	0.47	7.7	6	6	4	4	2	2	1	1	1	1
1-7/16 - 1-1/2	35	0.56	9.2	6	4	4	2	2	1	1	1	1	1/2
1-5/8 - 1-3/4	40	0.80	13.1	6	4	2	2	1	1	1	1	1/2	
1-15/16 - 2	45-50	0.89	14.6	6	4	2	1	1	1	1	1/2		
2-3/16 - 2-1/4	55	1.09	17.9	6	4	2	1	1	1	1/2			
2-7/16 - 2-1/2	60	1.30	21.3	4	2	1	1	1	1/2				
2-11/16 - 3	65-75	2.42	39.7	4	2	1	1	1/2					
3-3/16 - 3-1/2	80-85	3.92	64.2	4	2	1	1/2						
3-11/16 - 4	90-100	5.71	93.6	4	1	1/2							
4-3/16 - 4-1/2	100-115	6.50	106.5	4	1	1/2							
4-15/16 - 5	125	10.00	163.9	2	1	1/2							

These guidelines are for usage on applications approved by FMC.

Lubricate with a multi-purpose roller bearing NLGI Grade 1 or 2 grease having rust inhibitors, anti-oxidant additives, and a minimum oil viscosity of 400 SSU at 100°F. For operation requiring a monthly or less cycle the grease should also be suitable for temperatures up to 250°F continuous, dynamically stable and must not churn or whip.

Some greases having the desired properties are:

American - Rykon Grease No. 2 EP, Mobil - Mobilgrease® 28, Texaco - Molytex EP2 grease.

If bearings are subjected to temperatures below 32° or above 200°F, consult equipment manufacturer for proper lubrication.

Conditions of vibration exceeding 1 to 2 mils, moisture or dirt will require a more frequent lubrication cycle or special lubricant selection. Rotate bearings during relubrication where good safety practice permits.

Lubricate bearing prior to extended shutdown or storage and rotate shaft monthly to aid corrosion protection.

601-65-084

FMC Corporation • Bearing Division • Indianapolis, Indiana 46206



SKF SPHERICAL ROLLER BEARINGS

RELUBRICATE ON THIS SCHEDULE UNDER NORMAL OPERATING CONDITIONS

SHAFT DIA.	1 1	SPEED IN R.P.M.												
(IN.)	RS	300	500	700	900	1100	1300	1500	1800	2400	2700	3000		
-3/16 -7/16	НОП	6060 5520	3550 3220	2470 2220	1875 1670	1490 1320	1230 1070	1035 900	825 700	565 465	475 380	410		
-11/16 -15/16	NI NC	5090 5090	2930 2930	2010 2010	1495 1495	1170 1170	940 940	780 780	600	375 375				
-7/16 -15/16	ATION	4560 4270	2590 2400	1745 1600	1280 1155	985 875	770 675	625 535	460 375					
-7/16 -15/16	BRICA	3580 3380	1940 1800	1240 1125	845 750	600 515	425							
-7/16 -15/16	13	3050 2900	1570 1470	940 850	590	370								

LUBRICATION NOTES

The upper half of the housing has two tapped holes 30° from the vertical center line. One hole is in the center of the housing; the other is to the side. Lubricate through the center hole for spherical roller bearings with W33 feature (with groove around the outer ring) and lubricate through the side hole for selfaligning ball bearings and spherical roller bearings without W33 feature (without groove around outer ring). This is important! The lubricant will not get to the bearing if it is applied through the center hole when a bearing without the grooved

GREASE LUBRICATION: If grease is used as a lubricant it should be smeared between the rolling elements and worked in. The lower half of the housing should be packed 1/3 to 1/2 full.

BALL BEARINGS: An apparent channeling grease with a ASTM penetration of 190 minimum should be used.

ROLLER BEARINGS: Greases to be used should have an ASTM penetration above 300 and should not channel.

GREASE CLASSIFICATION

CLASS	TYPE OF BASE (1)			OIL VIS	NLGI (2)	
CLITOO	11120		102 (1)	@ 100°F.	@ 210°F.	GRADE
Α	Lithium	or	Equal	200-500	48-55	0
В	",	"	,,	400-600	58-68	1
С	",	"	"	800-1000	75-82	1
D	Lithiu	m (Only	800-1000	75-82	2

TYPE OF CREASE & DELLIBE CYCLE RECOMMENDED

Operating Temp.	Grease Class Chart) fo	Suggested (8) Relube Cycle		
of Brg. (4)	Low (5)	Medium	High	
0-70	A or B	A or B		6-12 months
70-120	B or C (6)	B or C		6-12 months
120-160	B or C (6)	C or D	D (7)	2-3 weeks
160-200	С	C or D	D (7)	1-4 weeks

- (1) Calcium Complex Greases Not Recommended For Spherical Roller Bearings.
- (2) National Lubricating Grease Institute Consistency Code.
- (3) Definition of speed categories: Low Up to ¼ of catalog speed limit for static oil lubication. Medium ¼ to ½ catalog speed limit for static oil lubication.
- High ½ to full catalog speed limit for static oil lubrication.
- (4) Consult SKF Engineering if temperature is below 0° or above 200°F.
- (5) Extremely slow speed, will require special consideration if loads are high.*(6) Use type "C" where load is heavy, 15,000 hours bating life or less and/or speeds are less than 100 RPM.
- (7) Consult SFK Engineering Grease lube not normally recommended under this combination of operating conditions.
- (8) Clean Dry applications only
 - For moderate conditions of dirt and /or moisture, use cycle of 1 to 2 months. For extreme conditions of dirt and/or moisture use cycle of 1 week. Vertical applications normally require shorter than normal relube cycle
- (9) Never mix greases with unlike bases.
- (10) Remove old grease at least once a year
- *Under all conditions, application should be checked using the SKF lubricant film parameter found in the Engineer Date Catalog.

SAF 225/226 SPIT HOUSING PILLOW BLOCKS WITH SKF SPHERICAL ROLLER BEARINGS

RELUBRICATE ON THIS SCHEDULE

							SI	PEED (R.P.)	м.)					EACH IN	NTERVAL NCES)
PILLOW BLOCK NUMBER	SHAFT		300	500	700	900	1100	1300	1500	1800	2400	2700	3000	SEI	BLOCK
225/226	DIA.			300	100	,,,,	1100	1500	1500		2100	2100	3000	225	226
09	1-7/16	S)	6775	3995	2800	2140	1715	1425	1210	980	690	595	515	0.35	0.52
10	1-11/16	JR	6400	3760	2630	2000	1600	1325	1120	900	625	535	515	0.37	0.79
11	1-15/16	5	6070	3555	2475	1880	1495	1230	1040	830	565	480	410	0.45	0.93
13	2-3/16	H	5530	3215	2220	1670	1320	1075	900	705	465	385	320	0.67	1.21
15	2-7/16	AL	5090	2935	2010	1495	1170	945	780	600	375	300		0.72	1.58
16	2-11/16	>	4900	2810	1915	1420	1105	885	725	550	330	260		0.83	1.77
17	2-15/16	ER	4720	2700	1830	1345	1040	830	670	505	295			0.97	1.94
18	3-3/16	5	4560	2590	1750	1280	980	775	625	460				1.15	2.19
20	3-7/16	7	4265	2400	1600	1155	875	675	535	380				1.49	2.82
22	3-15/16	ON	4010	2230	1465	1045	775	585	450	300				1.91	3.45
24	4-3/16	E	3780	2075	1385	940	680	505	370					2.24	4.02
26	4-7/16	CA	3575	1935	1235	845	595	425	300					2.65	4.68
28	4-15/16	RIG	3385	1805	1130	755	515	350						3.06	5.50
30	5-3/16	CB	3210	1685	1035	670	440	280						3.54	6.21
32	5-7/16	EL	3050	1575	940	590	365							4.17	6.97
34	5-15/16	R	2900	1470	855	515	295							4.79	7.77

- Notes: 1. Lubricate with a Grade 2 lithium or non-soap base grease having an oil viscosity of 500-1000 SUS at 100°F.
 - 2. Should bearing operating temperature be below 32°F, or above 200°F, consult fan manufacturer for lubrication recommendations.
 - 3. Clean and repack annually.
 - 4. If fans are to be stored after arrival at job site, bearings should be immediately relubricated and shaft rotated monthly for corrosion protection.

Air Filters

All filters are shipped loose in boxes inside of unit. See packing list received with each unit showing what section of unit filters are shipped in. It is mandatory that filters be installed in the filter frames of each unit before putting the unit into operation to protect the coils and keep them clean.

Upstream access filter frames have a removable section of the frame secured in place with sheet metal screws. It is necessary to remove this section for each horizontal row of filters, install the filters and secure the removable frame section back in place.


Side access slide filters have a side plate to the filter frame secured on with sheet metal fasteners. The opposite side is hinged. Remove the fasteners, swing open side plate, slide filters into filter frame, close side plate and re-install sheet metal fasteners.

Due to the wide variety of bag filters, hepa filters, roll filters and odor removing filters it is not possible to cover all of them in this manual. However, when these filters are supplied installation instructions are shipped with each type.

Caution: If equipment is to be run during construction, roll filter media installed across the return air opening should be used as a temporary filter and changed frequently.



CREASE ADDED AT



VENTLOCK . 333 DOOR LATCH

Door Latch

Remove shipping set screw before attempting to open door.

The first quarter turn of the latch handle engages the flange, and during the next quarter turn not only does the bevel on the flange impart compression amounting to 5/32", but a stud on the latch handle works against a cam in the latch barrel pulling in the striker another 1/8". In other words, total compression of over 1/4" is provided by this latch.

The door handle should be checked for proper adjustment so that the door makes a positive seal against the door gasket. To adjust door handle, loosen locking set screws, move flange to desired position on latch shaft, retighten locking set screws.

Door Gaskets

³/16" x ¾" closed cell door gasketing is applied to the door frame opening. At time of startup, the door frame and gasketing should be inspected for possible damage by workmen during the hookup of the equipment.

Dampers

Caution: Dampers, operators, controls and linkage must be checked prior to applying power to the operators making sure nothing will obstruct the operation of the damers. Do not over-drive damper operators as this may cause damage to the dampers.

Multizone Damper Motor

Function: Positions zone dampers in response to zone thermostat. One end switch from each motor should be connected in series to prevent heating source from operating until at least one zone is calling for heat.

Location: Discharge end of unit above or below dampers.

Fresh Air — Return Air and Exhaust Air Damper Motors

Function: One or more damper motors operate outside air, return air and exhaust air dampers, which function in response to mixed air thermostat or through mixed air lock out to minimum

position. Spring return on damper motors close outside air dampers, close exhaust dampers and open return air dampers when there is no power to the motors.

Location: Mixed air section, return air section and/or exhaust air section.

Minimum Position Potentiometer (If Supplied)

Function: To maintain minimum outside air setting when energized. Position may be tailored to suit individual job.

Location: Inside of damper motor in mixed air section or in remote control panel.

A good check-out should guarantee that:

1. The motor operates the load properly.

2. The motor responds properly to a controller.

3. The motor returns the damper to the starting position whenever power to the motor is interrupted.

4. There is no binding or stalling of the motor as the motor travels through its entire range.

Note: To simplify checkout procedure it is suggested that an auxiliary potentiometer be substituted for the controller. This may be obtained through your local controls supplier.

Enthalpy Control or Economizer Change Over Thermostat

Function: To drive fresh air dampers and exhaust air dampers to the minimum or closed position and the return air dampers to full open position. When the outside air temperature is below the setting of the control the fresh air dampers, return air dampers and exhaust air dampers are in full economizer cycle operation.

Location: Return air section with the sensing element extending into the fresh air section.

Parts Replacement Ordering

Due to the variation of components supplied with this type of equipment, it is not possible to publish a generalized parts list. When requesting replacement parts, the following information must be given:

- 1. Complete Governair nameplate data such as model and serial number.
- 2. Name of part, giving full description, including model and serial number, if available.

Coils

Chilled Water and Direct Expansion Coils:

Chilled water and direct expansion coils must not exceed 600 feet per minute to prevent condensate water from being pulled off the coil and outside the condensate drain pan. Air velocity of 500 feet per minute is more desirable.

The static pressure drop across each coil will change with the number of rows deep and other design conditions. Consult the written submittal for each unit on each job.

Note: 1. For condensate drain traps, see Table of Contents under "Drain Traps."

2. For winterizing see Table of Contents, "Freeze Protection of Coils."

Hot Water Coils

The static pressure across hot water coils will change with the number of rows deep and fins per inch. This also is closely related with the temperature rise desired leaving the coil.

The temperature rise of the air leaving the coil is also dependent on the airflow across the coil, the gallons of water flow through the coil and the entering water temperature into the coil. Consult the submittal for each specific job for the above information.

Note: When using ethylene glycol or other antifreeze solutions, consult Governair for the required de-rating of each coil. It will be necessary to give the percentage of ethylene glycol required.

Winterizing — See "Freeze Protection of Coils."

Steam Coils

The static pressure drop across steam coils will change with the number of rows deep and fins per inch. Consult the submittal issued for each specific unit for above information.

DTH Steam Coils are commonly called non freeze coils. Caution: There is no coil that is absolutely free from freezing.

Winterizing — See Table of Contents "Freeze Protection of Coils."

Piping & Control

Consult the job specification for the specific piping requirements for each unit.

Freeze Protection of Coils

All chilled water, hot water and steam coils can be damaged during freezing weather. Precautionary measures must be taken to prevent freezing such as:

- 1. Draining each coil and related piping, making sure that all low areas also drain.
- 2. After draining, flush coils with an antifreeze solution such as ethylene glycol. A solution of 50% ethylene glycol and 50% water will protect from freezing to approximately 35° F below zero at sea level.
- 3. In case of unit shutdown during winter operation, such as unit power failure, night shutdown and weekend shutdown the controls must be installed so the valves will go to the full heat position, all fresh air dampers and exhaust dampers go to the full closed position, and all return air dampers go to the full open position. The water circulation pumps must keep circulating water through the coils and/or auxiliary heat must be maintained within the unit cabinet.

Condenser Coils:

Condenser coils must be kept clean at all times. Debris such as paper, cottonwood lint, etc. restricting the air flow across the coil must be removed at once. Dirty coils and restricted air flow will cause nuisance tripping of the high pressure control and higher operating costs. Where condenser coils are exposed to a contaminated atmosphere it will be necessary to clean the coils with some type of cleaner to remove the contamination. Most refrigeration wholesalers can recommend a cleaner for your specific need.

Note: See Trouble Shooting Guide.





ELECTRIC HEATER TYPICAL

NOTE: When ordering replacement parts give the complete model and serial number of both the electric heater and the Governair unit.


Air Pressure Switch sensing tube removable inside the heater control panel.


Automatic primary hi-limit











Secondary hi-limit safety device. Without removing heater from duct, the heat limiter, or fuse link is manually replaceable in the control panel by removing one screw.



Gas Heating

Piping

All piping must run in accordance with requirements outlined in the pamphlet, "Installation of Gas Appliances and Gas Piping," ASA221:30 published by the American Gas Association. Pressure test the gas supply piping before connecting furnace using pipe cap or high pressure gas cock. A ground joint union is provided for burner rack removal. Install manual gas cock and provide ground joint union for ease of installation.

The gas input to the duct furnace can be obtained by reading the gas meter supplying the unit. Make certain that no other appliance is being served through the meter; if so, shut them off. Then determine flow through gas meter for a one minute interval. Input to unit can be determined from the following formula:

60 X gas flow for one minute (in cubic feet) X heating value of gas (in BTU per cubic foot) = input to unit (BTU/Hr.).

If correct input rating is not attained, orifice size must be corrected or manifold pressure adjusted.

Never overfire the duct furnace. Short life, overheating and cycling will result. Know how much gas you are using and properly set the input.

SIZING GAS SUPPLY LINES

TABLE 1 — Capacity of piping in cubic feet per hour based on 0.3 inches water column and 0.6 specific gravity.

LENGTH OF PIPE _		DIA	METER OF	PIPE - INC	CHES	
	1/2	3/4	1	11/4	11/2	2
20 Feet	92	190	350	730	1100	2100
30 Feet	73	152	285	590	890	1650
40 Feet	63	130	245	500	760	1450
50 Feet	56	115	215	440	670	1270
60 Feet	50	105	195	400	610	1150
70 Feet	46	96	180	370	560	1050
90 Feet	40	84	160	320	490	930
100 Feet	38	79	150	305	460	870
125 Feet	34	72	130	275	410	780

TABLE 2 — Conversion table to be used when gases of specific gravity are other than 0.60.

S.G.*	M.**	S.G.*	M.**	S.G.*	M.**	S.G.*	M.**
.35	1.31	.65	.960	1.00	.780	1.60	.610
.40	1.23	.70	.930	1.10	.740	1.70	.590
.45	1.16	.75	.900	1.20	.710	1.80	.580
.50	1.10	.80	.870	1.30	.680	1.90	.560
.55	1.04	.85	.840	1.40	.660	2.00	.550
.60	1.00	.90	.820	1.50	.630	2.10	.540

^{*}Specific Gravity

EXAMPLE: (1) Input of unit: 175,000 BTU/Hr. (2) Length of pipe needed: 30 feet. (3) If gas is 1.60 specific gravity propane with a heating value of 2,500 BTU/Hr.

Then:
$$\frac{175,000 \text{ BTU/Hr.}}{2,500 \text{ BTU/Hr.}} = 70 \text{ Cu. Ft./Hr.}$$

(From Table 2) 1.60 specific gravity has a multiplier of 0.610. Multiply 70 by 0.610 or 42.76 (43) cu. ft./hr. Referring to Table 1, a ½" pipe at a flow rate of 73 cubic feet per hour.

^{**}Multiplier

Gas Leak Test

Pipe joint compound resistant to the action of liquified petroleum gases should be applied to all pipe connections. After all connections are made, disconnect the pilot supply, at pilot cock, and bleed system of all air. Reconnect pilot line and pressure test all supply lines. Use soap solution for leak detection. Never use an open flame for leak testing.

Caution: All safety and operating controls have been checked during the factory test period; however, it is advisable to complete a similar check when first operating the unit. BEFORE ATTEMPTING ANY SERVICE WORK, MAKE SURE ALL ELECTRICAL SWITCHES AND MANUAL VALVES ARE CLOSED.

Duct Furnace

To provide adequate gas pressure at furnace, refer to Table 1 and 2 for correct sizing of gas supply line. The unit is equipped for a maximum gas supply pressure of ½ pound, or 8 ounces, and requires a minimum of 3 ounces supply pressure. Higher supply pressure requires an additional service regulator to reduce to the ½ pound maximum.

Remove ½" pipe plug from furnace manifold and connect to a manometer to measure the gas pressure with unit in operation. Turn gas pressure regulator adjusting screw IN (clockwise) to increase pressure and OUT (counter clockwise) to decrease pressure. A manifold pressure of less than 2.5" is not recommended.

Electronic Proven Pilot System

This solid state ignition control lights a pilot burner by spark. Pilot gas is ignited and burns during each running cycle (intermittent pilot). Main burner and pilot gas are extinguished during the "off" cycle. Applicable to all gas burning equipment using a proven pilot. (See figure 1)

Operation

The sensing circuit is continuously monitored and when the thermostat calls for heat, if no defects have occured, the electric spark and pilot valve are automatically energized to produce a pilot flame on each operating cycle. The sensing probe proves the presence of the pilot flame; internal switch action de-energizes the spark gap and energizes the main burner electric valve. The main gas ignites and the heating cycle is in normal operation. When the thermostat is satisfied the main burner valve and the pilot valve are de-energized. (See figure 2)




Figure 1 — Type J999EKW pilot burner with integral spark electrode.




Figure 2

Start-Up - Power Modulating Burners

All safety and operating controls have been checked during the factory test period; however, it is advisable to complete a similar check when first operating the unit. Before attempting any service work, make sure all electrical switches and manual valves are closed.

A. PROCEDURE

- 1. Remove any shipping blocks from:
 - a. Gas pressure switch(s) (if required) may have shipping screws. Remove screws if supplied.
 - b. Unit programming controller may be shipped with a paper shipping block. Remove programmer cover and remove paper shipping block reinstall cover and adjust manual reset.
- 2. The high limit should be set for 200° F. The fan control should be set at 120° F on high and 90° F on low. Note that fan operation is intermittent.
- 3. Combustion air and exhaust air proving switches are factory set for 0.2" to 0.4" W.C.
- 4. Open pilot gas cock and purge air from gas line through plugged tee in pilot line. Do not depend on sensing the odor of gas to determine if the gas line is purged.
- 5. Push reset button on unit programming controller.
- 6. Close main disconnect switch.
- 7. The On-Off burner switch on the master control panel will operate the fans.
- 8. All three phase motors were properly phased during factory testing. If rotation is reversed, interrupt main power supply and interchange any two of the incoming power leads. Reestablish power and recheck fan operation.
- 9. On three phase units, the starter contacts should pull in and hold quietly without "clatter." If they do not operate quietly, check immediately for proper line voltage. Even temporary low voltage at start-up will cause constant operating trouble and must be corrected before the Counterflo heater is placed in service.
- 10. Recheck all set screws on motor sheave and fan sheave. Check alignment of belt(s) and pulley(s). Run blower for a few minutes and adjust motor take-up if necessary. Motor is mounted on an adjustable base. Do not over-tighten belt(s) since excessive tension will reduce belt life and cause excessive load on bearings. After initial start, allow the belts a few days' running time to become seated in pulley grooves, then readjust as necessary. Do not roll belts over grooves or sheaves as this will result in permanent belt damage.
- 11. Open manual hand valves. After manual valves have been opened, burner should ignite automatically if thermostat is in control circuit.
- 12. The burner assembly for either gas or oil fired Counterflo heaters generally requires readjustment of the flame test settings for proper operation under actual field conditions. The most accurate guides to proper burner adjustment are:
 - a. Flame travel within the combustion chamber.
 - b. Temperature and CO₂ content of the flue gasses.
 - c. Proper action of the flame sensor.



Warning: Never stand within the swing radius of the access door when making flame observations through the peephole.

Proper flame travel within the stainless steel combustion chamber differs from the pattern usually desired for a refractory lined furnace. Never adjust the burner to produce a short "bushy" flame concentrated in the front end of chamber as shown in Figure 1A. Such a flame concentrates heat release in the front end of the chamber and creates a short circuit between the burner and economizer tube section which results in high stack temperature. Figure 1B illustrates a flame that is much too long and will cause over-heating of the rear wall. A correct flame should be fairly vigorous, free of smoky haze, and should barely impinge on the rear wall of the chamber. Figure 1C illustrates proper flame travel. This long steady flame provides adequate time for complete combustion and balanced heat release to all surfaces of the chamber. Typical draft conditions noted in Figure 2 for firing at full rate capacity. Adjust to field conditions when necessary.




Figure 1 — Flame Patterns

13. Burner Start-Up

a. Gas Systems:

Open the air louver on the air inlet to approximately the one-half open position. Open the manual gas valve slowly, burner will ignite. Open valve until gas pressure on the gauge is approximately 4 ounces. Observe flame conditions. If gas flame has yellow or yellow tip appearance, open combustion air louver wider until flame appears short and hard.

Adjust gas pressure regulator to hold 4 ounces gas pressure on burner while firing with the manual gas cock in the wide open position. Read gas meter serving burner, input should be approximately that stated on the burner nameplate. If not, readjust regulator to obtain rates input. **Note:** Check to see if other appliances are on before reading meter.

When the gas input rate is established, air adjustments may be made. The final air setting should produce a flue gas analysis of between 8½% and 9½% CO2 without CO. Your local gas utility may aid you in making burner adjustments if you do not have the proper instruments.

Start and stop burner several times to insure proper operation. Check for proper functioning of high limit and operating control. Burner is now ready for normal operation.

COUNTERFLO MODEL #	FULL RATED MBH OUTPUT	EXHAUS	TER RPM		MBER SURE ''W.C.)	BREECHING PRESSURE (Pos. "W.C.)	
		GAS	OIL	GAS	OIL	GAS	OIL
40 55 60 85	400 550 600 850	1400 1500 1300 2030	1400 1500 1300 2030	.05 .05 .25 .15	.07 .33 .70 .60	.055 .38 .60 .50	.033 .71 .90 .80
100 125 150 175	1000 1250 1500 1750	1500 1900 1700 1800	1500 2000 1550 1750	.20 .45 .50	.55 .70 .40 .55	.75 .90 1.10 1.25	1.00 1.10 1.10 1.10
200 225 250 275	2000 2250 2500 2750	1800 2000 2000 1635	1750 1850 1850 1675	.55 .60 .65 .60	1.00 1.00 1.00 1.00	1.40 1.48 1.50 2.00	1.50 1.55 1.60 2.90
300 325 350 400 450	3000 3250 3500 4000 4500	1635 1635 1850 1850 1850	1675 1675 1850 1850 1850	.65 .60 .50 .50	1.30 1.00 1.00 1.00 1.00	2.00 2.00 2.00 2.00 2.00	2.70 2.80 2.90 2.70 2.80

Note: Valves shown are those obtained when firing at full rated output.

Figure 2 — Typical Draft Conditions for Counterflo Heaters

- 14. The typical sequence of operation for ON-OFF gas fired unit is as follows:
 - a. Closing fused disconnect switch will energize 115 volt control circuit through control transformer.
 - b. The On-Off burner switch (XB) on the master control panel will operate the blower. Unit burner operation is controlled by the On-Off thermostat (RT). Blower motor (M1) will operate through blower motor starter (1M) if starter overloads are all operational and bonnet temperature is above bonnet fan switch set point. The bonnet fan switch will remain in the electrical circuit after burner shutdown until blower has cooled heat exchanger to a temperature below the setpoint of the control.
 - c. After continuous flame has been established, ignition transformer and pilot valve drop out of circuit.
 - d. If safety shutdown should occur upon failure to ignite pilot, failure to light the main burner flame, or loss of flame while main burner is firing, the internal lockout switch will trip and lockout the protectorelay.

Maintenance Schedule and Lubrication Requirements

A. MAINTENANCE SCHEDULE

Weekly

- 1. Check that fan belts are tight and sheaves are lined up.
- 2. Turn cleaning handle of fuel oil filter.
- 3. Inspect oil pump and burner for oil leakage.
- 4. Remove burner drawer assembly, inspect nozzle and electrode tips, and remove any carbon deposits.
- 5. Check fuel oil supply.
- 6. Check gas pressure at burner.



Monthly

1. Check all valves, piping and connections for leaks.

2. Check combustion air louver settings as outlined in burner start-up procedures.

3. Drain fuel filter.

4. Make sure that photocell or UV sight glass is clean. Use lens tissue or soft tissue for cleaning the sight glass.

5. Remove pilot assembly and check spark electrode, flame rod, and pilot head.

6. Repeat control system check-out.

7. If coke oven gas or another type of dirty gas is being used, clean all valve seats, gas orifices, etc.

Quarterly

1. Check limit control to insure operation.


2. Check stack condition and stack connection, supports and draft.

3. Lubricate exhaust pillow block ball bearing units with a good grade of ball bearing grease.

Preventative Maintenance

ITEM	DESCRIPTION	SUGGESTED SCHEDULE		
la land	DECORM TIEN		Semi- Annually	Annually
1.	Clean filters or replace (more often if necessary)	X		
2.	Check belts – adjust or replace	X		
3.	Check for possible stoppage of condensate drain line	X		
4.	Check for obstructed or dirty condenser coils	X		
5.	Check for shortage of R-22	X	See on	K Park
6.	Check compressor crankcase heaters	X		
7.	Check operation of all controls	X		
8.	Check all starter and contacts		Х	
9.	Grease all bearings (see lubrication sections, motors, and bearings)		X	
10.	Clean condenser coils			X





Belt Tensioning Gauge

Troubleshooting Air Side

An air moving system consists of the entire air circuitry through which air flows. Included in the system are such components as duct work, fittings, branch ducts, dampers, heat exchangers, filters, coils, elbows, registers, grilles, and other items through which air flows or which offer obstruction to air flow.

While differences in temperature and humidity may cause air movement, it may be considered very slight in comparison to the positive circulation required in an air conditioning system. To accomplish this air movement, a fan has two functions to perform.

- 1. To produce sufficient pressure or head to accelerate the mass of air from a state of rest to the required velocity, and
- 2. To produce sufficient pressure to overcome any resistances to the flow of air

The determination of these pressures is a very important part of troubleshooting an air conditioning system. The generally accepted standard instrument for measuring these unit pressures is the Pitot Tube (see Figure 1). The Pitot Tube is used in conjunction with an Inclined Manometer, Magnehelic Gauge, or a Tube Manometer.

When the Pitot Tube is used in conjunction with these instruments, one is able to read velocity pressure (Vp), static pressure (Sp), and total pressure (Tp) within the system.




Figure 1 — Construction of Pitot Tube

Pitot Tube

The pitot consists of an impact tube within a larger static tube. When the impact tube is pointed directly into the air stream, the small static pressure holes are perpendicular to the air stream and are not affected by air velocity.

To read velocity pressure, the total pressure tap at the end of the pitot tube is connected to one leg of a manometer and the static pressure tap at the side of the pitot tube is connected to the other leg of the manometer. Refer to Figure 2.




Figure 2 — Pitot Tube Connections

Inclined Manometer

This instrument, also known as a draft gauge, is a simple, foolproof device, which responds directly to the air pressure exerted against it (transmitted from the Pitot tube), and reads directly in inches of water. Ranges for these instruments vary, and the technician should have one or more instruments to cover the range of 0 to 8 inches of water. Refer to Figure 3.

Magnahelic Pressure Gauge

"Magnahelic" is not a generic term but is registered by Dwyer Instrument Company. The magnahelic gauge is a diaphragmoperated gauge that has several advantages over a liquid
manometer; (1) It need not be leveled to 0 and can be used
easily on a ladder or unlevel surface. (2) When hooked up to
the Pitot tube it need not be purged of air bubbles as the
liquid manometer may. (3) There is less chance of parallax
error in reading the dial face. (4) It is easily transported
without the chance of losing the liquid charge. Unless extreme accuracy is required, this instrument may replace the
manometer for average air conditioning work, and like the
manometer, is available in a variety of ranges. The dial is only
4 inches in diameter and therefore has a limited scale; several
instruments are required to cover the normal ranges encountered in average air conditioning jobs. Refer to Figure 4.




Figure 3 — Inclined Manometer

"U" Tube Manometer

Pressure is defined as force per unit area — and the best way to measure air pressure is to balance a column of liquid of known weight against the air pressure and measure the height of liquid columns so balanced. The units of measure commonly used are, inches of mercury (in Hg.), using mercury as the fluid and inches of water (in. WG.) using water or oil as the fluid.

Instruments employing this principle are called manometers. The simplest form is the basic well known U-tube manometers (see Figure 5). This device indicates the difference between two pressures or between a single pressure and atmosphere, when one side is open to atmosphere.




Figure 4 — Magnahelic Pressure Gauge

If a U-tube is filled to the half way point with water and air pressure exerted on one of the columns, the fluid will be displaced. Thus one leg of water column will rise and the other falls. The difference in height "h" which is the sum of the readings above and below the half way point, indicates the pressure in inches of water column.

The U-tube manometer is a primary standard because the difference in height between the two columns is always a true indication of the pressure regardless of variations in the internal diameter of the tubing.




Figure 5 — "U" Tube Manometers



Figure 6 — Tube Manometer



The Dwyer Slack Tube Manometers are as accurate as the finest laboratory "U" gauges and they are made to roll up compactly for easy carrying and to withstand rough usage. For use on all Governair units the manometers should cover at least a 16 inch range. See Figure 6.

Duct Pressures and How They Work

Velocity — When air moves at a given velocity in a duct it creates a pressure corresponding to the velocity; this is a measure of the kinetic energy in the fluid and it is known as the *velocity pressure* (Vp). Velocity pressure is always exerted in the direction of air flow. The relationship between the velocity and the velocity pressure may be expressed by the following formulas:

$$V_p = \frac{V}{4005}$$

$$V = 4005$$
 Vp

It is therefore a simple matter to determine the velocity (fpm) of an airstream if the Vp can be measured. For example, if a Pitot tube manometer hook-up reads 0.250 in. water, we substitute for the above equation:

$$4005$$
 0.250 = 2002 fpm

Static Pressure — Independent of its velocity, air, when confined within an enclosure such as a duct or tank, will exert itself perpendicularly to the walls of the enclosure. This is the compressive pressure existing in a fluid, and it is known as the static pressure (Sp). Unlike velocity pressure) which is always positive, static pressure when it is above atmospheric pressure will be positive, but when below atomospheric pressure it will be negative. The discharge side of a fan in a supply system will read a positive pressure, the inlet side of the fan in an exhaust system will read a negative or minus pressure.

Total Pressure — Static pressure is exerted whether air is at rest or in motion. The algebraic sum of static pressure and velocity pressure gives the *total pressure* (Tp). Therefore:

$$Vp = Tp - Sp$$

The manometer does not sense the actual velocity pressure directly but by using the Pitot tube hook-up with the static opening connected to the low pressure side of the gauge, and the total pressure opening connected to the high pressure side of the gauge, the manometer will read the difference between the two, or the *velocity pressure*.

Velocity pressure and static pressure change in the duct work with every change in the duct configuration, but the total pressure, on the other hand, remains constant. Hence, as the velocity pressures decreases, the static pressure increases and vice versa, because the static pressure is always the difference between the total pressure and the velocity pressure. It should be remembered, however, that in an actual duct system, the internal friction will cause a loss of total pressure.

The static pressure in an exhaust system is always below atmospheric pressure, and it is customary among ventilation engineers to omit the minus sign affecting the static (gauge pressure). These men know, of course, that the total pressure is higher than the static pressure by the amount of the velocity pressure.

When the unit is designed for connection to a duct system and the installing contractor assembles ducts, elbows, registers, grilles, etc. to the outlet and/or inlet of the unit, the static pressure drop through this external duct work is called external static pressure. See Figure 7.




Figure 7 — Air Moving System

Fans selected must be capable of moving the desired air flow through the entire air moving system including the unit (internal SP) and also the duct system (external SP).

At a given flow rate the internal static pressure losses plus the external static pressure losses equal the system static pressure or the summation static pressure. These pressures are of great importance when troubleshooting for causes of reduced capacity, vibration, and noise.

Changes in the cross sectional area of duct (contractions or enlargements) cause changes in the velocity of the air flowing through the duct.

When the velocity decreases, the velocity pressure also decreases. Some of the velocity energy is lost as a result of the design of the duct where the area changes. Some of the velocity energy is converted into static pressure energy in the continuing duct work. This conversion of velocity energy to static pressure is called static regain.

When contacting Governair for assistance the following information will be required:

- 1. Unit Model No.
- 2. Job Name (Not Contractor)
- 3. Unit Model No.
- 4. Customer's Unit Identification
- 5. Design Data and Actual Data.
 - A. Fan RPM
 - B. Unit SP (Across Fan)
 - C. Unit CFM
 - D. Pressure Drop of Water Across Cooling Coil (PSIG)
 - E. Air Pressure Drop Across Coil (In. of Water)
 - F. Temperature Differential Across Cooling Coil (°F)
 - G. Voltage
 - H. Amperes
- For Fan or Motor RPM (Use a Tachometer, Stroboscope or Revolution Counter).

- 7. The Voltage and Amperes can be obtained by using a separate meter or a clamp-on type AMP meter.
- 8. A sketch of the Duct Configuration would assist us in trying to resolve the problem.
- 9. The most important item is to provide a detailed explanation of the problem.
- 10. Most of us recognize that an orifice is the best method of measuring flow in piping. This is also true in an air system and is the reason for reading step 5D.

For further assistance in troubeshooting the air unit refer to the troubleshooting chart which follows:

TROUBLESHOOTING CHART

SYMPTOM		SOURCE	PROBABLE CAUSE
	1.	IMPELLER HITTING INLET RING	Impeller not centered (check shaft clamp.) Inlet ring damaged or not adjusted. Shaft loose in bearing (check locking Collar.) Impeller loose on shaft (check shaft clamp.) Bearing loose in bearing support (check mounting bolts.)
	2.	DRIVE	Sheave not tight on shaft (motor or fan.) Belts hitting belt guard. Belts loose. Adjust after 48 hours operation. Belts too tight. Belts wrong cross section. Belts not "matched" in length on multi-belt drive. Variable pitch sheaves not adjusted so each groove has same pitch diameter (multi-belt drives.) Misaligned sheaves. Belts worn. Motor, motor base or fan not securely anchored. Belts oily or dirty.
	3.	BEARING	Defective bearing. Needs lubrication. Loose on bearing support. Loose on shaft (check locking collar.) Misaligned (check alignment binding.) Foreign material inside bearing. Worn bearing. Fretting corrosion between inner race and shaft.
IOISE	4.	Loose on shaft (check shaft clamp.)	Defective impeller. Do not run fan. Contact manufacturer. Unbalance. Foreign material on fan blades.
	5.	HOUSING	Foreign material in housing. Inlet cones loose or not adjusted.
	6.	ELECTRICAL	Lead-in cable not secure or is too rigid. AC hum in motor or relay. Starting relay chatter. Motor bearings. Single phasing a 3-phase motor.
	7.	SHAFT	Bent. Undersized. May cause noise at impeller, bearings or sheave. Loose internal balance weights. Bearing alignment.
	8.	HIGH AIR VELOCITY	Duct work too small. Fan running too fast. Fan selection too small. Static pressure lower than expected. Registers and grilles too small. Insufficient fade area of heating or cooling coil.
	9.	OBSTRUCTION IN HIGH VELOCITY AIR STREAM MAY CAUSE RATTLE, OR PURE TONE WHISTLE	Dampers. Registers. Loose dampers or splitters. Grilles. Sharp elbows. Sudden expansion of duct work. Sudden contraction of duct work. Turning vanes.



	SYMPTO	OM SOURCE	PROBABLE CAUSE
	10.	PULSATION OR SURGE	Oversized duct work. Parallel fan operation. Loose dampers or splitters. System instability. Ducts vibrate at same frequency as fan pulsations. Organ pipe action on long duct.
	11.	HIGH VELOCITY THROUGH CRACKS, HOLES OR PAST OBSTRUCTIONS	Leaks in duct work. Registers or grilles.
NOISE	12.	RATTLES AND/OR RUMBLES	Excessive duct velocities. Vibrating ductwork. Flex connector too tight or touching. Vibrating parts not isolated from building.
	13.	FAN	Forward curve impeller installed backwards. Fan running backwards. Impeller not centered with inlet cones. Fan speed too slow.
	14.	DUCT SYSTEM	Actual system is more restrictive (more resistance to flow) than expected. Dampers closed. Splitter rod disconnected. Registers closed. Leaks in supply ducts. Open duct seams. Insulating duct liner loose. Fire dampers closed.
	15.	FILTERS	Dirty or clogged (dirt, lint, snow, grass.)
	16.	COILS	Dirty or clogged (construction trash.)
CFM-LOW	17.	RECIRCULATION	Internal cabinet leaks in bulkhead separating fan outlet (pressure zone) from fan inlets (suction zone.) Leaks around fan outlet at connection through cabinet bulkhead.
	18.	OBSTRUCTED FAN INLETS	Elbows, cabinet walls or other obstructions restrict air flow. Inlet obstructions cause restrictive systems but do not cause increased negative pressure readings near the fan inlet(s). Fan speed may be increased to counteract the effect of restricted fan inlet(s). (Observe fan RPM limits).
	19.	NO STRAIGHT DUCT AT FAN OUTLET	Fans which are normally used in duct systems are tested with a length of straight duct at the fan outlet. If there is no straight duct at the fan outlet, decreased performance will result. If it is not practical to install a straight section of duct at the fan outlet the fan speed may be increased to overcome this pressure loss. Observe fan RPM limits.
	20.	OBSTRUCTIONS IN HIGH VELOCITY AIR STREAM	Obstruction near fan outlet. Sharp elbows near fan outlet. Improperty designed or no turning vanes.
CFM – HIGH	21.	SYSTEM	Oversized duct work. Access door open. System not balanced. Resistance less than specified. Registers or grilles not installed. Dampers set to by-pass coils. Filter(s) not in place.
	22.	FAN	Backward inclined impeller installed backwards (HP will be high.) Variable motor sheave not adjusted. Fanspeed too fast.
STATIC PRESSURE INCORRECT	23.	SYSTEM FAN OR INTERPRETATION OF MEASUREMENTS	GENERAL DISCUSSION The velocity at any point of measurement is a function of the velocity of the air and its density. The static pressure at a point of measurement in the system is a function of system design (resistance to flow), air density and the amount of air flowing through the system. The static pressure measured in a "loose" or oversized system will be less than the static pressure in a "tight" or undersized system for the same airflow rate. In most systems, pressure measurements are indicators of how the installation is operating. These measurements are the result of air flow and as such are useful indicators in defining system characteristics.

REFER TO THE TROUBLESHOOTING SECTION FOR THE PROPER METHODS OF OBTAINING CORRECT READINGS



SYMPTOM		SOURCE	PROBABLE CAUSE
STATIC PRESSURE	24.	SYSTEM	System has less resistance to flow than expected. This is a common occurrence. Fan speed may be reduced to obtain desired flow rate. This will reduce HP, conserve energy, and save operating costs.
LOW -	25.	AIR DENSITY	Pressures will be less with high temperature air or at high altitudes.
CFM HIGH	26.	FAN	Backward inclined impeller installed backwards, HP will be high. System resistance less than specified. Fan speed too high.
STATIC PRESSURE LOW, CFM LOW	27.	SYSTEM	Fan inlet and/or outlet conditions not same as tested. See general discussion (23). Also see 13 thru 20.
STATIC PRESSURE HIGH, CFM LOW	28.	SYSTEM	Obstruction in system. Dirty Filters. Dirty coil. Closed fire damper. System too restricted. Also see 13 through 20.
SYMPTOM		SOURCE	PROBABLE CAUSE
SYMPTOM		SOURCE	PROBABLE CAUSE

Motor Trouble Shooting Guide

Apparent Trouble	Possible Causes	Correction
High Current Draw	First check accuracy of ammeter reading on all three phases	
Running Idle	High Line Voltage 5 to 10% over nameplate. Smaller motors (140-213 frames) may increase current at a faster rate.	Consult power company — possibly reduce by using lower transformer tap.
Running Under Load	Motor Overloaded	Reduce load or use larger motor
	High Line Voltage 5 to 10% over motor nameplate voltage on small motors (140-213 frames only)	Consult power company — possibly reduce by using lower transformer tap.
	200 volt motor on 230 or 240 volt system	Change to 230 volt motor.
	Low Line Voltage 5 to 10% lower than nameplate voltage on any size	Consult power company — possibly increase by using high transformer tap.
	230 volt motor on 208 volt system	Change to 200 volt motor.
Unbalanced Current Draw	Unbalanced Line Voltage due to:	Carefully check voltage across each phase at the
(5% or more of the average current draw)	a. Power Supply	motor terminals with a good, properly calibrated voltmeter.
	b. Unbalanced System Loading	If the voltage per phase is more than 1% out of balance, the current will be out of balance by an
	c. High Resistance Connection	even greater percentage.
	d. Undersized Supply Lines	If there is doubt as to whether the trouble lies with the power supply or the motor, check per the following:
		lollowing:



Trouble Shooting Guide - Motors, continued

APPARENT TROUBLE	POSSIBLE CAUSE	CORRECTION
	Defective Motor	Rotate all three input power lines to the
		motor by one position — i.e., move line #1 to #2 motor lead, line #2 to #3 motor lead and line #3 to #1 motor lead.
		a. If the unbalanced current draw pattern follows the input power lines, the problem is in the power supply.
		 b. If the unbalanced current draw pattern follows the motor leads, the problem is in the motor.
		Correct the voltage balance of the power supplor replace the motor, depending on answer to a. & b. above.
Excessive Voltage Drop (more than 2 or 3% of nominal supply voltage)	Excessive Starting or Running Load	Reduce load or install larger motor.
	Inadequate Power Supply	Consult power company
	Undersized Supply Lines	Increase Line sizes
	High Resistance Connections	Check motor leads and eliminate poor connection
Overload Relays Tripping		
Upon Starting	Slow Starting (10 - 15 seconds or more) due to High Inertia Load	Reduce starting load. Increase motor size if necessary.
	Low voltage at motor terminals	Improve power supply and/or increase line size.
Under Load	Overload	Reduce load or increase motor size.
	Unbalanced Current Draw	Balance supply voltage.
	Single Phasing	Eliminate.
	Excessive Voltage Drop	Eliminate.
	Too frequent starting or intermittent overloading	Reduce frequency of starts and overloading or increase motor size.
	High Ambient Starter Temperatures	Reduce.
	Wrong Size Relays	Correct size per nameplate amperes of motor. Relays have built in allowance for service factor ampere draw.
Motor Runs Excessively Hot	Overloaded	Reduce load or load peaks and number of starts in cycle or increase motor size.
	Blocked Ventilation a. TEFC's	Clean External ventilation system — check fan.
	b. O.D.P.'s	Blow out internal ventilation passages.
		Eliminate external interference to motor ventilation.
	High Ambient Temperature over 40° or 105° F	Reduce ambient temperature or provide outside source of cooler air.
	Unbalanced Current Draw	Balance supply voltage. Check motor leads for tightness.
	Single Phased	Eliminate.
Won't Start (just hums and heats up)	Single Phased	Shut power off. Eliminate single phasing. Check motor leads for tightness.
	Rotor or bearings locked	Shut power off. Check shaft for freeness of rotation.
		Be sure proper sized overload relays are in each of the 3 phases of starter
	C: I N I	
Runs Noisy Under Load (excessive electrical noise or chatter under load)	Single Phased	Shut power off. If motor cannot be restarted, it single phased. Eliminate single phasing.

APPARENT TROUBLE	POSSIBLE CAUSE	CORRECTION
Slow Starting (10 or more seconds on small motors - 15 or more seconds on large motors)		
Across the Line Start	Excessive Voltage Drop (5 - 10% voltage drop causes 10 - 20% or more drop in starting torque)	Consult power company — Check system. Eliminate voltage drop.
	High Inertia Load	Reduce starting load or increase motor size.
Reduced Voltage Start	Excessive Voltage Drop. Loss of Starting Torque.	Check and eliminate per above.
Y-Delta	Starting Torque Reduced to 1/3	Reduce starting load or increase motor size, or
PWS	Starting Torque Reduced to 1/2	Choose type of starter with higher starting torque, or
Auto. Transformer	Starting Torque Reduced to 1/4 to 5/8	Reduce time delay between 1st and 2nd step of starter — get motor across the line sooner.
Load Speed Appreciably Below Nameplate Speed	Overload	Reduce load or increase voltage.
	Excessively Low Voltage	NOTE: A reasonable overload or voltage drop of 10 - 15% will reduce speed only 1-2%
		A report of any greater drop would be questionable.
	Wrong Nameplate	If speed is off appreciably, i.e., from 1800 to 1200 RPM, check Lincoln code stamp on stator with nameplate. If codes do not agree, replace with motor of proper speed.
	Inaccurate method of measuring RPM.	Check meter using another device or method.
Excessive Vibration (mechanical)	Out of Balance a. Motor Mounting	Be sure motor mounting is tight and solid.
	b. Load	Disconnect belt or coupling $-$ restart motor $-$ i vibration stops, the unbalance was in load.
	c. Sheaves or Coupling	Remove sheave or coupling — tape 1/2 key in shaft keyway and restart motor — if vibration stops, the unbalance was in the sheave or coupling
	d. Motor	If the vibration does not stop after checking a, b and c above, the unbalance is in the motor — replace the motor.
	e. Misalignment on Close Coupled Application	Check and realign motor to the driven machine.
Noisy Bearings (listen to bearings)		
Smooth Mid Range Hum	Normal fit	Bearing OK
High Whine	Internal fit of bearing too tight	Replace bearing - check fits
Low Runble	Internal fit of bearings too loose	Replace bearing - check fits
Rough Clatter	Bearing Destroyed	Replace bearing — Avoid: a. Mechanical Damage b. Excess Greasing c. Wrong Grease d. Solid Contaminants e. Water running into motor f. Misalignment on close coupled application
Mechanical Noise	Driven Machine or Motor Noise?	Isolate motor from driven machine — check difference in noise level.
	Motor Noise Amplified by resonant mounting	Cushion motor mounting or dampen source of resonance.
	Driven Machine Noise transmitted to motor through drive	Reduce noise of driven machine or dampen transmission to motor.
	Misalignment on close coupled application	Improve alignment.

Trouble Shooting Guide Cooling Cycle

Complaint	Cause	Correction
A. Cooling will not start	Main and/or control fuses open. Note: check all lock out devices	Replace fuse. Note: As per unit wiring diagram
	Cool switch in remote panel in off or heat position	2. Reset to on or cooling position
	3. Low ambient outside lockout thermostat	3. Reset thermostat to 55 degrees
	4. Cold deck sensor on multizone unit only	4. Reset. Replace if defective
	5. Room sensor on single zone unit only	5. Reset. Replace if defective
	 Supply and return blower overload relays. (Note: not all units have return air motors) 	Reset overloads. Check for cause of tripping
	7. Condenser fan overload relays	7. Reset overloads. Check for cause of tripping
	8. Oil safety tripped	8. Reset. Note: control circuit being energized prior to installation of compressor fuses will trip oil safety. Check for slipping or broken blower belts and dirty filters
	9. Cooling relay interlock	9. If defective, replace
	10. Low pressure switch will not close	10. Check for refrigerant leak. If leak, repair & recharge with refrigerant. If defective low pressure switch, replace
	11. Compressor "off" on internal overload	11. Allow one (1) hour for compressor to cool before condemning compressor
	12. Overload sensor in compressor defective. Caution: use an OHM meter or proper resister when checking sensors or the remaining good sensors will also be damaged (Contact Governair for proper resister)	12. If sensors are open, these may be replaced with a radio type resister. The remaining sensors will still be protection for the compressor. The sensor cannot be replaced
	13. Liquid line solenoid will not open	13. Check holding coil, replace if defective If complete valve defective, replace valve
B. Compressor runs but little or	1. Low on refrigerant	1. Locate leak – repair and recharge
no cooling	2. Dirty filters	Clean and/or replace. Note: if cleanable filters, spray with a good grade of filter coating
	3. Loose or broken belts	3. Tighten or replace
	4. Zone damper closed, multizone units only	4. Room thermostats set above room temperature – reset
	5. Zone damper motor loose or broken	5. Tighten or replace
	6. Defective zone damper	6. Replace motor



Trouble Shooting Guide — Cooling Cycle, continued

Complaint	Cause	Correction
B. Compressor runs but little or no cooling (continued)	7. Zone damper motor and room thermostat wiring reversed	7. Correct wiring
	8. Fresh air dampers open above 70 degrees F.	8. Reset thermostat to 70 degrees F.
	Fresh air and return air damper linkage loose or broken	9. Readjust or repair
	 Defective fresh air & return air damper motor holding dampers open above 70 degrees outside ambient 	10. Replace damper motor
	11. Low on refrigerant	11. Check for leak – repair and recharge
	12. Weak or damaged valve plates in compressor	12. Replace valve plates
	13. Broken pistons & rods in compressor	 Replace compressor. Note: some compressors have replaceable pistons, rods, and crankshafts
C. Conditioned area too cold	1. Room thermostat set too low	1. Readjust thermostat
	2. Mixed air thermostat set too low if on economizer	2. Reset mixed air stat to 55 degrees Fahrenheit
	Zone damper linkage loose or broken — multizone units only	3. Adjust linkage, tighten, and/or repair
D. Compressor will not shut off	Room thermostat set too low or defective on single zone units	1. Reset room thermostate or replace
	Cold deck thermostat on multizone units set too low or defective	2. Reset cold deck thermostat or replace
	Liquid line solenoid and/or hot gas bypass solenoid will not shut off	Check for dirt under valve seat. If defective — replace
E. Compressor short cycles	Low on refrigerant — cycling on low pressure control	1. Check for leak – repair and recharge
	2. Dirty filters – or broken blower belts	2. Replace filters – tighten or replace belts
	3. Solenoid leaking	Check for dirt under valve seat. If defective, replace
	4. Compressor valve plate reeds leaking	4. Replace valve plate
F. Compressor tripping out oil safety	 Incorrect superheat setting of expansion valve. 	1. Adjust superheat. Note: see section "Adjusting Superheat"
	2. Defective oil safety switch	2. Replace
	3. Defective oil pump	3. Check oil pressure, oil pressure should be between 10 to 30 lbs. suction pressure. (Copeland Compressor)
	4. Worn compressor bearing resulting in low oil pressure (See section "Checking Oil Pressure")	4. Replace compressor. Note: Some type of compressors may have internal parts replaced



Trouble Shooting Guide — Cooling Cycle, continued

Complaint	Cause	Correction
G. Compressor tripping on internal heat overload	Short of refrigerant with insufficient cooling of motor windings	 Check for leak – repair and recharge. Check for high superheat. (See section "Setting Superheat")
	 Too high of condenser temperature (high head pressure). Possible restricted condenser, broken fan blade or burned out condenser fan motor 	Lower condensing temperature (head pressure). Replace condenser fan or fan motor.
	3. Defective expansion valve power element causing wide super heat	3. Replace power element. Note: When replacing power element, readjust superheat. (See section "Adjusting Superheat")
	4. Low or high line voltage	4. Correct voltage
H. Noisy Compressor	 Shipping hold-down nuts tight, not permitting compressor to float free on mounting springs 	1. Loosen hold-down nuts
	Broken valve reeds causing compressor to vibrate	2. Replace valve plates
	3. Broken pistons and rods causing compressor to vibrate or rattle	 Replace compressor. Note: Some compressors have replaceable pistons rods and crankshafts
	4. Discharge or suction line clamp loose	3. Tighten or replace clamp
I. Off due to high head pressure	1. Restricted air flow across condenser	1. Remove restriction
safety switch	2. Slipping or broken fan belts	2. Tighten or replace belts
	3. Overcharge of refrigerant	3. Correct charge
	Heating Cycle	
Figure 1 4 Section 1		
A. No heat — all types. Also see each type heat for additional causes	1. Open fuse in control circuit	1. Replace fuse. Note: as per unit wiring diagram
A. No heat — all types. Also see each type heat for additional causes	Open fuse in control circuit Outside ambient lockout thermostat set below outside temperature	
A. No heat — all types. Also see each type heat for additional causes	Outside ambient lockout thermostat	wiring diagram 2. Reset above ambient temperature —
A. No heat — all types. Also see each type heat for additional causes	Outside ambient lockout thermostat set below outside temperature Heat switch in remote panel in off or	wiring diagram 2. Reset above ambient temperature — replace if defective 3. Reset to "on" or heating position
A. No heat — all types. Also see each type heat for additional causes	2. Outside ambient lockout thermostat set below outside temperature 3. Heat switch in remote panel in off or cool position 4. Hot deck thermostat set too low —	wiring diagram 2. Reset above ambient temperature — replace if defective 3. Reset to "on" or heating position 4. Reset to desired temperature. Replace
A. No heat — all types. Also see each type heat for additional causes	 Outside ambient lockout thermostat set below outside temperature Heat switch in remote panel in off or cool position Hot deck thermostat set too low – Multizone units only. Space (wall) thermostat keeping hot deck dampers closed – Multizone 	wiring diagram 2. Reset above ambient temperature — replace if defective 3. Reset to "on" or heating position 4. Reset to desired temperature. Replace if defective 5. (a) Set above room temperature (b) Check wiring. If wrong, correct
A. No heat — all types. Also see each type heat for additional causes	 Outside ambient lockout thermostat set below outside temperature Heat switch in remote panel in off or cool position Hot deck thermostat set too low – Multizone units only. Space (wall) thermostat keeping hot deck dampers closed – Multizone units only Space (wall) thermostat set too low – 	wiring diagram 2. Reset above ambient temperature — replace if defective 3. Reset to "on" or heating position 4. Reset to desired temperature. Replace if defective 5. (a) Set above room temperature (b) Check wiring. If wrong, correct (c) If defective, replace 6. Set above room temperature, replace



Trouble Shooting Guide — Heating Cycle, continued


Complaint	Cause	Correction
B. No Heat — Gas Duct Furnace	1. Exhaust motor defective	1. Replace
	2. Pilot or main gas cock in closed position	2. Open gas cock
	3. Ignition control defective	3. Replace. Do not attempt to repair
	4. Ignition electrode defective	4. Adjust or replace
	5. Low or High pressure gas safety switch open	5. Check for gas pressure — replace if defective
C. Pilot will not ignite, but ignition sparks	(A) No gas pressure (B) Pilot shut off cock in off position (C) Pilot gas solenoid will not open	(A) Turn on gas (B) Turn to on position (C) Check for 24 volt power at solenoid coil – replace if defective
D. Pilot lights, but gas valve	1. (A) Thermocouple or flame rod	1. (A) Replace
will not open	defective (B) Broken wire to valve (C) Defective valve	(B) Repair wire (C) Replace valve
E. Burner lights but will not come up to high fire	1. Low gas pressure	 1. (A) Let low fire at 1¾" w.c. (B) Set high fire at 3½" w.c. (C) If low incoming gas pressure to unit, check with gas company
F. Raw gas smell	1. Gas leak in gas piping	1. Repair leak
G. Sooting of the burner	1. (A) Blockage of combustion air	1. (A) Remove blockage, also, check
	(B) Over firing of burner	exhaust motor (B) Check gas pressure – may be too high
H. No heat electric	1. Manual high limit tripped	1. Reset – check for reason of tripping
	2. Broken heating element	2. Replace
	3. Heat limiters blown	3. Replace
	4. Fuses blown	4. Replace
I. No heat — hot water and steam	1. Defective control motor	1. Replace
	Broken control linkage from motor to valve	2. Repair or replace
	3. Defective control valve	3. Replace



Trouble Shooting Guide Dampers & Damper Actuators

Complaint	Cause	Correction
J. Fresh air and return air dampers will not modulate	(A) Outside ambient override thermostat or enthalpy control incorrectly set	1. (A) Reset to correct setting. Replace if defective
	(B) Minimum pot incorrectly set	(B) Reset
	(C) Damper linkage loose or broken	(C) Repair
	(D) Control circuit open	(D) Find open wire – repair
	(E) No power to damper motor	(E) Check power source – replace fuse if blown
	(F) No power to damper motor	(F) Replace
K. Mixed air too warm or too cold	1. (A) Thermostat set incorrectly	1. (A) Set at 55° F. If defective, replace
	(B) Manual potentiometer set incorrectly	(B) Reset for correct minimum fresh air
	(C) Damper linkage	(C) Repair
L. Fresh air and exhaust dampers will not go to closed position	1. (A) Damper motor linkage loose or broken	1. (A) Repair or adjust
when power is off	(B) Damper binding	(B) Relieve location where binding





GOVERNAIR

Manufacturers of Air Conditioning and Refrigeration Equipment

4841 N. Sewell Street • Oklahoma City, Oklahoma 73118 • (405) 525-6546 • Telex 796-268

SUBMITTAL DATA

PROJECT: A/C BUILDING AS-205

CAMP LEJEUNE, NC

DATE: 12/11/87

SERIAL NO.: 25997

SOLD TO: HUMPHREY HEATING

& ROOFING, INC. P.O. BOX 1268

JACKSONVILLE, NC 28540

REF. DWG.: 32636

TAG: AC-1

MODEL NO.: ACU-302

NO. UNITS: 1

DRAWINGS FOR AIR COOLED CONDENSERS RECORD ONLY

UNIT CAPACITY:

CAPACITY BALANCED WITH RSA-01 REFERENCE DRAWING NUMBER 32637 27,900 CFM THRU CONDENSER

CONSTRUCTION:

- Structural formed steel base, BASE FRAME

CABINET - FLOOR - 14 gauge galvanized steel single wall,

WALLS - 20 gauge galvanized steel single wall

ROOF - 20 gauge galvanized steel single wall,

- "Landmark Beige" enamel finish inside & out, PAINT

- Single wall construction with hinges, ACCESS DOORS

- Ventlok 333, DOOR LATCHES

COMPRESSOR SECTION:

COMPRESSOR - Semi-hermetic model 3DB1-1000, (1 REQ'D)

Spring isolated,

Suction and discharge line vibrasorbers, 1/2" armaflex suction line insulation,

- Semi-hermetic model 3D51-1500, COMPRESSOR

(1 REQ'D) Spring isolated,

> Suction and discharge line vibrasorbers, 1/2" armaflex suction line insulation,

DRAWINGS FOR RECORD ONLY

CONDENSER SECTION:

CONDENSER COIL: - 3 row, 1/2" copper tubes, 10 aluminum fins per inch, 35" fin width,

84" fin length, 12 pass with sub-cool

circuit, 1 req'd,

3 row, 1/2" copper tubes, 10 aluminum CONDENSER COIL -

fins per inch, 30" fin width, 66" fin length, 12 pass with sub-cool circuit,

- 27 1/4" dia, (3 req'd), direct drive, PROP FANS

setup 27/2,

MOTORS - 2 horsepower, 208/3/60 TEFC, 1140 RPM,

56 frame.

LOW AMBIENT - Adjustable to 0 F degrees with flooded

OPERATION condenser head pressure control valves,

REFRIGERANT CIRCUIT (EACH COMPRESSOR):

- ASME full charge with relief, RECEIVER

Inlet and outlet valves,

FILTER DRIER - Sealed,

SIGHT GLASS - One per circuit,

SOLENOID VALVE - Liquid line,


ELECTRICAL REQUIREMENTS:


208/3/60 power with 120 volt control,


120 volt transformer furnished and installed,

ELECTRICAL CONTROLS:

See Wiring Diagram WD-32636







Job: A/C Building AS-205

12/18/87

Tag: AC-1

Model: ACU-302 Serial No. 25997 Drwg. No. WD-32636


SEQUENCE OF OPERATION


(COMPRESSOR CIRCUIT TYPICAL)

When CR1 contacts close power is applied thru the compressor safeties energizing the liquid line solenoid RS-1 and time delay relay TD1. The compressor contactor Cl and the oil pressure switch OP1 will be energized for three minutes before being under control of the low pressure switch Low1 for low ambient control. The low pressure switch allows the compressor to pumpdown after CR1 contacts open. Contacts at terminal 3 close and bring on the condenser fans according to ambient temperature. TD2 is a delay-on-make timer used to lock out the compressor for five minutes during recycle.

The control panel contains a lead-lag switch to switch compressor operation according to the room thermostat.

DATE 12/17/87 PAGE 4 OF 6
* Governair - 4841 N. Sewell OKC, OK 73118*






Late A

and Age

. . . . A. T.



The state of the s

.

(· · · · · · · · · · · · · · · · · · ·		
· · · · · · · · · · · · · · · · · · ·		
1 4		
is a second of the second of t		

:

.

1

SUBMITTAL DATA ISSUE (A)

PROJECT: A/C BUILDING AS-205

CAMP LEJUENE, NC

DATE: 12/11/87 12/30/87

SERIAL NO .: 25998

SOLD TO: HUMPHREY HEATING

& ROOFING, INC. P.O. BOX 1268

JACKSONVILLE, NC 28540

REF. DWG.: 32637-A

TAG: AH-1

MODEL NO.: RSA-02

DRAWINGS FOR RECORD ONLY

NO. UNITS: 1

ETL LABEL

AIR FLOW DATA:

SUPPLY AIR: 9,000 CFM at .10" Electronic Air Cleaner-Future

.15" Damper/Hood

.25" Filters

.88" Coil - DX .07" Coil - HW

.07 0011

.25" Unit

.50" External Static - Available

2.20" Total Static Design

COOLING CAPACITY - R-22

BTU/HR TOTAL - 358,500

BTU/HR SENSIBLE - 125,969

ENTERING AIR - 79.1 deg. DB, 66.2 deg. WB,

LEAVING AIR - 60 deg. DB, 57.0 deg. WB,

SUCTION TEMP. - 45.5 deg.

AMBIENT TEMP. - 90 deg.

A.P.D. - 0.88

HEATING CAPACITY - Water

BTU/HR TOTAL - 388,124

ENTERING AIR - 20 deg. DB,

LEAVING AIR - 59.8 deg. DB,

ENT./LVG. WATER - 180.0 deg./160 deg.

GPM - 40

FEET P.D. - 1.6

A.P.D. - 0.07

MECOLD OWING

CONSTRUCTION:

BASE FRAME - Structural steel tube electrically welded,

LUGS, LIFTING - Fixed,

CABINET - FLOOR - 18 gauge galvanized steel single wall,

WALLS - 18 gauge galvanized steel single wall ROOF - 18 gauge galvanized steel single wall,

PAINT - "Landmark Beige" enamel finish inside & out,

INSULATION - 1" fiberglass, 1 1/2 lb. density,

ACCESS DOORS - Double wall construction with standard

galvanized steel hinges,

DOOR LATCHES - Ventlok 333,

CONDITIONER SECTION:

COOLING COIL - DX 5 row, 5/8" copper tubes, 12 aluminum

fins per inch, 19.38 sq. ft. total, 45" fin width, 62" fin length, 10 pass, 1 req'd,

EXPANSION VALVE - One per compressor with distributor,

BLOWER ASSEMBLY - One - 20" forward curve, class I, DWDI,

778 RPM, 2118 outlet velocity, 5.32 B.H.P.

Isolators - spring,

Relubrication lines extended to drive side,

Variable pitch sheaves,

MOTOR - 7 1/2 horsepower, 208/3/60 ODP, 1750 R.P.M.,

213T frame, pivot base,

DRAIN PAN - Insulated with drain connection,

mastic coated, traps furnished and installed

"By Others",

FILTER RACK - Angle with 2" throwaway filters,

HEATING COIL RE - 1 row, hot water,

5/8" copper tubes, 8 aluminum fins per inch,

19.38 sq. ft. total, 45" fin width,


62" fin length, 2 pass,

OA-RA DAMPERS - Outside air rainhood,

Opposed blade,

Damper motor and controls furnished and

installed "By Others",




ELECTRICAL REQUIREMENTS:


208/3/60 power with 24 and 120 volt control, 24 volt transformer furnished and installed, 120 volt transformer furnished and installed,


ELECTRICAL CONTROLS:

See Wiring Diagram WD-32637



PROJECT		DING AS-205	DATE: 12/11/87
			SERIAL NO.: 25998-A
SOLD TO	: HUMPHREY & ROOFIN		REF. DWG.: 32637-A
	P.O. BOX	71LLE, NC 28540	TAG: AH-1
	JACKSON	TILLE, NC 20040	MODEL NO.: RSA-02
			NO. UNITS: 1
<u> L</u>	OOSE PARTS	S SHIPPED WITH UNIT	FOR FIELD INSTALLATION
	QUANTITY		
ITEM	PER UNIT	DESCRIPTION	
1	9	25" x 20" x 2" Thr	owaway Filters
2 3 4 5 6 7 8 9	1	O.A. Rainhood	1 0 11
-3	1	Q674B1034 Honeywel T874B1019 Honeywel	1 Subbase
5		1074B1019 Honeywell	1 Thermostat
6			
7			
- 8			
10			
11			
12		- <u> </u>	
13			
15			
	D. D. D. G.		UNITE DOD DIELD INCOMILLATION
LOOSE	PARTS SH	IPPED SEPARATE FROM	UNIT FOR FIELD INSTALLATION
	QUANTITY		
ITEM	PER UNIT	DESCRIPTION	
	a de Alberta de la companya de la co		
2 3			
3_4			
4			





18 GA. GALV. STEEL RAIN HOOD FOR (x) OUTSIDE, () EXHAUST AIR

1 REQ'D

PAGE . 5 OF 7



MODEL:	RSA-02

DATE: 12/14/87


TAG AH-1


SERIAL NO.


25998

DRAWING NO. 32637-A

LVH







Job: A/C Building AS-205

12/18/87

Tag: AH-1 Model: RSA-02 Serial No. 25998 Drwg. No. WD-32637

SEQUENCE OF OPERATION

The unit is started by the room thermostat subbase. Unit operation is determined by the cool/off/heat switch. Fan operation is determined by the fan on/off switch. Auxillary contacts on the supply fan starter enable the compressors in the ACU.

(TEMPERATURE CONTROLS)


The cooling is controlled by a room thermostat. This stages on the compressors to maintain setpoint.


The heating is also controlled by the room thermostat. The thermostat energizes the heat relay "HR" and "HR" contacts enable the heating valve controls furnished and installed "By Others".

Power for the electronic air filters is provided at the control panel between terminals 1 and 2.

DATE 12/17/87 PAGE 7 OF 9

* Governair - 4841 N. Sewell OKC, OK 73118*






Line Are

	,
. 1	
it of the state of	
de de la companya de	
de la companya de la	
· •	
and the second s	

ı



في كي

المناسبة


·	w	
	>	
•		-
1 11		
i de la companya de l		
		• • • • • • • • • • • • • • • • • • •
1 1		
in a definition of the second		
·		•
1 1		•
in the state of th		
· · · · · · · · · · · · · · · · · · ·		• • • • • • • • • • • • • • • • • • •

TAB PLACEMENT HERE

DESCRIPTION:

	Farris Safety Valve
7	Tab page did not contain hand written information
_	Tab page did not contain hand written information
1	Tab mage contained hand written information
_	Tab page contained hand written information *Scanned as next image

Confidential Records Management, Inc. New Bern, NC 1-888-622-4425 9/08



Farris

MCAS, NEW RIVER NG2470-86-C-5548 Po# 109-284

if i

SAFETY-RELIEF VALVE USER INSTALLATION MANUAL

This booklet is designed to assist in the proper installation of an important safety device, the pressure relief valve. The pressure relief valve which you have received is a precision instrument. Correct installation is essential for plant, property, personnel and

public safety. Failure of a pressure relief valve could lead to catastrophic overpressure of pressurized equipment and/or release of fluids under pressure. The discharge of contained fluids may be hazardous and all precautions should be taken to insure safe disposal.

TELEDYNE FARRIS SAFETY-RELIEF VALVES GENERAL INFORMATION

These definitions are intended to assist you in the correct installation of Teledyne Farris Pressure Relief Valves.

Safety Valve—An automatic pressure relieving device actuated by the static pressure upstream of the valve, and characterized by rapid full opening or pop action. It is used for steam, gas or vapor service.

Relief Valve—An automatic pressure relieving device actuated by the static pressure upstream of the valve, which opens in proportion to the increase in pressure over the opening pressure. It is used primarily for liquid service.

Safety Relief Valve—An automatic pressure actuated relieving device suitable for use as either a safety or relief valve, depending on application.

Pressure Relief Valve—A pressure relief valve is a pressure relief device which is designed to reclose and prevent the further flow of fluid after normal conditions have been restored.

Set Pressure—Set pressure, in pounds per square inch gage, is the inlet pressure at which the pressure relief valve is adjusted to open under service conditions. In a safety or safety relief valve in gas, vapor, or steam service, the set pressure is the inlet pressure at which the valve pops under service conditions. In a relief or safety relief valve in liquid service, the set pressure is the inlet pressure at which the valve starts to discharge under service conditions.

Differential Set Pressure—The pressure differential in pounds per square inch between the set pressure and the constant superimposed back pressure. It is applicable only when a conventional type safety relief valve is being used in service against constant superimposed back pressure.

Cold Differential Test Pressure—Cold differential test pressure, in pounds per square inch gage, is the inlet static pressure at which the pressure relief valve is adjusted to open on the test stand. This pressure includes the corrections for service conditions of back pressure or temperature, or both.

Operating Pressure — The operating pressure of a vessel is the pressure, in pounds per square inch gage, to which the vessel is usually subjected in service. A vessel is usually designed for a maximum allowable working pressure, in pounds per square inch gage, which will provide a suitable margin above the operating pressure in order to prevent any undesirable operation of the relief device. (It is suggested that this margin be as great as possible consistent with economical vessel and other equipment design, system operation and the performance characteristics of the pressure relieving device.)

Maximum Allowable Working Pressure— Maximum allowable working pressure is the maximum gage pressure permissible at the top of a completed vessel in its operating position for a designated temperature. This pressure is based on calculations for each element in a vessel using nominal thicknesses, exclusive of allowances for corrosion and thickness required for loadings other than pressure. It is the basis for the pressure setting of the pressure-relieving devices protecting the vessel. The design pressure may be used in place of the maximum allowable working pressure in cases where calculations are not made to determine the value of the latter.

Overpressure — Overpressure is a pressure increase over the set pressure of a pressure relief valve, usually expressed as a percentage of set pressure.

Accumulation — Accumulation is the pressure increase over the maximum allowable working pressure of the vessel during discharge through the pressure relief valve, expressed as a percent of that pressure or in pounds per square inch.

Blowdown — Blowdown is the difference between actual popping pressure of a pressure relief valve and actual reseating pressure expressed as a percentage of set pressure or in pressure units.

Lift – Lift is the actual travel of the disk away from closed position when a valve is relieving.

Back Pressure—Back pressure is the static pressure existing at the outlet of a pressure relief device due to pressure in the discharge system.

Constant Back Pressure — Back pressure which does not change appreciably under any condition of operation whether the pressure relief valve is closed or open.

Variable Back Pressure — Back pressure which may change appreciably when the valve is open.

Built-Up-Back Pressure — Built-up back pressure is pressure existing at the outlet of a pressure relief device occasioned by the flow through that particular device into a discharge system.

Superimposed Back Pressure—Superimposed back pressure is the static pressure existing at the outlet of a pressure relief device at the time the device is required to operate. It is the result of pressure in the discharge system from other sources.

STORAGE & HANDLING PRECAUTIONS

Because cleanliness is essential to the satisfactory operation and tightness of a pressure relief valve. all necesary precautions should be taken to keep out all foreign materials. Valves which are not installed soon after receipt should be closed off properly at both inlet and outlet flanges or screwed ends. Particular care should be taken to keep the valve inlet and internals absolutely clean. Preferably, valves should be stored indoors or in a location where dirt and other forms of contamination are at a minimum. Valves should be handled carefully and not subjected to heavy shocks. If due consideration is not given to this point, some internal damage or misalignment can result and seat tightness may be adversely affected. Store, transport and install valves with the stem in the vertical position.

INSPECTION ON DELIVERY

Visual Inspection — When a valve is first received, it should be given a visual inspection to note its condition. If any problems are noticed, they should be reported to the manufacturer, or his local representative. All wire seals must remain intact to insure warranty.

Points that should be checked:

- 1. Look for any shipping damage.
- Confirm the nameplate data and the valve size, type and trim/options against ordering documents.
- 3. Insure that factory wire seals are intact.
- 4. If the valve will not be installed immediately, store it properly.
- 5. Confirm by test that valve is ready for installation.

DETERMINATION OF AS-RECEIVED RELIEVING PRESSURE

Before the valve is installed, it is considered important to determine the set pressure of the valve as recieved. Test procedures for determining relieving pressure vary with local plant practices. Note, cold differential test pressures must be taken into account.

CHECKING THE VALVE FOR TIGHTNESS

After the valve is satisfactorily checked for set pressure, check for leakage. It is important to minimize leakage from pressure relief valves. Excessive leakage could lead to fouled or inoperable valves and serious product loss, and could also be hazardous to personnel and equipment.

The valve can be tested for tightness on the test stand by increasing the pressure on the valve up to 90 percent or more of the set pressure and observing the discharge side of the valve for evidence of leakage. Methods of determining leakage are covered by applicable standards and specific user requirements. One reference for seat

tightness testing is API Standard 527. A summary of set pressure tolerances and leak rates is contained in the tables on this page.

COMPLETION OF NECESSARY RECORDS

All necessary records should be completed before the valves go into service. These records are important for effective future use of the valve. They will provide some guidance as to when to retire valves and replace components as well as providing the historical record of the conditions and services under which the valve operated. One publication for reference on pressure relieving devices is the American Petroleum Institute's "Guide for Inspection of Refinery Equipment, Chapter XVI".

OPERATING DIFFERENTIALS GENERAL GUIDE FOR SELECTING DIFFERENTIAL BETWEEN OPERATING AND SET PRESSURES

The variety of service conditions encountered in Section VIII applications precludes a rigid set of rules. Operational difficulties will be minimized by providing as much differential as possible for known conditions of a particular application. The following are suggested minimum differentials:

General Gases, Vapors & Liquids

	Pressures		
Seat Type & Construction	Set Pressure PSIG	Set Pressure Tolerance (+) or (-)	Minimum Differential Suggested
Metal Seat & Soft Seat	16 to 70	2 PSIG	5 PSIG
Metal Seat		71 to 1000 3%	10%
Special Category Metal Seat	71 to 1000		7%
Soft Seat			5%
Metal Seat	1001 1 0000	00/	7%
Soft Seat	1001 to 6000	6000 3%	5%

Leakage Rates for Safety Relief Valves for Set Pressures to 1000 Pounds Per Square Inch Gage (6.9 Megapascals at 60° F) (15.6°C)

Type of Valve	Manufacturer's	Maximum Leakage Rate (Bubbles per Minute)	Approximate Leakage Rate		
	Orifice Size		(Standard Cubic Feet per 24 Hour)	(Standard Cubic meter per 24 Hour)	
Conventional Balanced bellows	F and smaller G and larger F and smaller G and larger	40 20 50 30	0.60 0.30 0.75 0.45	0.017 0.0085 0.021 0.013	

Note: Leak tests are performed as follows: For Flanged Valves – 90% of set pressure. For Screwed Valves – 85% of set pressure.

FOR SAFE INSTALLATION

DO

Store valves in original packing in a clean, dry area until ready to install.

Test valves, if possible, prior to installing.

Install close to pressure source; in no case exceed a 2 to 3% pressure drop

Allow space for disassembly.

Install to allow in-line maintenance and adjustment.

Remove body pipe plug to allow valve body to drain and check periodicially.

Remove plastic push plug from the bonnet of bellows type valves.

Remove inlet and outlet flange protectors.

DO NOT

Lift valves up by the test lever.

Remove flange protectors until just before installing.

Tighten flange bolts unevenly.

Place intervening valves of any sort between the safety-relief valves and the vessels or lines they protect.

Place heavy discharge piping on valve outlets without sufficient support.

Install valve other than in a vertical position.

Install a valve fitting with diameter less than valve inlet.

INSPECTION OF INLET AND OUTLET PIPING

Before pressure relief valve is installed in service the upstream and downstream piping is open and available for inspection. New systems, especially, are likely to contain welding beads, pipe scale or other foreign material which can be inadvertently trapped during construction and destroy the seating surface the first few times the valve opens. Wherever possible, the system should be purged thoroughly before the valve is installed.

A reference on pressure relief valve installation is the American Petroleum Institutes RP-520 Pt. II, Installation of Pressure Relief Valves.

VALVE LOCATION AND POSITION

Always install pressure relief valves with the stem in a vertical position, inlet at the bottom, outlet on the side. There are some rare exceptions, but there are very few valves which can operate dependably in other positions.

On installations where there are pressure fluctuations at the pressure source (as with valves on compressor discharge) which peak close to the set pressure of the valve, it will be beneficial to locate the pressure relief valve farther from the source and in a more stable pressure region.

Regarding proximity to other valve equipment, it is recommended that valves be mounted a sufficient distance downstream from any source of turbulence, such as:

Reducing Stations Orifice Plates and Flow Nozzles Other Valves and Fittings

Also, most top guided pressure relief valves are suitable for mounting on stationary equipment only, otherwise, they cannot operate dependably.

Where liquid valves are installed, ensure the inlet is below the liquid level.

LIFTING LEVER

To prevent stem damage, the valve should have a minimum of 75% of set pressure under the disc before engaging the test lever.

PRESSURE RELIEF VALVE INSTALLATION

Caution should be taken to be certain that all protective material on the valve flanges and any extraneous materials inside the valve body or nozzle are completely removed. Some of these materials may damage the seats or be trapped between the seats causing leakage.

Be sure the bonnets on balanced bellows valves are vented. Remove the plastic push plug inserted for shipment. Plan the disposal of the potential small fluid discharge to a safe place to avoid possible ignition or hazard to personnel.


Whenever any connection is made to an outlet, provide drainage from that piping or from the valve


body. This can also be handled by sloping the piping, thus avoiding disposal problems. Properly support discharge piping. Confirm that the pressure relief valve is being installed in the proper location. Use proper gaskets or sealants to install the valve, insuring that they do not block or contaminate the inlet or outlet of the valve. Torque flange bolting or use wrenching flats for screwed type valves. Release any shipping straps from lifting levers and confirm proper lever freedom.

It is recommended that the valve be isolated during pressure testing of the system, either by blanking or closing a stop valve. If gagging is used, extreme caution must be exercised to avoid damaging the valve and to insure that the gag is removed after use.

INSTALLATION

API RP 520, Part II - Installation





GENERAL NOTES

These reference materials are available and should be helpful in the installation and testing of Pressure Relief Valves.

Since it is impossible to include all the industry practices that are used in the installation of a Pressure Relief Valve, this manual has been prepared to describe routine field handling and installation procedures to make a safe and acceptable installation.

American National Standards Institute, New York, N.Y.

ANSI B16.5 – Steel Pipe Flanges and Flanged Fittings

ANSI B16.34—Steel Valves, Flanged and Butt-welding End.

ANSI B95.1—Terminology for Pressure Relief Devices.

ANSI/ASME PTC 25.3 — Performance Test Code, Safety and Relief Valves.

ANSI/ASHRAE 15-78 — Safety Code for Mechanical Refrigeration, [B9.1].

American Petroleum Institute Washington, D.C.

API RP 520, Recommended Practice for the Design and Installation of Pressure Relieving Systems in Refineries, Part I – Design.

API RP 520, Part II - Installation.

API RP 521, Guide for Pressure Relief and Depressuring Systems.

API Standard 526, Flanged Steel Safety Relief Valves.

API Standard 527, Commercial Seat Tightness of Safety Relief Valves with Metal-to-Metal Seats.

API Standard 2510, Design and Construction of LP-Gas Installations at Marine and Pipeline Terminals, Natural Gas Processing Plants Refineries, and Tank Farms.

Guide for Inspection of Refinery Equipment, Chapter XVI, Pressure-Relieving Devices.

API PAPER 62-73, Computerized Safety Valve Maintenance Records by J.H. Forrester, Jr., May 17, 1973.

American Society of Mechanical Engineers, New York, N.Y.

Section VIII, Rules for Construction of Pressure Vessels, Division I.

Section I, Rules for Construction of Power Boilers.

Compressed Gas Association, Inc., New York, N.Y.

Safety Relief Device Standards:

Part 1—Cylinders for Compressd Gases, Pamphlet S-1.1.

Part 2—Cargo and Portable Tanks for Compressed Gases, Pamphlet S-1.2.

Part 3—Compressed Gas Storage Containers, Pamphlet S-1.3.

National Board of Boiler and Pressure Vessel Inspectors, Columbus, Ohio.

National Board Inspection Code, NB-23. National Board Authorization to Repair ASME and National Board Stamped Safety Valves and Safety Relief Valves, NB-65.

National Fire Protection Association, Quincy, Massachusettes.

NFPA No. 30, Flammable and Combustible Liquids Code.

NFPA no. 58, Standard for the Storage and Handling of Liquefied Petroleum Gases.

NFPA No. 59, Standard for the Storage & Handling of Liquified Petroleum Gases at Utility Gas Plants.

NFPA No. 59A, Standard for the Production, Storage & Handling of Liquified Natural Gases (LNG).



GUARANTEE

All products manufactured by Teledyne Farris Engineering are guaranteed free of defects in material and workmanship, when used within the range recommended, for a period of one year. When authorized, any defective product may be returned to the factory, and if found defective, will be repaired or replaced free of charge, F.O.B. our factory. No charge for labor or other expense incurred will be allowed as the liability of Teledyne Farris Engineering is measured by the refund price of the defective product only.


TELEDYNE FARRIS ENGINEERING

ASMEDIA CERTARIED


1855-01 SERIES

1856W SERIES

SAFETYARELIEFWALVES



1855-OL SERIES




1856M SERIES

FOR STEAM, LIQUIDS, GAS, AND LIQUEFIED GASES

po# 109-284 MCAS, New River N62470-86-C-5548 Jacksonville, NC

Teledyne Farris Safety Valves/High Capacity/Screwed Connections



TYPE 1855-OL Male Inlet, Female Outlet, Open Lever


The Teledyne Farris 1855-OL Series embodies the most progressive engineering design features for three-way High Capacity operation—High Capacity with minimum inlet pipe size; High Capacity with ASME-NB certification; High Capacity with the greatest economy to you. Temp. Range -20° F to $+450^{\circ}$ F.

The 1855-OL Series has extra-long top guiding for safe, positive protection. This valve also features optically machined and lapped flat seat and SELF-ALIGNING disc for maximum tightness and positive shut-off.

			V	V			
VALVE INLET	1/2	%	ST.	11/2	2	21/2	3
SIZE OUTLIET	3/4	11//3	11/2	21/2	3	4	4
SEATIDIA.	1/2	%	量1器	11/2	2	21/2	3
MAX: SET PRESS: PSIG	300	300	300	300	300	250	2450)
PLAIN CAP	61/4	65/8	7%	9	111/2	181/4	151/4
A OPENILEVER	65%	71/8	7%	9%	121/2	141//	163/8
PACKED LEVER	73/A	81/4	8%	111%	141%	16	181/4
B	19/16	111/16	j 15%16	2%	3%10	31%6	41/8
C	27/16	213/16	31%	4	43%	5%16	65%6
APPROX: WEIGHT	3	31/2	5	111	20	30	40

- NOTES: 1. Conforms to ASME Pressure Vessel Code, Section VIII and has been tested and rated for capacity by the National Board of Boiler and Pressure Vessel Inspectors.
 - 2. Flanged inlets available on quantity orders.
 - "O" Ring Seat Seal for additional tightness optional. Add "R" to type number (example: 1855R-OL).
 - 4. Plain cap (no lever) & packed lever designs available on application.
 - 5. Test lever required for Air, Steam & Hot Water Service.
 - Types 1855 and 1855-PKD may be used for back pressure to 50 PSIG when specified.

PART NAME	MATERIAL
Body	ASTMBIGHTH Brassor ASTMB62, Bronze
Bonnet	ASTMANA CLB. Castron
Disc	ASTM BIG HIH Brass
Blow Down films	ASTMIBIO HIH Brass
6 ap	ASTM/A47 Gr 32510, Malls from
Stem	ASTM A581 Type 308 St. St.
Spring/Adj, Screw	ASTMEDIG HILL Bress
Jam Nut	ASTM/BIG HAR Brass
Spring Button, Upper	ASTM A108 Gr 11/17
Spring Button, Lower	Carbon Steel, Plated
Groov-Pin	Statinless Steel, Hardened
Spring	Carbon Steel, Rust Proofed
TestiLever	ASTM A47 Gr. 32510, Mall-Iron
Stem Test Washer	AISIGI117
. Stem Jam Nut	Steel Plated
Button Hollivet	Steer
Sat Serew	Steel, Plated
	_
	<u> </u>
1 <u>117</u>	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
Ċ F	
La.	



CAPACITIES: 1850 SERIES

STEAM-10% OVERPRESSURE

amated steam in pounds per hour at not covernessing ABME Pressure Vessel Gode (UV), Section VIII

PRESS, PSIG 1856M(C)	
PSIG	x4
5# INCR 20 445 66 123 75 285 4927 10 10 92 207 355 5575 827 1332 72299 20 131 296 507 821 1182 1902 3284 40 1182 1902 3284 40 210 473 8811 1313 1890 3042 5252 66 60 289 651 963 1559 2245 3612 6236 60 289 650 1115 1805 2599 4482 7220 10 70 328 738 1267 2051 2295 34752 8204 11 80 368 827 1448 2297 3307 5322 9189 13 90 407 9916 1570 2543 3661 5892 10170 14 100 4466 1004 1722 2789 4015 6462 1110 110 4486 1004 1722 2789 4015 6462 1110 120 525 1181 2026 3281 4724 7602 13130 16 110 120 525 1181 2026 3281 4724 7602 13130 16 110 140 1720 1720 1720 1720 1720 1720 1720 172	=
10 92 207 3355 575 827 1332 2292 2293 20 20 131 2296 5507 821 1182 1902 3284 30 210 473 8811 1313 1890 3042 5252 3284 30 249 561 963 1559 2245 3612 666 66 66 66 66 66 66	142
20 131 296 507 821 1182 1902 3284 40 40 4172 5051 4180 4272 4268 40 40 40 40 40 40 40 4	710
30	311
40 210 473 8811 1313 1890 3042 5252 560 60 289 650 1115 1805 2599 4182 7720 10 70 328 8738 1267. 2051 2953 4752 8204 11 80 368 827 1418 2297 3307 5532 9189 13 100 446 1004 1722 2789 4015 6448 11160 110 110 4486 11004 1722 2789 4015 6448 11160 16 110 16 16 110 16 16 16 16 16 16 16 16 16 16 16 16 16	728
50 249 561 963 1559 2245 3612 5236 60 289 650 1115 1805 2599 4182 7720 10 70 328 738 1267 2051 2953 4752 8204 11 80 368 827 1418 2227 3307 5322 9189 13 90 407 916 1570 2543 3661 5592 10170 14 100 446 1004 1722 2789 4415 6462 11160 110 4486 1093 1874 3035 4370 7032 12140 17 120 525 1181 2026 3281 4724 7602 13130 15 130 3564 31270 2178 3527 55078 8172 3110 14 140	145
60 289 650 1115 1805 22599 4182 7220 8204 11 80 70 80 80 80 80 80 80 80 80 80 80 80 80 80	563
70 328 738 1267 2051 2253 4752 8204 11 80 368 827 41418 2297 3307 5322 89189 12 90 407 55 446 21 100 40 1722 2789 4015 6462 11160 16 16 16 16 16 16 16 16 16 16 16 16 16	981
80 368 827 1418 2297 3307 5532 89189 11 90 4407 916 1570 2543 3661 5592 10170 14 100 4446 1004 1722 2789 4015 6462 11160 16 110 2486 21093 1874 3035 4370 7032 12140 17 120 5525 1181 2026 3281 4724 7602 13130 18 130 564 2170 2178 3527 5078 88172 1100 20 150 150 160 160 160 160 160 160 160 160 160 16	400
90	820
100 4 446 1004 1722 2789 44015 6482 11160 110 4486 1003 1874 3035 4370 7032 12140 17 120 525 11181 2026 3281 4724 7602 13130 112 120 212 120 120 120 120 120 120 12	230
110	650
120	070
130	490
140	900
150 \$\frac{1}{2}\$ \$\frac{1}{2}	320
160	730
170	150
2.00% H012	570
\$180 \$\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\	990
11020 % 319030 % ZZ	4007
190	320
200 200 2100 21000 21000 21000 2000 200	240
210 学 多年879 学 31978 第 3393 第 4 37912 2 12730 第 21980 31	660
	070
	190
240 章 2244 章 3849 章 38976 章 14440 章 24940 章 35	107
	320
· 260 章 · 261076 章 ○ 2421 章 ②4153 章 ○ ○ ○ 39685 章 15580 章 ③ 2421 章 ②4153 章 ○ ○ ○ 39685 章 15580 章 ③ 2421 章 ②4153 章 ○ ○ ○ ○ ○ ○ ○ ○ ○ ○ ○ ○ ○ ○ ○ ○ ○ ○	1
270 270 271116 22510 24305 24305 10040 16150 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2	1918
280 2598 2598 44457 20 10393 16720 25 25 25 25 25 25 25 25 25 25 25 25 25	- W
290 年 1194 金梁 第2687 英 至4609 第一 10745	131
2300 美 1234 美 42776 474761美 美 11097 17860 美 美	

ONOTE Heavy black his incleases pressure timis of (BBM) (C)

AIR—10% OVERPRESSURE

Av. in standard state potentiality at 10% over ressure and sore as ME in oscillar villa. The source visigation of a choice of the control of

SET 1855 1/2x/4 3/4x/11/4 1x11/2		12 (20 %)	22.						90% FIA	TITIE:
PRESS, PSIG. 1856M(C) 1856M(C)		100			VALVE	TYPE A	ND SIZE	-	1 - 5 19	18 17 TH
PSIG	91	1855	1/2×3/4	3/4×11/4	1x11/2	-	11/2x21/2	2x3	21/2x4	3x4
5# INCR 7.0 16 27 44 62 101 175 252 10 33 74 126 204 294 473 816 1175 20 47 105 180 291 420 675 1166 1678 30 61 136 234 379 546 877 1515 2181 40 75 168 288 466 671 1079 1864 2684 50 89 199 342 553 796 1282 2214 3187 60 102 231 395 641 922 1484 2563 3690 70 117 262 449 728 1048 586 2912 4193 89 199 342 553 796 1282 2214 3187 80 130 294 503 815 1174 1889 3222		1856M(C)		1x11/4	-	11/2×2	2x21/2	21/2x3	3x4	-
10	1# INCR	海洲强烈1.	4 Ou Not	3.1	- ₹ 5	9	-12	20	35	50
20 47 105 180 291 420 675 1186 1678 30 61 136 234 379 546 877 1515 2181 40 75 168 288 466 671 1079 1864 2684 50 89 199 342 553 796 1282 2214 3187 60 102 231 395 641 922 1484 2563 3690 70 117 262 449 728 1048 186 2912 4193 80 130 294 503 815 1174 1889 3262 4696 90 144 325 557 903 1300 2091 3611 5200 100 158 357 611 990 126 293 3960 5703 110 172 388 665 1078 1551 2496 4310 6206 120 186 420 779 116 1677 2698 4659 6709 130 200 45 773 125 1803 2900 5009 7212 140 214 483 827 1340 1928 3102 5358 7715 150 228 514 88 1427 2054 3305 5707 8218 160 222 242 545 334 194 2180 3507 6057 8721 170 256 577 988 1602 2306 3709 6406 9224 180 270 609 1042 1689 243 3912 6755 9727 190 284 40 1096 1776 2557 4114 7105 10230 120 326 734 1258 2047 2935 4721 8153 11739 1230 326 734 1258 2047 2935 4721 8153 11739 1230 326 734 1258 2047 2935 4721 8153 11739 1230 326 734 1258 2047 2935 4721 8153 11739 1230 326 734 1258 2047 2935 4721 8153 11739 1230 326 734 1258 2047 2935 4721 8153 11739 1230 326 734 1258 2047 2935 4721 8153 11739 1230 326 734 1258 2047 2935 4721 8153 11739 1230 326 734 1258 2047 2935 4721 8153 11739 1230 326 734 1258 2047 2935 4721 8153 11739 1230 332 868 829 1420 2301 3311 5328 9201 33250 1260 3382 860 1473 2388 3437 5530	5# INCR	多数数 7.	0	1 16	27	44	62	101	175	252
136	10	33	3	74	126	204	294	473	* 816	1175
40	20	10/8 V 4	7.2 - 15	105	-180	- 291	420	675	1166	1678
Section Sect	30 🥶	6	13.46.754	136	234	379	546	877	1515	2181
102	40 %	10.05 7	5 🗦 🗀 🖹	168	288	466	671	1079	1864	2684
To 117 262 449 728 1048 186 2912 4193 130 294 503 815 1174 1889 3262 4696 390 144 325 557 903 1306 2091 3611 5200 1000 158 357 611 990 126 2293 3960 5703 1100 172 388 665 1078 1551 2496 4310 6206 120 186 420 7719 1165 1677 2698 4659 6709 1300 2200 445 773 162 1803 2900 5009 7212 140 214 483 827 1340 1928 3102 5358 7715 1500 228 514 88 1427 2054 3305 5707 8218 1600 2242 545 334 154 2180 3507 6057 8721 3700 256 5777 988 1602 2306 3709 6406 9224 1800 270 600 1042 1689 243 3912 6755 9727 1900 284 400 1096 1776 2557 414 7105 10230 2200 228 671 1150 1864 2683 4310 7454 10730 2200 2298 671 1150 1864 2683 4310 7454 10730 2200 3326 734 1258 2047 235 4721 8153 11739 2230 336 356 766 1312 2118 3060 4923 8502 12242 2240 354 797 1366 2213 3186 5126 8852 12745 2250 368 829 1420 2301 3311 5328 9201 33250 2260 3326 892 1527 2476 3563 5732	50	89	9	199	342	553	796	1282	. 2214	3187
80 130 294 503 815 1174 1889 3262 4696 90 144 325 557 903 130g 2091 3611 5200 100 158 357 611 990 126 2293 3960 5703 110 172 388 665 1078 1551 2496 4310 6206 130 200 451 773 162 1803 2900 5009 7212 140 214 483 827 1340 1928 3102 5358 7715 150 2228 514 88 1427 2054 3305 5707 8218 160 242 545 34 544 2180 3507 6057 8721 170 256 577 988 1602 2306 3709 6406 9224 180 270 609 1042 1689 243	60	102	2 💠 😘	231	395	641	922	1484	2563	3690
90		3888117	7	262	449	- 728	1048	1686	2912	* 4193
100	₩ 80 %	130)	294	503	815	1174	1889	3262	4696
110	≥ 90 →	144	1.5.7	325	557	903	1300	2091	3611	5200
\$120 186 \$420 \$719 \$1165 \$1677 \$2698 \$4659 \$6709 \$130 \$200 \$45 \$773 \$52 \$1803 \$2900 \$5009 \$7212 \$140 \$214 \$483 \$27 \$1340 \$1928 \$102 \$3588 \$7715 \$150 \$228 \$514 \$88 \$1427 \$2054 \$305 \$5707 \$218 \$160 \$242 \$545 \$34 \$162 \$2306 \$307 \$6057 \$8721 \$170 \$256 \$577 \$988 \$1602 \$2306 \$309 \$6406 \$9224 \$180 \$270 \$600 \$1042 \$1689 \$243 \$3912 \$6755 \$9727 \$190 \$284 \$40 \$1096 \$1776 \$2557 \$414 \$7105 \$10230 \$200 \$298 \$671 \$1150 \$1864 \$2683 \$4316 \$7454 \$10730 \$210 \$312	第100章	158	3 (3	357	611	990	1/26	2293	3960	5703
130	≨110 黨	经验 2172	2	388	665	1078	1551	2496	4310	
140	图120 美	*** 186	30分開	420	719	-1165	1677	2698	4659	6709
150 228 514 88 1427 2054 3305 5707 8218 360 3605 3707 3218 3606 3242 545 344 154 2180 3507 6057 8721 3709 3646 9224 3675 3709 3646 9224 3675 3709 3646 9224 3675 3709 3646 9224 3675 3709 3646 9224 3675 3709 37	第130 卷	200		451	773	1252	1803	2900	5009	7212
160	140	214	製作的語	483	827	1340	1928	3102	5358	7715
170		228	3 经公司	514	188 B	1427	2054	3305	- 5707.4	× 8218
180 270 600 1042 1689 243 3912 6755 9727 190 284 40 1096 1776 2557 414 7105 10230 200 298 671 1150 1864 2683 4316 7454 10730 210 312 703 1204 1951 2809 4518 7805 11236 220 326 734 1258 2047 2935 4721 8153 11739 2230 336 766 1312 2118 3060 4923 8502 12242 240 354 7797 1366 2213 3186 5126 8852 12745 250 368 829 1420 2301 3311 5328 9201 13250 260 3382 860 1473 2388 3437 5530 -		242	2 公立議	源545家	334	1344	2180	3507	6057	8721
190 284	№170 ≥	256	語学等	577	988	1602	2306	3709	6406	9224
200 298 671 1150 1864 2683 4310 7454 10730 210 312 703 1204 1951 2809 4518 7805 11236 220 326 734 1258 2047 2935 4721 8153 11739 230 368 797 1366 2213 3186 5126 8852 12745 250 368 829 1420 2301 3311 5328 9201 13250 270 396 892 1527 2476 3563 5732		元 章 270) 金叶海绵	608	1042	1689	2431	3912 4	6755	5-9727
210 312 703 1204 1951 2809 4518 7805 11236 220 326 734 1258 2047 2935 4721 8153 11739 230 36 766 1312 2118 3060 4923 8502 12242 240 354 797 1366 2213 3186 5126 8852 12745 250 388 829 1420 2301 3311 5328 9201 13250 2260 382 860 1473 2388 3437 5530 — — — — — — — — — — — — — — — — — — —		284	是沙漠	640	≥1096	1776	2557	4114	7105	10230
220 326 734 1258 2047 2935 4721 8153 11739 230 766 1312 2118 3060 4923 8502 12242 240 554 797 1366 2213 3186 5126 8852 12745 250 368 829 1420 2301 3311 5328 9201 13250 2260 382 860 1473 2388 3437 5530 — — 2270 396 892 1527 2476 3563 5732 — — 280 410 923 1581 2563 3689 5935 — — 290 424 954 1635 2650 3815 6137 — —		298	建加速	671	1150 -	1864	2683	4310	7454	10730
230 3 766 1312 2118 3060 4923 8502 12242 240 354 777 1366 2213 3186 5126 8852 12745 250 368 829 1420 2301 3311 5328 9201 13250 2260 382 860 1473 2388 3437 5530 — 3270 3270 396 892 1527 2476 3563 5732 — 3280 410 9923 1581 2563 3688 5935 — 3270 3280 4424 9954 1635 2650 3815 6137 — 3270 3270 3270 3270 3270 3270 3270 3270		312		703	1204	1951	2809	4518	7805	911236 A
240 354 797 1366 2213 3186 5126 8852 12745 250 368 829 1420 2301 3311 5328 9201 13250 2260 382 860 1473 2388 3437 5530 — — — — — — — — — — — — — — — — — — —		326		734	1258	2047	2935	4721	8153	11739
250 368 829 1420 2301 3311 5328 9201 13250 2260 382 860 1473 2388 3437 5530	110	3/0	的特別提	766	1312	2118	3060	4923 🛠	8502	12242
260 382 860 1473 2388 3437 5530 320		354	安 斯特及基	797	1366	2213	3186	5126 %	8852	12745
270 396 892 1527 2476 3563 5732 28280 410 9923 1581 2563 3689 5935 290 424 954 1635 2650 3815 6137 1	250	368	新的银石	829	1420	2301	3311	5328	9201	13250
\$280 \$\ \begin{array}{cccccccccccccccccccccccccccccccccccc	10000	382	建筑建筑	860	1473	2388	3437	5530	28 - 28 8 8 2015 8	90 — [132]
290 424 954 1635 2650 3815 6137 /	-10.1			892	1527	2476	3563	5732	一海線	\$ - A.S
2000 3013 3137 344 345 345 345 345 345 345 345 345 345	∞280 😤	410	12.00	923	31581	2563	3689	5935	74-738	11-11
#300 = 438 4986 1689 2761 3941 6339 4-45 4-45	15.000	10/10/29/5 19	THE STATE OF THE SALE	954	1635	2650	3815	6137	2.2	學一流(
	₩300 €	438	數級強能	€986	≋1689 ≱	2761	3941	6339 🐇	\$ - X\$	3433


NOTE Heavy black line indicates pressure limits of 1856M(C)

WATER-25% OVERPRESSURE

Water in galliens per minute all 25% avergressure. For expanities at 10% overpressure, multiply values in jable by 0,6

1				VALVE	TYPE A!	ND SIZE		100	
SET	1855	1/2×3/4	3/4×11/4	1x11/2	_	11/2x21/2	2x3	21/2x4	3x4
PRESS. PSIG	1856M(C)	1/2×3/4 3/4×3/4	1x11/4	-	11/2x2	2x21/2	21/2x3	3x4	-
-× 10 🤞	学: 13.	7.50	海线8.44	通利15 餘	23 %	34	₩ 60 ·	93 🔆	133
20 %	*** 5.	3 1	凝11.9 基	第21號	> 33 %	48	85	132	188
等30 %	45 SO 6.	5.数4字	14.5	26 %	41	58	103	161	230
全840億	你还没证7. !	C	後16.8年	\$30 m	47	67	119	187	266
> 50 蒙	8.		18.8	333	52	75	133	209	297
83 60 B	9.		20.6	36	57	82	146	228	326
第70 潮	9.9	9個學語	22.2	% 39 A	62 💸	89	158	246	352
≠5 80 ±	维持 10.8	5条种类	23.8	42	· 66	95	168	263	376
90 🥸	构设约11.3	- 11 - 1	25.2	1 5	70	101	179	280	398
3100 ₹	经 交换11.8	B等和的	₹ 26.6 €	47	74	106	189	295	421
110 🐇	12.3		28	49	77	111	198	309	442
120 🔌	12.5	9 凝重流	29.2	52	8	-116	207	324	461
130 🙈	13.4	- Comment of States	30.3	₩ 54 E	84	121	215	336	480
×140 ×	黑色连14.0) 新统	31.5	₹ 56 M	87	126	223	350	498
150	14.4	4 被称言	32.6	58	91	130	231	361	516
160	14.9	13898	33.6	60	44.94	134	239	373	533
170	15.3	3等网络	34.7	64	96	.56138 ÷	246	384	548
4180	15.8	3 高海底	35.7.	63	. 99	143	254	396	564
190	16.2	2 20 20 5	36.6	65	102	2146	260	406	579
₹200 %		1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	37.6	為67.得	105	150	- 267	417	594
210	17.1	Carlo division	38.	\$ 68 被	107	154	273	426	608
220	17.5		39.4	经70余	-110	157	280	436	622
≈230 ·	17.7	laber.	40.4	字71 滤	112	161	286	447	637
⇒240 ⊴	18.2	27.5->	41.2	₩73 🕾	- 114	164	292	456	651
≎250 🤃	18.6	1.111 (A. 144)	42	美75 深	∜117 .5	168	298	466	665
260	19.0		43	76	119	171.	304	** - 34	-
270 =	19.4		5443.7 F	78	121	174	310	54	- 3
€ 280 €	19.7			₹ 79	124	178	316	- 0	
290	20.0	77. 42	45.4	₹ 80 🛠	126	181	322	- 4	
≥300 €	20.4	No.	46.2	¥:82 ₺	128	184	327	. I L 1 111	

NOTE: Heavy black hite industris pressure limits of 1856M(6)



TAB PLACEMENT HERE

DE	SCRIPTION:
	Values
	Tab page did not contain hand written information
K	Tab page contained hand written information
	*Scanned as next image

Confidential Records Management, Inc. New Bern, NC 1-888-622-4425 9/08




Foot Valves Check Valves

Simmons Manufacturing Company

Post Office Box 509 McDonough, Georgia 30253 Telephone (404) 957-3976

887-2

Printed in U.S.A.




AMERICAN MADE




Check these outstanding features ... of Simmons Foot and Check Valves

- "O" RING—BUNA "N". . . Suited for hot and cold water, in a full range of sizes.
- CAST BRONZE POPPET. . . One piece construction, with stainless steel selflocking nut.
- MONEL POPPET SPRING . . . This premium quality spring is used on all Simmons valves . . . both foot and check.
- VALVE SEAT. . . Tapered for positive sealing and self-cleansing.
- CAST BRONZE VALVE
 BODY. . . Durable, heavy, one-piece construction—same composition as bronze poppet.

400 Series Foot Valve



Available with solid brass perforated strainer as shown or with stainless steel perforated strainer.









class 125 bronze gate

Screw-in Bonnet • Rising Stem • Solid Wedge

125 PSI Steam to 406°F or 207°C





S-111 Copper to Copper

11.0

Nominal		Dimensions		Approx.	Master	
Size	A	8	C	T-111	8-111	Quantity
1/41	111/18	45/6	11/16	.6	X	100
3/•†	111/10	43/0	17/10	.6	.6	100
Yet	115/10	41/0	1894	.7 -	.6	100
3/4	21/10	513/16	7/0	1.0	.9	50
, , 1	27/10	73/32	.1:	1.7	1.5	30
11/4	25/a	81/8	13/10	2.4	2.1	20
11/2	27/0	913/16	11/4	3.3	3.1	10
, 2	31/10	11%18	15/10	5.0	4.7	10
21/2	41/4	145/10	113/16	10.5	9.4	4
3	41/2	161/2	115/10	15.0	13.3	4

[†] No packing gland, packing only in these sizes.

Not available this size.






T-111 threaded



S-111 solder








class 125 bronze globe Screw-in Bonnet • Integral Seat • Renewable Discs


150 PSI Steam to QBOX to \$200 of made? IEP 050 125 PSI Steam to 406°F or 207°C 200 PSI Non-Shock Cold Water, Oil, or Gas

Conforms to MSS SP-80 (MSS SP-80 replaces Federal Spec. WW-V-51 cancelled April, 1983)


MATERIAL LIST



T-211-Y N.P.T. to N.P.T.



T-211-B N.P.T. to N.P.T.



S-211-Y Copper to Copper

TARES	PART	SPECIFICATION TO THE PROPERTY OF THE PROPERTY
1.	Handwheel Nut	Zinc Plated Steel with Clear Chromate
2.	Identification Plate	Aluminum repro-
OF DESCRIPTION	Handwheel	Aluminum ASTM B-85 Alloy A03800
4.	Stem	Silicon Bronze ASTM B-371 Alloy C69400
	Packing Gland	Bronze ASTM B-62 or ASTM B-584 Alloy C84400 or ASTM B-282 or B-10
	Packing Nut	Bronze ASTM B-62 or ASTM B-584 Alloy C84400
7.	Packing	TFE Impregnated Asbestos or Non Asbestos Fibres
8.	Bonnet	Bronze ASTM B-62
9.	Disc Holder Nut	Bronze ASTM B-140 Alloy C31400 or B-62
*10.	Disc Holder	Bronze ASTM B-62
	Seat Disc	Water, Oil or Gas Steam (TFE) (Y)
*11a.	Seat Disc	Bronze ASTM B-62 (B)
*12.	Disc Nut	Bronze ASTM B-62
13.	Body	Bronze ASTM B-62

Disc, order Disc Nut (12) and Disc Holder (10) and proper disc (11). NOTE: S-211 not available with (B) Disc.

DIMENSIONS - WEIGHTS - QUANTITIES

Nominal	1	Dimensions	10	Apprex.	Approx. Net Wt.		
Size	A	8	C	T-211	8-211	Quantity	
*1/8	23/8	33/8	113/10	9	.8	50	
6 7 *1/4†	2º/a	39/0 -	113/10	9	.8	50	
*3/et	23/8	33/a	113/16	.8	8.	50	
1/21	29/30	3º/a	1"1/16	9	.8	50	
3/4	31/16	43/4	21/4	1.6	1.7	30	
6 % 1 ()	311/10	511/10	213/10	2.6	2.7	20	
e 11/4 ·	45/16	61/4	31/16	3.5	3.3	10	
1'/a	411/16	73/10	3%/16	5.5	4.9	10	
2 - 1	5º/a	715/16	48/16	8.0	7.8	6	
C 21/2	65/s	103/16	51/4	15.5	15.4	2	
3	73/4	113/18	61/2	22.2	20.1	2	

ORDERING: T-211 is normally furnished with a TFE Steam Disc (T-211-Y)


Available with Bronze Disc (T-211-B) S-211 is furnished only with TFE Disc (S-211-Y).





T-211 threaded










class 125 bronze check

Horizontal Swing • Regrinding Type • Y-Pattern • Renewable Discs

125 PSI Steam to 406°F or 207°C of 19812 129 221 200 PSI Non-Shock Cold Water, Oil, or Gas

Conforms to MSS SP-80 (MSS SP-80 replaces Federal Spec. WW-V-51 cancelled April, 1983)




TEL JAIR TO MATERIAL LIST

PART	SPECIFICATION
1. Bonnet Bron	ize ASTM B-62
2. Body A Bron	ize ASTM 8-62 €
3. Hinge Pin and Bron	ze ASTM B-140 Alloy C31400 or 4 Alloy C23000
4. Disc Hanger Bron	ze ASTM B-62
5. Hanger Nut Bron	ze ASTM B-97 Alloy C65500
6. Disc Holder Bron	ze ASTM B-62


-Water, Oil or Gas (Buna-N) (W) 7.1 Seat Disc Trotte Steam (TFE) (Y) Bronze ASTM B-62 (B) Screw Driver Slot for Regrind With same William over Bronze ASTM B-16 or B-62, or B-97 Alloy C65500 8. Seat Disc Nut

9. Hinge Pin Plug Bronze ASTM B-140 Alloy C32000



"Sizes %", 1", 1%", and 1%" only. or to the table and presented by






DIMENSIONS - WEIGHTS - QUANTITIES

Secretary total datase see

T-413-Y N.P.T. to N.P.T.



S-413-W Copper to Copper

NIBCO check valves may be installed in both horizontal and vertical lines with upward flow or in any intermediate position. They will operate satisfactorily in a declining plane (no more than 15°).

WARNING - Do Not Use For Reciprocating Air Compres-sor Service.

Veminal	Dimensions			Approx.	Net Wt.	Master Carton	JANK TOW
Size	A	B	Č	, T-413	\$-413	Quantity	7.7.
1/4	. 21/6 €	15/6	11/4	5	.5	50	Symp 1 147
3/4	21/0	15/8	15/16	. ,5	.5	50	AT THE
1/2	27/16	111/10	11/2	.6	.5	50	
1/4	215/16	17/2.00	17/4	1.0	.8	50	
ή	30/10	25/16	21/4	1.5	1.2	30	
11/4	43/16	211/10	23/4	2.2	1.8	20	
11/2	41/2	215/16	31/8	2.9	2.5	10	Contraction of the Contraction o
2	51/4	313/10	33/4	5.0	4.2	10	
21/2	8	51/10	55/16	12.0	10.5	5	Bon-
3	9'/4	61/4	61/4	18.2	15.5	4	and a team

ORDERING T-413 and S-413 normally turnished with Bronze Disc (T-413-B) or (S-413-B).

Both available with TFE Steam Disc (T-413-Y), (S-413-Y), or W.O.G. Disc



solder

was trevel in the castage in






FIGURE 6000

A.S.M.E. Standard—N.B. Certified





BRONZE SAFETY VALVES

High Capacity, Full Nozzle

PRESSURE SETTINGS: STEAM TO 250 PSI. 406° F. AIR/GAS TO 300 PSI. 300° F.

Forged copper alloy—disc and full nozzle. Seats lapped to optical flatness. Valve housing is heavy cast bronze. Wide hex on body provides ample wrench clearance for easy installation. Factory tested and adjusted for precise opening without simmer, and for correct blowdown.

APPLICATIONS

Steam boilers, generators, lines, unfired vessels. Compressor intercoolers, aftercoolers, receivers.

PARTS UST

A state of the sta									
ITEM	DESCRIPTION	MATERIAL	ITEM	DESCRIPTION	MATERIAL				
1	Body	Forged Copper	14	Pressure Screw	Brass				
1005541		Alloy	15	Reg. Ring Set Screw	Brass				
3	Сар	Bronze	16	Guide Set Screw	Brass				
4	Hood	Brass Die Cast	17	Lift Nut	Steel-Cad. Plated				
5	Disc	Forged Copper	18	Lever	Stl. Stamp Br. Plt.				
		Alloy	. 19	Spring Pin	Stn. Stl.				
6	Regulator ring	Bronze	20	Press. Screw L'Nut	Brass				
7	Guide Spindle	Bronze Steel-Cad. Plated	21	Hood Set Screw (FHMS)	Brass Pl.				
9	Spindle Retainer	Brass	22	Name Plate Screw (Dr.)	Steel Brs. Pit.				
10	Sp. Retainer Locknut	Brass	23	Seal	Lead & Wire				
11	Ball	St. Steel	24	Body Set Screw	Stl. Brs. Plt.				
12	Spring	Steel-Cad. Plated		Name Plate	Brass				
13	Spring Plate (top)	Steel-Cad. Plated	25	Vibration Damp. Sp.	Ph. Br.				

*Item 25—Optional at Extra Cost. (Not Shown)

THE STANFARE

		Discharge	Conn	ections	Overall	CL to	CL to	in the state	
In- Ori- Out- let fice let	Figure Number	Area Sq. In.	Inlet "D"	Outlet "E"	Height "A"	Inlet "B"	Outlet "C"	Approx. Wt. Lbs.	
1/4 × D × 1/4 1/4 × D × 1/4	6000-D-1 6000-D-2	0.121 0.121	½"M. ¾"M.	3/4"FE. 3/4"FE.	63/2 53/8	21/6	1%	11/2	
% x E x 1 1 x E x 1	6000-E-1 6000-E-2	0.216 0.216	3/4"M. 1" M.	1" FE. 1" FE.	7½ 7%	21/2	13/4 13/4	2½ 2¾	
1 x F x 1½ 1½ x F x 1½	6000-F-1 6000-F-2	0.338 0.338	1" M. 1¼"M.	1¼"FE. 1¼"FE.	8½ 85%	2% 2%	2 2	3¾ 4	
11/4 x G x 11/2 11/2 x G x 11/2	6000-G-1 6000-G-2	0.554 0.554	1½"M. 1½"M.	1½"FE. 1½"FE.	95% 97%	31/8	2% 2%	53/4	
1½ x H x 2 2 x H x 2	6000-H-1 6000-H-2	0.863 0.863	1½"M. 2" M.	2" FE. 2" FE.	10% 11%	35%	2¾ 2¾	8 81/2	
2 × J × 2½ 2½ × J × 2½	6000-J-1 6000-J-2	1.414 1.414	2" M. 2½"M.	2½"FE. 2½"FE.	135% 137%	41/4	3% 3%	141/2	

CARACITIES

See page 3

Manufactured for Spirax Sarca, Inc. by Kunkie Valve Co.




FIGURE 6000 SERIES

CAPACITY IN POUNDS OF SATURATED STEAM PER HOUR

To correct capacities for superheat see page 6

RIFICE				ı.		F	1	Ğ-		(f		1		
(Vii)	AFIGURA.		. eu	d an	/exi	(g. t.	94,34		- ns	(1 1) (1)	LKTK	Teachtain.		
eri Oric	10.70 2.75		theyed 1	100 Te	No. of House fine the gray Acco	(Un -/Hour Crosso 160% Ale	Liver- extract			Alle //ICC	(OF Also STATE	10071		
5	99	110	176	196	275	308	450	504	703	786	1153	1289		
10	124	140	221	250	347	391	568	641	886	1001	1453	1640		
15	150	170	267	303	418	475	685	778	1069	1215	1752	1991		
20	175	200	312	357	489	558	802 919	916	1251	1429	2051 2350	2342		
25	201	230	358	410	561	642	919	1053	1434	1044	2330	2073		
30	226	260	404	464	632	725	1036	1191	1616	1858	2650	3045		
35	252	290	449	517	703	809	1152	1328	1799	2072	2949	3396		
40	278	320	495	571	775	893	1269	1465	1981	2286	3248	3747		
45	303	350	540	625	846	977	1386	1602	2164	2500	3547	4098		
50	329	380	586	678	918	1061	1503	1739	2347	1 14	3846	4447		
55	354	410.	631	732	989	1145	1620	1876	2529	2928	4146	4800		
60	386	440	677	785	1060	1229	1737	2014	2711	3142	4445	5151		
65	405	470	723	839	1132	1312	1854	2151	2894	3356	4744	5503		
70	431	500	768	892	1203	1396	1971	2289	3076	3570	5043	5854		
75	457	530	814	946	1274	1479	2088	2426	3259	3784	5343	6205		
80	482	560	860	1000	1346	1563	2205	2563	3441	3999	5642	6556		
85	508	590	905	1053	1417	1647	2322	2700	3624	4213	5941	6907		
90	533	620	950	1106	1489	1731	2439	2837	3806	4427	6240	7258		
95	559	650	996	1159	1560	1815	2556	2974	3989	4641	6540	7609		
100	586	680	1042	1212	1631	1899	2673	3111	4171	4855	6839	7960		
105	610	710	1087	1265	1703	1983	2790	3248	4354	5069	7138	8311		
110	636	740	1133	1319	1774	2067	2907	3385	4536	5283	7437	8662		
115	661	770	1178	1372	1845	2151	3024	3522	4719	5497	7736	9013		
120	687	800	1224	1425	1917	2235	3141	3660 3797	4901 5084	5711	8036	9365		
125	712	830	1269	1479	1988	2318	3258	3/9/	3004	3723	6333	///		
130	738	860	1315	1532	2060	2402	3375	3935	5266	6140	8634	10067		
135	764	890	1361	1586	2131	2486	3492	4072	5449	6354	8933	10418		
140	789	920	1406	1640	2202	2569	3608	4' 09	5632 5814	6568	9233 9532	10769		
145	815 840	950 980	1452	1694	2273	2653 2736	3725 3842	346 4483	5997	6996	9831	11471		
						98 - 27				-	- 5000			
160	891	1040	1588	1853	2488	2904	4076	4757	6362	7424	10430	12173		
170	943	1100	1680	1961	2631	3071	4310	5032	7092	7832 8281	11028	12875		
180	994	1160	1771	2068	2773	3239 3406	4544	5306 5581	7457	8709	12225	14280		
190 200	1045	1220 1280	1953	2282	3059	3574	5012	5855	7822	9138	12824	14982		
ar y	4 22 A	and the base	1137.4	THE LA	antique.		20 1 1 1 1			0511	12400	15/0		
210	1147	1340	2044	2389	3202	3642	5246	6130	8187 8552	9566	13422	15684		
220	1198	1400	2135	2496 2603	3344	3809 4077	5714	6678	8917	10423	14619	17088		
230 240	1301	1520	2318	2710	3630	4244	5948	6953	9282	10851	15218	17790		
250	1352	1580	2409	2816	3773	4411	6181	7227	9647	11279	15816	18492		


Lbs./Hour Steam, 90% basis 3% Accumulation

The capacities shown in these columns are for saturated steam and apply to volves for use on power boilers in accordance with current A.S.M.E. Code, Section 1.

Lbs./Hour Steam, 90% basis 10% Accumulation

The capacities shown in these columns are for saturated steam and are in accordance with A.S.M.E. Unfired Pressure Vessel Code, Section VIII.

Note: For Air/Gas Capacity Please Contact The Factory.



FEATURES OF THE 25-SERIES REGULATORS

FOR PRESSURE


High-Performance Materials


Sarco builds 25-Series Regulators with high-quality heat- and corrosion-resisting materials at all critical points. For example, valve stems are stainless steel; head and seat are hardened stainless steel; diaphragms are two-ply phosphor bronze; and pilot valve seals are Teffon. The engineering design has been thoroughly proven in service.

Low Maintenance Cost

Whenever inspection or maintenance does become necessary, a Sarco 25 Regulator saves downtime and labor because all its key parts are more readily accessible than corresponding parts of any other currently available regulator valve. For example, with the body cap removed, the main valve head lifts off its stem, and the seat comes out with a conventional hex socket wrench. The extreme simplicity of these and other maintenance operations is a long-term user benefit.

Proportions and details are somewhat different in larger, flanged valve bodies. Principles are the same.





Easier Pilot Interchangeability

Inventories can be reduced considerably, because it is not necessary to stock each valve size you will need with every type of pilot control it might require. Just put the desired pilot on the right size valve. Sarco will be glad to ship valves and pilots boxed separately so that they can be assembled as required without the trouble of switching components.

It has always been possible to install any type of pilot—or combination of pilots—on a 25-Series valve body. Now it is easier than ever.

No need to change integral tubing connection: Just bolt the pilot you select to the flanged cover plate. Or bolt on the flanged adapter plate and install a combination of two or three pilots on the same valve body. These are simple jobs, and they take only a few minutes.

Any size 25-Series valve body—from ½-inch to 6-inch—can be equipped for any functional operating mode in exactly the same way. Pilots are completely interchangeable.

Interchangeable Pressure Pilot Springs


The pressure pilot accommodates any one of three easily interchangeable pilot springs—each designed to give best performance in a given pressure range. Pilot springs are color coded by Sarco for error-free selection. Spring installation is a quick, simple task.


Choice of Pilots

Shown here with a pressure pilot, these Sarco regulators are also available with multiple-pilot combinations. An electrically actuated auxiliary pilot can be used with either the pressure or traperature pilot. Pressure and temp viure pilots can be combined on one valve body, and this combination can have an electrically actuated auxiliary pilot. Or, an electric pilot alone can operate the valve for on-off control. All pilots and all their combinations are interchangeable.

Dead-End Shutoff

Whenever a pilot valve closes, the single-seated main valve shuts off tight. No leakage! The main valve return spring plus steam pressure acting on the valve head ir are dead-end shutoff.






PRESSURE REDUCING VALVE TYPE 25P

The 25P is an accurate, reliable regulator that allows steam from a high pressure supply to be used at a more economical low pressure, and protects valuable equipment from overpressure.

HOW THE 25P, 25PA & 25PI WORK

Normal positions before start-up are with the main valve closed and the pilot valve held open by spring force or air pressure. Entering steam passes through the pilot valve into the main diaphragm chamber and out through the control orifice. As flow through the pilot valve exceeds flow through the orifice; control pressure increases in the diaphragm chamber, and that opens the main valve. As steam flows through the main valve, the increase in downstream pressure feeds back through the pressure sensing line to

the underside of the pressure diaphragm. When the force below that diaphragm balances the compression force of the spring above it, the pilot valve throttles. The control pressure maintained in the main diaphragm chamber positions the main valve to deliver just enough steam for the desired delivery pressure. Adjustment of the spring or air pressure above the pressure diaphragm changes the downstream pressure set point. When steam is not longer required, the Sensing Line pressure increases closing



the pressure pilot and the control pressure bleeds back through the control orifice. This allows the main valve to hold the desired reduced pressure and it may close tight for a dead-end shutoff.

HOW TO SIZE AND INSTALL THE 25P PRESSURE REDUCING VALVE

From the inlet and reduced pressure conditions select the standard or reduced port valve, from page 12 or 13, which meets the actual steam capacity requirements. Reduced port valves have less capacity for lower steam velocities through the valve. Satisfactory performance and low maintenance depends on selecting the valve correctly. An undersized valve will not be able to hold the reduced pressure under maximum load conditions. An oversized valve may hunt because the main valve will be barely cracked open, and can subject the valve seat and head to premature wear.

Complete the valve section with the pilot Valve Spring Color which meets the downstream pressure condition.

How to order

When ordering a Sarco 25P Pressure Reducing Valve, please include all the following data:

- valve size by nominal pipe/flange
- body construction of cast iron or cast steel
- type of control—25P for pressure reduction
- steam supply pressure
- reduced pressure range and color of pilot valve spring selected
- intended application

For example: Sarco 1" Cast Iron Pressure Reducing Valve Type 25P for 150 psig inlet pressure, yellow spring for 3 to 30 psig reduced pressure, for 15 psig process heating.

Piping layout should be planned so that the reducing valve will be on a horizontal run with bypass piping provided so that the system can be operated under manual control while the reducing valve is isolated for servicing.


Pipe sizes should be determined on the basis of steam velocity and sized from the table on page 19. The reducing valve, sized from the table on page 12 or 13, is likely to be smaller than inlet piping and will almost always be smaller than downstream piping.


PILOT VALVE

Downstream Pressure Color Code

3 to 30 psig YELLOW
20 to 100 psig BLUE
80 to 250 psig RED

THE STATE OF THE S





CAPACITIES FOR STANDARD 25P-25PA-25PI-25PE VALVES


pounds of saturated steam per hour

STEAM	OUTLET STEAM	a service	design of territors	eri Berri A		NOMINAL	VALVE SI	ZE			*:-
PRESSURE, PSIG	PRESSURE, PSIG	1/2"	3/4"	1"	11/4"	11/2"	2′′	21/2"	3′′	4"	6'
	etrius :			il Eur	ţ.	711		1	4.0	2.1	
15	10	95	175	285	380	540	950	1,500	2,000	3,100	7,00
	5	135	250	405	545	780	1,365	2,185	2,890	4,480	10,17
	3	155	285	465	620	880	1,550	2,470	3,260	5,080	11,44
20	12	120	230	365	490	700	1,225	1,960	2,590	4,025	9,10
	8	155	290	470	630	900	1,575	2,520	3,330	5,175	11,70
	0-5	180	335	540	720	1,025	1,795	2,870	3,790	5,895	13,32
25	15	145	270	435	580	830	1,450	2,325	3,070	4,770	10,79
	10	195	360	580	775	1,110	1,950	3,110	4,110	6,385	14,43
	0-7	205	385	620	825	1,180	2,065	3,305	4,360	6,785	15,34
30	20	155	290	470	630	900	1,575	2,520	3,330	5,175	11,70
	15	220	410	665	890	1,270	2,220	3,555	4,700	7,300	16,51
	0-12	230	430	695	925	1,320	2,310	3,695	4,885	7,590	17,16
40	30	155	290	470	630	900	1,575	2,520	3,330	5,175	11,70
	25	250	470	755	1,010	1,440	2,520	4,030	5,330	8,280	18,72
	8-18	280	525	850	1,135	1,620	2,835	4,535	5,995	9,315	21,06
50	40	190	355	575	770	1,100	1,925	3,080	4,070	6,325	14,30
	30	315	585	955	1,275	1,820	3,185	5,095	6,735	10,465	23,66
	0-21	350	650	1,050	1,400	2,000	3,500	5,600	7,400	11,500	26,00
60	45	280	520	840	1,120	1,600	2,800	4,480	5,920	9,200	70,80
	35	360	670	1,080	1,440	2,060	3,605	5,770	7,620	11,845	78
	0-27	385	720	1,165	1,555	2,220	3,885	6,215	8,215	12,765	28,86
75	60	280	525	850	1,135	1,620	2,835	4,535	5,995	9,315	21,06
	50	41.5	775	1,250	1,665	2,380	4,165	6,665	9,800	13,685	30,94
	0-35	470	875	1,415	1,890	2,700	4,725	7,560	9,990	15,525	35,10
85	70	290	540	870	1,160	1,660	2,905	4,650	6,140	9,545	21,58
	50	490	915	1,480	1,975	2,820	4,935	7,895	10,435	16,215	36,65
	0-43	515	960	1,555	2,070	2,960	5,180	8,290	10,950	17,020	38,44
100	80	370	690	1,115	1,485	2,120	3,710	5,935	7,845	12,190	27,56
	60	580	1,080	1,740	2,325	3,320	5,810	9,295	12,285	19,090	43,16
	0-48	600	1,120	1,815	2,420	3,460	6,055	9,690	12,800	19,895	45,00
125	100	440	825	1,335	1,780	2,540	4,445	7,110	9,400	14,600	33,00
	80	680	1,275	2,060	2,745	3,920	6,860	10,975	14,500	22,540	50,96
	8-62	730	1,365	2,200	2,940	4,200	7,350	11,760	15,540	24,150	54,60
150	125	490	910	1,470	1,960	2,800	4,900	7,840	10,360	16,100	36,40
	100	800	1,490	2,400	3,205	4,580	8,015	12,825	16,945	26,335	59,54
	6-76	860	1,600	2,590	3,460	4,940	8,645	13,830	18,280	28,400	64,22
175	150	490	91.5	1,480	1,975	2,820	4,935	7,895	10,43%	16,215	36,66
	125	870	1,630	2,635	3,515	5,020	8,785	14,055	18,5 0	28,865	65,26
	0-87	985	1,840	2,970	3,960	5,660	9,900	15,850	20 /50	32,545	73,58
200	150	840	1,600	2,540	3,390	4,840	8,470	13,550	17,900	27,830	65,92
	125	1,075	2,000	3,240	4,330	6,180	10,815	17,300	22,870	35,530	80,34
	9-103	1,125	2,100	3,390	4,520	6,460	11,300	18,000	23,900	37,145	83,98
225	175	880	1,650	2,670	3,560	5,080	8,890	14,225	18,800	29,210	66,00
	150	1,160	2,180	3,500	4,660	6,660	11,655	18,650	24,640	38,300	86,60
	6-117	1,250	2,340	3,780	5,000	7,200	12,600	20,160	26,640	41,400	93,60
250	200	925	1,730	2,790	3,720	5,320	9,300	14,900	19,680	30,600	69,20
	150	1,340	2,500	4,050	5,400	7,720	13,500	21,600	28,600	44,400	100,36
	8-131	1,365	2,590	4,180	5,570	7,960	13,930	22,300	29,450	45,800	103,50
					ver the second	1,000					
						(),(i)	11/2/30	140			

^{*}Cast steel construction required for service above 250 psig.

Capacities are based on an accuracy of regulation of 1. P.S.I. and with pipe sizes to insure reasonable steam velocities. Refer to pipe sizing Chart Page 19.

Bold faced numbers in outlet steam pressure column indicate pressures at which maximum capacity occurs. Lower outlet pressures do not increase valve capacity.




TAB PLACEMENT HERE

DE	SCRIPTION:
	Cauges
	Tab page did not contain hand written information
K	Tab page contained hand written information *Scanned as next image

Confidential Records Management, Inc. New Bern, NC 1-888-622-4425 9/08

MECHANICAL CONTRACTORS GAUGE



APPLICATION

Designed to meet the requirements of Heating, Ventilating and Air Conditioning contractors and equipment manufacturers.

SPECIFICATIONS

Accuracy:

1% in the working range. 11/2% at upper and lower scale extremes. Meets

ASA Grade A.

Case & Ring: Black enamel finish. 41/2" drawn

steel case with friction fit ring.

White metal dial with black figures and graduations. Plain balanced point-

er Glass dial face.

Construction: Phosphor bronze bourdon tube with

brass socket and tip. " male NPT


bottom connection.

Movement:

Quality brass construction. Precision gears and finely finished bearing sur-

faces insure smooth motion and ex-

tended service life.




4-1/2	1-11/32	4-23/32	15/32	3-13/32
GAUGE	B	, c	, D	

	PRESSURE
7	0 - 30 psi
5414	0 - 60 psi
200	0 - 100 psi
	0 - 160 psi
	0 - 200 psi
Г	0 - 300 psi
T	0 - 600 psi
-	

VACUUM 0 - 30" Ha

COMPOUND 30" - 0 - 30 psi 30" - 0 - 60 psi





TAB PLACEMENT HERE

DE	SCRIPTION:
	Thermometers
	Tab page did not contain hand written information
ty/	Tab page contained hand written information *Scanned as next image

Confidential Records Management, Inc. New Bern, NC 1-888-622-4425 9/08

MOELLER

MODEL 4000 & 4250

BACK ANGLE BIMET THERMOMETERS


These rugged, fixed back angle thermometers are available in 2 different dial sizes, 5" (4000 series), 3" (4250 series) to fit all standard installations requiring this form. All standard stem lengths and ranges are available.


MODEL 4500 & 4750

STRAIGHT FORM BIMET
THERMOMETERS

As rugged and dependable as all Moeller BIMETS, the fixed bottom connected BIMETS are available in 5" (4500 series) & 3" (4750 series) dial sizes and are offered in all standard stem lengths and ranges.








MOELLER BIMET

Moeller BIMET thermometers offer excellent performance for industrial process applications as well as general commercial and industrial use. Field proven for accurate and fast response to temperature changes, ese rugged instruments feature weather proof and fume-proof cases with easy reading anti-parallax dials. Stainless steel construction gives maximum protection against corrosion.

FEATURES

- Weatherproof, fume-proof case with gasketed removable bezel, all 304 stainless steel construction.
- External calibration—simple zero reset screw adjustment at back of case.
- Stainless steel stems with all joints welded. Fixed or union connections.
- Anti-parallax scale, white aluminum dial with black easy reading

- numbers and graduations. Black finished, balanced pointer.
- BIMET helix—low mass, single coil is silicone dampened to limit pointer oscillation and accelerate heat transfer for faster response.
- Accuracy within 1% of included range.
- Clear extra heavy glass front standard. Plastic or shatterproof glass crystals available.



TAB PLACEMENT HERE

DE	SCRIPTION:
	Traps
	Tab page did not contain hand written information
DÍ	Tab page contained hand written information *Scanned as next image

Confidential Records Management, Inc. New Bern, NC 1-888-622-4425 9/08

FT-15 to FT-125 Series

Cast Iron

FT-15 to FT-125 SERIES

Sizes

34", 1", 114", 11/2", 2"

All sizes supplied with thermostatic air vent containing a welded stainless steel bellows.

Materials


Body and Cover: Cast Iron Internals: Stainless Steel

Pipe Connections

Screwed NPT

Features:

- Integral stainless steel air vent as standard.
- Corrosion resistant stainless steel float and main valve asser. My.
- All working parts attached to cover.
 Removable for easy in-line maintenance.



TYPE	SIZE	See Pig.	*		Jan		750	c	0	5.5	100	E	200 A	14	Service of	APPROX.	
	NPT	No.	in.	200	in.		in.		in.	1	in.		'n.		Lb.		
FT-15	94"	1	634	157	4%	117	35%	14	31/2	11	574	145	15%	93	9		
PT-15	1"	2	61/4	157	4%	117	35%		31/2	16	5%	7.40	1%		91/2		
FT-15 FT-15	114"	2	81/2		41/4	208	3	7.6	22 %a		5% 8%	图器	31/2		19		
FT-15	2"	2	913/4	249	4%	124	413%	125	1/4		91/4	230	1196	49	26		
F7-30	%"	1	61/4	157	4%	117	35%	BA	31/2	11	5%		13%	33	9		
FT-30	1"	1	69%	17.	4%	117	35%	-84	31/2	1	5%	144	13%		9		
FT-30	134"	2	81/2		411/4	1119	3		11/4		5% 8%	1,65	31/2		18		
FT-30	2"	2	913/4		43%	12	413/4	125	1/6		914	10	115%		26		
F1-75	张"	1	61%	1.57	4%	117	3%		31/2	renero Valo	5%	143	156		9		
FT-75	11"		61%		4%	1117	39%	e.	31/2		5%	164	15%		9		
PT-75	114"	2	81/2		434	3,00	3		11/4		8%	Sec.	31/2	2.4	18	藝。	
F 75	2"	3	9194	247	4%	108	419/4	74 125	13/6		91/6		31/2		26		
F-125	34"	1	67/4	157	4%	117	35%	84	31/2	215	5%	146	15%	33	9		
FT-125	1"	1 5	67%	315	4%	117	31/6		31/2	11	5%	246	196		9		
FT-125	114"	-	81/2		414	108	3	76	11/4		8%		31/2	3.4	18		
FI-125	2"		81/2		4%	108	4186	198	11/4		91/4		31/2	-4	18		

	a. Program	Sales S		Ä.	S. NE	D	IFFERE	LAITE	PRESSUI	RE	184	INC	. 15	1,00		4-11	
TYPE	SIZE	poig but Orifice	¥ 217	1/3 1035	1	2 (14)	5	10 +89	15 2005	20	25 3.7	30 12,1	40	50 3.5	75	100	125
FT-15 FT-15 FT-15 FT-15 FT-15	%" 1%" 1%" 1%"	.218 .218 .312 .300 .625	279 279 600 1100 2300	369 369 770 1700 2800	487 487 980 2400 3600	650 650 1240 3300 4650	785 785 1640 5000 6900	1000 1000 2000 6600 9000	1075 1075 2340 7600 10900		300						
FT-30 FT-30 FT-30 FT-30 FT-30	%" 1%" 1%" 1½"	,218 ,218 ,228 ,390 ,500	279 279 375 1000 1300	369 369 500 1300 1800	489 489 690 1700 2500	650 650 910 2300 3400	785 785 1200 3400 5200	1000 1000 1500 4600 6800	1075 1075 1680 5500 7800	1210 1210 1800 6000 8600	1300 1300 1900 6600 9300	1370 1370 2000 7000 10000					語の事情なる
FT-75 FT-75 FT-75 FT-75 FT-75	1" 1%" 1%" 2"	.166 .166 .312 .312 .421	160 160 550 550 850	213 213 725 725 1100	280 280 960 960 1500	365 365 1300 1300 2000	520 520 1900 1900 3100	700 700 2650 2650 4150	795 795 3050 3050 4750	875 875 3400 3400 5200	930 930 3700 3700 5500	970 970 4000 4000 5800	1120 1120 4400 4400 6400	1230 1230 4750 4750 6800	1450 1450 5400 5400 7700		10 May 10
FT-125 FT-125 FT-125 FT-125 FT-125	34" 1" 114" 114" 2"	.125 .125 .246 .246 .332	100 100 400 400 550	135 135 520 520 675	175 175 680 680 880	230 230 890 890 1225	330 330 1300 1300 1950	415 415 1700 1700 2c00	500 500 2050 2050 3000	\$65 565 2300 2300 2300 3250	620 620 2500 2500 3500	665 665 2700 2700 3800	750 750 3000 3000 4200	830 830 3200 3200 4600	970 970 3800 3800 5500	1110 1110 4200 4200 6100	1190 1190 4500 4500 6600

Limiting Conditions

Maximum operating pressure of each trap series in determined by orifice size and is noted by trap type (Example: 34" FT-75 equals 75 psi.

Options

All available without air vent and with optional NPT tapping as drain traps.

Some sizes can be supplied combined with steam lock release (SLR). Consult factory for details.

Typical Specification

Steam traps shall be of the mechanical ball float type having iron bodies with screwed connections and stainless steel heads and seats. Traps shall incorporate a stainless steel thermostatic air vent.




FIGURE 1




FIGURE 2





FIGURE 3



SARCO Type B Inverted Bucket Steam Traps




Fig. 3—Sarco type B1-X steam trap, sizes 1/2" or 3/4".

Size	Standard	With Blmetal Air Vent (see Fig. 5)
1/2" or ¾"	BT-X	812-X
***	B2 83	B22 B32
14"	В4	842
2/	B5 / 1	852 s

Type 61-X and 612-X trips with sta, sleet buckets and monel strainers. All other trops with bress buckets and strainers evallable at extra cost.

When ordering, please see the opposite page and give the complete catalog number. Example of an order correctly written; one 34" B2-125.





Fig. 4—Sarco type B steam trap, sizes 3/4" to 2".

the property of the state of th



Type B Inverted Bucket Traps

	Partie of the State of the Stat	Late Ties	WE'L	IMEN	SLON	4. 4		NET*
SIZE	TYPE	A -	188	C*	C-1.	D	SE EN	WT.
½ or ¾"	B1-X or B12-X*	5"	4"	3%	313/64	3/4	2%"	6¼ Lb.
* % *****	B2 to B22	6%"	5%4"	3%"	11/4	AM.	3146	12½ (L):
, Y	83 or 832	7%!	5%"	41/2/1	47/4"	41/41/	41/2"	19½ Lb.
14"	#- 84 or 842	9%"	7"	51/41/	51/4. ¹⁷ ×	7%"	514"	40 Lb.
1'y 18 ⁶ 0 c	B5 or B52	111/4"	8%"	613/6"	6%	10%!	6%"	75 16.

^{*}C-For traps without air vents. C-1-For traps with bimetal vents





Fig. 5—Both of the above steam traps available with bimetal air vents. Please note that all bimetal vents close at about 210°F, and remain closed to air-steam mixtures which are often as much as 20°F, below steam temperature. When air venting is a problem, please see page 4 and select another type of steam trap.

Construction Details

Faris	7yps B1-X 512-X	Type 82 ie 85 822 ie 852
Body, Cover, 194	Cast Iron—AS	TM A126, Class B
Seat, head	atoinless st	ael, hardened
Mechanism	stain	ess steel
Bucket	stainless steel	brass.*
Strainer Screen	Monel* Mesh 100 2	brass* perf
Seat gasket	stain	less steel
Cover gasket	graphi	fe asbestos 🛴 🛴 🔭 🖽
Cover screws		steel

^{*}Optional stainless steel buckets and strainers available at extre cost.

ALL TRAP BODIES ARE SUITABLE FOR 250 psig/17.2 bar
MAXIMUM OPERATING PRESSURE IS DETERMINED BY ORIFICE SIZE.



HOW TO SELECT SARCO BUCKET IKAPS

The tables below show the maximum capacities on continuous discharge at approximate steam temperature. Cold water discharge capacities are much higher.

When calculating the capacity requirement for the steam trap, use a safety factor of 2 or 3 times the normal load depending on the application. Then from the capacity table below select the trap with the required capacity and pressure range. Caution: Oversizing bucket traps, especially on light load applications such as main drips, can cause the trap to lose its seal and pass steam.

Be careful to select the inverted bucket trap with a seat suitable for the maximum pressure differential and with sufficient capacity to handle the load at the minimum expected pressure differential. The trap will not open if subjected to pressures above the orifice rating.


CAPACITY IN LBS. OF CONDENSATE PER HR.

ORIFICE 1 2 13 5 877 90 15 CAT. No.	810 895 895 1000 81-X - 75 812-X - 75 812-X - 75 8100 610 705	3/4" \$2 — 15 \$22 — 15 \$6' - 1700 1920 2110 2370 2810 3220 \$2 — 30 \$2 — 30 \$2 — 30 \$2 — 30 \$2 — 30 \$2 — 30 \$2 — 30 \$2 — 30 \$2 — 30 \$2 — 30 \$2 — 30 \$2 — 30 \$2 — 30 \$2 — 30 \$2 — 30 \$2 — 30 \$2 — 30 \$2 — 30 \$2 — 30 \$3 — 75 \$2 — 75 \$2 — 75 \$2 — 75 \$2 — 75 \$2 — 75 \$2 — 75 \$2 — 75 \$2 — 75 \$2 — 75 \$2 — 75 \$3 — 75 \$4 — 75 \$2 — 75 \$3 — 75 \$4 — 75 \$2 — 75 \$3 — 75 \$4 — 75 \$4 — 75 \$4 — 75 \$4 — 75 \$5 — 75 \$5 — 75 \$6 — 75	33 — 35 2140 2330 2600 2920 3590 3590 3590 3590 3590 34" 2340 2840 3230 3630 3900 4120 83 — 75 83 — 75 832 — 75 832 — 75 832 — 75 832 — 75	842 — 15 3940 4090 4350 4980 5990 6560 84 — 30 842 — 30 842 — 30 4730 4930 5680 6200	13,200 12,100 = 13,200 14,700 17,800 20,000 85 — 30 852 — 30 10,000 12,100 14,000 12,100 13,600 16,500 18,500 18,500 18,500 18,500
ORIFICE 2 13 5 5 15 15 CAT. No. () ORIFICE 30 CAT. No. () ORIFICE 10 20 30 40 60	812-X = 15 44' 665 715 755 835 960 1040 81-X = 30 812-X = 30 44'' 615 715 810 895 945 1000 81-X = 75 812-X = 75 812-X = 75 810 610 705	822 — 15 %' 1700 1920 2110 2370 2810 3220 822 — 30 822 — 30 822 — 30 822 — 30 822 — 30 823 — 75 824 — 75 825 — 75 826 — 75 827 — 75 827 — 75 828 — 75 828 — 75 828 — 75 828 — 75 828 — 75 828 — 75 828 — 75 828 — 75 828 — 75	832 — 15 2140 2330 2600 2920 3590 3590 833 — 30 832 — 30 832 — 30 34'' 2340 2840 3230 3630 3900 4120 83 — 75 832 — 75 832 — 75 952'' 1970 2500	B42 — 15 %'' 3940 4090 4350 4780 5790 6560 B42 — 30 842 — 30 84150 4930 5680 5200 6720 7140 84 — 75 842 — 75 842 — 75	352 — 1. 1,600 12,100 s 13,200 14,700 77,800 20,000 85 — 30 852 — 30 4,100 12,100 14,000 12,100 18,500 18,500 18,500 18,500 18,500
ORIFICE 2 13 5 5 15 15 CAT. No. () ORIFICE 30 CAT. No. () ORIFICE 10 20 30 40 60	665 775 635 960 1040 81-X - 30 812-X - 30 96" 615 715 810 895 945 1000 81-X - 75 812-X - 75 812-X - 75 810 705	## 1700 1920 2110 2370 2810 3220 ## 1920 2260 2260 2580 2870 3060 3220 ## 175 ## 1250 1600 1850	2140 2330 2600 2920 3590 3590 3590 3590 35900 3477 2340 2840 3230 3630 3900 4120 83 — 75 832 — 75 832 — 75	3940 4090 4350 4980 5990 6560 84 — 30 842 — 30 842 — 30 4930 4930 5680 6720 6720 7140 84 — 75 84 — 75 84 — 75 842 — 75	13,200 12,100 = 13,200 14,700 17,800 20,000 85 — 30 852 — 30 10,000 12,100 14,000 12,100 13,600 16,500 18,500 18,500 18,500 18,500
2 2 3 5 5 15 15 CAT. No. () ORIFICE 45 20 25 30 CAT. No. () ORIFICE	665 715 755 835 960 1040 81-X = 30 812-X = 30 %" 615 715 810 895 895 1000 81-X = 75 812-X = 75 812-X = 75 810 705	## 1700 1920 2110 2370 2810 3220 ## 30 ## 4920 2250 2250 2270 2260 2270 3060 3220 ## 47 3220 ## 47 3250 3260 327	2140 2330 2600 2920 3590 3590 3590 3590 34'' 2340 2840 3230 3630 3900 4120 83 — 75 832 — 75 832 — 75 832 — 75	3940 4090 4350 4780 5790 6560 842 — 30 842 — 30 4730 5680 6720 6720 7140 84 — 75 84 — 75 842 — 75	1,600 12,100 a 13,200 14,700 17,800 20,000 852 30 36,000 12,100 12,100 14,000 17,100 18,500 18,500 18,500 18,500
2 5 5 110 15 20 25 30 40 60 60	715 755 835 960 1940 81-X - 30 812-X - 30 46" 615 715 810 895 945 1000 81-X - 75 812-X - 75 812-X - 75 810 610 705	1920 2110 2370 2810 3220 822 — 30 822 — 30 822 — 30 4920 2260 2260 2870 3060 3220 82 — 75 82 — 75 82 — 75 82 — 75 82 — 75	2330 2600 2920 3590 3590 3590 35900 3630 2840 2840 3230 3630 3900 4120 83 — 75 832 — 75 832 — 75 832 — 75	4090 4350 4980 5990 6560 84 — 30 842 — 30 842 — 30 4930 4930 5680 6720 6720 7140 84 — 75 84 — 75 84 — 75 84 — 75	12,100 = 13,200 14,700 17,800 20,000 85 - 30 12,100 12,100 12,100 13,600 15,600 16,500
5 U11990 13 CAT. No. 10 ORIFICE 15 10 15 20 25 30 ORIFICE 10 20 30 40 60	755 835 960 1940 81-X = 30 812-X = 30 %" 615 715 810 895 945 1000 81-X = 75 812-X = 75 812-X = 75 810 610 705	#2110 2370 2810 3220 #22 — 30 #22 — 30 #4" # #250 #2870	2600 2920 3590 3590 3590 35900 3630 3630 3900 4120 83 — 75 832 — 75 832 — 75 832 — 75	4350 4780 5790 5590 6560 84 — 30 842 — 30 92" 4150 4930 5680 6720 6720 84 — 75 84 — 75 84 — 75 84 — 75	13,200 14,700 17,800 20,000 85 — 30 852 — 30 10,000 12,100 14,000 15,600 18,500 18,500 18,500 18,500 18,500
5 115 121 190 125 0RIFICE 15 10 125 20 225 230 0RIFICE 10 20 30 40 60	835 960 1040 81-X - 30 812-X - 30 96" 615 715 810 895 945 1000 81-X - 75 812-X - 75 812-X - 75 810 610 705	2370 2810 3220 B2 - 30 B22 - 30 46' 4920 2260 2580 2870 3060 3220 B2 - 75 B22 - 75 44'' 1250 1600 1850	2920 3590 9 3900 83 — 30 832 — 30 34" 2340 2840 3230 3630 3900 4120 83 — 75 832 — 75 832 — 75 832 — 75	4780 5790 6560 84 — 30 842 — 30 94" 4150 4930 5680 6720 6720 7140 84 — 75 84 — 75 84 — 75 84 — 75	14,700 17,800 1,20,000 85 — 30 852 — 30 10,000 12,100 14,000 15,600 18,500 18,500 18,500 18,500 19,860
ORIFICE 10 20 20 30 40 60	960 1040 81-X = 30 812-X = 30 96" 615 715 810 895 945 1000 81-X = 75 812-X = 75 82" 500 610 705	2810 3220 822 — 30 822 — 30 46" 4920 2260 2580 2870 3060 ± 3220 82 — 75 822 — 75 824 — 75 825 — 75 826 — 75 827 — 75	3590 9 3900 83 — 30 832 — 30 34" 2340 2840 3230 3630 3900 4120 83 — 75 832 — 75 832 — 75 832" 1970 2500	5990 3 6560 3 844 — 30 842 — 30 92" 4150 4930 5680 6720 6720 84 — 75 84 — 75 84 — 75 84 — 75 84 2 — 75	17,800 1,20,000 85 — 30 852 — 30 10,000 12,100 14,000 15,600 18,500 18,500 18,500 18,500 18,500 18,500
DRIFICE 5 10 125 20 25 30 20 30 40 60	81-X - 30 812-X - 30 812-X - 30 615 715 810 895 945 1000 81-X - 75 812-X - 75 82'' 500 610 705	3220 822 — 30 822 — 30 9467 1920 2260 2580 2870 3060 2 3220 82 — 75 822 — 75 824 — 75 825 — 75 826 — 75 827 — 75	83 — 30 83 — 30 832 — 30 34" 2340 2840 3230 3630 3900 4120 83 — 75 832 — 75 832 — 75 832 — 75	6560	20,000 85 30 852 30 4" 10,000 12,100 44,000 37,100 37,100 38,500 37,100 38,500 37,100 38,500 37,100 38,500
CAT. No. 10 10 15 20 25 30 CAT. No. 10 0RIFICE 10 20 30 40 60	81-X - 30 812-X - 30 815 715 810 895 975 1000 81-X - 75 812-X - 75 82'' 500 610 705	B2 — 30 B22 — 30 B22 — 30 1920 2260 2580 2870 3060 ± 3220 B2 — 75 B2 — 75 B22 — 75 B21 — 75 B22 — 75	83 — 30 832 — 30 %'' 2340 2840 3230 3630 3900 4120 83 — 75 832 — 75 832 — 75 832 — 75	84 — 30 842 — 30 92" 4150 4930 5680 6200 6720 7140 84 — 75 842 — 75	85 — 30 852 — 30 4" 10,000 12,100 44,000 315,500 37,100 316,500 385 — 77 852 — 77 9,860
ORIFICE 49 15 10 15 20 25 30 ORIFICE 10 20 30 40 60	810 895 895 1000 81-X - 75 812-X - 75 812-X - 75 8100 610 705	822 — 30 34° 4 1920 2260 2870 3060 3220 3220 34" 1250 1600 21850	832 — 30 34" 2340 2840 3230 3630 3900 4120 83 — 75 832 — 75 1970 2500	842 — 30 ½" 4150 4930 5680 6200 6720 7140 84 — 75 842 — 75 3840	852 — 30 10,000 12,100 14,000 15,500 16,500 18,500 18,500 18,500 18,500 18,500 18,500 18,500
5 10 15 20 25 30 CAT. No. • ORIFICE 10 20 30 40	815 715 810 895 945 1000 81-X - 75 812-X - 75 500 610 705	3060 ± 3220 B2 75 B22 75 1250 1600 ± 1850	2340 2840 3230 3630 3900 4120 83 75 832 75 832 75 82" 1970 2500	4150 4930 5680 6200 6720 7140 844 75 842 75	12,100 44,000 \$41,500 17,100 18,500 18,500 18,500 18,500 18,500 18,500 18,500 18,500
5 10 15 20 25 30 CAT. No. • ORIFICE 10 20 30 40	815 715 810 895 945 1000 81-X - 75 812-X - 75 500 610 705	3260 2580 2870 3060 3220 3200 300 3	2840 3230 3630 3900 4120 83 75 832 75 832 75 1970 2500	4930 5680 6200 6720 7140 844 — 75 842 — 75 3840 &	12,100 44,000 \$41,500 17,100 18,500 18,500 18,500 18,500 18,500 18,500 18,500 18,500
10 115 20 25 30 CAT. No. • ORIFICE 10 20 30 40 60	715 810 895 945 1000 81-X - 75 812-X - 75 500 610 705	2580 2870 3060 3220 82 75 822 75 4" 1250 1600 2 1850	3230 3630 3900 4120 83 75 832 75 832 75 1970 2500	5680 6200 # 6720 7140 # 8 842 — 75 842 — 75	14,000 15,500 17,100 18,500 18,500 18,500 18,500 18,500 18,500 18,500 18,500
20 25 30 CAT. No. • ORIFICE 10 20 30 40 60	895 1000 81-X -75 812-X -75 500 610 705	82 — 75 82 — 75 82 — 75 82 — 75 82 — 75 82 — 150 1600 1850	3630 3900 4120 83 75 832 75 32" 1970 2500	6200 6720 7140 683 75 842 75 75 3840 8	- 15
25 30 CAT. No. (*) ORIFICE 10 20 30 40 60	945 1000 B1-X - 75 B12-X - 75 \$2" 500 610 705	3220	83 75 832 75 832 75 1970 2500	6720 7140 %8 842 75 842 75	#7,100 #18,500 #85 — 7 #52 — 7 */4" 9,860
CAT. No. (*) ORIFICE 10 20 30 40 60	81-X - 75 812-X - 75 92" 500 610 705	3220 45 46 82 - 75 822 - 75 1250 1600 - 1850	#120 #33 — 75 #32 — 75 #2" 1970 2500	7140 % B4 — 75 B42 — 75 36" 3840 ×	85 — 7 852 — 7 852 — 7 7/4" 9,860
CAT. No. P ORIFICE 10 20 30 40 60	##ICE				
ORIFICE 10 20 30 40 60	812-X — 75 ⅓2'' 500 610 705 770	3250 1600 1850	\$32 — 75 ½" 1970 \$ 2500	%" 3840 X	852 — 7. %'' 9,860
ORIFICE 10 20 30 40 60	₩2" 500 610 705	1250 1600 1850	1970 2500	3840 😮	9,860
10 20 30 40 60	500 	1250 1600 1850	1970 2500	3840 😮	9,860
20 30 40 60	610 705 7770	1600 2 1850	2500	4720	C105944 A 244 1 1 20
30 40 60	705 770	量 1850	The state of the s	79.50	12,400
. 40 . 60	770		- TO TO THE RESERVE OF THE PARTY OF THE PART	5470	13,900
60		A ST STATE OF THE	3120	6080	15,200
The same of the sa		A STATE OF THE STA	3540	7150	17,900
	The state of the s	2550 , 90	3960	7570	19,200
CAT. No.					
ORIFICE 3	15 16 16 CO	136"	4"	**************************************	35"
20	446	1100	2080	4450	10,800
40	600	1440	2600	5530	13,500
60	695 × 1	1700	3020	\$1.6350 PM	15,600
80 -	765	1900	3380	7110	17,100
100	830	2080	3640	7750	18,900
125	920	2240	4100	8540	20,000
CAT. No.	And the second s	The state of the s			
ORIFICE	* %"		Annual Control of the		Contraction of the Contract of
60			10 10 10 10 10 10 10 10 10 10 10 10 10 1	The second secon	
** BO		A STATE OF THE PARTY OF THE PAR	-	Designation of the state of the last of th	
100		A SHARE FOR THE OWNER OF THE PARTY.			THE RESERVE AND ADDRESS OF THE PARTY OF THE
125					
			The state of the s	-	THE RESERVE AND ADDRESS OF THE PARTY OF THE
1 DIN	867	2220	3780	6300	
100	The second secon	00 000	B3 - 250	BA SEPARA	A P OF THE REAL PROPERTY.
CAT. No.		B22 - 250	B32 250	B42 — 250	852 - 25
e a sala	B12-X - 250	B22 - 250	B32 250	B42 — 250	852 - 25
CAT. No.	812-X - 250	822 — 250 %4" 1825	832 — 250 %"	B42 — 250	852 — 25 %"
CAT. No.	.070" 562	822 — 250 %4" 1825	832 — 250 %" 2760	842 — 250 ¼" 4730	852 — 25 %" 15,000
ORIFICE 125 150 175	.070" 562 600 630	342 — 250 342 — 1825 1940 2060 —	2760 2910 3120	4730 4780 5130	852 — 25 %" 15,000 16,100
CAT. No. • ORIFICE 125	.070" 562 600	822 — 250 %4" 1825 1940	832 — 250 %" 2760 2910	#42 — 250 #4" 4730 4980 5130 5500	852 — 25 %" 15,000 16,100 16,800 47,800
The second secon	40 60 80 100 125 CAT. No. ♦ ORIFICE 60 100 125	40 600 600 600 600 600 600 600 600 600 6	40 600 1440 60 695 1700 80 765 1900 100 830 2080 125 920 2240 CAT. No. ▶ B1-X −180 B2 −180 B12-X −180 B22 −180 ORIFICE ½"' ½"' 60 585 1500 100 703 1600 125 765 1940 150 816 2100	40 600 1440 2600 60 60 60 60 60 60 60 60 60 60 60 60	40 600 1440 2600 16530 60 60 605 1700 3020 416350 60 60 695 1700 3020 416350 60 60 695 1700 3020 416350 60 60 695 1700 3380 1710 60 60 60 60 60 60 60 60 60 60 60 60 60

No in AIL Jose Will Algoria in Algoria Algoria Algoria

de seu si

500 83-3



DE	SCRIPTION:
	Circuit
	Setters
	Tab page did not contain hand written information
Ď	Tab page contained hand written information *Scanned as next image

TYPE MPP-G & MSS-G METERED BALANCE MASTER RATINGS 300 psig 250°F/20.7 bar 121°C





When precise flows must be supplied and maintained to any piece of terminal equipment or zone, the Spirax Sarco Metered Balance Master enables you to supply this need. To the many fine features of our Balance Master (calibrated dial, stop-balancing features, pre-set flow) we have now added the ability to measure the precise flow going through the valve. This is accomplished by a differential meter that measures the pressure drop across the valve. A simple graph then converts that reading to flow. The Metered Balance Master and the Meter are equipped with "quick connectors" for quick-easy use. All measurements are made with the system in operation — no shut down is required.


And once the Metered Balance Master is set it will always return to the same flow after a shutdown.


All include wheel handle.


					DIMENSI	31/E			
TYPE	Siza	Α		.9	C	D.	E	F	G
HPAG	1//2	23/3/3/6	32/16	1 7,416	1.11/32	1 11/42	1 1/12		-87e - 1
MPP.G	*3/4	27/37/16	3 3/16	19//6	1.172	1.172	1.19%	2 1 /8	18/18
IMPP/G		3.1/12	31/2	1 111746	1.5/4	1 8 Hr	1-1/2	2.174	. Heyes
Miles G	1.274	3857/8	4	1 1/13	31315716	1/16746	1148	2.3/8	778
MPP-G	111/		45 27/2	12.41/16	.294S	2.076	1.172	2.5/8	77.8
: 3MPP (G	2	1-	6506	2.1/2	2/9/16	29/36	1372	27/8	7/8
MSS-G	137	2 13/16	0.000 G	1,1116	45766	1646/62	1 172		578
e (Misjs∤a	874	245946	.e	3.5971(6)	√ ₹/ Δ	1.814	JEE W.	1200/8	. } € <i>1</i> Į.












DE	SCRIPTION:
	girainers
	Tab page did not contain hand written information
	Tab page contained hand written information *Scanned as next image



CAST IRON FLANGED TYPE STRAINERS





WORKING	PRESSURES -	NON SHOCK
大学 - 大学の大学を	Saturated Steam	Cold Water, Oll, Gas
#751 To 12" 14"-24"	125 PSI @ 450°F 100 PSI @ 353°F	200 PSI @ 150°F 150 PSI @ 150°F
14 '-24"	250 PSI @ 450°F	500 PSI @ 150°F 300 PSI @ 150°F
#751-8W to 12" #751-HC 14'524"	not recommended	175 PSI

BERVICE RECOMMENDATIONS: Used extensively to strain foreign matter from pipe lines and provide inexpensive protection for costly pumps, meters, valves, and similar mechanical equipment.

SCREENS: Normally furnished made from heavy gauge perforated stainless steel sheet, re-inforced in larger sizes for liquid service. 3/64" perforations usually furnished for steam service in sizes through 10"; 1/16" perforations for larger sizes in steam service. Strainers for liquid service usually furnished with 1/16" perforation in sizes through 4" and 1/8" perforations are available. For services requiring extremely fine straining we suggest 5/32" perforated metal screens lined with an appropriate wire mesh. See page B-3.



MUELLER BREECH-LOK" STRAINERS

Furnished as standard in sizes 8" and larger. A one-quarter turn securely locks the screen in its seat and frees the servicemen for bolting the cover flange to the body of the streiner.

CONSTRUCTION: All 751 type strainers feature machined seats in both the body and cover flange for secure screen retention. Cover flanges for the #751-SW are light enough for easy handling -- the hinge arrangement on the #751-HC minimizes the inconvenience of servicing large strainers. O-ring sealed cover flanges are available.

SELF CLEANING is done by opening the valve or plug connected to the blowoff outlet. Advise when strainers are to be mounted in vertical piping; we can rotate the cover bringing the blowoff to the lowest point.

BLOWOFF OUTLETS: Tapped NPT, sizes specified below. Not normally furnished plugged.

CAPACITY: These strainers have screens with open areas many times greater than the corresponding pipe size and thereby reduce pressure loss to a minimum. Dependent upon the selection of perforations, ratios as great as six to one are available.


PRESSURE DROP: See charts, page C-1.

GALVANIZED STRAINERS available from stock in all SIZAS.

INDIVIDUALLY HYDROSTATICALLY TESTED


MATERIAL: Cast Iron ASTM A126-B

	SIZE	1-1/2"		2.119	3"	3-1/2"	4.	5	8.	8"	10"	12"	14"	16"	18"	20"	24"
	Season 751 way	7 1/2	0	1012	12	13 3/8	14 8/16	16 7/8	18.34	24	27 6/8	32 1/4	37 1/4	42 3/8	46 1/6	84 1/2	55 34
	762	8 1/18	9 5/16	11 176	12 5/9	14.3/8	15 5/8	18 1/4	20 3 18	25 1/8	29 1/8	33 3/4	38 34	44 1/8	47 34	56	57 34
-	761-SW	7 1/2	9 1.9	10.12	12		14 9/16	16 7/8	18 3/4	24	100						-
	751-HC	/ 1/4	2 0 114	1	1		Broadwale Chin and Laure				27 5/6	32 1/4	37 14	42 38	48 1/6	54 1/2	55 34
0	751.752.7614C	4 3/4	6	7 189	918	9	10 7/8	12 15/16	14 17	16 7/16	19 1/4	22 7/3	26 1/2	29 5/8	36 11/16	40 1/2	44 1/16
0	751-SW	7	6 1/4	8.3*	11		13	16 1/8	17 74	18 1/2							
C		1/2	1/2	1	1 1/4	114	1 1/2	2		2	2	2	2	2	1 3	2	2
-	75.1	13	23	37	45	36	76	1.8	176	26	346	716	803	1380	2272	2512	4018
NI.	78	24	26	AC.	5.9	76	93	146	164	-316	475	760	906	1135	24,00	3350	4706
	751-SW	22	26	42	40		106	142	1.38	255							
	751-HC				*					K HOLE	420	706	860	1060	2120	3020	4080
-	in Area sq in.	-	30		1 54	75	95		7.78	397	577	796	1093	1409	1810	229.)	2859





SELF CLEANING "Y" TYPE SCREWED END STRAINERS



#11

1/4" THROUGH 4"

4" equipped with bolted cover




#11-FCB


SIZES THROUGH 2"



#11-BC

2"-214" AND 3"





EXTRA HEAVY
IRON BODY

WORKING PRESSURES - NON-SHOCK

Steam Water Oil Gen

250 PSI @ 400°F.

Water-Oil-Gas 400 PSI @ 150°F

SERVICE RECOMMENDATIONS: Used extensively to strain foreign matter from pipe lines and provide inexpensive protection for costly pumps, meters, valves and other similar mechanical equipment. The #11-FCB features a bronze, straight threaded and gasketed cap which can be removed for cleaning. The #11-BC provides the same features with a botted cover. The #11-FCB is available in sizes through 2" and the #11-BC is stocked in 2", 2 ½" and 3" sizes.

screens: 20 mesh stainless steel screens (1/32" openings) usually furnished in all sizes through 2" for water service and 30 mesh (1/50" openings) for steam service in those sizes. 2½", 3" and 4" strainers furnished with perforated stainless steel screens, 3/64" openings for steam and 1/16" openings for water. The #11-FCB supplied with 20 mesh sinless steel screens for water service and 30 mesh for steam service. #11-BC normally supplied in all sizes with perforated stainless steel screens, 3/64" openings for steam and 1/16" for water. A large variety of perforated metals and wire mesh screens other than those normally furnished are available, see page 8-3.

CONSTRUCTION: All sizes feature a machined seat in the body, designed to make the screen self aligning and at the same time holding the screen securely in place by a straight threaded and gasketed cap. The 4" size features a flanged blowoff cap, similar to those used with our flanged "Y" strainers.

FEATURES: The machined seats in both the body and cap allow easy assembly and disassembly. The alternative is a strainer which employs a pipe bushing to lock the screen in place which will likely deform the screen, allowing sediment to bypass the strainer.

SELF CLEANING is accomplished by opening the valve or plug connected to the blowoff outlet.

BLOWOFF OUTLETS: Tapped NPT, sizes specified below. Not normally furnished plugged.

CAPACITY: Generously proportioned bodies, with screens that have an open area many times greater than the corresponding pipe size, insure low pressure loss.

PRESSURE DROP: See charts, page C-1.


GALVANIZED STRAINERS: Available from stock in all sizes.

INDIVIDUALLY HYDROSTATICALLY TESTED.

MATERIAL: Cast Iron ASTM A-126 Class B.

DIMENSIONS AND WEIGHTS - APPROXIMATE APPLY POR CERTIFIED DEAWING

	SIZE	1/4"	3/8	1/2"	3/4"	1"	1-1/4"	1-1/2"	2"	2-1/2"	3"	4"
	11	3 13/16	3 13 16	3 13 16	4 3 4	5 7/16	6 5/16	7 1/2	8 1/8	10 1/2	12 1/2	15376
A	11-FCB			3 13 16	434	5 7/16	6 5/16	7 1/2	8 1/8			
	11-BC								7 13 16	12	12	
	11	2 3/16	2316	2 3 16	2 7/8	3 1/4	3 3/4	4 11/16	5 1/2	6 5/8	6 7/8	11 1/4
В	11-FCB			2316	2 7/8	3 1/4	3 3/4	4 11/16	5 1/2			
	11-BC								6	8 3/4	8 34	
	11	3/8	3.5	3.8	1 12	3/4	3/4	1	1 1/4	1 1/2	1 1/2	112
C	11-FCB			3.8	1 12	3/4	3/4	1	1 1/4			
	11-8C								1	1	1	The second
	11	1/4	1 1/2	1 44	1 234	4	6 1/4	10 1/2	15	25	36	70
Weight	11-FCB .			2	2:0	4	612	10 1/2	15 1/2			
	11-BC			F. Carlotte					16	47	47	



DE	SCRIPTION:
	Values
	Tab page did not contain hand written information
	Telemontined hand weitten information
Ж	Tab page contained hand written information *Scanned as next image

Bronze Gate Valves

MATERIAL

Hammond industrial bronze gate valves class 125 and class 150 pressure-containing parts are cast of ASTM B-62 bronze alloy. Class 200, class 300 and class 350 pressure-containing parts are cast of ASTM B-61 bronze alloy.

WHERE TO USE GATE VALVES

- For fully-open or fully-closed service. NOT FOR THROTTLING
- · For minimum line-pressure drop.
- · For minimum fluid entrapment in the line.
- · For relatively infrequent operation.

STEM AND DISC SELECTION GUIDE

Rising stem, so id wedge disc valves, simplest and most widely used gate valves offer four mor advantages:

- · Operator can determine at a glance whether the valve is open
- · Stem threads are out of the fluid flow when fully open and protected by the back seat.
- · Solid wedge disc valves most successfully handle viscous fluids. Recommend d for steam service.
- · Can be installed with stem in any position.

Rising stem, double disc (or split wedge) valves also have the advantage of easy readability for open or closed. In addition they:

- · Are recommended for non-condensing gases and liquids at normal temperatures. NOT FOR STEAM SERVICE.
- · Can adjust to the seating surface even though one-half of the disc is out of alignment due to foreign matter between the seat
- · Can remain pressure-tight despite slight distortion of the valve
- · Should be installed with stem vertical only

Non-rising Stem Valves

- · Usur y installed where space is limited.
- · Usu. ly shorter-lived than rising stem because stem threads are always in contact with the fluid.

BONNET SELECTION GUIDE

Union bonnet gates:

- · Easily dismantled without risk of injury to body-bonnet bearing
- · Stronger because of their heavy union nut.
- Safer no danger of bonnet being screwed off in normal operation.


Inserted bonnet gates are lower priced but are not recommended when pressure and temperature extremes are likely.

CLASS 125

IB610

Features:

- Threaded Ends
- · Quick Open Cam Action
- . Sizes 1/2" thru 2"




Oil or Gas

CLASS 125

IB635

Features:

- Solder Ends
- Threaded Bonnet
- Rising Stem
- Solid Wedge
- Integral Seat
- Maileable Iron Handwheel
- Meets WWV54, Type II. Class A
- Meets MSS SP-80
- · Sizes 3/8" thru 3"




125 psi Steam to 406°F 200 psi Non-Shock Cold Water, Oil or Gas

CLASS 125


IB640 .


Features:

- Threaded Ends
- Threaded Bonnet
- · Rising Stem
- Solid Wedge
- · Integral Seat
- Malleable Iron Handwheel
- Meets WWV54. Type II. Class A
- Meets MSS SP-80
- · Sizes 1/2" thru 3"



125 psi Steam to 406°F 200 psi Non-Shock Cold Water. Oil or Gas








Class 125 Bronze Gata Valve Screwed Bonnet-Ricing Stem Selid Wedge Disc Salder Ends

2-85

RATING

125 PSI Steam To 400°F 200 PSI Non-Sheck Cold Water, Olf or Gas Federal Specification WW-Y-54 Type II, Class A MSS SP-80



DIMENSIONS IN INCHES

SIZE	A	В	3	0
3/8	2-1/4	5	2	11/16
1/2	1-29/32	5-1/16	2	1/2
3/4	2-15/32	6-9/32	2-3/8	3/4
1	2-13/16	7-1/4	2-3/4	29/32
1-1/4	3-5/32	8-1/2	3	31/32


SIZE	A	В	C	D
1-1/2	3-9/16	10-1/16	3-1/2	1-3/32
2	41/8	12-1/16	4	1-11/32
2-1/2	5-1/4	15-15/32	5 1/4	1-5/8
3	6-1/16	18	6	1-7/8

MATERIAL SPECIFICATIONS

1	Handwheel Nut	Steet	
2	Identification Plate	Aluminum	
3	Handwheel	Malicable Iron	ASTM A-47 (32510)
4	Stem	Cast Bronze	ASTM 8-62
5	Packing Nut 36"-1"	Brass Rod	ASTM 6 16
	11/4"-3"	Cast Bronze	ASTM B 584 Alloy 844

5	Gland Follower	Sintered Brass	ASTM 8-282 Type 1
7	Packing Ring	Teffon - Asbestos	
	Bonne!	Cast Bronze	ASTM B-62
9	Body	Cast Bronze	ASTM B-62
10	Disc	Cast Bronze	ASTM B-62





Class 125 Bronze Gate


HAMMOND IB640

Class 125 Bronze Gate Valve Screwed Bonnet - Rising Stem Solid Wedge Disc Threaded Ends

2-85

RATING

125 PSI Steam To 406°F 200 PSI Non-Shock Cold Water, Oil or Gas Federal Specification WW-V-54 Type II, Class A MSS SP-80



DIMENSIONS IN INCHES

SIZE	A	В,	C
1/4	1-29/32	5	2
3/8	1.29/32	5	2
1/2	2-1/16	5-1/16	2
3/4	2-3/16	6-9/32	2.3/8
i	2-7/16	7-1/4	2-3/4


SIZE	A	8	C
1-1/4	2.25/32	8-1/2	3
1-1/2	2-29/32	10-1/16	3 1/2
2	3-5/32	12-1/16	4
2-1/2	4-11/16	15-15/32	5-1/4
3	5-1/8	18	6

MATERIAL SPECIFICATIONS

Handwheel Nut	Steel	
Identification Plate	Aluminum	100
Handwheel	Malleable Iron	ASTM A-47 (32510)
Stem	Cast Bronze	ASTM 8-62
Packing Nut	Brass Rod Cast Bronze	ASTM 8-16 ASTM 8-584 Alloy 844

6	Gland Follower	Sintered Brass	ASTM B-282 Type !
7	Packing Ring	Teffon - Asbestos	
8	Bonnes	Cast Bronze	ASTM 8-62
9	Body	Cast Bronze	ASTM 8-62
10	Disc	Cast Bronze	ASTM B-62









Submittal Data Information Pressure Reducing Valves, Dual Controls and Pressure Relief Valve

101-005

Numbers: 329, 3291, 335, 334, 3341 and 333 SUPERSEDES: SD100-2.2


JOB: VARIOUS BLOG (BS5548) NEW RIVER, M. CAS

PRESSURE REDUCING VALVES - 329 AND 335


PURPOSE: To automatically feed water to a hot water heating system whenever pressure in the system drops below the pressure setting of the valve


FEATURES: • Fast fin rate on all models


- · Pressure setting adjustment separated from fast fill lever for easy, fast adjustment
- Built-in check to prevent emptying system if incoming pressure fails
- System pressure adjusting range 10 to 25 PSI












PRODUCT	CONSTRUCTION		MUMIXAM	MAXIMUM	DIM	ENSIONS, INC	CHES	SHIPPIN	S WI/LB.	
NO.	MAJERIAL	CONNECTION	SUPPLY SIDE PRESSURE	TEMPERAJURE	Α	В	С	EA.	CTN.	
329	CAST IRON	15" (15MM) NPT & SWEAT			4¼ (108MM)	3¾ (95MM)	1% (35MM)			
3291	CAST IRON	½" (15MM) NPT	200 PSI (1380 KPA)	212°F (100°C)	4% (111MM)	3¾ (95MM)	1% (35MM)	2.4 (1.1 KG)	30 (14 KG)	
335	BRONZE	%" (20MM) NPT				3¾ (95MM)	3¾ (95MM)	1% (35MM)		eresponential tale

Quality Through Design — COMPARE.



Bronze Check Valves

Check valves are used to check or prevent backflow in lines. Line pressure forces the disc to open and allow flow in the direction desired. When pressure drops, gravity and line back-pressure close the disc, preventing backflow.

MATERIAL

Hammond industrial bronze check valves class 125 and class 150 pressure-containing parts are cast of ASTM B-62 bronze alloy. Class 300 and class 350 pressure-containing parts are cast of ASTM B-61 bronze alloy.

SWING CHECK VALVES

Swing check valves are used:

- . To control direction of flow and for quick, automatic reactions to flow change.
- · For minimum resistance to flow.
- · Some Hammond bronze swing check valves offer T-pattern design; others offer Y-pattern design, regrinding, with free floating hinge pin.

Swing check valves are recommended for use in conjunction with gate valves. They should not be used in a rapid cycling system i.e., with a reciprocating pump, or for air compressor service where they could cause chatter and damaging vibration.

LIFT CHECK VALVES

Lift check valves differ from swing check valves in that their flow characteristics are the same as globe valves, with a resultant increased pressure drop. They are generally used in conjunction with globe valves, and are recommended for use with reciprocating pump and air compressor systems.

Check valves equipped with TFE discs are recommended for the following services:

- · For water service where foreign matter such as dirt or sand may be in the line. Soft disc protects the seats.
- For positive shutoff at low line pressure.
- For quieter operation where noise might be objectionable.

CLASS 125

Threaded Ends

Bronze Disc

T-Pattern

IB904

Features:

- Meets WV51, Type IV, Class A
- Meets MSS SP-80
- · Sizes 1/4" thru 2"





125 psi Steam to 406°F 200 psi Non-Shock Cold Water, Oil or Gas

*Warning - Do not use for reciprocating air compressor service.


CLASS 125

Threaded Ends

Y-Pattern

IB940 ·

- Renewable Bronze Disc



- Meets MSS SP-80
- Sizes ¼" thru 3"





125 psi Steam 406°F 200 psi Non-Shock Cold Water, Oil or Gas

*Warning - Do not use for reciprocating air compressor service.

CLASS 125

IB942

Features:

- Threaded Ends
- Y-Pattern
- TFE Disc
- Meets MSS SP-80
- Sizes 1/2" thru 2"





Solder Ends

LASS 125

- T-Pattern
- Bronze Disc

Features:

- . Meets WWV51, Type IV, Class A
- Meets MSS SP-80
- · Sizes 3/4" thru 2"





IB912

125 psi Steam to 406°F 200 psi Non-Shock Cold Water, Oil or Gas

*Warning - Do not use for reciprocetting air compressor service.

CLASS 125


IB941

- · Solder Ends
- · Y-Pattern
- · Renewable Bronze Disc

Features:

- Meets WWV51, Type IV, Class A Meets MSS SP-80
- . 3/8" thru 3"





125 psi Steam to 406°F 200 psi Non-Shock Cold Water, Oil or Gas

*Warning - Do not use for reciprocating air compressor service.

CLASS 150

Features:

- Threaded Ends
- Y-Pattern
- · Renewable Bronze Disc
- Meets MSS SP-80
 Sizes ¼" thru 3"






125 psi Steam to 406°F 200 psi Non-Shock Cold Water, Oil or Gas

*Warning - No not use for reciprocating air compressor service

125 psi Steam to 406°F 200 psi Non-Shock Cold Water, Oil or Gas

. Warning - Do not use for reciprocating air compressor service.



Class 125 Bronze Swing Check




Class 125 Bronze Swing Check Valve With Bronze Disc Selder Ends

2-85

RATING

125 PSI Steam To 406°F 200 PSI Non-Shock Cold Water, Oll or Gas Federal Specification WW-V-51 Type IV. Class A MSS SP-80

Warning - Do not use for reciprocating air compressor service.



DIMENSIONS IN INCHES

SIZE	A	B	C
3/8	2.9/16	1-17/32	3/8
1/2	2.9/16	1-17/32	1/2
3/4	3-5/16	1-3/4	3/4
1	4-1/16	2-1/32	29/32
1-1/4	4-5/16	2-3/16	31/32


SIZE	A	В	C
1-1/2	4-15/16	2-1/2	1-3/32
2	5-7/8	2-7/8	1-11/32

MATERIAL SPECIFICATIONS

1	Bonnet	Cast Bronze	ASTM 8-584 Alloy 844
2	Body	Cast Bronze	ASTM 8-62
3	Hinge	Cast Bronze	ASIA 8 584 Alloy 844
4	Disc Nut	Brass Rod	ASTM 8 16

5	Disc	3/4 .3/4 .	Brass Rod	ASTM B-16
		1"-2"	Brass Rod Cast Bronze	ASTM B 62





DESCRIPTION: Bacil Flow Preventors Tab page did not contain hand written information Tab page contained hand written information *Scanned as next image

WILKINS

HWS-HWR-CW WHATER MAKE-UP

BACKFLOW PREVENTERS REDUCED PRESSURE PRINCIPLE

MODEL 575

Sizes 3/4" - 2"



FEATURES

LOW HEAD LOSS

- Exceeds all standards
- Lowest in industry

LOW MAINTENANCE COSTS

- No special tools required to service units
- Few moving parts
- In-line serviceability

COMPACT SIZE

Easy to install

CAST BRONZE MAINCASE

Sturdy, durable, corrosion resistant

POPPET TYPE CHECK VALVES

- Independently operated
- Spring loaded, stainless steel springs
- Corrosion resistant

HYDRAULICALLY ACTUATED RELIEF VALVE

Discharges backflow to atmosphere

PERFORMANCE

Witkins' Model 575 Reduced Pressure Backflow Preventers EXCEED the requirements of AWWA, for flow rates and head loss and are fully approved by U.S.C. Research Foundation, IAPMO, ASSE and C.S.A.

Head loss is the lowest in the industry.

Proper performance is dependent upon the user adhering to recommended installation procedures, and having licensed, qualified personnel perform regular, periodic inspection and maintenance.

Two shut-off valves and four test cocks are provided for testing. All Model 575 devices can be disassembled and repaired without removing the unit from the line.

APPLICATION

The Model 575 has been designed for installation in potable water lines where a potential heath hazard exists.

Wilkins' low head loss makes the device most suitable where system pressures are low or where it is important to hold pressure loss to a minimum.

CONSTRUCTION

Witkins' Model 575 Reduced Pressure Backflow Preventer consists of a main body with two check valves and a connecting external pressure relief valve located between the two check valves. Check valves are spring loaded and operate independently. The relief valve functions automatically by sensing the pressure differential across the first check valve and discharges backflow to atmosphere in the event the check valves become damaged or fouled. Springs are made of stainless steel and all other component parts are made of corrosion resistant material.

WARRANTY

Wilkins' Backflow Preventers are warranted against defects in material and workmanship for a period of one year from date of shipment strictly in accordance with Wilkins' Certificate of Limited Warranty.


All Model 575 Backflow Preventers manufactured by Wilkins contain only Wilkins authorized parts. Replacement of any part of the Model 575 Backflow Preventer with a part other than a Wilkins' authorized part immediately voids Wilkins' Limited Warranty.

Certificates of Limited Warranty are available upon request

CAUTION

Installation and Maintenance

All Model 575 Backflow Preventers should be installed and maintained only by licensed personnel. Proper performance is dependent upon regular inspection and maintenance. These should be performed in accordance with Wilkins' specifications and instructions and prevailing governmental and industry standards and codes.



SPECIFICATIONS

The Reduced Pressure Backflow Preventer shall consist of a connecting pressure differential relief valve located between two independently operated spring-loaded poppet type check valves. The maincase shall be of bronze and consist of four test cocks which provide for in-line testing and maintenance. Stainless steel springs and corrosion resistant materials shall be used through-out. Head loss characteristics shall be at least equal to Wilkins' Model 575.

APPLICATION

Designed for potable water systems where a potential health hazard exists.

TEMPERATURE RANGE

33°F - 140°F

MAXIMUM OPERATING PRESSURE


150 PSI


MATERIALS

All corrosion resistant

PRESSURE LOSS AT MAXIMUM ALLOWABLE FLOW RATE: (ASSE & USC) STANDARD

SIZE	MAX. FLOW RATE	PRESSURE LOSS
3/4"	30 GPM	9.3 PSI
1"	50 GPM	8.4 PSI
11/4"	75 GPM	8.2 PSI
11/2"	100 GPM	7.4 PSI
2"	160 GPM	8.4 PSI





Additional flow capacity available within allowable pressure loss.

NOTE: 13.5 PSI MINIMUM NET INLET PRESSURE IS REQUIRED TO INITIATE FLOW.

Damage to the device could result wherever water hammer and/or water thermal expansion could cause excessive line pressure. Where this could occur shock arrestors and/or pressure relief valves should be installed downstream of the device.

OPTIONS

SIZES

3/4", 1", 14", 11/2", 2"

GATE VALVES

Specify: With Gates or

POPPETS

Synthetic polymer

CONNECTIONS

Screwed

SENSING LINES

Sizes 3/4" & 1" - Internal


Sizes 11/4" - 2" - External

DIMENSIONS

		DIMENSIONS (inches)					
SIZE		В	С	D	E	F	lbs.
3/4	113/8	81/2	31/2	5	31/2	7	20
1	113/8	81/2	31/2	5	31/2	7	21
1521 11/4	161/4	12	4%	6 1/16	33/4	71/4	30
11/2	161/4	12	45/8	71/16	33/4	71/4	30
- 8 2	161/4	12	45/8	85/8	33/4	71/4	35

WILKINS REGULATOR CO.

A Division of Zurn Industries, Inc.



DE	SCRIPTION:
	NIA
	Tab page did not contain hand written information
	Tab page contained hand written information
	*Scanned as next image

SIGHT GLASS

Clear liquid el viewing area. R

Universal indicator element for

Glass resists
pitting and
etching.


Two piece construction
with Parker "O" ring
eliminates leaks.

Leak proof
fused sight glass.
No need for
dust cover.

Copper plated,
furnace
brazed steel
design.

Refrig. piping liquid line

- Available in all popular connections up to 1 1/6".
- Extended copper plated steel fittings permit solder installation without disassembly.
- Compact design, low silhouette, short lay-in length.
- Extremely accurate.
- · Easy viewing.
- U.L. listed for 500 psi working pressure. File No. SA4744.







Model No.	SAE Male Flare Connection Size	Overall Length	Model No.	SAE Male x Female Flare Connection Size	Overall Length	Model No.	ODS Sweat Connection Size	Overall Length	Cut-out Length
PSG-2	1/4"	3.42"	PSG-2MF	V4"	3.05"	PSG-2S	1/4"	4.88"	4.19"
PSG-3	3/8"	3.56"	PSG-3MF	3'8"	3.17"-	PSG-3S	3/8"	4.88"	4.12"
PSG-4	1/2"	3.82"	PSG-4MF	1/2"	3.39"	PS3-49	1/2"	4.88"	3.87"
PSG-5	5/8"	4.06"	PSG-5MF	5/6"	3.69"	PSG-F ;	5/8"	4.88"	3.62"
F3G-5	78	1 4.00	1 00 01111		-	PSG- S	7/8"	6.25"	4.73"
PSG-10T replacement indicator element and "O" ring							11/8"	6.25"	4.45"

Moisture-color indication in PPM at liquid line specific temperatures


System Refrigera	ant	R-12		R-	22	R-502		
Liquid Line Tem		75°F	125°F	75°F	125°F	75°F	125°F	
System Condition-Indicator Color					D-1	Below	Below	
Dry	Green	Below 5	Below 15	Below 30	Below 60	10	30	
Caution	Yellow Green	5-15	15-50	30-110	60-220	10-50	30-120	
Wet	Yellow	above 15	above 50	above 110	above 220	above 50	above 120	

Immediate steps should be taken to protect the system when the moisture indicating element shows "Wet".

The dest protection system available is a Parket Ceramic Filter-Kore Dryer and Parket Suction Line Filter Uryer.

The sight-glass moisture indicator should normally be installed between a Parker


Ceramic Filter Kore Dryer and a refrigerant control device.



DE	SCRIPTION:
	f. ITer
/	Dryer
	Tab page did not contain hand written information
Ď(Tab page contained hand written information *Scanned as next image

FICTER lequid line-Refriq, piping

• UL listed for 2500 psig minimum bursting pressure.



- Unique fiber cup gives greater filtration capacity
- Chemically inert molecular sieve dessicant has greater water capacity
- 100% molecular sieve beads for maximum water pick-up. Approved for R-12, R-22, R-500 and R-502


- Fully welded and atmospherically controlled furnace brazed construction,
- Corrosion resistant paint gives 400 hour salt spray protection.
- Perforated baffle support plates insure rigid internal construction to prevent release of dessicant.

This unique Parker refrigerant dehydrator has the ability to reach very low end-point dryness levels. It is available in a range of sizes for use with the common halocarbon refrigerants.


The fiber cup design, filled with molecular beads, filters out contaminant particles down to 20 microns in size while allowing an unrestricted flow of the maximum amount of refrigerant. This results in the least pressure drop, trouble-free operation, and longer system life. You can virtually forget emergency calls caused by clogged dryers.

The heavy-gauge steel shell is fully welded and brazed in a controlled-atmosphere furnace to withstand pressures, prevent leaks and give longer service life. Available with nickel-plated flare fittings or solid copper solder-type connections. Rated in accordance with ARI Standard No. 710 for liquid-line dryers.

Individually cartoned with protective caps on fittings to keep moisture out and prolong shelf life.



Parker Mfg. Co., Refrigeration Components Group, 2445 S. 25th Ave., Broadview, Ill. 60153 728462



TAB PLACEMENT HERE

DE	SCRIPTION:
	Chemical
	Feeders
	Tab page did not contain hand written information
Ø	Tab page contained hand written information *Scanned as next image

Confidential Records Management, Inc. New Bern, NC 1-888-622-4425 9/08



IMCOR Custom Designed Feeders Are:

Easy to Install

Safe to Use

Suitable for Liquid, Powder, or Briquettes


Maintenance Free

Available in Popular Sizes

Type HV - 2 gallon, and AV - 5 gallon (other sizes available on special order) By-Pass Feeders are equipped with a large 3-1/2" diameter opening. Closing requires only a 1/4" turn for a perfect seal every time, eliminating troublesome fill valves. The cover and "O" ring seal are removed as a unit; however, only when all pressure has been released from the feeder.

All IMCOR Feeders are suitable for hot or cold water applications up to 200 psi working pressure. Feeders are normally furnished without valves and fittings; refer to drawing for these requirements and some suggested piping diagrams.

ANALYSIS - CHEMICALS - EQUIPMENT





Date: August 4, 1987

Issuing Office: Quality Engineering

To: Triangle Automated Controls

6316 Angus Drive Raleigh, NC 27612 Attn: Tony Battista

Subject: Valves for Contract #05-84-4061 Camp Lejeunne

Dear Tony,

The VB-9213, VB-9223 and VB-9313 valves used in valve assemblies on the subject project, are manufactured in compliance to the following standards:

Cast Bronze - Screwed, Flared and Union End Fittings

(VB-9xxx-0-4-Pm VB-111-0-3-P)

Standard: ANSI B16.15-1971

Materials: ASTM B145 Class 4B, 5A or ASTM B62 (4A)

Cast Iron - Flanged End Fittings (VB-9xxx-0-5-P)

Standard: ANSI B16.1-1975

Materials: ASTM Al26 Class B

UL Recognized per UL Standard 429 - Electrically Operated Valves Guide No.: YIOZ2.

Sincerely,


Jack Karch

Supervisor, Quality Engineering

JK/ka

cc: Eddie Wolmarans

(Jay Johnson Co., Inc.)



TAB PLACEMENT HERE

DE	SCRIPTION:
	Temperature
	Control System
	Tab page did not contain hand written information
	Tab page contained hand written information *Scanned as next image

Confidential Records Management, Inc. New Bern, NC 1-888-622-4425 9/08

TEMPERATURE CONTROL SUBMITTAL

JOB: REPLACE AIR CONDITIONING UNITS VARIOUS BUILDINGS MARINE CORPS AIR STATION, NEW RIVER, N.C. CONTRACT # N62470-86-B-5548


ARCHITECT:

ENGINEER: CHEATHAM AND ASSOCIATES

CONTRACTOR: HUMPHREY HEATING AND ROOFING

Submitted by:

TRIANGLE AUTOMATED CONTROLS, INC.
2716 Discovery Drive
Raleigh, North Carolina 27612
(919)878-8015




JOB: CONTRACT# n62470-86-B-5548
REPLACE AIR CONDITIONING UNITS
VARIOUS BUILDINGS
MCAS, NEW RIVER, N.C.

EQUIPMENT SCHEDULE

Job #: A-024/J-024

PAGE: 1 of 3 DATE: 1/23/88

QNTY.	IDENTIFIER	PART NUMBER	MANUFACTURER	DESCRIPTION	LOCATION
1	SPACE	TC-1103-500	Building AS-202 Barber Colman	Space cooling thermostat, 2 pos.	In space
1	SUBBASE	AT-603	Barber Colman	Subbase switch for fan AUTO/ON	At space thermostat
1	TS-1	T S−8501	Building AS-205 Colman	O.A. temperature sensor	Element in O.A.
1	TS-2	TS-8201	Barber Colman	H.W.S. temperature sensor	Element in H.W.S.
1		AT-215	Barber Colman	Bulb well	With TS-2
1	RC-1	CP-8102	Barber Colman	2 input reset controller for convertor control	In control panel
1	V-2	VS-9223-201-4-5	Barber Colman	Control valve, c2 way:03/4",	At steam convertor
1	R-3	RH2B-U24	IDEC	Control relay, DPDT, 24 VAC	In control panel
1	T-2	TP-8102	Barber Colman	Space thermostat, heating, proport.	In space
1	V-1	VS-9313-351-4-10	Barber Colman	Control valve, 3 way, 1 1/2" proportional, Cv = 33	At AHU h.w. coil
1		TC-1152	Barber Colman	Space thermostat, cooling, 2 stage	In space
1		AT-608	Barber Colman	Subbase switch, fan AUTO/ON, HEAT/COOL	At cooling thermostat
1		TC-4111	Barber Colman	Thermostat O.A. limit	Bulb in O.A. duct
2	R-2, R-3	RH2B-U24	IDEC	Control Relay, DPDT, 24 VAC	In control panel
3		SH2B-05	IDEC	Relay base	In control panel




JOB: REPLACE AIR CONDITIONING UNITS VARIOUS BUILDINGS MCAS, NEW RIVER, N.C.

EQUIPMENT SCHEDULE

Job #: A-024/J-024

PAGE: 2 of 3 DATE: 1/23/88

QNTY.	IDENTIFIER PART NUMBER		MANUFACTURER	DESCRIPTION	LOCATION
			BUILDING AS-236		
6	COOLING	TC-1103	Barber Colman	Space thermostat cooling, 2 pos	In space
6	T-2	TP-8102	Barber Colman	Space thermostat, heating, proport.	In space
2	V-3	VS-9313-201-4-4	Barber Colman	Control valve, 3 way, 1/2" proportional, Cv = 4	At AHU 3 & 5
3	V-4	VS-9313-201-4-6	Barber Colman	Control valve, 3 way, 3/4" proportional, Cv = 6.8	At AHU 1,2 &6
1	V-5	VS-9313-351-4-11	Barber Colman	Control valve, 3 way, 2" proportional, Cv = 55	At AHU 4
6		AT-603	Barber Colman	Subbase switch, fan AUTO/ON HEAT/COOL	At cooling thermostat
4	O.A. T'stat	eTC-4111	Barber Colman	Thermostat, O.A. limit	Bulb in O.A. duct of AHU 1, 2, 4 & 6
12	R-2, R-3	RH2B-U24	IDEC	Control relay, DPDT, 24 VAC	In control panel
13		SH2B-05	IDEC	Relay base	In control panel
1	V-6	¿VS-9223-351-4-10	Barber Colman	Control valve, 2 way, 1 1/2" N.C. proportional, Cv = 25	At steam convertor
1	TS-1	TS-8501	Barber Colman	O.A. temperature sensor	Element in O.A.
1	TS-2	TS-8201	Barber Colman	H.W.S temperature sensor	Element in H.W.S
1		AT-215	Barber Colman	Bulb Well	With TS-2




JOB: REPLACE AIR CONDITIONING UNITS VARIOUS BUILDINGS MCAS, NEW RIVER, N.C.

EQUIPMENT SCHEDULE

Job #: A-024/J-024

PAGE:3 of 3 DATE:1/23/88

QNTY.	IDENTIFIER	PART NUMBER	MANUFACTURER	DESCRIPTION	LOCATION
			AS-236 (cont)		
1	RC-1	CP-8102	Barber Colman	2 input reset controller for steam convertor	In control panel
1	R-3	RH2B-U24	IDEC	Control relay, DPDT, 24VAC	In control panel
1				Control panel, 20" X 16"	In mech. room
			BUILDING AS-502		
1	SPACE	TC-1103-500	Barber Colman	Space thermostat, cooling, 2 pos.	In space
1	SUBBASE	AT-603	Barber Colman	Subbase switch, fan AUTO/ON	At cooling thermostat
			的 是是一层的		Asil
					Value of the state



Sequence of Operation

- 8.1.1 Building AS-202: When the temperature rises above the setting of the cooling thermostat with the fan selector switch in "AUTO" position, the compressor and the fan shall be energized together. When the fan selector switch is in the "ON" position, the compressor shall cycle and the fan shall run continuously.
- 8.1.2 Building AS-205: When the thermostat is in the "COOL" position and the fan selector switch is in the "AUTO" position the compressors shall be energized on a temperature rise by two cooling stages of the thermostat and the fan shall cycle with the compressors. When the fan selector switch is in the "ON" position, the fan shall run continuously. When the thermostat is in the "HEAT" position the three way hot water control valve shall modulate hot water from full coil by-pass to full flow through the coil as the space temperature falls. The fan shall run continuously during the heating modes.
- 8.1.2.1 Converter Controls: A 2 input controller with one sensing element in the outside air and one sensing element in the hot water supply shall control a normally closed steam valve. The supply water temperature shall be reset upwards as the O.A. temperature falls. Reset schedule is such that at 20 degrees O.A., H.W.S. is 180 degrees and at 60 degrees O.A., H.W.S. is 100 degrees.
- 8.1.2.2 Pump Control: When the steam control valve begins to modulate open, the hot water pump shall be energized and shall remain energized until the steam control valve completely closes.
- 8.1.2.3 A safety low limit thermostat shall deenergize the air handling unit's fan when the mixed air temperature entering the heating coil drops below 35 degrees F.
- 8.1.3 Building AS-236: When any of the six thermostats are in the "COOL" position and the fan selector switch is in the "AUTO" position, the compressor shall be energized on a temperature rise and the fan shall cycle with the compressor. When the fan selector switch is in the "ON" position, the fan shall run continuously. When the thermostat is in the "HEAT" position the three way hot water control valve shall modulate hot water from full coil by-pass to full flow through the coil as the space temperature falls. The fan shall run continuously during the heating modes.
- 8.1.3.1 Converter Controls: A 2 input controller with one sensing element in the outside air and one sensing element in the hot water supply shall control a normally closed steam valve. The supply water temperature shall be reset upwards as the O.A. temperature falls. Reset schedule is such that at 20 degrees O.A., H.W.S. is 180 degrees and at 60 degrees O.A., H.W.S. is 100 degrees.
- 8.1.3.2 Pump Control: When the steam control valve begins to modulate open the hot water pump shall be energized and shall remain energized until the steam control valve completely closes.

- 8.1.3.3 A safety low limit thermostat shall deenergize the air handling unit fan when the mixed air temperature entering the heating coil drops below 35 degrees F. Not applicable for AHU 3 and 5.
- 8.1.4 Building AS-502: When the temperature rises above the setting of the cooling thermostat with the fan selector switch in "AUTO" position, the compressor and the fan shall be energized together. When the fan selector switch is in the "ON" position, the compressor shall cycle and the fan shall run continuously.
- 8.1.5 Building AS-3502: Existing controls shall be reused. An existing high limit pressure selector and pneumatic electric switch shall energize the new condensing unit and provide full cooling. Existing hot water control valve will be reused and connected to new heating coil in air handling unit.



General Instructions

75- 1, 75- 2
Solid State Sensing
Temperature and Humidity
Series TS-8000 and HS-8000


Temperature Sensing

GENERAL INFORMATION


Sensing is accomplished by the use of a temperature sensitive Balco resistance wire packaged in the form of room, duct, averaging and outdoor type configurations. The design of the entire system is around a 1000 Ω sensing element at 70°F.

WIRING

Make all electrical connections to the element in accordance with the installation and wiring diagram for the job. Comply with national and local electrical codes. Do not use the element box as a junction box for other control circuits. It is generally advisable to use flexible conduit for connecting box to rigid conduit. Restrict element leads to shortest length practical. Barber-Colman twisted cable or factory approved cable should be used.



Part No.	Use	Location	Mounting	Terminal Code Wiring
TS-8101	Room Sensor w/o Setpoint	Wall	Mounting Control Element Screw	①) Output
TS-8111	Room Sensor w/Setpoint	Wall	Printed Screw Circuit Mounting Board Screw	① J Terminals
TS-8201	Duct Immersion 7" Immersion Length	Duct or Well AT-215 3/4" NPT	AT-215 Thermowell Immersion Temperature	Pigtails:
TS-8201 -106	Immersion 4" Insertion Length	Well AT-225 1/2" NPT	3 7	Black (C) Controlling
TS-8331	Lagged Sensor	Duct	(2) 1/8" Dia Holes	Black (L)* Controlling *Found only on the TS-8331
TS-8405	5' Average	Duct		
TS-8422	22' Average	Duct	Duct Mounting Dimensions	
TS-8241	Diffuser	Ceiling	Mount on Face of Ceiling Diffuser. See Instructions for B-C Models PB, PS or SFS, SFB. Pg. 2	Pigtails: Black Black
TS-8261	Light Fixture	Light Fixture	Mount in Return Grill of Light Fixture	Pigtails: Black Black
TS-8501	Outdoor Air	Outside of Building		Pigtails: Black Black Controlling
TS-8531	Solar	Outside of Building	Use Conduit Connectors	Orange } Element (Solar)
TS-8533	Econostat	Outside of Building		Red Heater Red (Econostat)





General Instructions

Solid State Sensing Temperature and Humidity Series TS-8000 and HS-8000


Temperature Sensing


GENERAL INFORMATION

Sensing is accomplished by the use of a temperature sensitive Balco resistance wire packaged in the form of room, duct, averaging and outdoor type configurations. The design of the entire system is around a 1000 Ω sensing element at 70°F.

WIRING

Make all electrical connections to the element in accordance with the installation and wiring diagram for the job. Comply with national and local electrical codes. Do not use the element box as a junction box for other control circuits. It is generally advisable to use flexible conduit for connecting box to rigid conduit. Restrict element leads to shortest length practical. Barber-Colman twisted cable or factory approved cable should be used.





Solid State Humidity Sensing

Sensing is accomplished by the use of a nonorganic resistance type material which will be housed either in a room or duct type mounting base. Selection of the proper AH-100 series element will provide the capability of control over a 15% range. Elements are available through the span of 5% to 95% R.H.

The average resistance of each element at midrange is approximately 22,000 ohms, except the violet element, which is 50,000 ohms. A resistor of appropriate value may be substituted in the bridge circuit to verify the element resistance.

CAUTION

Do not measure resistance of element with an ohmmeter, as DC voltage across the element will cause polarization and a new element will be required. Basic element is not repairable. Order a replacement from the factory or local branch office.

CARE OF ELEMENT

The elements are wrapped with a moisture pervious cellophane, which actually is an air filter. On installations using duct elements, where air velocities are reasonably high **do not remove cellophane**. Always install element with wrapping so that perforations in cellophane are on downstream side of air currents. Punch more holes (only in downstream side of cellophane) to increase element sensitivity.




TABLE 1.

Part Number	Sensing Element Color	Relative Humidity Range
AH-100	Violet	85% to 95%
AH-101	Blue	70% to 85%
AH-102	Green	50% to 70%
AH-103	Yellow	40% to 55%
AH-104	Orange	30% to 45%
AH-105	Brown	10% 10 30%

WIRING


Make all electrical connections to the device in accordance with the installation wiring diagram for the job. Comply with national and local electrical codes. Restrict element leads to shortest length practical, using three conductor twisted cable, 18 gauge minimum.

CAUTION

Power wiring must never be installed in the same conduit.

LOCATION


Locate the sensing element where it will be exposed to unrestricted natural air circulation and to the average conditions of the controlled space. Do not locate it near extreme sources of heat, cold, or moisture.



Duct — HS-8200 Series

Room — HS-8100 Series






CALIBRATION

- Place DC-VOM on output of CP-8102 controller, OP1 (+) and COM (-).
- 2. Read humidity at the sensor.
- 3. Place jumper on proper pin, per chart below.
- 4. Adjust the controller (CAL A) to 7.5 Vdc output.
- 5. Refer to CP-8102 literature if further details are required.

GENERAL INFORMATION



MOUNTING OF DIFFUSER SENSOR TS-8241

Sensor should be mounted to the face of the ceiling diffuser so that it projects downward into the room. See Figure 1. If the diffuser has an adjustable pattern, the discharge air direction must be adjusted to a horizontal pattern. This will insure a representative sample of room air over the element (Figure 2). The transmitter will not perform satisfactorily if the discharge is adjusted to a vertical pattern.



Figure 1.

Sensor Mounted in Perforated Face Ceiling Diffuser

Model PB or PS




Figure 2.
Room Air Induced over Sensor by Discharged Air

A 7/16-inch hole is required in the diffuser face for mounting.

The SFS and SFB louver faced diffusers are available in nine air patterns, both in the square and rectangular design. For proper installation, use Table 2 which shows sensor location and the mounting figure referred to in the installation procedure. APNS-107 must be ordered separately.

SENSOR MOUNTING PROCEDURE ON SFS AND SFB USING APNS-107 KIT

- 1. Drill a 5/16" hole for sensor leads
 - a. Fig. 3. Locate hole center on an angled surface about 5/16" from an edge of the 1/2" square so as to avoid drill contact with the welded center plate mounting brackets.
 - Fig. 4. Locate the hole center on one louver about 5/16" from junction of two center back to back louvers.
 - Fig. 5. Locate hole center on an end louver about 1/2" from the junction of the louver and the mounting flange.
- Bring field leads through the 5/16" hole. If required, remove the louver assembly from the mounting flance.
- 3. Center the APNS-107 bracket over the 5/16" hole (use as a template) and drill 1/8" holes for the mounting screws.
 - Fig. 3. Drill two holes near edges of square center plate.
 - Fig. 4. Drill two holes, one each on bottom edge of back to back louvers.
 - c. Fig. 5. Drill one hole on end louver.
- Assemble the sensor to APNS-107 bracket as shown in Figs. 3, 4, and 5.
 - Fig. 5. Cut off one side of APNS-107 as shown.
- Make field connections to sensor leads and push leads up through the 5/16" hole.
 - Wrap friction or electrical tape around the leads and fill the 5/16" hole, preventing direct primary air passage over the sensor.
- Attach APNS-107 as shown in Figs. 3, 4 and 5 using #6 screws.
 - Fig. 5. Cover the crack between the end louver and mounting flange at least 12" on each side of the sensor. A 24" length of 3/4" tape stuck to mounting flange can be used.
- The sensor installation is complete





TABLE 2. SENSOR LOCATION AND FIGURE SHOWING MOUNTING DETAILS

	SENSOR LOCATION							
Air Pattern	Center of Diffuser	Center of Side with No Air Throw		Corner Opposite Air Throw		End Opposite Air Throw		
	Sq. Rect.	Sq.	Rect.	Sq.	Rect.	Sq.	Rect.	
0	Fig. 3 Fig. 4							
2		Fi	g. 4					
3								
4	Fig. 4							
5								
6	10.54m. 33. 1-54			Eig 2	Fig. 5			
7				rig. S	rig. 5			
8						Fi	g. 5	
9	State Comment	1					g. U	

TS-8241 must not be located nearer than 18" from a wall or corner of a room when used on air patterns 2, 6, 7, 8, or 9. This allows space for induced air to pass over TS-8241.

AIR PATTERNS (As Viewed from Diffuser Face)

Number is air pattern designation when ordering.



			Temperature Sensors				Humidity Sensors	
Specifications			Room Light Fixture	Duct/ Immersion	Averaging	Selective Ratio Discharge	Sensors must be ordered separately. Refer to Sensor Range Table 1.	
			Diffuser*				Room	Duct
	\$ize**		4%×2%×1%	4%×3½×9%	4% × 3½ × †	4%×3½×9%	4%×2%×1%	4%×3½×9½
		Mounting	Wall	Duct/ Immersion	Duct	Duct	Wall	Duct
Pac	kage	Mounting Position	Vertical	Vertical	Vertical	Vertical	Vertical	Vertical
258 2770	1	Connection	Terminals	Pigtails	Pigtails	Terminals	Pigtails	Pigtails
osa je ko Germani		Ambient Temp. Limits	-40 to 250°	-40 to 250°	-40 to 250°	-40 to 250°	35 to 135°	35 to 135°
-		Resistance	1000 Ω	1000 Ω	1000 Ω	1000 Ω		
Sensor		Sensitivity	2.2 Ω/°F	2.2 Ω/°F	2.2 Ω/°F	2.2 Ω/°F		
		Length	34.6	6"	5' or 22'	6"		6"
		Control Range						
	Impedance							
Input	170.10°	Selpoint Range	55 to 85°				Up to 20% R.H.	Up to 20% R.H.
		Calibration Range					±5%	±5%
	Adjust	Throttling Range					CARLES IN S	HATTER TO
		Ratio	1			5 to 20/1	figur 11	
		Impedance	1.1.77	164 16 16 18		Made at	weigh.	a Parada
	Voltage	Range	1					
		Reference		91	- it	Negative	. Negative	Negative
Output		Voltage	1 1 1 1 1 1					
	Power Supply	Current					1133	17 22 1
34		Regulation	1 110000			1000	1, 1, 4, 4	
	. 1	Voltage						
L	pad	Current		- 5		I film dis		
		Voltage				6.2 Vdc ±.4	24Vac±10%	24Vac±109
Po	wer	Current	1177.65	The West	1000000	1 mA	25 mA	25 mA

Barber-Colman Company ENVIRONMENTAL CONTROLS DIVISION

1354 Clifford Avenue P.O. Box 2940 Loves Park, IL U.S.A. 61132-2940 Para. 2.2.2.9

RC-1



General Instructions


CP-8102 Electronic Two Input Temperature or Humidity Controller

Electronic controller receives temperature or humidity sensor inputs and sends a variable electronic signal, 1 to 15 Vdc, to up to six System 8000® actuators or relays (controlled devices). Additional devices can be controlled with the use of adapters. These actuators or relays operate heating, cooling, humidification or dehumidification equipment in HVAC systems.

FEATURES AND BENEFITS

The reliable, easy to install CP-8102 electronic controller incorporates an amplifier with inputs for 1000ohm Balco® temperature sensors, humidity sensors or remote setpoint adjustor. Two setpoint dials, ratio authority dials, throttling range dials and calibration potentiometers are visable and accessible without removing controller cover allow for easy field adjustment. Coded screw terminals make sensor, remote setpoint, power supply and output signal wiring easy to install and change. The CP-8102 controller is used with other System 8000 devices.





CP-8102

Wiring Connections: Coded screw terminals for all control inputs and outputs.

Safe Ambient Temperature Limits:

Operation: 40 to 135°F (4.4 to 57°C) Storage: -40 to 160°F (-40 to 71°C)

Dimensions: 4" (102 mm) high × 11" (279 mm) wide × 2-1/2"

(64 mm) deep

Part Number	Control Dial Range Setpoint "A"	Control Dial Range Setpoint "B"	Throttling Range for 3 Vdc Output Change	Authority Ratio Adjustment Setpoint "A" Setpoint "B"	Control Output Voltage†	Power Required	Power Supply Available
CP-8102	20 to 120°F	20 to 120°F	Adjustable 2 to 10°F by Dial*	.5:1 to 25:1 Adjustable	1 to 15 Vdc 10 mA Max.	THE REPORT OF THE PARTY OF THE	60 Vdo
CP-8102-116	-6 to 48°C	-6 to 48°C	Adjustable 1 to 6°C by Dial*	by Dial	Factory Set for D.A.	20 vac 23 mA	6.2 Vdc 7 mA Max.

	11	to 6°C by Dial*		D.A.	
	ENTS for additional throttling ranges.		S-8111	Room sensor with setpoint	
† Units factory ca temperature.	alibrated for 7.5 Vdc output with sensor at se	tpoint T	S-8131	Room button type sensor	
		. 1	S-8201	Duct/immersion sensor	
Options: None		1	S-8204	High temp. duct/immersion :	
ACCESSORIE				requires AT-8435 remote se	
AD-8122	Signal adaptor for dual outputs		0.0044	applications except differenti	
AD-8123	(two direct acting)		S-8241	Diffuser sensor	
AD-0123	Signal adaptor for dual outputs (one direct, one reverse acting)		S-8261	Light fixture sensor	
AD-8124	Signal adaptor for dual outputs		S-8331	Lagged sensor (CN-8101 is	
AD-0124	(one reverse, one direct acting)		S-8405	5' averaging sensor	
AD-8912	12" enclosure		S-8422	22' averaging sensor	
AD-8969-201	Off set resistor kit: 5, 10, 15 & 20°F		S-8501	Outdoor sensor	
AD-8969-901	Extended throttling range jumper		S-8531	Solar sensor (CN-8101 is rec	
ASP-301	Power supply required for HSP-6X81		S-8533	Econostat sensor	
7.01 001	humidity transmitter	T	ool-201	Calibration kit for system 800	
ASP-581	Indication meter 20 to 80% RH		DEFINITIONS		
AT-8122	Remote setpoint adjuster, dual scale 120°F (-6 to 49°C)			eration: Either direct-acting or re-	
AT-8155	Remote setpoint adjuster, dual scale 250°F (10 to 121°C)			(D.A.) means that an increase in to causes the voltage output (OP1)	
AT-8158	Remote setpoint adjuster, dual scale 85°F (13 to 29°C)			ng (R.A.) means that an increase in (s) causes the voltage output (OP1	
AT-8222-101	Setpoint scale for humidity 20% to 10	2006			
AT-8435	Remote setpoint adjuster, dual scale 450°F (10 to 232°C) for use with TS only	8204 W	hether inpu	ol Action: The direction of reset A setpoint is reset upward or dedecrease at input B.	
CN-8101	Multi-purpose bridge		irect reset:	(D.R.) A temperature decrease on	
HS-8101	Room humidity sensor			int downward.	
	[2012] [2012] [2012] [2012] [2012] [2012] [2012] [2012] [2012] [2012] [2012] [2012] [2012] [2012] [2012] [2012]				

TS-8131	Room button type sensor
TS-8201	Duct/immersion sensor
TS-8204	High temp. duct/immersion sensor requires AT-8435 remote setpoint for a applications except differential control
TS-8241	Diffuser sensor
TS-8261	Light fixture sensor
TS-8331	Lagged sensor (CN-8101 is required)
TS-8405	5' averaging sensor
TS-8422	22' averaging sensor
TS-8501	Outdoor sensor
TS-8531	Solar sensor (CN-8101 is required)
TS-8533	Econostat sensor
Tool-201	Calibration kit for system 8000
DEFINITIONS	

ner direct-acting or reverse-acting.

is that an increase in temperature at voltage output (OP1) to increase.

ans that an increase in temperature ne voltage output (OP1) to decrease.

The direction of reset determines is reset upward or downward on a

perature decrease on input B resets ard.

Reverse reset: (R.R.) A temperature decrease on input B resets input A setpoint upward.

HS-8201

TS-8101

Duct humidity sensor

Room sensor




Figure 1. CP-8102

CONTROL TERMINAL INPUTS (See Figure 1)

ISA: Any TS-8000 Temperature Sensor (1000 ohm Balco)

ISB: Any TS-8000 Temperature Sensor (1000 ohm Balco)

AB1, AB2, AB3: Auxiliary inputs; any remote setpoint adjuster AT-8000 series, HS-8X01 humidity sensor, CN-8101 multipurpose bridge

CONTROL TERMINAL OUTPUT (See Figure 1)

OP1: 1 to 15 Vdc (10 mA maximum). Units factory calibration for 7.5 Vdc output with sensor at setpoint temperature.

ADJUSTMENTS: (See figure 1)

Temperature Setpoint "A": By dial 20 to 120°F (-6 to 48°C), or by remote setpoint adjuster (See Accessories).

Temperature Setpoint "B": By dial 20 to 120 °F (-6 to 48 °C), or by remote setpoint adjuster (See Accessories).

Setpoint "A" Calibration: By potentiometer.

Setpoint "B" Calibration: By potentiometer. For reset control, set Setpoint "B" at value where Setopint "A" will be reset, Adjust Setpoint "A" at control point required with no reset from sensor "B".

THOTTLING RANGE: By dial 2 to 10°F, 1 to 6°C. By pin selection 15, 25, 40 and 60°F (8, 14, 22, 33°C). Remove J9 jumper from JC9 and attach to required throttling range pin. By extended throttling range adjuster, AD8969-901 (order separately), 55, 65, 75, 85, 100, 115, 125 and 140°F (31, 36, 42, 47, 56, 64, 69 and 78°C). The throttling range is the sum of the T.R. pins connected.

AUTHORITY RATIO

ADJUSTMENT: By dial .5 to 25:1. Ratio is the number of degrees change at Sensor "B" required to reset Setpoint "A" one (1) degree. Example: 25:1 means a 25°F (14°C) change at Sensor "B" will reset Setpoint "A" 1°F (.5°C).

Table 2


Controller Function	Jumper Connections Required				
	Bridge "A"	Bridge "B"			
Direct Acting*	J4 to JC6 J3 to JC5	J5 to JC5 J6 to JC6			
Reverse Acting	J4 to JC5 J3 to JC6	J5 to JC6 J6 to JC5			
Internal Setpoint Active*	J1 to JC1	J2 to JC3			
Internal Setpoint Inactive for Remote Setpoint	J1 to JC2	J2 to JC4			
Disable Bridge "B" for Single Sensor Input		Jumper 2 to AB3			

^{*} As supplied from factory.

To Obtain Reverse Reset: Both bridges should have the same action. Example: both direct acting, or both reverse acting.


To Obtain Direct Reset: Bridges should have different action. Example: one direct and one reverse acting.

Disable "A" Bridge Setpoint Disconnect Jumper J1 from JC1 Pin and reconnect to JC2 Pin.



Disable 'B" Bridge Setpoint if "B" Bridge is to be used. Disconect Jumper J2 from JC3 Pin and reconnect to JC4 Pin.

Figure 2. Disabling Setpoint "A" and/or Setpoint "B"



PRE-INSTALLATION: Open the carton and visually inspect the device for part number and obvious defects before proceeding with the installation.

Mounting screws are not provided.

INSTALLATION: Device may be mounted, in any position, in an inside location near the controlled equipment using the two slots in the track. AD-8912 enclosures can be ordered separately for remote installations.

CAUTION

Avoid locations where excessive vibration, moisture, corrosive fumes or vapors are present, or where high radio frequency or electro-magnetic interference generating devices are near.

See Figure 4 for mounting dimensions.




Figure 4. Mounting Dimensions

GENERAL WIRING INFORMATION

Make all connections according to job wiring diagrams and in compliance with national and local codes.

Two separate No. 18 twisted pair wires (six turns per foot [.3m]).

Class II, low voltage, are suitable for up to 1000 feet (300 m) for the sensor leads. See table 3 for longer runs.

Never run line voltage in the same conduit with unshielded sensing element leads. Use copper conduc-

Shielded cable (Belden No. 8422 or equivalent) must be used when it is necessary to install the DC signal leads in the same conduit with power wiring, or when it is known that high RFI/EMI generating devices are near. Ground the shield at the controller only on the COM (-) terminal.

tors only.

Table 3. Wiring Lengths

			LEN	GTH OF RUN IN F	IN IN FEET**				
Wire Gauge	"HS" Sensor To CP-8102	"TS" Sensor To CP-8102	CN-8101, AT-81X4 TS-8601 To CP-8102	"HSP" Transmitter To CP-8102	TSP-8101 To CP-8102	CP-8102 To Controlled Device	CP-8102 To Adaptor*		
22	125	_	_	_	Should be	_			
18	300	1,000	1,000	250	in Same	1,000	1,000		
16	12	2,250	_		Panel as	2,250	2,250		
14	economic de la companya de la compan	4,000	-	<u> </u>	Controller	4,000	4,000		

^{*} AD-8101, AD-812X, AD-8201, AD-8301, AD-8501

GENERAL RULES FOR WIRING CP-8102 TO CONTROLLED DEVICE(S)

- Never connect red lead (or +20 terminal) of any controlled device which has a regulated power supply to the red lead (or +20 terminal) of any other controlled device (see Figure 5).
- Controlled devices (MP-52XX) with unfiltered and unregulated power supplies must be filtered. CP-8102 will provide filtering for a maximum of two MP-52XX by connecting the two red leads together at the controller's +20 terminal (see Figure 6).
- Controlled devices with filtered and unregulated supplies: Up to six controlled devices with the red leads (+20 terminals) can be connected together. Number of units paralleled depends on the current (mADC) requirements of the controller or adaptor.

Table 4. Controlled Device Power Supply Characteristics

Filtered & Regulated	Filtered & Unregulated	Unfiltered & Unregulated
CC-8101		-17
CC-8102		
CC-8103	Track of the second	100 100 100 100 100
CC-8111 Series		
CC-8118 Series	MP-54XX	MP-52XX
CC-8218 Series	MS-8XXX	Actuators
CP-8161 Series	Actuators	
CP-8301 Series*		
CP-8425 Series		
CP-8501 Series		
CP-8502 Series		

^{*} Except CP-8301-101 which does not have a power supply.




Figure 5. Controlled Devices All Filtered

FIELD CHECKOUT

Units are factory calibrated and tested and should not require field checkout. If required, proceed as follows (see Figure 1):

_ NOTE ____

The following procedures can be used for either reverse or direct acting connected CP-8102 controllers.

- Initial Conditions for CP-8102
 - A. Jumper between AB2 and AB3 disconnected.
 - B. 20 Vdc +1 1.5 Vdc (23 mA) applied to the +20 and common terminals. This power is normally supplied by the controlled device.
- Connect a 20,000 ohm/volt DC VOM meter between the OP1 (+) terminal and COM (-) terminal of the CP-8102. Use a 20 Vdc or less range.
- Disconnect the temperature sensing element "A" from the ISA terminals of the CP-8102. Short ISA terminals together and VOM reading should be 1 Vdc or less if bridge "A" is direct acting and more than 15 Vdc if bridge A is reverse acting.
- Open ISA terminals and VOM reading should be greater than 15 Vdc if bridge "A" is direct acting and less than 1 Vdc if bridge "A" is reverse acting.
- The CP-8102 is a good unit if it passes tests in steps 3 and
 Replace the unit if tests 3 and 4 are not met.




Figure 6. At Least One of the Controlled Devices in MP-52XX (Unfiltered)

^{**1} Ft. approx. .3 meter

FIELD CALIBRATION PROCEDURES FOR CONTROLLERS WITH ONE AND TWO INPUTS

(See Figures 7 and 9):

The following procedures can be used for either reverse or direct acting connected CP-8102 controllers.

The CP-8102 is factory calibrated and shipped with both inputs connected for direct acting output.

Normally, the CP-8102 (connected for either direct or reverse acting) requires no field calibration but if a field calibration check or recalibration becomes necessary, then proceed as follows:

- Initial Conditions for CP-8102:
 - A. Setpoint "A" set for: 70°F.
 - B. Setpoint "B" set for: 70°F.
 - C. Ratio adjustment set for: 1:1.
 - D. Throttling range adjustment set for: 3°F.
 - E. Jumper between AB2 and AB3 disconnected.
 - F. 20 Vdc (23 mA) applied to the +20 and common terminals. This power is normally supplied by the controlled device.
- Connect a 20,000 ohm/volt DC VOM meter between the OP1 (+) terminal and COM (-) terminal of the CP-8102.
 Use a 20 Vdc or less range.
- Calibration of "A" input. Use one of the following two methods.
 - A. Temperature measurement methods:

Accurately measure the temperature at the temperature sensing element "A". Adjust setpoint "A" until the dial reading agrees with the temperature measured. Rotate setpoint "A" calibration potentiometer (located just to the right of setpoint "A" dial) until a VOM reading of 7.5±.2 Vdc is obtained.

B. Sensing element substitution method:

Disconnect the temperature sensing element "A" from the ISA terminals of the CP-8102. Reconnect a 1000 ohm ±.1% wire wound resistor (TOOL-203) to the ISA terminals. Adjust setpoint "A" for 70°F. Rotate setpoint "A" calibration potentiometer (located just to the right of setpoint "A" dial) until a VOM reading of 7.5±.2 Vdc is obtained.

NOTE

Method B above does not calibrate out any errors due to sensing element tolerances or wire lead resistance.

- 4. Calibration of "A" input complete.
 - If "B" input is not being used (jumper between AB2 and AB3 removed) then proceed to step 7 below.
- 5. Reconnect jumper between AB2 and AB3.
- Calibration of "B" input. Use one of the following two methods.
 - A. Temperature measurement method:

Accurately measure the temperature at the temperature sensing element "B". Adjust setpoint "B" until the dial reading agrees with the temperature measured. Rotate setpoint "B" calibration potentiometer (located just to the right of setpoint "B" dial) until a VOM reading of 7.5±.2 Vdc is obtained.

B. Sensing element substitution method:

Disconnect the temperature sensing element "B" from ISB terminals of the CP-8102. Reconnect a 1000 ohm ±.1%, wire wound resistor (TOOL-203) to the ISB terminals. Adjust setpoint "B" for 70°F. Rotate setpoint "B" calibration potentiometer (located just to the right of setpoint "A" dial) until a VOM reading of 7.5±.2 Vdc is obtained.

NOTE .

Method B above does not calibrate out any errors due to sensing element tolerances or wire lead resistance.

 CP-8102 calibration is complete. Remove all test meters, test resistor, etc. Reconnect all elements, place setpoints, throttling range and ratio adjustments as required for the application.




Figure 7. One or Two sensor Application

FIELD SERVICE

Units are factory calibrated and tested for direct acting control (D.A.) and reverse reset (R.R.) and should not require service. If required, proceed as follows (see Figure 8):

Power Supply

Apply ± 20 ; ± 1 , ± 1.5 Vdc (23 mA) to the ± 20 and common terminals. Proper power supply is always required for unit to function properly. The ± 6.2 ($\pm .3$) Vdc should be available from the controller, if required.

Tes

Connect a 20,000 ohm/volt DC VOM meter between +20 and common terminals. Controller power supply +20, +1 -1.5 Vdc (indicated by M1 in Figure 8) should be measured. Power supply is normally supplied by controlled device. Check +6.2 (±.3) Vdc power supply of controller with VOM.

Service

If the +20 Vdc level is not measured, service the (lead) controlled device, power supply or installation wiring as necessary to insure proper power supply.

Controller Output

See Field Calibration Procedures, on this page, for calibration of "A" setpoint using sensor element substitutes.

Test

With signal output measured between OP1 and COM at 7.5 ± .2 Vdc, rotate setpoint "A" dial several degrees (in increments of 1°F) each way from 70° setting to vary the M2 reading from 1 to 15 Vdc. The number of degrees that setpoint dial "A" is changed to vary the reading on M2 3 Vdc should be approximately 3°F (if T.R. is set at 5°F, 3 Vdc will change over 5°F).

Service

See Field Calibration Procedures, on page 5, for calibration of "B" setpoint using sensor element substitutes. (Make certain that jumper is connected to AB2 and AB3.)

Adjusting setpoint "B" several degrees from 70°F setting will cause the M2 reading to vary from 1 to 15 Vdc.

If output voltage cannot be made to vary over a 1 to 15 Vdc range, then replace the CP-8102 as defective.




Figure 8.




Figure 9.

MAINTENANCE

This is a quality product. Regular maintenance of the total system is recommended to assure sustained optimum performance.

TYPICAL APPLICATIONS




Figure 10. One or Two Temperature Sensor Application

Hot water reset is typical application for a two sensor application of the CP-8102. For example, perimeter radiation temperature, with hot water as a heating medium, is increased as the temperature of the outside air decreases. This method of control is known as reverse reset. A reset schedule shown below in table requires the hot water temperature to increase from 100° to 170°F, a change of 60°F, as the outside air temperature decreases from 60° to 0°F. If the throttling range of the CP-8102 controller is 10°F the setting of the CP-8102 will be as follows:

Setpoint "A": 110° Setpoint "B": 60°

Ratio Adjustment: 1 (change in outside air temperature/

change in hot water temperature)
Throttling Range: 10°F

Note: Controller function is Direct Acting * (see table 2)

* Factory setting

Table 5. Reset Schedule

Outside Air Temp. (°F)	Water Temperature (°F)	
60	110	1
0	170	-




Figure 11. Derivative (Lagged) Sensor




Figure 12. Three Temperature Sensor Application*





Figure 13. Solar and Outdoor Air Reset of Hot Water (Direct Acting Output)



NOTE: If the controller bridge is reverse acting, the red and blue wires at the AT-8XXX Series must be reversed (red to common, blue to +6.2).

Figure 14. Single Input with Remote Setpoint




Figure 15. Single Unit Winter-Summer Switching

- Cut both jumpers that are located between the terminal strip and cover on the left hand side of the device. (See Figure 15).
- Connect D.P.D.T. Switch (CYZP-11 or equivalent) according to Figure 15.

Switch contacts should have pilot duty ratings and maintain a 1 ohm or less contact rating over its normal life.

No recalibration of CP-8102 is required.

SINGLE UNIT SUMMER/WINTER SWITCHING (Continued):

Table 6. Bridge Connections for Summer/Winter (See Figure 15.)

				Time I Transport		JUM	PER TO PIN	CONNECTI	ONS
BRIDGE "A" (MAIN SENSOR)		BRIDGE "B" (RESET SENSOR)	RESET OF SETPOINT "A"		J3	J4	J5	J6	
Winter	Summer	Winter	Summer	Winter	Summer			Selection of the select	
D.A.	R.A.	C).A.	Reverse	Direct	JC5	JC6	COM	+6.2
R.A.	D.A.	0).A.	Direct	Reverse	JC6	JC5	COM	+6.2
D.A.	R.A.	F	R.A.	Direct	Reverse	JC5	JC6	+6.2	CON
R.A.	D.A.	F	R.A.	Reverse	Direct	JC6	JC5	+6.2	CON
).A.	D.A.	R.A.	Reverse	Direct	COM	+6.2	JC5	JC6
F	R.A.	D.A.	R.A.	Direct	Reverse	+6.2	COM	JC5	JC6
C).A.	R.A.	D.A.	Direct	Reverse	COM	+6.2	JC6	JC5
F	R.A.	R.A.	D.A.	Reverse	Direct	+6.2	COM	JC6	JC5




Table 7. Typica! Reset Schedule

Outside Air Temp. (°F)	Water Temperature(°F)
70°	110°
0.	140°
Above 70°	85°

Outside air temperature reset of supply water temperature with fixed temperature of 85°F with outside air temperature of 70°F

Setpoint "A": 110°F

Setpoint "B": 70°F

Ratio Adjustment: 2.33
Throttling Range: 10°F

AT-8122: Set 45°F for S.P. of 85 where O.A. is above 70°F

Relay is energized with outside air temperature below 70°.

Figure 15. Outside Air Temperature Reset of Hot Water with Fixed Temperature with Outside Air Temperature Above Selected Value

Resistor (5, 10, 15, 20°F offset) use AD-8969-201 kit.

Offsetting setpoint for Direct Acting Controller:

Raise, connector resistor to +6.2 terminal.

S.P.D.T. Switch, (i.e., timeclock, manual switch)

Lower, connect resistor to COM terminal.

Offsetting setpoint for Reverse Acting Controller:

Raise, connect resistor to COM terminal.


Lower, connect resistor to +6.2 terminal.

NOTE .

Standard two conductor twisted wire should be used if remote switching is employed.

Resistor must always be located at stat.

Figure 16. Setpoint Offset




Install 1000 ohm 1% (TOOL-203) resistor in ISB. Install AE-178 7 day time clock. Set setpoint "B" as desired for night setback.

Table 8.

Setpoint "B"	Night Setback			
70°F (21.1°C)	No Setback			
65°F (18.3°C)	5°F (2.8°C) Setback			
60°F (15.6°C)	10°F (5.6°C)Setback			
55°F (12.8°C)	15°F (8.3°C) Setback			

Figure 17. Night Setback



Note: Settings of 2-6 throttling range result in 2-6% RH throttling range for 3 Vdc output change 6 TR is maximum setting.

Figure 18. Humidity Control




Figure 19. Humidity Control & Indication

Barber-Colman Company ENVIRONMENTAL CONTROLS DIVISION


| 1354 Clifford Avenue | P.O. Box 2940 | Loves Park, IL U.S.A. 61132-2940



COLMAN General Instructions

TP-8101, TP-8102, TP-8103, TP-8124, TP-8125 Electronic Thermostats Proportional Controlling

TP-8101, TP-8102, TP-8103 Single Setpoint Adjustment



TP-8124 & TP-8125 Dual Setpoint Adjustment



Table 1

Part Number	Dial Marking	Control Dial Range	Throttling Range for 3 Vdc Output Change	Input Voltage	Output Voltage	Control Action	Wiring Connections	Number of Controlled Devices									
TP-8101	°F&°C	55-85°F	2, 3, 6 and			Factory Set	Name of the second										
TP-8101-116	°C	13-29°C	20°F	Direct-acting 3 Color-code									Direct-acting 3 C		Jumper Terminal 4 to 5	3 Color-coded	6 System 8000 Devices or 2 MP-5200
TP-8102	°F&°C	7-24°C (45-75°F)	Factory Set 3°F										et 20 Vdc 13 mA	2-15 Vdc or 15-2 Vdc		4 to 5 Terminals for	
TP-8103	°F&°C	24-41°C (75-105°F)	By Jumper/ Pins	ar S		For Reverse-acting Jumper Terminal 4 to 3	See Figure 2		Series Actuators								
TP-8124						Heating		6									
Dual Setpoints	°F&°C	Cooling 21-38°C (70-100°F) Cooling 2-10°F	20 Vdc	Heat 2-15 Vdc	/dc Jumper J7	Coded	System 8000 Devices or 2 MP-5200 Series										
TP-8125	°F&°C	Heating 7-24°C (45-75°F)	Adj. Factory Set	23 mA	DE PLANT TO STATE OF THE PARTY	23 mA	Cool Direct-act	Cool Direct-acting	23 mA 15-2 Vdc to pin B for Direct-acting See Figure Cool 2-15 Vdc Cooling	23 mA 15-2 Vdc Cool	23 mA 15-2 Vdc Direct-acting See		Terminals See Figure 3	Actuators in both Heating			
Dual °F & °C Setpoints		Cooling 24-41°C (75-105°F)	3°F			Direct-acting only		and Cooling									

DESCRIPTION

TP-8101, TP-8102, TP-8103

These self-contained room temperature controllers conserve energy in heating and/or cooling applications requiring a single setpoint adjustment. See Table 1 for particular characteristics.

The heating and cooling equipment is precisely controlled from a single 1000 ohm Balco sensor operating through a single controller for heating and/or cooling. The controller provides a proportional output to control System 8000 controlled devices for control of valves, dampers, electric heat, DX coils, etc.

TP-8124, TP-8125

These self-contained room controllers conserve energy in heating and/or cooling equipment in applications requiring heating and cooling setpoint adjustment.

See Table 1 for particular characteristics.

The heating and cooling equipment is precisely controlled from a single 1000 ohm Balco sensor operating through independent heating and cooling controllers. These controllers provide proportional outputs to control System 8000 controlled devices for control of valves, dampers, electric heat, DX coils, etc. The heating output (OP1 to COM) can be programmed for direct-acting or reverse-acting operation. The cooling output (OP2 to COM) provides a direct-acting output only.

Features

- TP-8124 meets ASHRAE 90-75 and DOE requirements.
 TP-8125 meets DOD requirements.
- Heating and cooling cannot operate simultaneously.
- Heating/cooling deadband obtained by adjustable dual setpoints and throttling range.
- Proportional outputs operate remote System 8000 controlled devices such as valves, dampers, electric heat coils, etc.
- Concealed adjustments eliminate occupant tampering.

INSTALLATION

Open the carton and visually inspect the device for part number and obvious defects before proceeding with the installation

Mounting screws are provided.

Locate the controller where it will be exposed to unrestricted natural air circulation and to the average conditions of the controlled space. Do not locate it near sources of heat or cold (such as lamps, motors, sunlight, radiators and concealed pipes or ducts within the wall) which might affect the control point. Avoid locations where excessive vibration, moisture, corrosive fumes or vapors are present, or where high radio frequency or electromagnetic generating devices are near.

Dimensions 111 mm (4-3/8") high × 73 mm (2-7/8") wide × 41 mm (1-5/8") deep.




Figure 1


Ambient Limits Operation: 40 to 140°F (4.4 to 60°C). Storage: -40 to 160°F (-40 to 71°C).

MODES OF OPERATION

- Direct-acting control (DA): Increase in temperature at the sensor causes the controller output signal to increase.
- Reverse-acting control (RA): Increase in temperature at the sensor causes the controller output signal to decrease.

THROTTLING RANGE

Throttling range (T.R.) is defined as the degrees (°F or °C) change at the temperature sensor in order to cause a 6 to 9 Vdc controller output signal change.



Wire Leads

Red = +20 Vdc (Input)
Yellow = Proportional Output
Blue = Common

Screw Terminals

- 1 = Common
- 2 = Auxiliary Input
- 3,4 = Connect for Reverse-Acting (RA)
- 4,5 = Connect for Direct-Acting (DA)
- $7 = 6.2 \, \text{Vdc}$
- 7.8 = Remote Sensor

Terminal Nomenclature
TP-8101, TP-8102 and TP-8103




Figure 3
Terminal Nomenclature
TP-8124 and TP-8125

WIRING

Make all electrical connections according to installation wiring diagrams. Comply with national and local electrical codes.

No. 18 multi-conductor thermostat cable may be used. Low voltage Class 2 wire is acceptable, but No. 18 or larger 600V wire should be used if splices are to be made in the same junction box with line voltage wiring.

The controller may be installed on either a 52 mm × 102 mm (2" × 4") flush switch box or a surface switch box. To install, proceed as follows:

- Wiring for the TP-8101, TP-8102 and TP-8103 is shown in Figures 4 and 5. See Figures 6 and 7 for TP-8124 and TP-8125 typical wiring.
- 2. "Pull" all wires required
- 3. Connect all control wiring to the thermostat.
- 4. Remove the thermostat cover by loosening the screw at the bottom of the cover. Pull the cover out from the bottom and up to disengage it from the base.
- 5. Fasten the base to the box with the screws provided.
- Replace the cover and tighten the cover screw.

WIRING OF CONTROLLED DEVICES TO CONTROLLER

Types of controlled devices and their power supplies:

- Filtered and regulated power supplies: All System 8000 controlled devices except MP-52XX and MP-54XX series actuators.
- Filtered and unregulated power supplies MP-54XX series actuators
- 3 Unfiltered and unregulated power supplies MP-52XX series actuators.

General rules for wiring controllers to controlled devices:

 Never connect red lead (or +20 terminal) of any controlled device which has a regulated power supply to the red lead (or -20 terminal) of any other controlled device

- Controlled devices with unfiltered and unregulated power supplies must be filtered. System 8000 controllers will provide filtering for a maximum of two controlled devices by connecting the two red leads (+20 terminals) together at the controller's red lead (+20 terminal).
- Controlled devices with filtered and unregulated supplies: Up to six controlled devices with the red leads (+20 terminals) can be connected together. Number of units paralleled depends on the current (mA DC) requirements of the controller or adaptor.
- 4. Devices and their internal supplies:

FILTERED & REGULATED		FILTERED & UNREGULATED	UNFILTERED & UNREGULATED			
C	C-8101	MP-54XX	MP-52XX			
C	C-8102	Actuators	Actuators			
C	C-8103		and the same of th			
C	C-8118 Series					
C	C-8218 Series					
·C	C-8111 Series		Sec. 10			
C	P-8301 Series					
C	P-8161 Series					
C	P-8425 Series					
C	P-8501 Series					
C	P-8502 Series					




Figure 5
TP-8101, TP-8102 and TP-8103
Typical Wiring with MP-52XX Actuators

Figure 6
TP-8124 and TP-8125
Typical Wiring with One or No MP-52XX Actuators

projector i 1720 del profito (\$20).

used as the cooling device.




Figure 7
TP-8124 and TP-8125
Typical Wiring with Two MP-52XX Actuators

ADJUSTMENTS

TP-8101, TP-8102, TP-8103

- Turn the setpoint adjuster to the required temperature setting. Normally, no further adjustments are required.
- 2. Throttling range settings of 2, 3, 6 and 20° are available by placing the T.R. jumper on the proper selector pin. See Figure 8. For other throttling ranges (1 through 60°) add a resistor to the auxiliary pins. Select the resistor from the chart below. Place the T.R. jumper on the auxiliary pin nearest the center of the controller.

Table 2. Throttling Range Resistor Values

1 4.3 Meg. ±5% E19-23-562 1.5 3.0 Meg. ±5% CYZR-481-860 2.0 2.2 Meg. ±5% CYZR-481-860 2.5 1.8 Meg. ±5% CYZR-481-580 3.0 1.5 Meg. ±5% CYZR-481-680 3.5 1.2 Meg. ±5% CYZR-481-680 4.0 1 Meg. ±5% CYZR-481-610 4.5 975K, ±1% CYZR-862-496 5.0 866K, ±1% 6.0 732K, ±1% 7.0 619K, ±1% CYZR-862-477 8.0 549K, ±1% 9.0 487K, ±1% 10.0 432K, ±1% CYZR-862-462 15.0 287K, ±1% CYZR-862-462 15.0 287K, ±1% CYZR-862-445 20.0 215K, ±1% CYZR-862-445 20.0 215K, ±1% CYZR-837-913 30.0 143K, ±1% CYZR-837-130 40.0 107K, ±1% 50.0 84.5K, ±1% E19-64-390 60.0 69.8K, ±1% CYZR-837-890	°F T.R.	Auxiliary Resistor	Barber-Colman Part Number
2.0	1	4.3 Meg. ±5%	E19-23-562
2.5	1.5	3.0 Meg. ± 5%	
3.0 1.5 Meg. ±5% CYZR-481-680 3.5 1.2 Meg. ±5% CYZR-481-450 4.0 1 Meg. ±5% CYZR-481-610 4.5 975K, ±1% CYZR-862-496 5.0 866K, ±1% 6.0 732K, ±1% 7.0 619K, ±1% CYZR-862-477 8.0 549K, ±1% 9.0 487K, ±1% 10.0 432K, ±1% CYZR-862-462 15.0 287K, ±1% CYZR-862-445 20.0 215K, ±1% CYZR-862-445 20.0 215K, ±1% CYZR-837-913 30.0 143K, ±1% CYZR-837-130 40.0 107K, ±1% 50.0 84.5K, ±1% E19-64-390	2.0	2.2 Meg. ±5%	CYZR-481-860
3.5	2.5	1.8 Meg. ± 5%	CYZR-481-580
4.0 1 Meg. ±5% CYZR-481-610 4.5 975K, ±1% CYZR-862-496 5.0 866K, ±1% 6.0 732K, ±1% 7.0 619K, ±1% CYZR-862-477 8.0 549K, ±1% 9.0 487K, ±1% 10.0 432K, ±1% CYZR-862-462 15.0 287K, ±1% CYZR-862-445 20.0 215K, ±1% 25.0 174K, ±1% CYZR-837-913 30.0 143K, ±1% CYZR-837-130 40.0 107K, ±1% 50.0 84.5K, ±1% E19-64-390	3.0	1.5 Meg. ± 5%.	CYZR-481-680
4.5 975K, ±1% CYZR-862-496 5.0 866K, ±1% 6.0 732K, ±1% 7.0 619K, ±1% CYZR-862-477 8.0 549K, ±1% 9.0 487K, ±1% 10.0 432K, ±1% CYZR-862-462 15.0 287K, ±1% CYZR-862-445 20.0 215K, ±1% 25.0 174K, ±1% CYZR-837-913 30.0 143K, ±1% CYZR-837-130 40.0 107K, ±1% 50.0 84.5K, ±1% E19-64-390	3.5	1.2 Meg. ± 5%	CYZR-481-450
5.0 866K, ± 1% 6.0 732K, ± 1% 7.0 619K, ± 1% 8.0 549K, ± 1% 9.0 487K, ± 1% 10.0 432K, ± 1% 15.0 287K, ± 1% 25.0 215K, ± 1% 25.0 174K, ± 1% CYZR-837-913 30.0 143K, ± 1% CYZR-837-130 40.0 107K, ± 1% 50.0 84.5K, ± 1% E19-64-390	4.0	1 Meg. ±5%	CYZR-481-610
6.0 732K, ±1% 7.0 619K, ±1% CYZR-862-477 8.0 549K, ±1% 9.0 487K, ±1% 10.0 432K, ±1% CYZR-862-462 15.0 287K, ±1% CYZR-862-445 20.0 215K, ±1% 25.0 174K, ±1% CYZR-837-913 30.0 143K, ±1% CYZR-837-130 40.0 107K, ±1% 50.0 84.5K, ±1% E19-64-390	4.5	975K, ±1%	CYZR-862-496
7.0 619K, ±1% CYZR-862-477 8.0 549K, ±1% 9.0 487K, ±1% 10.0 432K, ±1% CYZR-862-462 15.0 287K, ±1% CYZR-862-445 20.0 215K, ±1% 25.0 174K, ±1% CYZR-837-913 30.0 143K, ±1% CYZR-837-130 40.0 107K, ±1% 50.0 84.5K, ±1% E19-64-390	5.0	866K, ±1%	a to be referred by
8.0 549K, ±1% 9.0 487K, ±1% 10.0 432K, ±1% CYZR-862-462 15.0 287K, ±1% CYZR-862-445 20.0 215K, ±1% 25.0 174K, ±1% CYZR-837-913 30.0 143K, ±1% CYZR-837-130 40.0 107K, ±1% 50.0 84.5K, ±1% E19-64-390	6.0	732K, ±1%	
9.0 487K, ±1% CYZR-862-462 15.0 287K, ±1% CYZR-862-445 20.0 215K, ±1% CYZR-862-445 25.0 174K, ±1% CYZR-837-913 30.0 143K, ±1% CYZR-837-130 40.0 107K, ±1% E19-64-390	7.0	619K, ±1%	CYZR-862-477
10.0 432K, ±1% CYZR-862-462 15.0 287K, ±1% CYZR-862-445 20.0 215K, ±1% 25.0 174K, ±1% CYZR-837-913 30.0 143K, ±1% CYZR-837-130 40.0 107K, ±1% 50.0 84.5K, ±1% E19-64-390	8.0	549K, ±1%	
15.0 287K, ±1% CYZR-862-445 20.0 215K, ±1% 25.0 174K, ±1% CYZR-837-913 30.0 143K, ±1% CYZR-837-130 40.0 107K, ±1% E19-64-390	9.0	487K, ±1%	
20.0 215K, ±1% 25.0 174K, ±1% CYZR-837-913 30.0 143K, ±1% CYZR-837-130 40.0 107K, ±1% 50.0 84.5K, ±1% E19-64-390	10.0	432K, ±1%	CYZR-862-462
25.0 174K, ±1% CYZR-837-913 30.0 143K, ±1% CYZR-837-130 40.0 107K, ±1% 50.0 84.5K, ±1% E19-64-390	15.0	287K, ±1%	CYZR-862-445
30.0 143K, ±1% CYZR-837-130 40.0 107K, ±1% 50.0 84.5K, ±1% E19-64-390	20.0	215K, ±1%	
40.0 107K. ± 1% 50.0 84.5K, ± 1% E19-64-390	25.0	174K, ±1%	CYZR-837-913
50.0 84.5K, ±1% E19-64-390	30.0	143K, ±1%	CYZR-837-130
	40.0	107K. ±1%	
60.0 69.8K, ±1% CYZR-837-890	50.0	84.5K, ±1%	E19-64-390
	60.0	69.8K, ±1%	CYZR-837-890

TP-8124 and TP-8125

 Remove the cover and turn the setpoint adjuster (SPA) to the required lemperature for the heating mode (typically 65°F).

Turn the setpoint adjuster (SPB) to the required temperature for the cooling mode (typically 78°F).

The cooling signal is direct-acting, and stages cooling or proportionally opens a normally closed chilled water valve with a temperature increase.

The heating signal is factory set for reverse-acting. With a temperature decrease, the signal stages electric heat or proportionally increases the electric heat output controlled by a Barber-Colman CP-8400 or CP-80000 Series SCR controller.

 For applications that require a direct-acting signal in the heating mode such as a normally open heating valve, move jumper J7 to pin "B"

- The Temperature Deadband between heating and cooling is the difference in SPB and SPA settings. For example, the deadband is 13°F with SPA at 65°F and SPB at 78°F.
- The throttling ranges are factory set at 3°F for heating and cooling. These settings should not be changed for normal applications. Increase the throttling range only to achieve control stability (adjustable 2 to 10°F).

To adjust, turn the T.R. dial to position the required T.R. value closest to the thermostat cover.

5. Replace the cover.




Figure 8 TP-8101, TP-8102 and TP-8103




Figure 9a TP-8124 or TP-8125

SERVICE

TP-8101, TP-8102, TP-8103

NOTE .

The TP-8101, TP-8102 and TP-8103 have been factory calibrated to produce a 7.5 Vdc output signal at the yellow and blue leads (TO+ and TS-) when the setpoint and the temperature at the sensing element agree.

- 1. Verify wiring per job wiring diagram.
- 2. Measure with a 20,000 ohm per Vdc VOM.
 - a. Power supply 20 Vdc: Red (+) to blue (-) wires or test point pins TS- and TS+ (+ end of the 47 \(\mu\)f capacitor).
 - Output 2 to 15 Vdc: Yellow (+) to blue (-) wires or TO+ and TS- test pins. The voltage varies between 2-15 as the dial knob is rotated.
- 3. Consult EN 111 for additional service information.
- 4. Replace the controller if it is defective.

If calibration is necessary, proceed as follows:

- Connect a 20,000 ohm per Vdc VOM between the yellow (+) and blue (-) leads or TO+ and TS- pins on the thermostat.
- With the thermostat cover on, insert a 5/64" Allen wrench through the hole on the right-hand side of the thermostat into the setpoint potentiometer shaft.
- 3. Measure the temperature at the thermostat.
- Adjust the thermostat setpoint by rotating the Allen wrench until the setpoint dial reading equals the temperature measured in step 3 above.
- Using the thumb of your left hand, hold the knob in place.
 Avoid touching the lower left-hand corner of the thermostat where the sensor is located.
- 6. Rotate the Allen wrench until VOM reads 7.5 ±.3 Vdc.
- 7. The thermostat is calibrated.

TP-8142 and TP-8125

NOTE .

The TP-8124 and TP-8125 have been factory calibrated to produce 6.0 Vdc output signals at OP1 and OP2 to COM terminals when the setpoints and the temperatures at the sensing element agree.

Test the power supply and output as follows:

- Verify the wiring per the job wiring diagram.
- 2. Measure with a 20,000 ohm per Vdc VOM:
 - a. Power supply 20 Vdc: +20 (+) to COM (-).
 - Heating output: OP1 (+) to COM (-). Vdc varies between 2-15 as SPA is rotated.
 - Cooling output: OP2 (+) to COM (-). Vdc varies between 2-15 as SPB is rotated.
- 3. Replace the controller if it is defective.

If calibration is necessary, proceed as follows:

1. Remove the thermostat cover. Note room temperature

- 2. If room temperature is 75°F or greater:
 - Connect VOM internally to OP2 (+) and COM (-). See Figure 9B for details.
 - Rotate SPB until VOM reads 6.0 ±.3 Vdc. SPB pointer must indicate the temperature measured. If not, hold SPB shaft and rotate pointer (CCW) until it indicates the temperature measured.

SPB is calibrated.

- Disconnect VOM lead from OP2 and reconnect to OP1. Connect Jumper J7 to Pin A.
- d. Connect 1 MEG ±1% resistor (SYZE-13512 test kit) between AB1 and 6.2 connections.
- e. Rotate SPA until VOM reads 6.0 ±.3 Vdc. SPA should read temperature measured minus 10°F. If not, hold SPA shaft and rotate pointer (CCW) until it indicates temperature measured minus 10°F.

SPA is calibrated.

- 3. If room temperature is 74°F or less:
 - Connect VOM internally to OP1 (+) and COM (-). See Figure 9B for details.
 - b. Rotate SPA until VOM reads 6.0 ±.3 Vdc. SPA must indicate the temperature measured. If not, hold SPA shaft and rotate the pointer (CCW) until it indicates the measured temperature.

SPA is calibrated.

- Disconnect VOM lead from OP1 and re-connect to OP2. Connect Jumper J7 to Pin A.
- d. Connect 1 MEG, ±1% resistor (SYZE-13512 test kit) between AB2 and COM connections.
- e. Rotate SPB until VOM reads 6.0 ±.3 Vdc. SPB should read the measured temperature plus 10°F. If not, hold SPB shaft and rotate pointer (CCW) until it indicates the measured temperature plus 10°F.

SPB is calibrated.





Figure 9b



TP-8101, TP-8102 and TP-8103 Block Diagram




Figure 11 TP-8124 and TP-8125 Block Diagram

OPTIONS

TP-8101, TP-8102, TP-8103 (TP-8124 and TP-8125 have no options.)

Remote Setpoint Install the AT-8100 Series remote setpoint adjuster between terminals 1, 2 and 7. These are used for applications where the setpoint adjustment is mounted remote from the controller. See Figure 14, 15 or 16.

Remove the dial rim from the setpoint knob using wire cutters. Turn the dial to 70°F. The AT-11-404 blank cover is recommended to prevent dust infiltration.

Remote Sensing Remove the internal 1000 ohm sensor and install the remote sensor (TS-8000 Series) between terminals 7 and 8. This is used for applications where the sensor is mounted remote from the controller. See Figure 13.

Summer-Winter Changeover is accomplished without remote setpoints or selective ratio discharge. The controller operates in either the DA or RA mode. See Figure 12.

Jumper 4 to 5 — DA (direct-acting): A temperature increase causes an output voltage increase.

Jumper 3 to 4 — RA (reverse-acting): A temperature increase causes an output voltage decrease.

Selective Ratio Discharge Control Connect the ratio discharge sensor (Figure 19) to the room controller as shown in Figure 14, 15 or 16. This is used for room and discharge control applications.

Winter-Summer Operation is accomplished using selective ratio discharge and/or remote setpoints. For direct-acting, see Figure 14. For reverse-acting, see Figure 15. For winter-summer switching, see Figure 16.

For panel mounting, see Figure 18.






Figure 12. TP-8101, TP-8102 and TP-8103 with Single Pole Double Throw (SPDT) Winter-Summer Switching





TP-8101, TP-8102 and TP-8103 with Remote Setpoint and/or Selective Ratio Discharge Sensor Reverse-Acting Output Only






Figure 16
TP-8101, TP-8102 and TP-8103
with Remote Setpoint and/or
Selective Ratio Discharge Sensor
with Double Pole Double Throw (DPDT)
Winter-Summer Switching





RESISTORS						
Degrees	Resistance	B-C Part No.				
5	2.0 MEG. ±5%	-CYZR-481-530				
10	1.0 MEG, ±1%	CYZR-862-501				
15	681K, ±1%, 1/8W	E19-64-481				
20	499K, ±1%, 1/8W	CYZR-862-468				

Figure 17
TP-8101, TP-8102 and TP-8103
with Night Depression and/or
Morning Warm-Up





Figure 18 TP-8101, TP-8102 and TP-8103 Mounted on AD-8951



AUXILIARY RESISTORS						
Ratio	Resistance	B-C Part No.				
25.1	59K =1 1 5W	CYZR-932-66				
30:1	71.5K, =1%, 1/8W	R-868-19				
40.1	95.3K, ±1%, 1/8W	19-29-395				
50:1	121K, ±1%, 1/8W	CYZR-788-12				

TS-8601 Ratio Discharge Sensor for use with TP-8101, TP-8102 and TP-8103

MAINTENANCE

This is a quality product. Regular maintenance of the total system is recommended to assure optimum performance.

Barber-Colman Company ENVIRONMENTAL CONTROLS DIVISION

1354 Clifford Avenue P.O. Box 2940 Loves Park, IL U.S.A. 61132-2940

ALVES

3-WAY MIXING AND DIVERTING VALVES, SCREWED (1/2" TO 2") AND FLANGED (2-1/2" TO 4") WITH HYDRAULIC ACTUATORS

Para, 2,2,2,9 V-1, 3,4,5

TABLE 1. Select Valve Body including P Code

Size Valve Body

Fluid Temp.

°F (°C)

TABLE 1. Select **Valve Body** including **P Code** (Valve Size, Cv Rating, Port Code) or select **Valve Assembly** with correct Input Signal (see Table 3 also) less Actuator Code (XXX) including the **P Code** (Size, Cv Rating, Port Code). (See Pages 331-335 for Valve Sizing.)

78	APPL	ICATION								
Chilled or Hot Water										
Screwed	Flanged	Screwed	Flanged							
	1	100	4							
1/2"—2"	2-1/2"—4"	1/2"—2"	2-1/2"-3"							
VB-9313-0-4-P	VB-9313-0-5-P	VB-9323-0-4-P	VB-9323-0-5-P							

Valve Assembly 2-15 Vdc, System 8000			VS-9313-XXX-4-P	VS-9313-XXX-5-P	VS-9323-XXX-4-P	VS-9323-XXX-5-P
Valve Assemb	Valve Assembly 2-Position SPST			-	VA-9323-XXX-4-P	
Normal Position			Stem Up Flow "B" to "AB"	Stem Up Flow "B" to "AB"	Stem Up Flow "B" to "AB"	Stem Up Flow "C" to "L"
	Flow	Туре	Mixing	Mixing	Diverting	Diverting
color coded as		Body	Bronze	Iron	Bronze	Iron
e selection.		Seat	Bronze	Bronze	Bronze	Bronze
either a valve		Stem	Stainless Steel	Stainless Steel	Stainless Steel	Stainless Steel
rts (actuator.		Plug	Brass	Brass	Stainless Steel	Brass
ris (actuator,		Packing	Spring Loaded Teflon Cone	Spring Loaded Teflon Cone	Spring Loaded Teflon Cone	Grafoil
		Disc	None	None	None	None
				WATER		
313-351-4-11	D	Static	250	125	250	125
313-0-4-11	Pressure (psig)	Recom. Diff.*	35	35	35	35

TO SELECT A PORT CODE (P)

Max.

40° (4°)

281° (138°

P Code	Valve Size		C	Y		
-2**	1 /0"	2				
-4	1/2"	4		6		
-6	3/4"	6.8		8		
-8	1"	12	100 PM	12		
-9	1-1/4"	16		16		
-10	1-1/2"	33		30	Pr	ort
-11	2"	55		42	"U"	"L"
-12	2-1/2"		74		68	75
-13	3"		101		85	95
-14	4"		170			

40° (4°)

300° (149°

40° (4°)

281° (138°

40° (4°)

300° (149°

*Maximum recommended differential pressure in full open position. Do not exceed recommended differential pressure (pressure drop) or integrity of parts may be affected.

NOTE. Do not exceed close-off rating.

"NOTE. Factory assemblies are not available for 2-position applications using reduced port valve bodies.

NOTE: These charts are color coded as shown below to assist valve selection. Note it is possible to select either a valve assembly or component parts (actuator, valve linkage, valve body).

ORDERING EXAMPLES:

1. Valve

Assembly VS-9313-351-4-11

2. Valve Body VB-9313-0-4-11 Actuator MS-83013

Linkage AV-430

Valve Body Data less P Code (Size, Cv Rating, Port Code) or Valve Assembly less Actuator and less P Code (Size, Cv Rating, Port Code)

P Code (Size, Cv Rating, In Code)

Actuator or Actuator Code (XXX) for Valve Assemblies

☐ Valve Linkage

3-WAY MIXING AND DIVERTING VALVES, SCREWED (1/2" TO 2") AND FLANGED (2-1/2" TO 4") WITH HYDRAULIC ACTUATORS

TABLE 2. Select Actuator Type or Actuator Code (XXX). series with correct Input Signal having sufficient close-off for the application. If selecting Component Parts, select

Palve Linkage.					-	1500	-	1	
Valve Li	nkage VB-9313-0-4-P			AV	-600	AV	-600	EY ASSETS	
Valve Li	nkage VB-9313-0-5-P				_	- "	_	AV-430 AV-495 AV-430	
	nkage VB-9323-0-X-P			AV	-600	AV	-600		
	Input Signal				PST		5 Vdc		
Actu	ator Code (XXX)		Statement - married	-2	XX		XX	2-15 Vdc **	
April 1	ctuator Type				1X-XXX	MP-5X1X-XXX		-35X MS-8XX1X-XX	
	The state of the state of		Especial Special				SSURE RATI		NIA-NAA
Valve	Valve Body	P Code	Size	SU*	SD*	SU*	SD*	SU*	80*
		-2-4	1/2"	100	100	110	100	- 00	OU
	VB-9313-0-4: P	-6	3/4"	55	55	55	55		
VA-9313-XXX-4-P VS-9313-XXX-4-P		-8	1"	35	35	35	35		
VS-9313-XXX-4-P		-9	1-1/4"	22	22	22	22		
		-10	1-1/2"		EMPHONES AT SUR-TUR	100000000000000000000000000000000000000		35	33
		-11	2"					35	33
W0 0010		-12	2-1/2"		The LE		7.2. 196	20	20
VS-9313-XXX-5-P	VB-9313-0-5-P	-13	3"			60		12	12
		-14	4"					6	6
		4	1/2"	250	250	250	250		-
		-6	3/4"	250	250	250	250		
VA-9323-XXX-4-P	VB-9323-0-4-P	-8	1"	250	250	250	250		
VS-9323-XXX-4-P		-9	1-1/4"	250	250	250	250		
		-10	1-1/2"					250	250
The second of th		-11	2"	Thur diligion	War was	- 100		250	250
VS-9323-XXX-5-P	VR-9323-0-5-P	-12	2-1/2"	and the same		100 ESPT		125	125

"SU — Stem Up; SD — Stem Down; See Table(s) 5 for flow pattern, port designations, and normal position.

*Close off ratings for mixing or sequencing valves: (SU ="A" port, SD = "B" port) "A" port (SU) ratings equal pressure at port "A" minus pressure at port "B"; "B" port (SD)

**Certain models have built-in controller (See Table 3).

TABLE 3. Select exact Actuator or Actuator Code (XXX) if Factory Assembly is available

Input Signal	Wiring Figure No.	Voltage Vac 50/60 Hz	VA	Aux. Switch	Actuator Part No.	Actuator Code (XXX) For Factory Available Assy
		24		No	MA-5213	201
8		24		Yes	MA-5213-500	202
No. of the second secon		120	47.	No	MA-5210	211
Two-position SPST	See Figure 1	120	18	Yes	MA-5210-500	212
1	on Page 336	208	10	No	MA-5212	
di water and the		208	1	Yes	MA-5212-500	
		240		No	MA-5211	221
		240	53.0	Yes	MA-5211-500	222
		24		No	MP-5213	201
		24		Yes	MP-5213-500	202
	See Figure 12 on Page 339	120	18	No	MP-5210	211
2-15 Vdc, System 8000, Stroke occurs 6-9 Vdc approx.		120		Yes	MP-5210-500	212
Non-positive positioning		208		No	MP-5212	
		208		Yes	MP-5212-500	
		240		No	MP-5211	221
		240		Yes	MP-5211-500	222
		24		No	MP-5413	243
	See Figure 12	120	18	No	MP-5410	240
	on Page 339	208		No	MP-5412	1 - 3,35,500 - 13
2-15 Vdc, System 8000, start 6 Vdc factory set,		240		No	MP-5411	241
Adjustable 2-12 Vdc, 3 Vdc span, Positive positioning		24	36	No	MS-83013	351
	See Figure 12	120	37	No	MS-83010	353
	on Page 339	120	37	Yes	MS-83010-500	
		240	39	No	MS-83011	
		240	39	Yes	MS-83011-500	2.151.
		120	37	No	MS-84110	354
Built-in System 8000 controller, Uses TS-8XXX sensor	See Figure 19	120	37	No	MS-84110-011*	
	on Page 343	120	37	Yes	MS-84110-500	
ludes TS-8201-105 sensor		24	36	No	MS-84113	

2-WAY VALVES, SCREWED (1/2" TO 2") AND FLANGED (2-1/2" TO 4")

WITH HYDRAULIC ACTUATORS V-2.6

Para. 6.2.8

2.2,2.9

TABLE 1. Select Valve Body including P Code (Valve Size, Cv Rating, Port Code) or select Valve, Assembly with correct Input Signal (see Table 2 also) less Actuator Code (XXX) including the P Code (Size, Cv Rating, Port Code). (See Pages 331-335 for Valve Sizing.)

	APPL	ICATION		
Chilled or I 281°F 35 psig	Max.	Hot Water 300°F Max. 100 psig Steam	Hot Water 366°F Max. 150 psig Steam	
Screwed	Flanged	Scr	ewed	
S.	B			

	Size	1/2"—2"	2-1/2"-4"	1/2"-2"	1/2"-2"
	Valve Body	VB-9213-0-4-P	VB-9213-0-5-P	VB-9253-0-4-P	VB-9273-0-4-P
Normally Open Valves	Valve Assembly 2-15 Vdc Input, System 8000	VS-9213-XXX-4-P	VS-9213-35X-5-P	VS-9253-XXX-4-P	VS-9273-XXX-4-P
	Valve Assembly, Built-in System 8000 Controller	VS-9213-35X-4-P	VS-9213-35X-5-P	VS-9253-35X-4-P	VS-9273-35X-4-P
Agives	2-Position SPST Valve Assembly	VA-9213-2XX-4-P		VA-9253-2XX-4-P	VA-9273-2XX-4-P
	Valve Body	VB-9223-0-4-P	VB-9223-0-5-P	VB-9263-0-4-	VB-9283-0-4-P
Normally	Valve Assembly 2-15 Vdc Input, System 8000	VS-9223-XXX-4-P	VS-9223-35X-5-P	VS-9263-XXX-4-P	VS-9283-XXX-4-P
Closed Valves	Valve Assembly, Built-in System 8000 Controller	VS-9223-35X-4-P	VS-9223-35X-5-P	VS-9263-35X-4-P	VS-9283-35X-4-P
	2-Position SPST Valve Assembly	VA-9223-2XX-4-P		VA-9263-2XX-4-P	VA-9283-2XX-4-P
		E 101		=	

NOTE: These charts are color coded as shown below to assist valve selection. Note it is possible to select either a valve assembly or component parts (actuator, valve linkage, valve body).

ORDERING EXAMPLES:

- 1. Valve
 - Assembly VS-9223-212-4-8
- 2. Valve Body VB-9223-0-4-8 Actuator MP-5210-500

Linkage AV-600

- Valve Body Dala less P Code (Size, Cy Hating, Port Code) or Valve Assembly less Actuator Code (XXX) and loss P Code (Size, Cv Raling, Port Gode)
- P Code (Sazo, Cv Haling, Port Code)
- Actuator of Actuator Code (XXX) for Valve Assemblies
- ☐ Yelve Linkage

1 8000 Contro	ller	VS-9223-35X-4-P	VS-9223-35X-5-P	VS-9263-35X-4-P	VS-9283-35X-4-P
ssembly		VA-9223-2XX-4-P	- 1	VA-9263-2XX-4-P	VA-9283-2XX-4-P
Flow	Гуре	Equal %	Equal %	Equal %	Equal %
	Body	Bronze	Cast Iron	Bronze	Bronze
	Seat	Bronze	Bronze	Stainless Steel	Stainless Steel
	Stem	Stainless Steel	Stainless Steel	Stainless Steel	Stainless Steel
Material	Plug	Brass	Brass	Stainless Steel	Stainless Steel
	Packing	Spring Loaded Teflon Cone	Spring Loaded Teflon Cone	Spring Loaded Teflon Cone	Spring Loaded Teflon Cone
	Disc	Composition	Composition	Teflon	None
			STEAM		
	Static	250	125	250	250
Pressure	Inlet	35	35	100	150
(psig)	Recom. Diff.*	20	20	35	50
Fluid Tomp. "F ("C)	Max.	281" (138")	.'81" (1:88")	340" (171")	366" (180")
			WATER		
Pressure	Static	2".0	125	250	250
(psig)	Hocom Diff.*	35	35	35	50
Huld Lamp.	Min	40" (4")	40" (4")	40" (4")	40" (4")
t [c)	Max	(138")	201" (138")	300" (149")	366" (180")

TO SELECT A PORT CODE (P)

P todo	Valve Size			Cv	
1		0.4		0.4	04
7**	1/2"	1.1		13	13
3	1111	2.2		32	22
4		16		3.6	3.0
P.**	3/4"	5.0		50	50
b	3/4	6.2		63	0.9
1	1"	8.2		8.2	H.9 «
- 11		110		110	110
9	1 1/4"	16.0		160	160
10	1 1/2"	75.0		25.0	250
- 11	2"	40.0		40 0	40.0
12	2 1/2"		56		
13	3"		85		are are arrested in the
14	4"	and the same	145	after golden to all the gard	to vill tillger mediative

^{*}Maximum recommended differential pressure in full open position. Do not exceed recommended differential pressure (pressure drop) or integrity of parts may be affected.

NOTE: Do not exceed close-off rating.

2-WAY VALVES, SCREWED (1/2" TO 2") AND FLANGED (2-1/2" TO 4") WITH HYDRAULIC ACTUATORS

TABLE 2. Select **Actuator Type** or **Actuator Code (XXX)** series with correct Input Signal having sufficient close-off for the application. If selecting Component Parts, select







Input Signal Valve Linkage 1/2" — 1-1/4" Valve Valve Linkage 1/2" — 2" Valve					Two-Position SPST	2-15 Vdc System 8000	2-15 Vdc System 8000*
					AV-600	AV-600	_
						_	AV-430
	Valve Linkage 2-1/2" —		TO FAL				AV-495
	Actuator Code (XX	X)			2XX	2XX	35X
4/	Actuator Code				MA-521X-XXX	MP-5X1X	MS-8XX1X-XXX
Normal Position	Factory Avail. Valve Assembly	Valve Body	P Code	OIL	CI	OSE-OFF PRESSURE RAT	
	VA-9213-2XX-4-P VA-9253-2XX-4-P		-1-2-3-4	1/2"	180	190	
		VB-9213-0-4-P VB-9253-0-4-P VB-9273-0-4-P	-5-6	3/4"	75	85	
Normally Open	VA-9273-2XX-4-P		-7-8	1"	40	45	
or many open	VS-9213-XXX-4-P		-9	1-1/4"	25	30	
	VS-9253-XXX-4-P VS-9273-XXX-4-P		-10	1-1/2"			65
1. 7.	10 3E10 XXX 41		-11	2"			35
		VB-9213-0-5-P	-12	2-1/2"			20
Normally Open	VS-9213- 35 X-5-P		-13	3"			12
			-14	4"			6
A section	VA-9223-2XX-4-P	To 1 Other 1	-1-2-3-4	1/2"	250	220	
	VA-9263-2XX-4-P		-5-6	3/4"	140	90	
Normally Closed VA-9283-2XX-4-P VS-9223-XXX-4-P VS-9263-XXX-4-P	VB-9223-0-4-P VB-9263-0-4-P	-7-8	1"	75	50		
	VB-9283-0-4-P	.9	1-1/4"	45	30		
	VS-9283-XXX-4-P VS-9283-XXX-4-P		-10	1-1/2"			65
整数	10 3200 XXX-4-P		-11	2"			35
			-12	2-1/2"			20
iormally Closed	VS-9223-35X-5-P	VB-9223-0-5-P	-13	3"			12
			-14	4"			6

^{*}Close-off pressure ratings apply when valves are installed with pressure under the seat.

TABLE 3. Select exact Actuator or Actuator Code (XXX) if Factory Assembly is available

Input Signal	Wiring Figure No.	Voltage Vac 50/60 Hz	VA	Aux. Switch	Actuator Part No.	Actuator Code (XXX) For Factory Available Assy
·		24		No	MA-5213	201
		24		Yes	MA-5213-500	202
		120		No	MA-5210	211
Two-position SPST	See Figure 1	120	18	Yes	MA-5210-500	212
THE POSITION OF ST	on Page 336	208	18	No	MA-5212	
		208		Yes	MA-5212-500	
		240		No	MA-5211	221
		240		Yes	MA-5211-500	222
		24		No	MP-5213	201
	See Figure 12 on Page 339	24	18	Yes	MP-5213-500	202
		120		No	MP-5210	211
2-15 Vdc, System 8000, Stroke occurs 6-9 Vdc approx.		120		Yes	MP-5210-500	212
Non-positive positioning		208		No	MP-5212	Selection of the select
		208		Yes	MP-5212-500	
		240		No	MP-5211	221
		240		Yes	MP-5211-500	222
		24	18	No	MP-5413	243
	See Figure 12	120		No	MP-5410	240
	on Page 339	208		No	MP-5412	
2-15 Vdc, System 8000, start 6 Vdc factory set.		240		No	MP-5411	241
Adjustable 2-12 Vdc, 3 Vdc span, Positive positioning		24	36	No	MS-83013	351
	Can Figure 40	120	37	No	MS-83010	353
	See Figure 12 on Page 339	120	37	Yes	MS-83010-500	
	on raye 333	240	39	No	MS-83011	
		240	39	Yes	MS-83011-500	
		120	37	No	MS-84110	354
Built-in System 8000 controller, Uses TS-8XXX sensor	See Figure 19	120	37	No	MS-84110-011*	•
Som in System 6000 Controller, USES 13-0XXX SENSOR	on Page 343	120	37	Voc	MS-84110-500	

[&]quot;Certain models have built-in controller.

3-WAY MIXING AND DIVERTING VALVES, SCREWED (1/2" TO 2") AND FLANGED (2-1/2" TO 4") WITH HYDRAULIC ACTUATORS


TABLE 4. Dimensions


	DIME	NSIONS (In	ches)			
Server Ingeles	Valve Body					
	200*	350				
Part Number	Size	A	C	E	E	
	1/2"	3	1-7/16	7-15/16		
VA-9313-XXX-4-P	3/4"	3-5/8	1-7/8	8-1/4		
VS-9313-XXX-4-P	1"	4-5/8	2-1/4	8-1/2		
VS-9323-XXX-4-P	1-1/4"	4-5/8	2-3/4	8-1/2		
VA-9323-XXX-4-P	1-1/2"	6-1/8	3-7/8		18-5/8	
	2	6-1/8	3-7/8		18-5/8	
	2-1/2"	8-1/2	5-3/8		19-7/16	
V8-9313-35X-5-P	3"	9-1/2	6-3/8		19-13/16	
	4"	11-1/2	8-1/2		20-7/16	
V8-9323-35X-5-P	2-1/2"	9	7		20-3/4	
	3"	10	8		21-9/16	

^{*}Add 21/32" (52 mm) to the "E" dimension for a valve assembly using an AV-601 linkage extension that must be purchased separately.

Dimensions in inches (metric conversion 25.4 mm = 1 inch)


NOTE: Allow 3 inches clearance above actuator for removal.





Wiring Figure No. 1


2-POSITION, 2-WIRE ELECTRIC. SPST CONTROLLER REQUIRED. ALL UNITS ARE SPRING RETURN.



Valve Assembly	Normal Position	Powered Position	
VA-1112-6XX			
VA-921X-2XX	0	Closed	
VA-9253-2XX	Open		
VA-9273-2XX			
VA-922X-2XX		Open	
VA-9263-2XX	Closed		
VA-9283-2XX			
VA-9312-2XX	Flow	Flow	
VA-9313-2XX	"B" to "AB"	"A" to "AB"	
VA-9323-2XX	Flow "B" to "AB"	Flow "B" to "A"	

Wiring Figure No. 2

2-POSITION, 2-WIRE ELECTRIC. SPST CONTROLLER REQUIRED. ALL UNITS ARE SPRING RETURN.



Valve Assembly	Normal Position	Powered Position
VA-9213-30X		
VA-9253-30X	Open	Closed
VA-9273-30X		
VA-9213-31X		
VA-9253-31X	Closed	Open
VA-9273-31X		
VA-9313-30X	Flow "B" to "AB"	Flow "A" to "AB"
VA-9323-30X	Flow "B" to "AB"	"B" to "A"

Wiring Figure No. 3

2-POSITION, 2-WIRE ELECTRIC. SPST CONTROLLER REQUIRED. ALL UNITS ARE SPRING RETURN. Terminals 1, 5 & 6 are used for built-in auxiliary switch.

These terminals Install Jumper are marked L1 & L2 on line voltage (4) (5 (8) (7) actuators Control Actuator

Terminals 1, 5 & 6 are used for

MP-36X, 46X, 46XX ACTUATORS

MP-37X, 47X, 47XX


Valve Assembly	Normal Position	Powered Position	
VP-9213-3XX			
VP-9253-3XX	Claud	Open	
VP-9273-3XX	Closed		
VP-2224-15X			
VP-9313-3XX	Flow "A" to "AB"	Flow "B" to "AB"	
VP-9323-3XX-4	Flow "B" to "A"	Flow "B" to "AB"	
VP-9323-3XX-5	Flow "C" to "U"	Flow "C" to "L"	

NOTE: Switch control circuit is 0.5 amp at approx. 24 Vac on either low or line voltage actuators.

Wiring Figure No. 4

Controller

2-POSITION, 2-WIRE ELECTRIC. SPST CONTROLLER REQUIRED. ALL UNITS ARE SPRING RETURN.




Remove

Green Wire

to Unground Actuator

Valve Assembly	Normal Position	Powered Position	
VP-9213-3XX			
VP-9253-3XX	0	Closed	
VP-9273-3XX	Open		
VP-2224-15X			
VP-9313-3XX	Flow "B" to "AB"	"A" to "AB"	
VP-9323-3XX-4	Flow "B" to "AB"	Flow "B" to "A"	
VP-9323-3XX-5	Flow "C" to "I"	Flow "C" to "U"	

NOTE Switch control circuit is 0.5 amp at approx 24 Vac on either low or line voltage actuators



"L," to "3"

on Actuator

Open

Flow

"B" to "AB"

"L1" to "2"

on Actuator

Closed

Flow

"A" to "AB"


Valve


Assembly

VP-9213

VP-9313


MP-9810 ACTUATOR







Wiring Figure No. 12

SYSTEM BROSE 2-15 VDC INPUT






Valve Assembly	Increasing Vdc Input Signal	Normal Position Decreasing Vdc	
VP-1112			
VS-9211			
VS-9212	-		
VE THE A	Closed	Open	
VS-9253			
VS-9273			
VS-9221		S TREET	
VS-9222		Closed	
VS-9223	Open		
VS-9263			
V\$-9283			
MU-9393	Flow "A" to "AB"	Flow "B" to "AB"	
VS-9323-XXX-4	Flow "B" to "A"	Flow "B" to "AB"	
VS-9323-XXX-5	Flow "C" to "U"	Flow "C" to "L"	



Auxiliary switch shown with actuator retracted field adjusted 0-100% of stroke





General Instructions

TC-1151, TC-1152, TC-1153
Electric Two-Stage
Room Thermostats
Two-Position

For on-off control applications which require sequenced switching of two heating devices or two cooling devices.

Two bimetal operated snap action SPDT switches. Coded screw terminals. Switch differential adjustable 1 to 2°F. Differential between stages 2 to 10°F, factory set at 2 to 3°F. Units have plastic covers as standard. Mounts on flush 2-gang switch box or 4" × 4" surface box, or directly to wall (24 volt only).

Dimensions: 4-3/8" high × 4-3/4" wide × 1-5/8" deep.

ACCESSORIES

AT-101 Lock cover kit

AT-104 Dial stop pins (note: pins included with each unit)

AT-136 Title plates (day, night, heat, cool)

AT-546 Auxiliary mounting plate

AT-607 Selector switch sub-base DP4T

AT-608 Selector switch sub-base one DP4T, one DPDT


AT-1153 Wire guard


AT-1163 Plastic guard

AT-1165 Plastic guard

Tool-11 Calibration wrench

Tool-13 Contact burnishing tool






Note: Thermostat is designed for either heat or cool applications, not heat and cool.

Part	Control*	Full Los	ad Amps	Pilot Duty
Number	Dial Range	120 Vac	240 Vac	(VA)
TC-1151	55- 85°F (13-29°C)			20 @ 24 Vaa
TC-1152	45- 75°F (7-23°C)	3.0	1.5	28 @ 24 Vac
TC-1153	75-105°F (24-40°C)			140 @ 120/240 Vac

*Units dual marked in °F and °C; dial stop pins included to limit dial range.

OPTIONS

Add "dash-number" (-XXX) suffix to base part number for desired option.



- -500 Parallel Heat Anticipation 24V Standard Cover
- -501 Parallel Heat Anticipation 120V Standard Cover
- -502 Parallel Heat Anticipation 240V Standard Cover

- -601 10°F Night Depression 120V Standard Cover† -602 10°F Night Depression 24V Standard Cover†
- -603 10°F Night Depression 240V Standard Covert

†Normally, night depression is controlled by a centrally located time clock such as AE-174 or AE-178, or by selector switch sub-bases (AT-602 or AT-603).


INSTALLATION

Requirements


Locate thermostat where it will be exposed to unrestricted circulation of air which represents the average temperature of the controlled space. Do not locate the thermostat near sources of heat or cold, such as lamps, motors, sunlight or concealed ducts or pipes. The thermostat is designed for service in any normally encountered human environment.

Procedure

1. Pull all wires (Use copper wire only.)



- Fasten mounting plate to box or wall.
- Make electrical connections to thermostat screw type terminals. Make all connections in accordance with the job wiring diagram and in compliance with national and local electrical codes. Class I wiring is required unless all circuits to contacts are powered from a Class II source.
- Hook thermostat on top of mounting and swing down into place.
- Remove thermostat cover, attach thermostat to mounting plate with mounting screw, and attach thermostat cover.



CHECKOUT

After installing a thermostat, make an initial check of the switching action. Verify the switch action by listening to and watching the switch contacts, using a voltmeter between the proper sides of the switch, or observing the controlled device.

- Slowly turn the setpoint dial to a temperature above ambient. First the "R" contact should make and then "R1" contact should make.
- Slowly turn the setpoint setting down gradually and "B1" contact should make and "B" contact should make.

CALIBRATION

All thermostats are calibrated at the factory and normally will not require any such attention. However, if recalibration is necessary for any reason, proceed as follows:

- 1. Disconnect power to thermostat.
- Set the adjusting dial to correspond to actual room 'temperature.
- Remove thermostat cover, remove screw that secures right-hand of insulator, fold back insulator, and remove contact covers. (See Figure 1.)

Do not breathe on the thermostat or handle excessively as this will affect the accuracy of the final calibration.

 If the right contact blade is not made to "R" contact, use a 3/16" open end wrench to turn dial calibration screw clockwise (looking at the head of screw) until element makes to "R" contact.

Note: Each complete revolution of screw changes calibration approximately 6°F.

- Turn dial calibration screw counterclockwise until blade just breaks "R" contact.
- Temporarily replace the cover and set the dial to a higher temperature setting. The difference between the two settings should be equal to the amount of desired differential between stages (2 to 10°F).
- Remove the cover. If the left contact blade is not made to "R1", turn the between stage differential screw clockwise until element makes "R1" contact.
- Turn the between stage differential screw counterclockwise until blade just breaks "R1" contact. Unit is now calibrated.
- 9. Replace contact covers, insulator and thermostat cover.
- Recheck calibration about 30 minutes later to be sure heat from handling did not result in erroneous setting.

MAINTENANCE

Open areas at bottom and around base of thermostat should be kept clean and free from obstructions to allow proper flow of air. If switch contacts need cleaning, this may be done with a Tool-13 contact burnishing tool.

REPAIR

Field repair of the thermostat is not recommended. If the system is not operating correctly and the reason is traced to the thermostat, it should be replaced.




Figure 1

Barber-Colman Company ENVIRONMENTAL CONTROLS DIVISION

1354 Clifford Avenue P.O. Box 2940 Loves Park, IL U.S.A. 61132-2940



General Instructions

AT-602, 603, 607, 608 & 609-XXX Selector Switch Sub-Bases and Legend Plates


For use at the room thermostat to accommodate switching functions such as heating to cooling, day to night control, etc. **Device:** Rugged one piece molded beige plastic housing. One or two slide switches are double-pole, double throw (DPDT) or double pole-4 position (DP4T) allowing numerous control possibilities. DP4T can be used as two or three position by installing switch legend plates that limit switch travel. Coded screw terminals for the switch contacts are accessible for up to two No. 14 gauge wire connections. See Figure 2.


Installation

Use Class I wiring for all connections to switch subbases and to room thermostat unless all circuits are powered from a Class II source. Make all connections in accordance with national and local codes.

Install subbases on a flush switch box, a surface switch box or directly on a wall (for 24V applications only).


- 1. Pull the required wires.
- If plastic conduit box is used, connect green wire from subbase to system ground, otherwise clip out the green wire.
- Mount the subbase (see Figure 1). Screws are provided for switch box mounting.
- Connect proper wires to subbase screw terminals. Push
 excess wire into conduit box, allowing field wires (if any) for
 room thermostat to project through opening in subbase.
- Make all electrical connections to thermostats and install any jumpers as required. Refer to job wiring diagram and/or General Instruction Sheet for thermostat.
- 6. Install thermostat on subbase (see Figure 1).
- To install switch legend plate on subbase strip the paper backing off and press plate into subbase. Note: Legend plates must be ordered separately.






لِال Typical Single Unit Sub-Base

UL Typical Duplex Unit
Sub-base





Duplex Thermostat on Duplex Sub-Base

Figure 1

Single Thermostat on Single Sub-Base


	Switch Description				
Part Number	Upper Right	Lower Right	Used With		
AT-602		DP4T	All Single Room Therm		
AT-603	DPDT	DP4T	stats Except TK's, TA-115, TA-121, TA-133, TA-134, TC-114, and TC-142.		
AT-607	100	DP4T	TA-151, 115X, TC-15		
AT-608	DPDT	DP4T	114X, 115X, 116X, 2-Stage and Duplex Thermostats.		

	Inc	luctive		
Volts (AC)	Full Load Amps	Locked Rotor Amps	Non- Inductive Amps	Pilot Duty (VA)
24	5.8	34.8	6	125
120	5.8	34.8	6	125
240	2.9	17.4	3	125

^{*}The total load on both poles of a switch must not exceed the total electrical rating.

TYPICAL APPLICATIONS


THERMOSTAT CYCLES VALVE, SUMMER/WINTER CHANGEOVER THERMOSTAT, OFF-LOW-HIGH FAN



ITEMS: TC-1101, AT-602, AT-609-302


THERMOSTAT CYCLES 2 STAGES HEAT AND 1 STAGE COOL, HEAT-COOL SWITCH, OFF-LOW-HIGH FAN SWITCH

THERMOSTAT PROVIDES SEQUENCED HEAT & COOL, ON-OFF SWITCH, OFF LOCKS OFF SYSTEM & FAN, LOW-MED-HIGH FAN SWITCH




ITEMS: TC-1191; AT-603; AT-609-353

THERMOSTAT PROVIDES SEQUENCED HEAT & COOL OFF-HEAT-AUTO-COOL SWITCH




ITEMS: TC-1191, AT-602, AT-609-402

THERMOSTAT CYCLES HEAT & COOL, HEAT-COOL SWITCH, OFF-LOW-HIGH FAN SWITCH




ITEMS: TC-154, AT-608, AT-609-352



ITEMS: TC-1101; AT-603; AT-609-352

THERMOSTAT CYCLES HEAT AND COOL, HEAT-COOL



ITEMS: TC-1101, AT-602, AT-609-204

AT-609-XXX

Legend Plates for Switch Sub-Bases

Various switch indicating plates are available and must be ordered separately. These have a brown simulated leather finish with bright letters and pressure sensitive backing for simplified field installation. Blank plate on left side of AT-602 & 603 is factory installed.





Figure 2

										AT-6	09-X	XX S	WIT	CH	LEG	EN	D PL	ATES								
Switch Publish	Switch Action		Blank Plates*					Plates With Legends																		
LESSEEM	Rentan	291	301	401	250	350	450	202	203	284	205	208	251	252	253†	302	303	395	396	397	351	352	353	402	403	452
A	DPDT		le lis										On Off	On Off	On Auto			grude ix les		579.5	On Auto Fan	Heat	On Off			On Auto
В	DP4T																							Offi Heat Auto Cool	Off Low Med High	Off Heat Auto Gool
c	DP3T															Off Low High	Heat Off Cool	Occu Off Unoccu	Night Off Day	Off On Auto	Heat Off Gool	Off Low High	Low Med High			
D	DPDT							On Off	Occu Unoccu	Heat Cool	Night Day	Auto On	Low High	High Low	High Low		Service of			0.00						

[&]quot;Special lettering can usually be provided by local nameplate engravers. "Legend Plate limits travel of DP4T Switch to provide DPDT or DP3T. †"Fan Operation" legend placed between switches.

SWITCH POSITIONS



Barber-Colman Company ENVIRONMENTAL CONTROLS DIVISION

1354 Clifford Avenue P.O. Box 2940 Loves Park, IL U.S.A. 61132-2940

COLMAN General Instructions

OA. T'STAT

TC-4100 Series
TC-4200 Series
Bulb Thermostats
Return Air Thermostats

For on-off control of media temperature in ducts, tanks, liquid lines, etc.

TC-4100 Series **one stage** units control one electrical circuit. Available in single or dual bulb configurations. (See Performance Table.)

TC-4200 Series **two stage** units control two electrical circuits in sequence. Available in single or dual bulb configurations. (See Performance Table.)

Dual bulb units are used to vary the control point of the controlled media as a function of outside air temperature. The ratio specified is outdoor to indoor. A unit with a 1 to 1-1/2 ratio will increase the water temperature 1-1/2°F for a 1°F decrease in outdoor temperature.

Air bulb units feature a coiled, fast responding air bulb. Used in return air control applications.

Device: Liquid filled thermal element actuates one snap acting SPDT switch per stage. Large color coded terminals. Setpoint adjustment dial plate is marked in °F on one side and °C on the other. The thermal differential is adjustable within the limits shown in the performance table. The mechanism is enclosed in a metal case and the cover, and has 1/2-inch to 3/4-inch conduit opening in the bottom of the case. Remote bulbs are suitable for immersion, duct, or outside air mounting.

Dimensions


Bulb Units: 2-1/4" (57 mm) Wide × 4-5/8" (117 mm) High × 2" (51 mm) Deep.

Air Bulb Units: 2-1/4'' (57 mm) Wide \times 9" (229 mm) High \times 2" (51 mm) Deep.

Electrical Rating: All Units Except TC-4115*

Switch Rating (50/60 Hz)	24V	120V	240V
Full Load Amps	9.8	9.8	8.0
Locked Rotor Amps	58.8	58.8	48.0
Pilot Duty VA	60	360	360
Non-Inductive Amps (Resistive)	_	_	_
Single Stage	22	22	22
Two Stage	16	16	8.0


^{*}TC-4115 for System 8000 and dry circuit switching Electrical Rating: 1.0 amp at 24 Vac; .25 amp at 24 Vdc.





Typical Air Bulb (Single or Two Stage)





Performance and Selection Table


		Setpoint	Dualt		Dimensions		Diffe	rential	Maximum	Case	
Туре	Part Number	Adjustment Range	Bulb Ratio	Capillary (Copper)	Bulb (Copper)	Factory Set	Adjustable	Safe Bulb Temperature	Ambient Temperatur	
	TC-4111	-40 to 120°F		6					170°F		
	TC-4111-020	40 10 120		20						1 CO	
	TC-4112	100 to 260°F		6'			3°F	la su poello	310°F	i i ubba-	
Single Stage Single Bulb	TC-4115*	-40 to 120°F			3/8	× 4"		3 to 16°F	170°F	-40 to 150°	
4	TC-4121	-40 10 120 1									
	TC-4122	100 to 260°F		10' Armored	and the same				310°F	-	
	TC-4123	190 to 350°F							400°F		
					Indoor	Outdoor			Total of indoor and outdoor	2 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	
Single Stage Dual Butb	TC-4151	70 to 120°F	1:1-1/2	30' Each Bulb	3/8 × 4" 3/8 × 5-1/2"		3°F	1.5 to 10°F	temperatures must not exceed	-40 to 150°	
	TC-4152		1:1		3/8 × 4"	3/8 × 4"		3 to 16°F	280°F		
One Stage Air Bulb	TC-4166	50 to 90°F		None		oiled 2 × 2"	2°F	Fixed	-40 to 145°F Sate Bulb Range	-40 to 150°	
	TC-4211			6'				Per Stage	170°F		
Two Stage	TC-4221	-40 to 120°F			2/0	3 × 4"	3°F	Fixed	1701	-40 to 150°	
Single Bulb	TC-4222	100 to 260°F		10' Armored	3/0	^ 4	3 1	Between Stages	310°F	10.0.00	
	TC-4223	190 to 350°F		741110100		三年 医疗证明		2 to 10°F	400°F		
					Indoor	Outdoor		Per Stage Fixed	Total of indoor	Barrier V	
Two Stage Dual Bulb	TC-4251	70 to 120°F	1:1-1/2	30' Each Bulb	3/8 × 5-1/2" 3/8 × 4"		3°F	Between Stages 1.5 to 6.5°F	and outdoor temperatures must not exceed 280°F	-40 to 150°	
	TC-4252		1:1		3/8 × 4"	3/8 × 4"		2 to 10°F	200 1		
Two Stage	TC-4266	50 to 90°F		None		piled	3°F	Per Stage Fixed 2°F Between Stage Adj	-40 to 145°F Sate Bulb Range	-40 to 150°	

^{*}TC-4115 for System 8000 and dry circuit switching. Electrical Rating: 1.0 amp at 24 Vac: .25 amp at 24 Vdc. *TC-4151 and TC-4251 — For 1-1/2:1 ratio reverse bulbs and use extra dial supplied with unit.

Ratio Selection Table

Outdoor Temperature	Ratio											
(°F)		Dial Set at 70°F	Dial Set at 80°F	Dial Set at 90°F	Dial Set at 100°F	Dial Set at 110°F	Dial Set at 120°F					
	1 10 1-1/2	70 to 220	80 to 230	90 to 240	100 to 250	110 to 260	120 to 270					
-30	1 to 1	70 to 170	80 to 180	90 to 190	100 to 200	110 to 210	120 to 220					
	1-1/2 to 1	70 to 137	80 to 147	90 10 157	100 to 167	_						
	1 to 1-1/2	70 to 205	80 to 215	90 to 225	100 to 235	110 to 245	120 to 255					
-20	1 to 1	70 to 160	80 to 170	90 to 180	100 to 190	110 to 200	120 to 210					
	1-1/2 to 1	70 to 130	80 to 140	90 to 150	100 to 160	_						
	1 to 1-1/2	70 to 190	80 to 200	90 to 210	100 to 220	110 to 230	120 to 240					
-10	1 to 1	70 to 150	80 to 160	90 to 170	100 to 180	110 to 190	120 to 200					
	1-1/2 to 1	70 to 123	80 to 133	90 to 143	100 to 153	-						
manufacturer account on the state of the	1 to 1-1/2	78 to 175	80 to 185	90 to 195	100 to 205	110 to 215	120 to 225					
0	1 to 1	70 to 140	80 to 150	90 to 160	100 to 170	110 to 180	120 to 190					
	1-1/2 to 1	70 to 117	80 to 127	90 to 137	100 to 147							
	1 to 1-1/2	70 to 160	80 to 170	90 to 180	100 to 190	110 to 200	120 to 210					
+10	1 to 1	70 10 130	80 to 140	90 to 150	100 to 160	110 to 170	120 10 180					
	1-1/2 to 1	70 to 110	80 to 120	90 to 130	100 to 140	-	<u> </u>					
	1 10 1-1/2	70 to 145	80 to 155	90 to 165	100 to 175	110 to 185	120 to 195					
+20	1 10 1	70 to 120	80 to 130	90 to 140	100 to 150	110 to 160	120 to 170					
	1-1/2101	70 to 103	80 to 113	90 to 123	100 to 133							
NECESSARIE SERVICES SERVICES DE LA CONTRACTOR DE LA CONTR	1 to 1-1/2	70 to 130	80 to 140	90 to 150	100 to 160	110 to 170	120 to 180					
+30	1 10 1	70 to 110	80 to 120	90 to 130	100 to 140	110 to 150	1,20 to 160					
	1-1/2 to 1	7010 97	80 to 107	90 to 117	100 to 127	-						

[†]First number of reset ratio typically indicates outdoor air temperature change required to increase the setpoint by the second number.



Dual Bulb Selection

On the dual bulb units, indoor and outdoor bulbs are determined by the ratio selected. See Performance and Selection Table. Ratio refers to the outdoor air temperature change compared to the water temperature change. The dial setpoint is the water temperature setpoint when the outdoor temperature is 70°F.

To select ratio, it is necessary to know only: (1) outdoor design temperature, (2) maximum water temperature at outdoor design temperature, and (3) desired water temperature at 70°F outdoors. Use the Ratio Selection Table to determine the required ratio based on this information and set the dial per item (3). NOTE: If a 1-1/2:1 ratio is selected, the extra dial supplied with the unit must be used.

Options

Single bulb units are available with optional capillary lengths of 20' or 45'.


Accessories: (Order Separately)

Part No.		Description					
AT-201* AT-203* AT-206	Bulb Well	Copper, 3/4" MNPT 9-1/2" Stainless, 3/4" MNPT 9-1/2" Copper, 1/2" MNPT 4-1/2"					
AT-208	Duct Mount	ing Kit for Bulb					
AT-209	A Bulb Well	or Tank, Bulb Mounting Kit. is recommended. vith AT-201 or AT-203.)					
AT-210	Includes pla	Adjustment Kit. ste to conceal setpoint and lock cover screw.					
AT-211	Outside Bulb Shield						

^{*}Requires AT-209 Bulb Mounting Kit.

Example: Select ratio for an installation with a -10°F design temperature and estimated supply water temperatures of 75°F at 70°F outdoors and 125°F at -10°F outdoors. From Ratio Selection Table, -10°F for 1-1/2:1 ratio, note by interpolation (70°F to 123°F with dial at 70°F, 80°F to 133°F with dial at 80°F) that water temperature varies from 75°F to 128°F as outdoor temperature drops from 70°F to -10°F.

For this application, the 1-1/2:1 ratio should be selected. The extra dial supplied with the unit would be used, and the dial set at 75°F






Bulb Duct Mounting Kit AT-208





Liquid Line or Tank
Bulb Mounting Kit
AT-209
(Also Required with
AT-201 or AT-203 Well)



Pre-Installation

Refer to the INSTALLATION and Performance Data applicable to the part number of the device being installed. Make a visual inspection of the device for obvious signs of damage. Avoid locations where excessive moisture, corrosive fumes, vibration or high ambient exists.

Installation

Location

Locate the device allowing proper distance to the bulb location. The case can be mounted in any position. Refer to Figure 1 for case dimensions.

Procedure

Remote Bulb Models

Air Bulb Models — Mounting in Return Air Duct

- Remove cover and provide 2 holes for #10 round head screws using the housing as the template or by using the dimensions shown in Figure 1.
- Partially insert the mounting screws in the screw holes. Fit the housing over the screws, slide housing down on the screws and tighten the screws.




Figure 1. Case Dimensions

Air Bulb Models

Mounting Outside of Return Air Duct

- Prepare duct for mounting by cutting hole and providing mounting screw holes per Figure 1.
- 2. Fabricate a cover as shown in Figure 2.
- Carefully roll bulbs toward back of unit and insert through 2-1/4" x 2-1/2" hole.
- Remove cover and attach unit to duct with #10 screws.
- Attach cover over 2-1/4" × 2-1/2" hole.

Remote Bulb Mounting — Duct and Outdoor

Maximum insertion length (6 inches). Maximum safe bulb temperature above scale range. For dual bulbs, total of indoor and outdoor bulb temperatures must not exceed (280°F).

Duct: Install bulb with AT-208 kit as shown in Figure 3.




Figure 2. Field Supplied Duct Hole Cover Plate




Figure 3. Duct Mounting with AT-208

Outdoor: Install with AT-211 kit as shown in Figure 4.

- 1. Mount bulb to outside wall or surface with bulb clip.
- 2. Place shield over bulb and fasten to-mounting surface.





Figure 4. Outdoor Mounting with AT-211

Bulb Mounting — Liquid Line and Tank



Installation Hardware and Application Limitations

Part No.		Mtg.	Insertion	Applications at 250°F FI		Installation Per
	Description	Fitting	Size	Max. Recommended Velocity (FPS)	Max. Recommended Static Press. (PSIG)	Figure
AT-201	Copper Bulb Well**	3/4"	1/2" Dia O.D.	11	250	5
AT-203	Stainless Steel Bulb Well**	MNPT	9-1/2" Long	20	500	
AT-206	Copper Bulb Well	1/2" MNPT	1/2" Dia. O.D. 4-1/2" Long	11	250	5A
AT-209†	Bulb Mounting Kit	3/4" MNPT	Length of Bulb	4	150	5

^{*}Max. Recommended Fluid Temperature is 350°F.

^{**}Requires AT-209.

[†]Recommended Installation is with a Bulb Well.




Figure 5. AT-201 or AT-203 Installation

Install bulb well or adaptor from AT-209 into 3/4" FNPT opening. Place packing nut, washers, and packing from AT-209 over bulb support section and insert bulb into well or AT-209 adaptor. Push interlocking washers and packing into well or adaptor and tighten packing nut until firmly seated.

Bulb Support 1/2" MNPT AT-206 Bulb Wei Preferred Liquid Flow

Figure 5A. AT-206 Installation

Install AT-206 bulb well into 1/2" FNPT opening. Place packing (included with AT-206) over bulb support section and insert bulb into well. Push packing into nut on well using a screwdriver.

Concealed Setpoint and Lock Cover Screw

Order AT-210 Concealed Adjustment Kit separately.

- Peel off adhesive film from the concealed adjustment plate and place into the recess of cover.
- 2. Remove screw from cover.
- 3. Install lock cover screw provided with AT-210.

Wiring

The thermostat has one 1/2-inch to 3/4-inch conduit opening in bottom of housing. Make all electrical connections in accordance with the job wiring diagram and in compliance with national and local electrical codes. Terminal coding and switch action is shown in Figure 6, and Figure 7 shows two stage switching sequence.




Figure 6. Terminal Coding and Switch Action





Figure 7. Two Stage Switch Sequence

Typical Applications

Figure 8 shows a typical heating or cooling application for single stage units. Figure 9 shows typical heating and cooling applications for two stage units.




Red Cooling Valve


Brn Cooling Valve

L2

Switch COOLING APPLICATION
Terminals WIRING

Figure 8. Typical Heating or Cooling Application for Single-Stage Units





Some compressor unloaders must be de-

Two Compressor Packages May Be Sequenced
With The Wiring Shown

Checkout

After installing a thermostat, make an initial check of the switching action. Verify the switch action by listening to the switch contacts.

- Turn the setpoint dial to a temperature above ambient.
 This should cause the thermostat to switch, making orange to brown.
- Turn the setpoint dial setting down gradually. Orange to brown must break, making orange to red.
- Compare the differential of the device to the differential shown on the performance charts by turning the dial. The differential of the devices is the difference in dial reading between the make of orange to brown and the make of orange to red on single switch units.

Run/Adjust

Setpoint

Screwdriver adjustment. Scales dual marked °F on front and °C on back. To change scale, remove spring retaining ring, select scale and replace retaining ring.

Differential Adjustment

The differential is adjustable by turning the adjustor located on side of device (see Figure 10).

Single stage: Each line represents approximately 3°F change.




Figure 10

Two stage: Each notch represents approximately 2°F change between stages. (Differential per switch is fixed.)

To adjust differential:

- 1. Disconnect power to unit
- 2. Remove cover.
- Turn adjustor to approximately desired position.
- Check out by turning dial and noting dial readings where switch contacts make.
- After changing differential, recalibrate. See Service and Repair.

Service and Repair

Calibration

- With all power disconnected, soak bulb(s) for 10 minutes at known temperature (must be 70°F for dual bulb).
- 2. Turn dial and note where switch contacts make.
- 3. Turn dial midway between click points.
- Turn the calibration nut (located under dial) until the temperature of the bulb is indicated on the dial. (See Figure 10.)

NOTE

On two-stage units follow above procedure. "LO" switch is first stage on cooling applications. "HI" switch is first stage on heating applications.

Repair


Field repair is not recommended. Replace defective device.

Barber-Colman Company ENVIRONMENTAL CONTROLS DIVISION

1354 Clifford Avenue P.O. Box 2940 Loves Park, IL U.S.A. 61132-2940

F-18895-1 BK

MIDGET POWER TYPE RELAYS LARGE CAPACITY 10AMP-1, 2, 3, and 4 POLES



UL Recognized File No. E67770 E59804 E64245



GENERAL

IDEC's Midget Power RH relays are similar to our general purpose RR series relays with full 10 amp switching capacity. Compact in size, the RH series relays reduce space requirements which are an important feature in todays downsized equipment.

RH Midget Power relays are available in SPDT, DPDT, 3PDT and 4PDT contact configurations driven by AC or DC coils with a choice of either blade or PCB mount .078 inch(2mm) terminals. Top bracket mounting is available for SPDT, DPDT and 4PDT terminal blade models.

FEATURES

- Miniature size package allows compact system designing.
- 10 amp contact capacity.
- Dielectric strength--up to 2,000 volts.
- UL recognized and CSA certified.
- Indicator light or check button available on 2, 3 and 4-pole models.
- Complete accessories include IDEC's broad line of sockets, hold-down springs and mounting rails.

TYPE LIST

Terminal Style	Contact Configuration	Basic Type	With Indicator Light	With Check Button	Top Bracket Mounting Type
	SPDT	RH1B-U			RH1B-UT
B (Blade)	DPDT	RH2B-U	RH2B-UL	RH2B-UC	RH2B-UT
	3PDT	RH3B-U			11120-01
	4PDT	RH4B-U	RH4B-UL	RH4B-UC	RH4B-UT
	SPDT	RH1V2-U			NN4B-U1
V2	DPDT	RH2V2-U	RH2V2-UL	RH2V2-UC	
(PCB 0.078" wide)	3PDT	RH3V2-U	The same of the sa	111242-00	
	4PDT	RH4V2-U	RH4V2-UL	RH4V2-UC	

R-1, 2, 3 Para. 2.2,2.9

IDEC RH SERIES OF SERIES O

SPECIFICATIONS

Contact Material Contact Resistance Operate Time Release Time

Power Consumption (Approx.)

Insulation Resistance

Dielectric Strength

Frequency Response **Temperature Rise** Vibration Resistance Shock Resistance **Operating Temperature** Weight (Approx.)

Life Expectancy

Silver cadmium oxide (Ag-CdO)

50 mt! max (initial value)

SPDT(RH1), DPDT(RH2) 20 msec max . 3PDT(RH3), 4PDT(RH4) 25 msec max. SPDT(RH1). DPDT(RH2) 20 msec max . 3PDT(RH3), 4PDT(RH4) . . 25 msec max.

SPDT(RH1) ... AC 11 VA (50 Hz), 1 VA (60 Hz), DC 08W DPDT(RH2) ... AC 1 4 VA (50 Hz), 1.2 VA (60 Hz), DC, 0.9W 3PDT(RH3) AC 2 VA (50 Hz), 1.7 VA (60 Hz), DC 1.5W 4PDT(RH4)

AC: 25 VA (50 Hz). 2 VA (60 Hz). DC 1.5W 100 M!) min (measured at 500V DC megger)

SPDT(RH1)

Between live and non-live parts. 2000V AC, 1 minute

Between contact circuit and operating coil: 2000V AC, 1 minute

Between contacts of the same pole: 1000V AC, 1 minute

DPDT(RH2), 3PDT(RH3), 4PDT(RH4)

Between live and non-live parts 2000V AC, 1 minute

Between contact circuit and operating coil: 2000V AC, 1 minute

Between contact circuits 1500V AC, 1 minute

Between contacts of the same pole: 1000V AC, 1 minute

1800 operations hour

Coil: 85 deg max., Contact 65 deg max.

0 to 6g (55 Hz max)

SPDT(RH1), DPDT(RH2) 20g. 3PDT(RH3), 4PDT(RH4) ... 10g

-22° to +158°F (-30°C to +70°C)

RH1 24g. RH2 37g. RH3 50g. RH4 74g

Electrical 500,000 operations or more (120V AC, 10A)*

Mechanical 50,000,000 operations or more

Note.* 200,000 operations or more (120V AC, 10A) in SPDT(RH1), 3PDT(RH3), 4PDT(RH4) types

COIL RATINGS

	lated			Rated Co	urrent (m	A) : 15%	at 20°C				Coil Resi	stance (í))	Continuous	Pick up
	oltage		60	Hz			50	Hz				at 20°C	,	Applied Voltage	Voltage
	(V)	SPDT	DPDT	3PDT	4PDT	SPDT	DPDT	3PDT	4PDT	SPDT	DPDT	3PDT	4PDT	(Max.) 20°C	(min.)
	6V	150	200	280	330	170	238	330	387	18.8	96	6.0	5.4		0.000
	12V	75	100	140	165	86	118	165	196	76.8	40.5	25.3	21.2	110% of rated	80% of
AC	24V	37	50	70	83	42	59.7	81	98	300	156 7	103	84.5		rated
	120V	7.5	11	14.2	16 5	8.6	129	16 4	19.5	7680	4280	2770	2220	without	voltage
	*240V	-	5.5	7.1	8.3		6.5	82	9.8		15720	12110	9120	overheating	
		SP	DT	DP	DT	3PI	T	4PI	DT	SPDT	DPDT	3PDT	4PDT	nicale fra Lagrania	Section design
-	6V	12	8	150)	240		25	0	47	40	25	24	110% of	
DC	12V	6	4	75	,	120)	12	5	188	160	100	96	rated	80% of
100	24V	3	2	36	9	60) Landa de la companya de la company	6	2	750	650	400	388	voltage	rated
est /S	48V	1	8	18	3.5	30		3	1	2660	2660	1600	1550	overheating	Tomage
	110V	h. 25 1 (b)	8.0	9).1	12	.8	1	15		12100	8600	7340		

Note: Rated voltages marked with * are not available for SPDT models.

CONTACT RATING UL RATINGS (RH1, RH2, RH3, RH4)

		DECICT	VE (A)			NDUCT		HORSE POWER		
VOLTAGE		RESISTI	VE (A)			INDUCT	IVE (A)		SPDT	
(V)	SPDT	DPDT	3PDT	4PDT	SPDT	DPDT	3PDT	4PDT	DPDT	3PDT
120 AC	10	10	10	10	7	7		7.5	1/3	1/6
240 AC	10	10		7.5	7	7	6.5A/Pole 20A Total	5	1	1/3
30 DC	10	10	10	10	7	7	10	10		

TEMPERATURE CONTROL SUBMITTAL

JOB: REPLACE AIR CONDITIONING UNITS VARIOUS BUILDINGS MARINE CORPS AIR STATION, NEW RIVER, N.C. CONTRACT # N62470-86-B-5548


ARCHITECT:

ENGINEER: CHEATHAM AND ASSOCIATES

CONTRACTOR: HUMPHREY HEATING AND ROOFING

Submitted by:

TRIANGLE AUTOMATED CONTROLS, INC.
2716 Discovery Drive
Raleigh, North Carolina 27612
(919)878-8015



Sequence of Operation

- 8.1.1 Building AS-202: When the temperature rises above the setting of the cooling thermostat with the fan selector switch in "AUTO" position, the compressor and the fan shall be energized together. When the fan selector switch is in the "ON" position, the compressor shall cycle and the fan shall run continuously.
- 8.1.2 Building AS-205: When the thermostat is in the "COOL" position and the fan selector switch is in the "AUTO" position the compressors shall be energized on a temperature rise by two cooling stages of the thermostat and the fan shall cycle with the compressors. When the fan selector switch is in the "ON" position, the fan shall run continuously. When the thermostat is in the "HEAT" position the three way hot water control valve shall modulate hot water from full coil by-pass to full flow through the coil as the space temperature falls. The fan shall run continuously during the heating modes.
- 8.1.2.1 Converter Controls: A 2 input controller with one sensing element in the outside air and one sensing element in the hot water supply shall control a normally closed steam valve. The supply water temperature shall be reset upwards as the O.A. temperature falls. Reset schedule is such that at 20 degrees O.A., H.W.S. is 180 degrees and at 60 degrees O.A., H.W.S. is 100 degrees.
- 8.1.2.2 Pump Control: When the steam control valve begins to modulate open, the hot water pump shall be energized and shall remain energized until the steam control valve completely closes.
- 8.1.2.3 A safety low limit thermostat shall deenergize the air handling unit's fan when the mixed air temperature entering the heating coil drops below 35 degrees F.
- 8.1.3 Building AS-236: When any of the six thermostats are in the "COOL" position and the fan selector switch is in the "AUTO" position, the compressor shall be energized on a temperature rise and the fan shall cycle with the compressor. When the fan selector switch is in the "ON" position, the fan shall run continuously. When the thermostat is in the "HEAT" position the three way hot water control valve shall modulate hot water from full coil by-pass to full flow through the coil as the space temperature falls. The fan shall run continuously during the heating modes.
- 8.1.3.1 Converter Controls: A 2 input controller with one sensing element in the outside air and one sensing element in the hot water supply shall control a normally closed steam valve. The supply water temperature shall be reset upwards as the O.A. temperature falls. Reset schedule is such that at 20 degrees O.A., H.W.S. is 180 degrees and at 60 degrees O.A., H.W.S. is 100 degrees.
- 8.1.3.2 Pump Control: When the steam control valve begins to modulate open the hot water pump shall be energized and shall remain energized until the steam control valve completely closes.

- 8.1.3.3 A safety low limit thermostat shall deenergize the air handling unit fan when the mixed air temperature entering the heating coil drops below 35 degrees F. Not applicable for AHU 3 and 5.
- 8.1.4 Building AS-502: When the temperature rises above the setting of the cooling thermostat with the fan selector switch in "AUTO" position, the compressor and the fan shall be energized together. When the fan selector switch is in the "ON" position, the compressor shall cycle and the fan shall run continuously.
- 8.1.5 Building AS-3502: Existing controls shall be reused. An existing high limit pressure selector and pneumatic electric switch shall energize the new condensing unit and provide full cooling. Existing hot water control valve will be reused and connected to new heating coil in air handling unit.


JOB: CONTRACT# n62470-86-B-5548
REPLACE AIR CONDITIONING UNITS
VARIOUS BUILDINGS
MCAS, NEW RIVER, N.C.

EQUIPMENT SCHEDULE

Job #: A-024/J-024

PAGE: 1 of 3 DATE: 1/23/88

QNTY.	IDENTIFIER	PART NUMBER	MANUFAC	TURER DESCRIPTION	LOCATION
1	SPACE	TC-1103-500	Barber Colman	Space cooling thermostat, 2 pos.	In space
1	SUBBASE	AT-603	Barber Colman	Subbase switch for fan AUTO/ON	At space thermostat
1	TS-1	TS-8501	Barber Colman	0.A. temperature sensor	Element in O.A.
1	TS-2	TS-8201	Barber Colman	H.W.S. temperature sensor	Element in H.W.S.
1		AT-215	Barber Colman	Bulb well	With TS-2
1	RC-1	CP-8102	Barber Colman	2 input reset controller for convertor control	In control panel
1	V-2	VS-9223-201-4-5	Barber Colman	Control valve, c2 way:03/4",	At steam convertor
1	R-3	RH2B-U24	IDEC	Control relay, DPDT, 24 VAC	In control panel
1	T-2	TP-8102	Barber Colman	Space thermostat, heating, proport.	In space
1	V-1	VS-9313-351-4-10	Barber Colman	Control valve, 3 way, 1 1/2" proportional, Cv = 33	At AHU h.w. coil
1		TC-1152	Barber Colman	Space thermostat, cooling, 2 stage	In space
1		AT-608	Barber Golman	Subbase switch, fan AUTO/ON, HEAT/COOL	At cooling thermostat
1		TC-4111	Barber Colman	Thermostat O.A. limit	Bulb in O.A. duct
2	R-2, R-3	RH2B-U24	IDEC	Control Relay, DPDT, 24 VAC	In control panel
3		SH2B-05	IDEC	Relay base	In control panel




JOB: REPLACE AIR CONDITIONING UNITS
VARIOUS BUILDINGS
MCAS, NEW RIVER, N.C.

EQUIPMENT SCHEDULE

Job #: A-024/J-024

PAGE: 2 of 3 DATE: 1/23/88

QNTY.	IDENTIFIER	PART NUMBER	MANUFACTURER	DESCRIPTION	LOCATION	
			BUILDING AS-236			
6	COOLING	TC-1103	Barber Colman	Space thermostat cooling, 2 pos	In space	
6	T-2	TP-8102	Barber Colman	Space thermostat, heating, proport.	In space	
2	V-3	VS-9313-201-4-4	Barber Colman	Control valve, 3 way, 1/2" proportional, Cv = 4	At AHU 3 & 5	
3	V-4	VS-9313-201-4-6	Barber Colman	Control valve, 3 way, 3/4" proportional, Cv = 6.8	At AHU 1,2 &6	
1	V-5 VS-9313-351-4-11		Barber Colman	Control valve, 3 way, 2" proportional, Cv = 55	At AHU 4	
6		AT-603	Barber Colman	Subbase switch, fan AUTO/ON HEAT/COOL	At cooling thermostat	
4	O.A. T'stat	eTC-4111	Barber Colman	Thermostat, O.A. limit	Bulb in O.A. duct of AHU 1, 2, 4 & 6	
12	R-2, R-3	RH2B-U24	IDEC	Control relay, DPDT, 24 VAC	In control panel	
13		SH2B-05	IDEC	Relay base	In control panel	
1	V-6	VS-9223-351-4-10	Barber Colman	Control valve, 2 way, 1 1/2" N.C. proportional, Cv = 25	At steam convertor	
1	TS-1	TS-8501	Barber Colman	O.A. temperature sensor	Element in O.A.	
1	TS-2	TS-8201	Barber Colman	H.W.S temperature sensor	Element in H.W.S	
1		AT-215	Barber Colman	Bulb Well	With TS-2	




JOB: REPLACE AIR CONDITIONING UNITS VARIOUS BUILDINGS MCAS, NEW RIVER, N.C.

EQUIPMENT SCHEDULE

Job #: A-024/J-024

PAGE:3 of 3 DATE:1/23/88

QNTY.	IDENTIFIER	PART NUMBER		MANUFACTURER	DESCRIPTION	LOCATION
				AS-236 (cont)		
1	RC-1	CP-8102	Barber	Colman	2 input reset controller for steam convertor	In control panel
1	R-3	RH2B-U24	IDEC		Control relay, DPDT, 24VAC	In control panel
1					Control panel, 20" X 16"	In mech. room
				BUILDING AS-502		
1	SPACE	TC-1103-500	Barber	Colman	Space thermostat, cooling, 2 pos.	In space
1	SUBBASE	AT-603	Barber	Colman	Subbase switch, fan AUTO/ON	At cooling thermostat





TC-1100 Series, TCR-1101 **Two-Position Electric Room Thermostats**

APPLICATION

For low or line voltage on-off control of fan coils, fans, motor starters, contactors, two-position electric actuators.

SPECIFICATIONS

Sensing Element: Bimetal. Differential: 2°F (1°C).

Electrical Switch: Snap action SPDT.

Ratings, See Table 3.

Connections: Color coded 6" (152 mm) leads.

Cover: Beige plastic as standard. Locations: NEMA Type 1 indoor only.

Mounting: Flush or surface 2 × 4 switch box or directly to wall

(24 volt only).

Dimensions: 4-3/8'' high $\times 2-7/8''$ wide $\times 1-5/8''$ deep

 $(111 \text{ mm} \times 73 \text{ mm} \times 41 \text{ mm}).$

OPTIONS

Add "dash-number" (-XXX) suffix to base part number for desired option. For metal covers, specify TC2-110X-XXX.

Heat anticipator should be used when system differential varies from specified thermostat differential. Wide system differential may be due to thermostat guards, material on which thermostat is mounted, location of thermostat, etc. For models used in applications requ heat anticipators, contact factory.











-403++

-502 parallel heat anticipation 240V standard cover ††5/64" Allen screw used to secure cover.



-500 parallel heat anticipation 24V standard cover -501 parallel heat anticipation 120V standard cover

-601 10°F night depression 120V standard cover

-602 10°F night depression 24V standard cover -603 10°F night depression 240V standard cover


-401††

-404++

ACCESSORIES

AE-170 Series	Electric time clock
AT-101	Lock cover kit
AT-104	Dial stop pins (NOTE: Pins included with each unit.)
AT-136	Title plates (day, night, heat, cool)
AT-504	Plaster hole cover kit (small)
AT-505	Surface mounting base
AT-546	Auxiliary mounting plate
AT-602	Selector switch sub-base DP4T
AT-603	Selector switch sub-base one DP4T, one DPDT
AT 4400 0 :	and the second s

AT-1100 Series Thermostat guards TOOL-11 Calibration wrench TOOL-13 Contact burnishing tool








Figure 1. Switch Action and Lead Identification

TABLE 1. SPECIFICATIONS

Part Number	Setpoint Dial Range* °F (°C)	Cover Configurations		
TC-1101	55 to 85 (13 to 29)			
TC-1102	45 to 75 (7 to 23)	See Options		
TC-1103	7 5 to 105 (24 to 40)			
TCR-1101	55 to 85 only	One Blank Cover Insert & One Cover Insert with Control Dial Cutout**		

^{*}Dual marked (except TCR-1101), dial stop pins included to limit setpoint range. "One (1) 5/64" Allen head screw and 5/64" Allen wrench for securing cover to thermostat base included along with standard single slotted screw.

TABLE 2. AGENCY APPROVALS+

Configuration	UL	CSA
Metal Case (TC2-110X)	Yes	Yes
Plastic Cover (TC-110X)	Yes	No
Heat Anticipation or Night Depression (-500 or -600 Series)	Yes	Yes

TABLE 3. MAXIMUM ELECTRICAL RATINGS

Full Loa	d Amps	Locked Re	Pilot Duty		
24/120 Vac	240 Vac	24/120 Vac	240 Vac	(VA)	
4.4 Orange to Brown Lead	2.2 Orange to Brown Lead	26.4 Orange to Brown Lead	13.2 Orange to Brown Lead	40 A 24 Vac	
3.0 Orange to Red Lead	1.5 Orange to Red Lead	18 Orange to Red Lead	9 Orange to Red Lead	210 @ 120/240 Vac	

PRE-INSTALLATION

Inspection

Visually inspect the carton for damage. If damaged, notify the appropriate carrier immediately. If undamaged, open the carton and visually inspect the device for obvious defects. Return damaged or defective products.

Required Installation Items

- Wiring diagrams
- Tools (not provided):

Volt-ohm meter

Appropriate screwdriver for mounting screws and terminal connections

- Appropriate accessories
- Mounting screws, two (2) provided for securing to a 2 × 4 conduit box

INSTALLATION

CAUTION

- 1. Installer must be a qualified, experienced technician.
- Make all connections in accordance with the wiring diagram, and in accordance with national and local electrical codes. Class I wiring is required unless all circuits to contacts are powered from a Class II source. Use copper conductors only.
- 3. Do not exceed ratings of the device.

Mounting

Thermostats require upright mounting on a properly flat vertical surface. Locate the thermostat where it will be exposed to unrestricted circulation of air which represents the average temperature of the controlled space.

CAUTION

Do not locate the thermostat near sources of heat or cold, such as lamps, motors, sunlight or concealed ducts or pipes, or where there is a danger of electrocution (i.e., shower rooms).

The thermostat is designed for service in any normally encountered human environment. Avoid locations where excessive vibration, moisture, corrosive fumes or vapors are present. NEMA Type 1 covers are intended for indoor use primarily to provide a degree of protection against contact with the enclosed equipment.

Thermostats with guards that restrict air flow must have heating or cooling anticipation.




Figure 2. Thermostat Mounting

Procedure

- 1 Pull all wires
- Make electrical connections to thermostat. (Typical heat anticipation and night depression wiring diagrams are shown in Figures 6 through 8.)
- Remove thermostat cover and fasten thermostat to box or wall.
- 4. Attach thermostat cover.

CHECKOUT

After installing a thermostat, make an initial check of the switching action. Verify the switch action by listening to and watching the switch contacts or by using a voltmeter between the proper sides of the switch.

- Run the setpoint dial to a temperature above ambient. This should cause the thermostat to make a circuit between orange and brown leads.
- Turn the setpoint dial setting down below ambient. This should cause the thermostat to make a circuit between orange and red leads.

CALIBRATION (See Figure 3)

All thermostats are precision calibrated at the factory and normally will not require any further attention. However, if recalibration is necessary, proceed as follows:

- Turn off control power and power to night depression circuit, where applicable.
- Set setpoint dial to correspond to actual stable room temperature, as read from an accurate thermometer.
- Remove thermostat cover. Do not breathe on the thermostat or handle excessively as this will affect the accuracy of the final calibration.
- If contact blade is made to the left (red) contact, with a small screwdriver, turn calibration screw counterclockwise (looking at head of screw) until blade makes to right (brown) contact.

		-	-	-
	Put.		г	500
- Taken	F 70.	•		Since.

Each complete turn of screw changes calibration approximately 15°F (8°C).

Now turn screw very slowly clockwise until blade just makes the left (red) contact. Thermostat is now properly calibrated

If contact blade is originally made to the right (brown) contact, turn calibration screw slowly clockwise until element just makes the left (red) contact. Thermostat is now properly calibrated.

- 5. Replace thermostat cover.
- 6. Turn on control power.
- Recheck calibration about 30 minutes later to be sure heat from handling of or breathing on bimetal element did not result in an erroneous setting.

HEAT ANTICIPATION (See Figures 6 and 7)

Heat anticipation, series or parallel, is recommended for

- Systems with excess heating capacity that can cause objectionable space temperature swings.
- Thermostats mounted on walls (i.e., concrete) that change temperature slowly and/or have insufficient air flow over the device.

COOLING ANTICIPATION (See Figure 8)

Parallel cooling anticipation is recommended for:

- Cooling anticipations where current draw exceeds 1 ampere.
 Cooling lockout (self heat of the thermostat causing over cooling of the space) can occur on these applications.
- Systems with excess cooling capacity that can cause objectionable space temperature swings.
- Thermostats mounted on walls (i.e., concrete) that change temperature slowly and/or have restricted air flow over the device.




Figure 3.

CONCEALED CONTROL DIAL

Knurled Dial Removal (See Figure 4)

- Remove thermostat cover.
- Secure the control dial with hand so that the dial will not rotate
- Place needle nose pliers at knurled ring of the control dial at the points where the knurled ring is attached to the control dial.
- Twist the pliers at each knurled ring attachment point until the entire knurled ring of the control dial is removed.




Figure 4. Knuried Dial Removal

LIMIT CONTROL DIAL BANGE

Dial Stop Pin Insertion — Included with Mounting Plate (See Figure 5)

- Remove thermostat cover.
- Secure the control dial with hand so that the dial will not rotate.
- 3. Place a dial stop pin in the jaws of a needle nose pliers.
- Insert the dial stop pin in the appropriate hole on either (or both) side(s) of the control dial to restrict dial rotation.




Figure 5. Dial Stop Pin Insertion

MAINTENANCE

Regular maintenance of the total system is recommended to assure sustained optimum performance.

Open areas at bottom and around base of thermostat should be kept clean and free from obstructions to allow proper flow of air. If switch contacts need cleaning, this may be done with TOOL-13 (burnishing tool).

NOTE

Thermostat may require calibration after cleaning the contacts

REPAIR

These thermostats are not field repairable. Replace a defective thermostat with a functional unit.




Figure 6. Typical of Parallel Heat Anticipation (heater size determined by voltage) with or without Night Depression




Figure 7. Typical of Series Heat Anticipation (heater size determined by ampere rating of load) with or without Night Depression




Figure 8. Typical of Parallel Cooling Anticipation (anticipator size determined by voltage)




Figure 9. Typical Night Depression

Barber-Colman Company ENVIRONMENTAL CONTROLS DIVISION

| 1354 Clifford Avenue | P.O. Box 2940 | Loves Park IL U.S.A. 61132-2940



General Instructions

AT-602, 603, 607, 608 & 609-XXX Selector Switch Sub-Bases and Legend Plates


For use at the room thermostat to accommodate switching functions such as heating to cooling, day to night control, etc. **Device:** Rugged one piece molded beige plastic housing. One or two slide switches are double-pole, double throw (DPDT) or double pole-4 position (DP4T) allowing numerous control possibilities. DP4T can be used as two or three position by installing switch legend plates that limit switch travel. Coded screw terminals for the switch contacts are accessible for up to two No. 14 gauge wire connections. See Figure 2.

Installation

Use Class I wiring for all connections to switch subbases and to room thermostat unless all circuits are powered from a Class II source. Make all connections in accordance with national and local codes.

Install subbases on a flush switch box, a surface switch box or directly on a wall (for 24V applications only).


- Pull the required wires.
- If plastic conduit box is used, connect green wire from subbase to system ground, otherwise clip out the green wire.
- Mount the subbase (see Figure 1). Screws are provided for switch box mounting.
- Connect proper wires to subbase screw terminals. Push
 excess wire into conduit box, allowing field wires (if any) for
 room thermostat to project through opening in subbase.
- Make all electrical connections to thermostats and install any jumpers as required. Refer to job wiring diagram and/or General Instruction Sheet for thermostat.
- 6. Install thermostat on subbase (see Figure 1).
- To install switch legend plate on subbase strip the paper backing off and press plate into subbase. Note: Legend plates must be ordered separately.



1-1/4 IN 32 mm

AT-607 & 608

AT-602 & 603



Duplex Thermostat on Duplex Sub-Base

Figure 1


Single Thermostat on Single Sub-Base

50 0000		itch ription				
Part Number	Upper Right	Lower Right	Used With			
AT-602		DP4T	All Single Room Thermo-			
AT-603	DPDT	DP4T	stats Except TK's, TA-115, TA-121, TA-133, TA-134, TC-114, and TC-142.			
AT-607		DP4T	TA-151, 115X, TC-154			
AT-608	DPDT DF		114X, 115X, 116X, 2-Stage and Duplex Thermostats.			


	Inc	ductive		
Volts (AC)	Full Load Amps	Locked Rotor Amps	Non- Inductive Amps	Pilot Duty (VA)
24	5.8	34.8	6	125
120	5.8	34.8	6	125
240	2.9	17.4	3	125


240 2.9 17.4 3 125

*The total load on both poles of a switch must not exceed the total electrical rating.




TYPICAL APPLICATIONS






ITEMS: TC-1101, AT-602, AT-609-302

THERMOSTAT PROVIDES SEQUENCED HEAT & COOL, ON-OFF SWITCH, OFF LOCKS OFF SYSTEM & FAN, LOW-MED-HIGH FAN SWITCH




ITEMS: TC-1191; AT-603; AT-609-353

THERMOSTAT PROVIDES SEQUENCED HEAT & COOL OFF-HEAT-AUTO-COOL SWITCH




ITEMS: TC-1191, AT-602, AT-609-402

THERMOSTAT CYCLES 2 STAGES HEAT AND 1 STAGE COOL, HEAT-COOL SWITCH, OFF-LOW-HIGH FAN SWITCH




THERMOSTAT CYCLES HEAT & COOL, HEAT-COOL SWITCH, OFF-LOW-HIGH FAN SWITCH



ITEMS: TC-1101: AT-603: AT-609-352

THERMOSTAT CYCLES HEAT AND COOL, HEAT-COOL



ITEMS: TC-1101, AT-602, AT-609-204

AT-609-XXX Legend Plates for Switch Sub-Bases

Various switch indicating plates are available and must be ordered separately. These have a brown simulated leather finish with bright letters and pressure sensitive backing for simplified field installation. Blank plate on left side of AT-602 & 603 is factory installed.





Figure 2

Switch Pealtien	1700									AT-6	09-XX	XX S	WIT	CH	LEG	EN	DPL	ATES								
	Switch Action								Plates With Legends																	
	ACITOR	201	301	401	250	350	450	202	203	204	205	296	251	252	253†	302	303	395	306	387	351	352	353	402	403	452
A	DPDT												On Off	On Off	On Auto					- 15 A	On Auto Fan	Heat Cool	On Off			On Auto Far
В	DP4T																							Off Heat Auto Cool	Off Low Med High	Off Hea Auto Coo
C	DP3T															Off Low High	Heat Off Cool	Occu Off Unoccu	Night Off Day	Off On Auto	Heat Off Cool	Off Low High	Low Med High			
D	DPDT							On Off	Occu Unoccu	Heat Cool	Night Day	Auto On	Low High	High Low	High Low								- 1			

^{*}Special lettering can usually be provided by local nameplate engravers.

SWITCH POSITIONS




Barber-Colman Company ENVIRONMENTAL CONTROLS DIVISION

1354 Clifford Avenue P.O. Box 2940 Loves Park, IL U.S.A. 61132-2940

^{**}Legend Piale limits travel of DP4T Switch to provide DPDT or DP3T.

^{†&}quot;Fan Operation" legend placed between switches



TEMPERATURE CONTROL SUBMITTAL

JOB: REPLACE AIR CONDITIONING UNITS VARIOUS BUILDINGS MARINE CORPS AIR STATION, NEW RIVER, N.C. CONTRACT # N62470-86-B-5548

ARCHITECT:

ENGINEER: CHEATHAM AND ASSOCIATES

CONTRACTOR: HUMPHREY HEATING AND ROOFING

Submitted by:

TRIANGLE AUTOMATED CONTROLS, INC.
2716 Discovery Drive
Raleigh, North Carolina 27612
(919)878-8015

Sequence of Operation

- 8.1.1 Building AS-202: When the temperature rises above the setting of the cooling thermostat with the fan selector switch in "AUTO" position, the compressor and the fan shall be energized together. When the fan selector switch is in the "ON" position, the compressor shall cycle and the fan shall run continuously.
- 8.1.2 Building AS-205: When the thermostat is in the "COOL" position and the fan selector switch is in the "AUTO" position the compressors shall be energized on a temperature rise by two cooling stages of the thermostat and the fan shall cycle with the compressors. When the fan selector switch is in the "ON" position, the fan shall run continuously. When the thermostat is in the "HEAT" position the three way hot water control valve shall modulate hot water from full coil by-pass to full flow through the coil as the space temperature falls. The fan shall run continuously during the heating modes.
- 8.1.2.1 Converter Controls: A 2 input controller with one sensing element in the outside air and one sensing element in the hot water supply shall control a normally closed steam valve. The supply water temperature shall be reset upwards as the O.A. temperature falls. Reset schedule is such that at 20 degrees O.A., H.W.S. is 180 degrees and at 60 degrees O.A., H.W.S. is 100 degrees.
- 8.1.2.2 Pump Control: When the steam control valve begins to modulate open, the hot water pump shall be energized and shall remain energized until the steam control valve completely closes.
- 8.1.2.3 A safety low limit thermostat shall deenergize the air handling unit's fan when the mixed air temperature entering the heating coil drops below 35 degrees F.
- 8.1.3 Building AS-236: When any of the six thermostats are in the "COOL" position and the fan selector switch is in the "AUTO" position, the compressor shall be energized on a temperature rise and the fan shall cycle with the compressor. When the fan selector switch is in the "ON" position, the fan shall run continuously. When the thermostat is in the "HEAT" position the three way hot water control valve shall modulate hot water from full coil by-pass to full flow through the coil as the space temperature falls. The fan shall run continuously during the heating modes.
- 8.1.3.1 Converter Controls: A 2 input controller with one sensing element in the outside air and one sensing element in the hot water supply shall control a normally closed steam valve. The supply water temperature shall be reset upwards as the O.A. temperature falls. Reset schedule is such that at 20 degrees O.A., H.W.S. is 180 degrees and at 60 degrees O.A., H.W.S. is 100 degrees.
- 8.1.3.2 Pump Control: When the steam control valve begins to modulate open the hot water pump shall be energized and shall remain energized until the steam control valve completely closes.

- 8.1.3.3 A safety low limit thermostat shall deenergize the air handling unit fan when the mixed air temperature entering the heating coil drops below 35 degrees F. Not applicable for AHU 3 and 5.
- 8.1.4 Building AS-502: When the temperature rises above the setting of the cooling thermostat with the fan selector switch in "AUTO" position, the compressor and the fan shall be energized together. When the fan selector switch is in the "ON" position, the compressor shall cycle and the fan shall run continuously.
- 8.1.5 Building AS-3502: Existing controls shall be reused. An existing high limit pressure selector and pneumatic electric switch shall energize the new condensing unit and provide full cooling. Existing hot water control valve will be reused and connected to new heating coil in air handling unit.


JOB: CONTRACT# n62470-86-B-5548
REPLACE AIR CONDITIONING UNITS
VARIOUS BUILDINGS
MCAS, NEW RIVER, N.C.

EQUIPMENT SCHEDULE

Job #: A-024/J-024

PAGE: 1 of 3 DATE: 1/23/88

QNTY.	IDENTIFIER	PART NUMBER	188	MANUFACTURER	DESCRIPTION	LOCATION
				BUILDING AS-202		
1	SPACE	TC-1103-500	Barber	Colman	Space cooling thermostat, 2 pos.	In space
1	SUBBASE	AT-603	Barber	Colman	Subbase switch for fan AUTO/ON	At space thermostat
1	TS-1	T S−8501	Barber	BUILDING AS-205	O.A. temperature sensor	Element in O.A.
1	TS-2	TS-8201	Barber	Colman	H.W.S. temperature sensor	Element in H.W.S.
1		AT-215	Barber	Colman	Bulb well	With TS-2
1	RC-1	CP-8102	Barber	Colman	2 input reset controller for convertor control	In control panel
1	V-2	VS-9223-201-4-5	Barber	Colman	Control valve, cv way:03/4",	At steam convertor
1	R-3	RH2B-U24	IDEC		Control relay, DPDT, 24 VAC	In control panel
1	T-2	TP-8102	Barber	Colman	Space thermostat, heating, proport.	In space
1	V-1	VS-9313-351-4-10	Barber	Colman	Control valve, 3 way, 1 1/2" proportional, Cv = 33	At AHU h.w. coil
1		TC-1152	Barber	Colman	Space thermostat, cooling, 2 stage	In space
1		AT-608	Barber	Golman	Subbase switch, fan AUTO/ON, HEAT/COOL	At cooling thermostat
1		TC-4111	Barber	Colman	Thermostat O.A. limit	Bulb in O.A. duct
2	R-2, R-3	RH2B-U24	IDEC		Control Relay, DPDT, 24 VAC	In control panel
3		SH2B-05	IDEC		Relay base	In control panel




JOB: VARIOUS BUILDINGS
MCAS, NEW RIVER, N.C.

EQUIPMENT SCHEDULE

Job #: A-024/J-024

PAGE: 2 of 3 DATE: 1/23/88

QNTY.	IDENTIFIER	PART NUMBER	MANUFACTURER	DESCRIPTION	LOCATION
			BUILDING AS-236		
6	COOLING	TC-1103	Barber Colman	Space thermostat cooling, 2 pos	In space
6	T-2	TP-8102	Barber Colman	Space thermostat, heating, proport.	In space
2	V-3	VS-9313-201-4-4	Barber Colman	Control valve, 3 way, 1/2" proportional, Cv = 4	At AHU 3 & 5
3	V-4	VS-9313-201-4-6	Barber Colman	Control valve, 3 way, 3/4" proportional, Cv = 6.8	At AHU 1,2 &6
1	V-5	VS-9313-351-4-11	Barber Colman	Control valve, 3 way, 2" proportional, Cv = 55	At AHU 4
6		AT-603	Barber Colman	Subbase switch, fan AUTO/ON HEAT/COOL	At cooling thermostat
4	O.A. T'stat	eTC-4111	Barber Colman	Thermostat, O.A. limit	Bulb in O.A. duct of AHU 1, 2, 4 & 6
12	R-2, R-3	RH2B-U24	IDEC	Control relay, DPDT, 24 VAC	In control panel
13		SH2B-05	IDEC	Relay base	In control panel
1	V-6	VS-9223-351-4-10	Barber Colman	Control valve, 2 way, 1 1/2" N.C. proportional, Cv = 25	At steam convertor
1	TS-1	TS-8501	Barber Colman	0.A. temperature sensor	Element in O.A.
1	TS-2	TS-8201	Barber Colman	H.W.S temperature sensor	Element in H.W.S
1		AT-215	Barber Colman	Bulb Well	With TS-2
B					




REPLACE AIR CONDITIONING UNITS
VARIOUS BUILDINGS
MCAS, NEW RIVER, N.C.

EQUIPMENT SCHEDULE

Job #: A-024/J-024

PAGE:3 of 3 DATE:1/23/88

	7	<u> </u>			
QNTY.	IDENTIFIER	PART NUMBER	MANUFACTURER	DESCRIPTION	LOCATION
			AS-236 (cont)		
1	RC-1	_ CP-8102	Barber Colman	2 input reset controller for steam convertor	In control panel
1	R-3	RH2B-U24	IDEC	Control relay, DPDT, 24VAC	In control panel
1				Control panel, 20" X 16"	In mech. room
1			BUILDING AS-502		
1	SPACE	TC-1103-500	Barber Colman	Space thermostat, cooling, 2 pos.	In space
1	SUBBASE	AT-603	Barber Colman	Subbase switch, fan AUTO/ON	At cooling thermostat
			,		



TC-1100 Series, TCR-1101 Two-Position Electric Room Thermostats

APPLICATION

For low or line voltage on-off control of fan coils, fans, motor starters, contactors, two-position electric actuators.

SPECIFICATIONS

Sensing Element: Bimetal. Differential: 2°F (1°C).

Electrical Switch: Snap action SPDT.

Ratings, See Table 3.

Connections: Color coded 6" (152 mm) leads.

Cover: Beige plastic as standard. **Locations:** NEMA Type 1 indoor only.

Mounting: Flush or surface 2 × 4 switch box or directly to wall

(24 volt only).

Dimensions: 4-3/8" high × 2-7/8" wide × 1-5/8" deep

 $(111 \text{ mm} \times 73 \text{ mm} \times 41 \text{ mm}).$

OPTIONS

Add "dash-number" (-XXX) suffix to base part number for desired option. For metal covers, specify TC2-110X-XXX.

Heat anticipator should be used when system differential varies from specified thermostat differential. Wide system differential may be due to thermostat guards, material on which thermostat is mounted, location of thermostat, etc. For models used in applications requires series heat anticipators, contact factory.









-401††







-500 parallel heat anticipation 24V standard cover-501 parallel heat anticipation 120V standard cover

-502 parallel heat anticipation 240V standard cover -601 10°F night depression 120V standard cover

-602 10°F night depression 120V standard cover


-603 10°F night depression 240V standard cover

††5/64" Allen screw used to secure cover

ACCESSORIES

AE-170 Series	Electric time clock
AT-101	Lock cover kit
AT-104	Dial stop pins (NOTE: Pins included with each unit.)
AT-136	Title plates (day, night, heat, cool)
AT-504	Plaster hole cover kit (small)
AT-505	Surface mounting base
AT-546	Auxiliary mounting plate
AT-602	Selector switch sub-base DP4T
AT-603	Selector switch sub-base one DPAT one DPDT

AT-1100 Series Thermostat guards
TOOL-11 Calibration wrench
TOOL-13 Contact burnishing tool








Figure 1. Switch Action and Lead Identification

TABLE 1. SPECIFICATIONS

Part Number	Setpoint Dial Range* °F (°C)	Cover Configurations	
TC-1101	55 to 85 (13 to 29)		
TC-1102	45 to 75 (7 to 23)	See Options	
TC-1103	75 to 105 (24 to 40)		
TCR-1101	55 to 85 only	One Blank Cover Insert & One Cover Insert with Control Dial Cutout**	

*Dual marked (except TCR-1101); dial stop pins included to limit setpoint range.


*One (1) 5/64" Allen head screw and 5/64" Allen wrench for securing cover to thermostat base included along with standard single slotted screw.

TABLE 2. AGENCY APPROVALS†

Configuration	UL	CSA
Metal Case (TC2-110X)	Yes	Yes
Plastic Cover (TC-110X)	Yes	No
Heat Anticipation or Night Depression (-500 or -600 Series)	Yes	Yes

TABLE 3. MAXIMUM ELECTRICAL RATINGS

Full Loa	d Amps	Locked Rotor Amps		Pilot Duty
24/120 Vac	240 Vac	24/120 Vac	240 Vac	(VA)
4.4 Orange to Brown Lead	2.2 Orange to Brown Lead	26.4 Orange to Brown Lead	13.2 Orange to Brown Lead	40 A 24 Vac
3.0 Orange to Red Lead	1.5 Orange to Red Lead	18 Orange to Red Lead	9 Orange to Red Lead	210 @ 120/240 Vac



PRE-INSTALLATION

Inspection

Visually inspect the carton for damage. If damaged, notify the appropriate carrier immediately. If undamaged, open the carton and visually inspect the device for obvious defects. Return damaged or defective products.

Required Installation Items

- Wiring diagrams
- Tools (not provided):

Volt-ohm meter

Appropriate screwdriver for mounting screws and terminal connections

- · Appropriate accessories
- Mounting screws, two (2) provided for securing to a 2 × 4 conduit box

INSTALLATION

CAUTION .

- 1. Installer must be a qualified, experienced technician.
- Make all connections in accordance with the wiring diagram, and in accordance with national and local electrical codes. Class I wiring is required unless all circuits to contacts are powered from a Class II source. Use copper conductors only.
- 3. Do not exceed ratings of the device.

Mounting

Thermostats require upright mounting on a properly flat vertical surface. Locate the thermostat where it will be exposed to unrestricted circulation of air which represents the average temperature of the controlled space.

CAUTION .

Do not locate the thermostat near sources of heat or cold, such as lamps, motors, sunlight or concealed ducts or pipes, or where there is a danger of electrocution (i.e., shower rooms).

The thermostat is designed for service in any normally encountered human environment. Avoid locations where excessive vibration, moisture, corrosive fumes or vapors are present. NEMA Type 1 covers are intended for indoor use primarily to provide a degree of protection against contact with the enclosed equipment.

Thermostats with guards that restrict air flow must have heating or cooling anticipation.




Figure 2. Thermostat Mounting

Procedure

- 1. Pull all wires.
- Make electrical connections to thermostat. (Typical heat anticipation and night depression wiring diagrams are shown in Figures 6 through 8.)
- Remove thermostat cover and fasten thermostat to box or wall
- 4. Attach thermostat cover.

CHECKOUT

After installing a thermostat, make an initial check of the switching action. Verify the switch action by listening to and watching the switch contacts or by using a voltmeter between the proper sides of the switch.

- Run the setpoint dial to a temperature above ambient. This should cause the thermostat to make a circuit between orange and brown leads.
- Turn the setpoint dial setting down below ambient. This should cause the thermostat to make a circuit between orange and red leads.

CALIBRATION (See Figure 3)

All thermostats are precision calibrated at the factory and normally will not require any further attention. However, if recalibration is necessary, proceed as follows:

- Turn off control power and power to night depression circuit, where applicable.
- Set setpoint dial to correspond to actual stable room temperature, as read from an accurate thermometer.
- Remove thermostat cover. Do not breathe on the thermostat or handle excessively as this will affect the accuracy of the final calibration.
- If contact blade is made to the left (red) contact, with a small screwdriver, turn calibration screw counterclockwise (looking at head of screw) until blade makes to right (brown) contact.


NOTE .

Each complete turn of screw changes calibration approximately 15°F (8°C).

Now turn screw very slowly clockwise until blade just makes the left (red) contact. Thermostat is now properly calibrated.

If contact blade is originally made to the right (brown) contact, turn calibration screw slowly clockwise until element just makes the left (red) contact. Thermostat is now properly calibrated.

- 5. Replace thermostat cover.
- 6. Turn on control power.
- Recheck calibration about 30 minutes later to be sure heat from handling of or breathing on bimetal element did not result in an erroneous setting.



HEAT ANTICIPATION (See Figures 6 and 7)


Heat anticipation, series or parallel, is recommended for:

- Systems with excess heating capacity that can cause objectionable space temperature swings.
- Thermostats mounted on walls (i.e., concrete) that change temperature slowly and/or have insufficient air flow over the device.

COOLING ANTICIPATION (See Figure 8)

Parallel cooling anticipation is recommended for:

- Cooling anticipations where current draw exceeds 1 ampere.
 Cooling lockout (self heat of the thermostat causing over cooling of the space) can occur on these applications.
- Systems with excess cooling capacity that can cause objectionable space temperature swings.
- Thermostats mounted on walls (i.e., concrete) that change temperature slowly and/or have restricted air flow over the device.



CONCEALED CONTROL DIAL

Knurled Dial Removal (See Figure 4)

- Remove thermostat cover.
- Secure the control dial with hand so that the dial will not rotate.
- Place needle nose pliers at knurled ring of the control dial at the points where the knurled ring is attached to the control dial.
- 4. Twist the pliers at each knurled ring attachment point until the entire knurled ring of the control dial is removed.




Figure 4. Knurled Dial Removal

LIMIT CONTROL DIAL RANGE

Dial Stop Pin Insertion — Included with Mounting Plate (See Figure 5)

- 1. Remove thermostat cover.
- Secure the control dial with hand so that the dial will not rotate.
- 3. Place a dial stop pin in the jaws of a needle nose pliers.
- Insert the dial stop pin in the appropriate hole on either (or both) side(s) of the control dial to restrict dial rotation.




Figure 5. Dial Stop Pin Insertion

MAINTENANCE

Regular maintenance of the total system is recommended to assure sustained optimum performance.


Open areas at bottom and around base of thermostat should be kept clean and free from obstructions to allow proper flow of air. If switch contacts need cleaning, this may be done with TOOL-13 (burnishing tool).

NOTE

Thermostal may require calibration after cleaning the contacts.

REPAIR

These thermostats are not field repairable. Replace a defective thermostat with a functional unit.






Figure 6. Typical of Parallel Heat Anticipation (heater size determined by voltage) with or without Night Depression




Figure 7. Typical of Series Heat Anticipation (heater size determined by ampere rating of load) with or without Night Depression




Figure 8. Typical of Parallel Cooling Anticipation (anticipator size determined by voltage)





Figure 9. Typical Night Depression

Barber-Colman Company ENVIRONMENTAL CONTROLS DIVISION

1354 Clifford Avenue P.O. Box 2940 Loves Park, IL U.S.A 61132-2940

F-18785-4 BK LITHO IN U.S.A





General Instructions

AT-602, 603, 607, 608 & 609-XXX Selector Switch Sub-Bases and Legend Plates


For use at the room thermostat to accommodate switching functions such as heating to cooling, day to night control, etc. **Device:** Rugged one piece molded beige plastic housing. One or two slide switches are double-pole, double throw (DPDT) or double pole-4 position (DP4T) allowing numerous control possibilities. DP4T can be used as two or three position by installing switch legend plates that limit switch travel. Coded screw terminals for the switch contacts are accessible for up to two No. 14 gauge wire connections. See Figure 2.


Installation

Use Class I wiring for all connections to switch subbases and to room thermostat unless all circuits are powered from a Class II source. Make all connections in accordance with national and local codes.

Install subbases on a flush switch box, a surface switch box or directly on a wall (for 24V applications only).

- 1. Pull the required wires.
- If plastic conduit box is used, connect green wire from subbase to system ground, otherwise clip out the green wire.
- Mount the subbase (see Figure 1). Screws are provided for switch box mounting.
- Connect proper wires to subbase screw terminals. Push
 excess wire into conduit box, allowing field wires (if any) for
 room thermostat to project through opening in subbase.
- Make all electrical connections to thermostats and install any jumpers as required. Refer to job wiring diagram and/or General Instruction Sheet for thermostat.
- 6. Install thermostat on subbase (see Figure 1).
- To install switch legend plate on subbase strip the paper backing off and press plate into subbase. Note: Legend plates must be ordered separately.





Duplex Thermostat on Duplex Sub-Base

Figure 1


Single Thermostat on Single Sub-Base

			tch iption	en e
	Part Number	Upper Right	Lower Right	Used With
J	AT-602	1 1	DP4T	All Single Room Thermo- stats Except TK's, TA-115.
1	AT-603	DPDT	DP4T	TA-121, TA-133, TA-134, TC-114, and TC-142.
	AT-607		DP4T	TA-151, 115X, TC-154,
	AT-608	DPDT	DP4T	114X, 115X, 116X, 2-Stage and Duplex Thermostats.

	Inc	luctive		Pilot Duty (VA)	
Volts (AC)	Full Load Amps	Locked Rotor Amps	Non- Inductive Amps		
24	5.8	34.8	6	125	
120	5.8	34.8	6	125	
240	2.9	17.4	3	125	


^{*}The total load on both poles of a switch must not exceed the total electrical rating.

LITHO IN U.S.A. 2-84




TYPICAL APPLICATIONS

THERMOSTAT CYCLES VALVE. SUMMER/WINTER CHANGEOVER THERMOSTAT, OFF-LOW-HIGH FAN SWITCH




ITEMS: TC-1101, AT-602, AT-609-302

THERMOSTAT PROVIDES SEQUENCED HEAT & COOL, ON-OFF SWITCH, OFF LOCKS OFF SYSTEM & FAN. LOW-MED-HIGH FAN SWITCH




ITEMS: TC-1191; AT-603; AT-609-353

THERMOSTAT PROVIDES SEQUENCED HEAT & COOL OFF-HEAT-AUTO-COOL SWITCH




ITEMS: TC-1191, AT-602, AT-609-402


THERMOSTAT CYCLES 2 STAGES HEAT AND 1 STAGE COOL, HEAT-COOL SWITCH, OFF-LOW-HIGH FAN SWITCH



THERMOSTAT CYCLES HEAT & COOL, HEAT-COOL SWITCH, OFF-LOW-HIGH FAN SWITCH



THERMOSTAT CYCLES HEAT AND COOL, HEAT-COOL SYSTEM SWITCH



ITEMS: TC-1101, AT-602, AT-609-204

AT-609-XXX Legend Plates for Switch Sub-Bases

Various switch indicating plates are available and must be ordered separately. These have a brown simulated leather finish with bright letters and pressure sensitive backing for simplified field installation. Blank plate on left side of AT-602 & 603 is factory installed.





Figure 2

		A.		- 8	- 15 15		A			AT-6	09-X	XX S	WIT	CH	LEG	EN	D PL	ATES								
Switch Pusition	Swritch Action					Plates With Legends																				
r assituat	PERSONAL	261	301	491	250	350	450	202	203	204	205	206	251	252	253†	302	303	305	306	397	351	352	353	402	403	452
A	DPDT												On Off	On Off	On Auto						On Auto Fan	Heat Cool	On Off			On Auto
8	DP4T															1						4		Off Heat Auto Cool	Off Low Med High	Off Heat Auto Cool
С	DP3T															Off Low High	Heat Off Cool	Occu Off Unoccu	Night Off Day	Off On Auto	Heat Off Cool	Off Low High	Low Med High			
0	DPDT							On Off	Occu Unoccu	Heat Cool	Night Day	Auto On	Low High	High Low	High Low											

[&]quot;Special lettering can usually be provided by local nameplate engravers.
"Legend Plate limits travel of DP4T Switch to provide DPDT or DP3T.


SWITCH POSITIONS



Barber-Colman Company ENVIRONMENTAL CONTROLS DIVISION

1354 Clifford Avenue P.O. Box 2940 Loves Park, IL U.S.A. 61132-2940

^{†&}quot;Fan Operation" legend placed between switches.



TEMPERATURE CONTROL SUBMITTAL

JOB: REPLACE AIR CONDITIONING UNITS VARIOUS BUILDINGS MARINE CORPS AIR STATION, NEW RIVER, N.C. CONTRACT # N62470-86-B-5548


ARCHITECT:

ENGINEER: CHEATHAM AND ASSOCIATES

CONTRACTOR: HUMPHREY HEATING AND ROOFING


Submitted by:

TRIANGLE AUTOMATED CONTROLS, INC.
2716 Discovery Drive
Raleigh, North Carolina 27612
(919)878-8015




Sequence of Operation

- 8.1.1 Building AS-202: When the temperature rises above the setting of the cooling thermostat with the fan selector switch in "AUTO" position, the compressor and the fan shall be energized together. When the fan selector switch is in the "ON" position, the compressor shall cycle and the fan shall run continuously.
- 8.1.2 Building AS-205: When the thermostat is in the "COOL" position and the fan selector switch is in the "AUTO" position the compressors shall be energized on a temperature rise by two cooling stages of the thermostat and the fan shall cycle with the compressors. When the fan selector switch is in the "ON" position, the fan shall run continuously. When the thermostat is in the "HEAT" position the three way hot water control valve shall modulate hot water from full coil by-pass to full flow through the coil as the space temperature falls. The fan shall run continuously during the heating modes.
- 8.1.2.1 Converter Controls: A 2 input controller with one sensing element in the outside air and one sensing element in the hot water supply shall control a normally closed steam valve. The supply water temperature shall be reset upwards as the O.A. temperature falls. Reset schedule is such that at 20 degrees O.A., H.W.S. is 180 degrees and at 60 degrees O.A., H.W.S. is 100 degrees.
- 8.1.2.2 Pump Control: When the steam control valve begins to modulate open, the hot water pump shall be energized and shall remain energized until the steam control valve completely closes.
- 8.1.2.3 A safety low limit thermostat shall deenergize the air handling unit's fan when the mixed air temperature entering the heating coil drops below 35 degrees F.
- 8.1.3 Building AS-236: When any of the six thermostats are in the "COOL" position and the fan selector switch is in the "AUTO" position, the compressor shall be energized on a temperature rise and the fan shall cycle with the compressor. When the fan selector switch is in the "ON" position, the fan shall run continuously. When the thermostat is in the "HEAT" position the three way hot water control valve shall modulate hot water from full coil by-pass to full flow through the coil as the space temperature falls. The fan shall run continuously during the heating modes.
- 8.1.3.1 Converter Controls: A 2 input controller with one sensing element in the outside air and one sensing element in the hot water supply shall control a normally closed steam valve. The supply water temperature shall be reset upwards as the O.A. temperature falls. Reset schedule is such that at 20 degrees O.A., H.W.S. is 180 degrees and at 60 degrees O.A., H.W.S. is 100 degrees.
- 8.1.3.2 Pump Control: When the steam control valve begins to modulate open the hot water pump shall be energized and shall remain energized until the steam control valve completely closes.



- 8.1.3.3 A safety low limit thermostat shall deenergize the air handling unit fan when the mixed air temperature entering the heating coil drops below 35 degrees F. Not applicable for AHU 3 and 5.
- 8.1.4 Building AS-502: When the temperature rises above the setting of the cooling thermostat with the fan selector switch in "AUTO" position, the compressor and the fan shall be energized together. When the fan selector switch is in the "ON" position, the compressor shall cycle and the fan shall run continuously.
- 8.1.5 Building AS-3502: Existing controls shall be reused. An existing high limit pressure selector and pneumatic electric switch shall energize the new condensing unit and provide full cooling. Existing hot water control valve will be reused and connected to new heating coil in air handling unit.



CONTRACT# n62470-86-B-5548


JOB: REPLACE AIR CONDITIONING UNITS VARIOUS BUILDINGS MCAS, NEW RIVER, N.C.

EQUIPMENT SCHEDULE

Job #: A-024/J-024

PAGE: 1 of 3 DATE: 1/23/88

QNTY.	IDENTIFIER	PART NUMBER		MANUFACTURER	DESCRIPTION	LOCATION
1	SPACE	TC-1103-500	Barber Co	BUILDING AS-202	Space cooling thermostat,2 pos.	In space
1	SUBBASE	AT-603	Barber Co	lman	Subbase switch for fan AUTO/ON	At space thermostat
1	TS-1	TS-8501	Barber Co	BUILDING AS-205 Diman	O.A. temperature sensor	Element in O.A.
1	TS-2	TS-8201	Barber Co	lman	H.W.S. temperature sensor	Element in H.W.S.
1		AT-215	Barber Co	lman	Bulb well	With TS-2
1	RC-1	CP-8102	Barber Co	olman	2 input reset controller for	In control panel
1	V-2	VS-9223-201-4-5	Barber Co	lman	Control valve, c2 way:03/4",	At steam convertor
1	R-3	RH2B-U24	IDEC		Control relay, DPDT, 24 VAC	In control panel
1	T-2	TP-8102	Barber Co	lman	Space thermostat, heating, proport.	In space
1	V-1	VS-9313-351-4-10	Barber Co	lman	Control valve, 3 way, 1 1/2" proportional, Cv = 33	At AHU h.w. coil
1		TC-1152	Barber Co	olman	Space thermostat, cooling, 2 stage	In space
1		AT-608	Barber Co	olman	Subbase switch, fan AUTO/ON, HEAT/COOL	At cooling thermostat
1		TC-4111	Barber Co	olman	Thermostat O.A. limit	Bulb in O.A. duct
2	R-2, R-3	RH2B-U24	IDEC		Control Relay, DPDT, 24 VAC	In control panel
3		SH2B-05	IDEC		Relay base	In control panel



REPLACE AIR CONDITIONING UNITS

VARIOUS BUILDINGS


MCAS, NEW RIVER, N.C.

EQUIPMENT SCHEDULE

Job #: A-024/J-024

PAGE: 2 of 3 DATE: 1/23/88

QNTY.	IDENTIFIER	PART NUMBER	MANUFACTURER	DESCRIPTION	LOCATION
			BUILDING AS-236		
6	COOLING	TC-1103	Barber Colman	Space thermostat cooling, 2 pos	In space
6	T-2	TP-8102	Barber Colman	Space thermostat, heating, proport.	In space
2	V-3	VS-9313-201-4-4	Barber Colman	Control valve, 3 way, 1/2" proportional, Cv = 4	At AHU 3 & 5
3	V-4	VS-9313-201-4-6	Barber Colman	Control valve, 3 way, 3/4" proportional, Cv = 6.8	At AHU 1,2 &6
1	V-5	VS-9313-351-4-11	Barber Colman	Control valve, 3 way, 2" proportional, Cv = 55	At AHU 4
6		AT-603	Barber Colman	Subbase switch, fan AUTO/ON HEAT/COOL	At cooling thermostat
4	O.A. T'stat	eTC-4111	Barber Colman	Thermostat, O.A. limit	Bulb in O.A. duct of AHU 1, 2, 4 & 6
12	R-2, R-3	RH2B-U24	IDEC	Control relay, DPDT, 24 VAC	In control panel
13		SH2B-05	IDEC	Relay base	In control panel
1	V-6	VS-9223-351-4-10	Barber Colman	Control valve, 2 way, 1 1/2" N.C. proportional, Cv = 25	At steam convertor
1	TS-1	TS-8501	Barber Colman	0.A. temperature sensor	Element in O.A.
1	TS-2	TS-8201	Barber Colman	H.W.S temperature sensor	Element in H.W.S
1		AT-215	Barber Colman	Bulb Well	With TS-2




JOB: REPLACE AIR CONDITIONING UNITS
VARIOUS BUILDINGS
MCAS, NEW RIVER, N.C.

EQUIPMENT SCHEDULE

Job #: A-024/J-024

PAGE:3 of 3 DATE:1/23/88

QNTY.	IDENTIFIER	PART NUMBER	MANUFACTURER	DESCRIPTION	LOCATION
			AS-236 (cont)		
1	RC-1	CP-8102	Barber Colman	2 input reset controller for steam convertor	In control panel
1	R-3	RH2B-U24	IDEC	Control relay, DPDT, 24VAC	In control panel
1				Control panel, 20" X 16"	In mech. room
			BUILDING AS-502		
1	SPACE	TC-1103-500	Barber Colman	Space thermostat, cooling, 2 pos.	In space
1	SUBBASE	AT-603	Barber Colman	Subbase switch, fan AUTO/ON	At cooling thermostat
	- 44				



TC-1100 Series, TCR-1101 Two-Position Electric Room Thermostats

APPLICATION

For low or line voltage on-off control of fan coils, fans, motor starters, contactors, two-position electric actuators.

SPECIFICATIONS

Sensing Element: Bimetal. Differential: 2°F (1°C).

Electrical Switch: Snap action SPDT.

Ratings, See Table 3.

Connections: Color coded 6" (152 mm) leads.

Cover: Beige plastic as standard.

Locations: NEMA Type 1 indoor only.

Mounting: Flush or surface 2 × 4 switch box or directly to wall

(24 volt only).

Dimensions: 4-3/8" high $\times 2-7/8$ " wide $\times 1-5/8$ " deep

 $(111 \text{ mm} \times 73 \text{ mm} \times 41 \text{ mm}).$

OPTIONS

Add "dash-number" (-XXX) suffix to base part number for desired option. For metal covers, specify TC2-110X-XXX.

Heat anticipator should be used when system differential varies from specified thermostat differential. Wide system differential may be due to thermostat guards, material on which thermostat is mounted, location of thermostat, etc. For models used in applications requires series heat anticipators, contact factory.



G



-40111







-403†† -404††

-500 parallel heat anticipation 24V standard cover

-501 parallel heat anticipation 120V standard cover

-502 parallel heat anticipation 240V standard cover

-601 10°F night depression 120V standard cover
 -602 10°F night depression 24V standard cover

-603 10°F night depression 240V standard cover

††5/64" Allen screw used to secure cover

ACCESSORIES


TOOL-11

TOOL-13

AE-170 Series	Electric time clock
AT-101	Lock cover kit
AT-104	Dial stop pins (NOTE: Pins included with each unit.)
AT-136	Title plates (day, night, heat, cool)
AT-504	Plaster hole cover kit (small)
AT-505	Surface mounting base
AT-546	Auxiliary mounting plate
AT-602	Selector switch sub-base DP4T
AT-603	Selector switch sub-base one DP4T, one DPDT
AT-1100 Series	Thermostat guards

Calibration wrench

Contact burnishing tool








Figure 1. Switch Action and Lead Identification

TABLE 1. SPECIFICATIONS

Part Number	Setpoint Dial Range* °F (°C)	Cover Configurations		
TC-1101	55 to 85 (13 to 29)			
TC-1102	45 to 75 (7 to 23)	See Options		
TC-1103	75 to 105 (24 to 40)			
TCR-1101	55 to 85 only	One Blank Cover Insert & One Cover Insert with Control Dial Cutout**		

^{*}Dual marked (except TCR-1101), dial stop pins included to limit setpoint range.
**One (1) 5/64" Allen head screw and 5/64" Allen wrench for securing cover to thermostat base included along with standard single slotted screw.

TABLE 2. AGENCY APPROVALS†

Configuration	UL	CSA
Metal Case (TC2-110X)	Yes	Yes
Plastic Cover (TC-110X)	Yes	No
Heat Anticipation or Night Depression (-500 or -600 Series)	Yes	Yes

TABLE 3. MAXIMUM ELECTRICAL RATINGS

Full Loa	d Amps	Locked Re	Pilot Duty		
24/120 Vac	240 Vac	24/120 Vac	240 Vac	(VA)	
4.4 Orange to Brown Lead	2.2 Orange to Brown Lead	26.4 Orange to Brown Lead	13.2 Orange to Brown Lead	40 A 24 Vac	
3.0 Orange to Red Lead	1.5 Orange to Red Lead	18 Orange to Red Lead	9 Orange to Red Lead	210 @ 120/240 Vac	

PRE-INSTALLATION

Inspection

Visually inspect the carton for damage. If damaged, notify the appropriate carrier immediately. If undamaged, open the carton and visually inspect the device for obvious defects. Return damaged or defective products.

Required Installation Items

- Wiring diagrams
- Tools (not provided):

Volt-ohm meter

Appropriate screwdriver for mounting screws and terminal connections

- Appropriate accessories
- Mounting screws, two (2) provided for securing to a 2 × 4 conduit box

INSTALLATION

CAUTION

- 1. Installer must be a qualified, experienced technician.
- Make all connections in accordance with the wiring diagram, and in accordance with national and local electrical codes. Class I wiring is required unless all circuits to contacts are powered from a Class II source. Use copper conductors only.
- 3. Do not exceed ratings of the device.

Mounting

Thermostats require upright mounting on a properly flat vertical surface. Locate the thermostat where it will be exposed to unrestricted circulation of air which represents the average temperature of the controlled space.

- CAUTION .

Do not locate the thermostat near sources of heat or cold, such as lamps, motors, sunlight or concealed ducts or pipes, or where there is a danger of electrocution (i.e., shower rooms).

The thermostat is designed for service in any normally encountered human environment. Avoid locations where excessive vibration, moisture, corrosive fumes or vapors are present. NEMA Type 1 covers are intended for indoor use primarily to provide a degree of protection against contact with the enclosed equipment.

Thermostats with guards that restrict air flow must have heating or cooling anticipation.




Figure 2. Thermostat Mounting

Procedure

- 1. Pull all wires
- 2. Make electrical connections to thermostat. (Typical heat anticipation and night depression wiring diagrams are shown in Figures 6 through 8.)
- Remove thermostat cover and fasten thermostat to box or wall.
- 4 Attach thermostat cover.

CHECKOUT

After installing a thermostat, make an initial check of the switching action. Verify the switch action by listening to and watching the switch contacts or by using a voltmeter between the proper sides of the switch.

- Run the setpoint dial to a temperature above ambient. This should cause the thermostat to make a circuit between orange and brown leads.
- Turn the setpoint dial setting down below ambient. This should cause the thermostat to make a circuit between orange and red leads.

CALIBRATION (See Figure 3)

All thermostats are precision calibrated at the factory and normally will not require any further attention. However, if recalibration is necessary, proceed as follows:

- Turn off control power and power to night depression circuit, where applicable.
- Set setpoint dial to correspond to actual stable room temperature, as read from an accurate thermometer.
- Remove thermostat cover. Do not breathe on the thermostat or handle excessively as this will affect the accuracy of the final calibration.
- If contact blade is made to the left (red) contact, with a small screwdriver, turn calibration screw counterclockwise (looking at head of screw) until blade makes to right (brown) contact.

NOTE

Each complete turn of screw changes calibration approximately 15°F (8°C).

Now turn screw very slowly clockwise until blade just makes the left (red) contact. Thermostat is now properly calibrated.

If contact blade is originally made to the right (brown) contact, turn calibration screw slowly clockwise until element just makes the left (red) contact. Thermostat is now properly calibrated.

- 5. Replace thermostat cover.
- 6. Turn on control power.
- Recheck calibration about 30 minutes later to be sure heat from handling of or breathing on bimetal element did not result in an erroneous setting.

HEAT ANTICIPATION (See Figures 6 and 7)


Heat anticipation, series or parallel, is recommended for:

- Systems with excess heating capacity that can cause objectionable space temperature swings.
- Thermostats mounted on walls (i.e., concrete) that change temperature slowly and/or have insufficient air flow over the device.

COOLING ANTICIPATION (See Figure 8)

Parallel cooling anticipation is recommended for:

- Cooling anticipations where current draw exceeds 1 ampere.
 Cooling lockout (self heat of the thermostat causing over cooling of the space) can occur on these applications.
- Systems with excess cooling capacity that can cause objectionable space temperature swings.
- Thermostats mounted on walls (i.e., concrete) that change temperature slowly and/or have restricted air flow over the device.



CONCEALED CONTROL DIAL

Knurled Dial Removal (See Figure 4)

- 1. Remove thermostat cover.
- Secure the control dial with hand so that the dial will not rotate.
- Place needle nose pliers at knurled ring of the control dial at the points where the knurled ring is attached to the control dial.
- Twist the pliers at each knurled ring attachment point until the entire knurled ring of the control dial is removed.




Figure 4. Knurled Dial Removal

LIMIT CONTROL DIAL RANGE

Dial Stop Pin Insertion — Included with Mounting Plate (See Figure 5)

- 1. Remove thermostat cover.
- Secure the control dial with hand so that the dial will not rotate.
- 3. Place a dial stop pin in the jaws of a needle nose pliers.
- Insert the dial stop pin in the appropriate hole on either (or both) side(s) of the control dial to restrict dial rotation.




Figure 5. Dial Stop Pin Insertion

MAINTENANCE

Regular maintenance of the total system is recommended to assure sustained optimum performance.

Open areas at bottom and around base of thermostat should be kept clean and free from obstructions to allow proper flow of air. If switch contacts need cleaning, this may be done with TOOL-13 (burnishing tool).

NOTE -

Thermostat may require calibration after cleaning the contacts.

REPAIR

These thermostats are not field repairable. Replace a defective thermostat with a functional unit.




Figure 6. Typical of Parallel Heat Anticipation (heater size determined by voltage) with or without Night Depression




Figure 7. Typical of Series Heat Anticipation (heater size determined by ampere rating of load) with or without Night Depression




Figure 8. Typical of Parallel Cooling Anticipation (anticipator size determined by voltage)




Figure 9. Typical Night Depression

Barber-Colman Company ENVIRONMENTAL CONTROLS DIVISION


1354 Clifford Avenue P.O. Box 2940 Loves Park, IL U.S.A. 61132-2940





TP-8101, TP-8102, TP-8103, TP-8124, TP-8125 Electronic Thermostats Proportional Controlling

TP-8101, TP-8102, TP-8103 Single Setpoint Adjustment



TP-8124 & TP-8125 Dual Setpoint Adjustment




Table 1

Part Number	Dial Marking	Control Dial Range	Throttling Range for 3 Vdc Output Change	Input Voltage	Output Voltage	Control Action	Wiring Connections	Number of Controlled Devices
TP-8101	°F&°C	55-85°F	2, 3, 6 and			Factory Set		6 System 8000
P-8101-116	°C	13-29°C	20°F		0.45.44	Direct-acting Jumper Terminal	3 Color-coded	
TP-8102	°F&°C	7-24°C (45-75°F)	Factory Set 3°F	20 Vdc 13 mA	2-15 Vdc or 15-2 Vdc	4 to 5 For Reverse-acting	Pigtail Leads Terminals for Options	Devices or 2 MP-5200
TP-8103	°F&°C	24-41°C (75-105°F)	By Jumper/ Pins			Jumper Terminal 4 to 3	See Figure 2	Series Actuators
TP-8124 Dual Setpoints	°F&°C	Heating 7-24°C (45-75°F) Cooling 21-38°C (70-100°F)	Heating and Cooling 2-10°F	20 Vdc	Heat 2-15 Vdc or	Heating Factory Set Reverse-acting Jumper J7	Coded	6 System 8000 Devices or 2 MP-5200 Series
TP-8125 Dual Setpoints	°F&°C	Heating 7-24°C (45-75°F) Cooling 24-41°C (75-105°F)	Independently Adj. Factory Set 3°F	23 mA	Cool 2-15 Vdc	to pin B for Direct-acting Cooling Direct-acting only	Terminals See Figure 3	Actuators in both Heating and Cooling

DESCRIPTION

TP-8101, TP-8102, TP-8103

These self-contained room temperature controllers conserve energy in heating and/or cooling applications requiring a single setpoint adjustment. See Table 1 for particular characteristics.

The heating and cooling equipment is precisely controlled from a single 1000 ohm Balco sensor operating through a single controller for heating and/or cooling. The controller provides a proportional output to control System 8000 controlled devices for control of valves, dampers, electric Leat, DX coils, etc.

TP-8124, TP-8125

These self-contained room controllers conserve energy in heating and/or cooling equipment in applications requiring heating and cooling setpoint adjustment.

See Table 1 for particular characteristics

The heating and cooling equipment is precisely controlled from a single 1000 ohm Balco sensor operating through independent heating and cooling controllers. These controllers provide proportional outputs to control System 8000 controlled devices for control of valves, dampers, electric heat, DX coils, etc. The heating output (OP1 to COM) can be programmed for direct-acting or reverse-acting operation. The cooling output (OP2 to COM) provides a direct-acting output only.

Features

- TP-8124 meets ASHRAE 90-75 and DOE requirements.
 TP-8125 meets DOD requirements.
- Heating and cooling cannot operate simultaneously.
- Heating/cooling deadband obtained by adjustable dual setpoints and throttling range.
- Proportional outputs operate remote System 8000 controlled devices such as valves, dampers, electric heat coils, etc.
- Concealed adjustments eliminate occupant tampering.

INSTALLATION

Open the carton and visually inspect the device for part number and obvious defects before proceeding with the installation.

Mounting screws are provided.

Locate the controller where it will be exposed to unrestricted natural air circulation and to the average conditions of the controlled space. Do not locate it near sources of heat or cold (such as lamps, motors, sunlight, radiators and concealed pipes or ducts within the wall) which might affect the control point. Avoid locations where excessive vibration, moisture, corrosive fumes or vapors are present, or where high radio frequency or electromagnetic generating devices are near.

Dimensions 111 mm (4-3/8") high \times 73 mm (2-7/8") wide \times 41 mm (1-5/8") deep.




Figure 1


Ambient Limits Operation: 40 to 140°F (4.4 to 60°C) Storage: -40 to 160°F (-40 to 71°C).

MODES OF OPERATION

- Direct-acting control (DA): Increase in temperature at the sensor causes the controller output signal to increase.
- Reverse-acting control (RA): Increase in temperature at the sensor causes the controller output signal to decrease.

THROTTLING RANGE

Throttling range (T.R.) is defined as the degrees (°F or °C) change at the temperature sensor in order to cause a 6 to 9 Vdc controller output signal change.



Wire Leads

Red = +20 Vdc (Input) Yellow = Proportional Output Blue = Common

Screw Terminals

1 = Common

2 = Auxiliary Input

3,4 = Connect for Reverse-Acting (RA)

4.5 = Connect for Direct-Acting (DA)

7 = 6.2 Vdc

7.8 = Remote Sensor

Figure 2
Terminal Nomenclature
TP-8101, TP-8102 and TP-8103




Figure 3
Terminal Nomenclature
TP-8124 and TP-8125

WIRING

Make all electrical connections according to installation wiring diagrams. Comply with national and local electrical codes.

No. 18 multi-conductor thermostat cable may be used. Low voltage Class 2 wire is acceptable, but No. 18 or larger 600V wire should be used if splices are to be made in the same junction box with line voltage wiring.

The controller may be installed on either a 52 mm × 102 mm (2" × 4") flush switch box or a surface switch box. To install, proceed as follows:

- Wiring for the TP-8101, TP-8102 and TP-8103 is shown in Figures 4 and 5. See Figures 6 and 7 for TP-8124 and TP-8125 typical wiring.
- 2. "Pull" all wires required.
- 3. Connect all control wiring to the thermostat
- Remove the thermostat cover by loosening the screw at the bottom of the cover. Pull the cover out from the bottom and up to disengage it from the base.
- Fasten the base to the box with the screws provided.
- 6 Replace the cover and tighten the cover screw.

WIRING OF CONTROLLED DEVICES TO CONTROLLER

Types of controlled devices and their power supplies:

- Filtered and regulated power supplies. All System 8000 controlled devices except MP-52XX and MF-54XX series actuators.
- Filtered and unregulated power supplies: MP-54XX series actuators.
- 3 Unfiltered and unregulated power supplies: MP-52XX series actuators

General rules for wiring controllers to controlled devices:

Never connect red lead (or +20 terminal) of any controlled device which has a regulated power supply to the red lead (or +20 terminal) of any other controlled device

- Controlled devices with unfiltered and unregulated power supplies must be fittered. System 8000 controllers will provide filtering for a maximum of two controlled devices by connecting the two red leads (+20 terminals) together at the controller's red lead (+20 terminal).
- Controlled devices with filtered and unregulated supplies:
 Up to six controlled devices with the red leads (+20 terminals) can be connected together. Number of units paralleled depends on the current (mA DC) requirements of the controller or adaptor.
- 4. Devices and their internal supplies:

FILTERED & REGULATED	FILTERED & UNREGULATED	UNFILTERED & UNREGULATED
CC-8101	MP-54XX	MP-52XX
CC-8102	Actuators	Actuators
CC-8103		
CC-8118 Series		
CC-8218 Series	N	
CC-8111 Series		
CP-8301 Series		
CP-8161 Series		
CP-8425 Series		
CP-8501 Series		
CP-8502 Series		




Figure 4
TP-8101, TP-8102 and TP-8103
Typical Wiring without MP-52XX Actuators




Figure 5
TP-8101, TP-8102 and TP-8103
Typical Wiring with MP-52XX Actuators




Figure 6
TP-8124 and TP-8125
Typical Wiring with One or No MP-52XX Actuators

A CONTROL OF THE PARTY OF THE P




Figure 7
TP-8124 and TP-8125
Typical Wiring with Two MP-52XX Actuators

ADJUSTMENTS

TP-8101, TP-8102, TP-8103

- Turn the setpoint adjuster to the required temperature setting. Normally, no further adjustments are required.
- 2. Throttling range settings of 2, 3, 6 and 20° are available by placing the T.R. jumper on the proper selector pin. See Figure 8. For other throttling ranges (1 through 60°) add a resistor to the auxiliary pins. Select the resistor from the chart below. Place the T.R. jumper on the auxiliary pin nearest the center of the controller.

Table 2. Throttling Range Resistor Values

°F T.R.	Auxiliary Resistor	Barber-Colma Part Numbe		
1	4.3 Meg. ±5%	E19-23-562		
1.5	3.0 Meg. ±5%			
2.0	2.2 Meg. ±5%	CYZR-481-860		
2.5	1.8 Meg. ±5%	CYZR-481-580		
3.0	1.5 Meg. ±5%	CYZR-481-680		
3.5	1.2 Meg. ±5%	CYZR-481-450		
4.0	1 Meg. ±5%	CYZR-481-610		
4.5	975K, ±1%	CYZR-862-496		
5.0	866K, ±1%			
6.0	732K, ±1%			
7.0	619K, ±1%	CYZR-862-477		
8.0	549K, ±1%			
9.0	487K, ±1%			
10.0	432K, ±1%	CYZR-862-462		
15.0	287K, ±1%	CYZR-862-445		
20.0	215K, ±1%			
25.0	174K, ±1%	CYZR-837-913		
30.0	143K, ±1%	CYZR-837-130		
40.0	107K, ±1%			
50.0	84.5K, ±1%	E19-64-390		
60.0	69.8K, ±1%	CYZR-837-890		

TP-8124 and TP-8125

 Remove the cover and turn the setpoint adjuster (SPA) to the required temperature for the heating mode (typically 65°F).

Turn the setpoint adjuster (SPB) to the required temperature for the cooling mode (typically 78°F).

The cooling signal is direct-acting, and stages cooling or proportionally opens a normally closed chilled water valve with a temperature increase.

The heating signal is factory set for reverse-acting. With a temperature decrease, the signal stages electric heat or proportionally increases the electric heat output controlled by a Barber-Colman CP-8400 or CP-80000 Series SCR controller.

 For applications that require a direct-acting signal in the heating mode such as a normally open heating valve, move jumps: 37 to pin "B".

- The Temperature Deadband between heating and cooling is the difference in SPB and SPA settings. For example, the deadband is 13°F with SPA at 65°F and SPB at 78°F.
- The throttling ranges are factory set at 3°F for heating and cooling. These settings should not be changed for normal applications. Increase the throttling range only to achieve control stability (adjustable 2 to 10°F).

To adjust, turn the T.R. dial to position the required T.R. value closest to the thermostat cover.

Replace the cover.




Figure 8 TP-8101, TP-8102 and TP-8103




Figure 9a TP-8124 or TP-8125

SERVICE

TP-8101, TP-8102, TP-8103

NOTE .

The TP-8101, TP-8102 and TP-8103 have been factory calibrated to produce a 7.5 Vdc output signal at the yellow and blue leads (TO+ and TS-) when the setpoint and the temperature at the sensing element agree.

- 1. Verify wiring per job wiring diagram.
- 2. Measure with a 20,000 ohm per Vdc VOM.

 - Output 2 to 15 Vdc: Yellow (+) to blue (-) wires or TO+ and TS- test pins. The voltage varies between 2-15 as the dial knob is rotated.
- 3. Consult EN 111 for additional service information.
- 4. Replace the controller if it is defective.

If calibration is necessary, proceed as follows:

- Connect a 20,000 ohm per Vdc VOM between the yellow (+) and blue (-) leads or TO+ and TS- pins on the thermostat.
- With the thermostat cover on, insert a 5/64" Allen wrench through the hole on the right-hand side of the thermostat into the setpoint potentiometer shaft.
- 3. Measure the temperature at the thermostat.
- Adjust the thermostat setpoint by rotating the Allen wrench until the setpoint dial reading equals the temperature measured in step 3 above.
- Using the thumb of your left hand, hold the knob in place.
 Avoid touching the lower left-hand corner of the thermostat where the sensor is located.
- 6. Rotate the Allen wrench until VOM reads 7.5 ±.3 Vdc.
- 7. The thermostat is calibrated.

TP-8142 and TP-8125

NOTE -

The TP-8124 and TP-8125 have been factory calibrated to produce 6.0 Vdc output signals at OP1 and OP2 to COM terminals when the setpoints and the temperatures at the sensing element agree.

Test the power supply and output as follows:

- 1. Verify the wiring per the job wiring diagram.
- 2. Measure with a 20 000 ohm per Vdc VOM:
 - a. Power supply 20 Vdc: +20 (+) to COM (-).
 - Heating output: OP1 (+) to COM (-). Vdc varies between 2-15 as SPA is rotated.
 - Cooling output: OP2 (+) to COM (-). Vdc varies between 2-15 as SPB is rotated.
- 3. Replace the controller if it is defective.

If calibration is necessary, proceed as follows:

Remove the thermostat cover. Note room temperature.

- 2. If room temperature is 75°F or greater:
 - a. Connect VOM internally to OP2 (+) and COM (-). See Figure 9B for details.
 - b. Rotate SPB until VOM reads 6.0 ±.3 Vdc. SPB pointer must indicate the temperature measured. If not, hold SPB shaft and rotate pointer (CCW) until it indicates the temperature measured.

SPB is calibrated.

- Disconnect VOM lead from OP2 and reconnect to OP1. Connect Jumper J7 to Pin A.
- d. Connect 1 MEG ±1% resistor (SYZE-13512 test kit) between AB1 and 6.2 connections.
- e. Rotate SPA until VOM reads 6.0 ±.3 Vdc. SPA should read temperature measured minus 10°F. If not, hold SPA shaft and rotate pointer (CCW) until it indicates temperature measured minus 10°F.

SPA is calibrated.

- 3. If room temperature is 74°F or less:
 - Connect VOM internally to OP1 (+) and COM (-). See Figure 9B for details.
 - b. Rotate SPA until VOM reads 6.0 ±.3 Vdc. SPA must indicate the temperature measured. If not, hold SPA shaft and rotate the pointer (CCW) until it indicates the measured temperature.

SPA is calibrated.

- Disconnect VOM lead from OP1 and re-connect to OP2. Connect Jumper J7 to Pin A.
- d. Connect 1 MEG, ±1% resistor (SYZE-13512 test kit) between AB2 and COM connections.
- e. Rotate SPB until VOM reads 6.0 ±.3 Vdc. SPB should read the measured temperature plus 10°F. If not, hold SPB shaft and rotate pointer (CCW) until it indicates the measured temperature plus 10°F.

SPB is calibrated.




Figure 9b




Figure 10 TP-8101, TP-8102 and TP-8103 Block Diagram




Figure 11
TP-8124 and TP-8125 Block Diagram

OPTIONS

TP-8101, TP-8102, TP-8103 (TP-8124 and TP-8125 have no options.)

Remote Setpoint Install the AT-8100 Series remote setpoint adjuster between terminals 1, 2 and 7. These are used for applications where the setpoint adjustment is mounted remote from the controller. See Figure 14, 15 or 16.

Remove the dial rim from the setpoint knob using wire cutters. Turn the dial to 70°F. The AT-11-404 blank cover is recommended to prevent dust infiltration.

Remote Sensing Remove the internal 1000 ohm sensor and install the remote sensor (TS-8000 Series) between terminals 7 and 8. This is used for applications where the sensor is mounted remote from the controller. See Figure 13.

Summer-Winter Changeover is accomplished without remote setpoints or selective ratio discharge. The controller operates in either the DA or RA mode. See Figure 12.

Jumper 4 to 5 — DA (direct-acting): A temperature increase causes an output voltage increase.

Jumper 3 to 4 — RA (reverse-acting): A temperature increase causes an output voltage decrease.

Selective Ratio Discharge Control Connect the ratio discharge sensor (Figure 19) to the room controller as shown in Figure 14, 15 or 16. This is used for room and discharge control applications.

Winter-Summer Operation is accomplished using selective ratio discharge and/or remote setpoints. For direct-acting, see Figure 14. For reverse-acting, see Figure 15. For winter-summer switching, see Figure 16.

For panel mounting, see Figure 18.







Figure 12. TP-8101, TP-8102 and TP-8103 with Single Pole Double Throw (SPDT) Winter-Summer Switching







TS-8601 Selective Ratio Discharge






Figure 16
TP-8101, TP-8102 and TP-8103
with Remote Setpoint and/or
Selective Ratio Discharge Sensor
with Double Pole Double Throw (DPDT)
Winter-Summer Switching





	RESISTORS	and the second
Degrees	Resistance	B-C Part No.
5	20 MEG. ±5%	CYZR-481-530
10	1.0 MEG, ±1%	CYZR-862-501
15	681K, ±1%, 1/8W	E19-64-481
20	499K. ±1%. 1/8W	CYZR-862-468

Figure 17
TP-8101, TP-8102 and TP-8103
with Night Depression and/or
Morning Warm-Up





Figure 18 TP-8101, TP-8102 and TP-8103 Mounted on AD-8951



AUXILIARY RESISTORS					
Ratio	Resistance	B-C Part No.			
25 1	59k = 1% 1 3V	C+2R-932-66			
30.1	71.5K - 196. 1 9W	CYZR-868-19			
40:1	95.3/ ±1%.1.8W	E19-29-395			
50:1	121K ±1% 1/8W	CYZR-788-12			

Figure 19
TS-8601 Ratio Discharge Sensor for use with
TP-8101, TP-8102 and TP-8103

MAINTENANCE

This is a quality product. Regular maintenance of the total system is recommended to assure optimum performance.

Barber-Colman Company ENVIRONMENTAL CONTROLS DIVISION

1354 Clifford Avenue P.O. Box 2940 Loves Park, IL U.S.A. 61132-2940

F-18097-4 BK

2.2,2,9

TABLE 1. Select Valve Body including P Code (Valve Size, Cv Rating, Port Code) or select Valve. Assembly with correct Input Signal (see Table 2 also) less Actuator Code (XXX) including the P Code (Size, Cv Rating, Port Code). (See Pages 331-335 for Valve Sizing.)

	APPL	ICATION	Windows W.
Chilled or 281°F 35 psig	Max.	Hot Water 300°F Max. 100 psig Steam	Hot Water 366°F Max. 150 psig Steam
Screwed	Screwed Flanged		ewed
100000			







	Size	1/2"-2"	2-1/2"-4"	1/2"-2"	1/2"-2"
	Valve Body	VB-9213-0-4-P	VB-9213-0-5-P	VB-9253-0-4-P	VB-9273-0-4-P
Normally	Valve Assembly 2-15 Vdc Input, System 8000	VS-9213-XXX-4-P	VS-9213-35X-5-P	VS-9253-XXX-4-P	VS-9273-XXX-4-P
Open Valves	Valve Assembly, Built-in System 8000 Controller	VS-9213-35X-4-P	VS-9213-35X-5-P	VS-9253-35X-4-P	VS-9273-35X-4-P
Valves	2-Position SPST Valve Assembly	VA-9213-2XX-4-P		VA-9253-2XX-4-P	VA-9273-2XX-4-P
	Valve Body	VB-9223-0-4-P	VB-9223-0-5-P	VB-9263-0-4-	VB-9283-0-4-P
Normally	Valve Assembly 2-15 Vdc Input, System 8000	VS-9223-XXX-4-P	VS-9223-35X-5-P	VS-9263-XXX-4-P	VS-9283-XXX-4-P
Closed Valves	Valve Assembly, Built-in System 8000 Controller	VS-9223-35X-4-P	VS-9223-35X-5-P	VS-9263-35X-4-P	VS-9283-35X-4-P
421408	2-Position SPST Valve Assembly	VA-9223-2XX-4-P		VA-9263-2XX-4-P	VA-9283-2XX-4-P
The second second	Flow Town	Faural 0/	[N	F10/	F10/

NOTE: These charts are color coded as shown below to assist valve selection. Note it is possible to select either a valve assembly or component parts (actuator, valve linkage, valve body).

ORDERING EXAMPLES:

- 1. Valve
 - Assembly VS-9223-212-4-8
- 2. Valve Body ... VB-9223-0-4-8
 Actuator MP-5210-500
 Linkage AV-600
- Valve Body Data less P Code (Size, Cv Rating, Port Code) or Valve Assembly less Actuator Code (XXX) and less P Code (Size, Cv Haling, Port Gode)
- P Code (Size, Cv Hating, Port Gode)
- Actuator of Actuator Code (XXX) for Valve Assemblies
- Valve Linkage

n 8000 Controller		VS-9223-35X-4-P	VS-9223-35X-5-P	VS-9263-35X-4-P	VS-9283-35X-4-P	
ssembly		VA-9223-2XX-4-P	_	VA-9263-2XX-4-P	VA-9283-2XX-4-P	
Flow Type		Equal %	Equal %	Equal %	Equal %	
Body		Bronze	Cast Iron	Bronze	Bronze	
	Seat	Bronze	Bronze	Stainless Steel	Stainless Steel	
	Stem	Stainless Steel	Stainless Steel	Stainless Steel	Stainless Steel	
Material	Plug	Brass	Brass	Stainless Steel	Stainless Steel	
	Packing	Spring Loaded Teflon Cone	Spring Loaded Teflon Cone	Spring Loaded Teflon Cone	Spring Loaded Teflon Cone	
	Disc	Composition	Composition	Teflon	None	
			STEAM		Treestand	
	Static	250	125	250	250	
Pressure	Inlet	35	35	100	150	
(psig)	Recom. Diff.*	20	20	35	50	
Huld Tomp. "F ("C)	Max.	(1381")	281° (138°)	340" (171")	366" (180")	
			WATER			
Pressure	Statte	2"50	125	250	250	
(paig)	Recom Diff.*	35	315	35	50	
Huld Lamp	Min	40" (4")	40" (4")	40" (4")	40" (4")	
t [C]	Max	(438")	(1.88.)	300" (149")	366" (180")	

TO SELECT A PORT CODE (P)

P Lodo	Valve Size			v	
1**		0.4		0.4	0.4
7**	1/2"	1.1		13	13
3**	1"	7.7		22	22
4		16		36	3.6
h**	3/4"	5.0		5.0	50
- 6	3/4	6.2		62	6.9
1		16.2		B2'	8.9
- 11		110		110	110
9	11/4"	16.0		160	160
10	1 1/2"	25.0		250	250
- 11	2"	40.0		400	40.0
12	2 1/2"		56		
13	3"		85		\$4.78 E. S.
14	4"		145		

^{*}Maximum recommended differential pressure in full open position. Do not exceed recommended differential pressure (pressure drop) or integrity of parts may be affected.

NOTE: Do not exceed close-off rating.

[&]quot;NOTE: Factory assemblies are not available for 2-position applications using reduced port valve bodies.

2-WAY VALVES, SCREWED (1/2" TO 2") AND FLANGED (2-1/2" TO 4") WITH HYDRAULIC ACTUATORS

TABLE 2. Select **Actuator Type** or **Actuator Code (XXX)** series with correct Input Signal having sufficient close-off for the application. If selecting Component Parts, select







Input Signal					Two-Position SPST	2-15 Vdc System 8000	2-15 Vdc System 8000**
Valve Linkage 1/2" — 1-1/4" Valve					AV-600	AV-600	-
Valve Linkage 1/2" — 2" Valve						-	AV-430
A COLUMN	Valve Linkage 2-1/2" —				AV-495		
Actuator Code (XXX)					2XX	2XX	35X
Actuator Code					MA-521X-XXX	MP-5X1X	MS-BXX1X-XXX
Normal Position	Factory Avail. Valve Assembly	Valve Body	P Code	OIL	CI	OSE-OFF PRESSURE RAT	
VA-9213-2YY-4-P	VA-9213-2XX-4-P		-1-2-3-4	1/2"	180	190	
	VA-9253-2XX-4-P		-5-6	3/4"	75	85	
Normally Open	VA-9273-2XX-4-P	VB-9213-0-4-P VB-9253-0-4-P	-7-8	1"	40	45	The Control of the Co
,	VS-9213-XXX-4-P VS-9253-XXX-4-P	VB-9273-0-4-P	-9	1-1/4"	25	30	
	VS-9273-XXX-4-P		-10	1-1/2"			65
750		3.00 940 95	-11	2"			35
Age of the second		Marian State	-12	2-1/2"			20
Normally Open	VS-9213-35X-5-P	VB-9213-0-5-P	-13	3"	The second second		12
			-14	4"			6
	VA-9223-2XX-4-P	10.00	-1-2-3-4	1/2"	250	220	
	VA-9263-2XX-4-P		-5-6	3/4"	140	90	
Normally Closed	VA-9283-2XX-4-P	VB-9223-0-4-P VB-9263-0-4-P	-7-8	1"	75	50	
, 0.000	VS-9223-XXX-4-P VS-9263-XXX-4-P	VB-9283-0-4-P	-9	1-1/4"	45	30	
	VS-9283-XXX-4-P		-10	1-1/2"			65
	10 0000 AAA 41	and the state of the state of	-11	2"		建设金属的	35
			-12	2-1/2"			20
Normally Closed	VS-9223-35X-5-P	VB-9223-0-5-P	-13	3"			12
Class att			-14	4"			6

^{*}Close-off pressure ratings apply when valves are installed with pressure under the seat.

TABLE 3. Select exact Actuator or Actuator Code (XXX) if Factory Assembly is available

Input Signal	Wiring Figure No.	Voltage Vac 50/60 Hz	VA	Aux. Switch	Actuator Part No.	Actuator Code (XXX) For Factory Available Assy	
		24		No	MA-5213	201	
		24		Yes	MA-5213-500	202	
		120		No	MA-5210	211	
Two-position SPST	See Figure 1	120	18	Yes	MA-5210-500	212	
	on Page 336	208	10	No	MA-5212		
		208		Yes	MA-5212-500		
		240	a keren	No	MA-5211	221	
and the second of the second o		240		Yes	MA-5211-500	222	
		24	E GAR	No	MP-5213	201	
		24	1 1	Yes	MP-5213-500	202	
		120		No	MP-5210	211	
2-15 Vdc, System 8000, Stroke occurs 6-9 Vdc approx.	See Figure 12 on Page 339	120	18	Yes	MP-5210-500	212	
Non-positive positioning		208		No	MP-5212		
STATE OF STREET STATE OF STREET STATE OF STREET		208		Yes	MP-5212-500		
			240		No	MP-5211	221
tion statement the transport of the property o		240		Yes	MP-5211-500	222	
		24	1,30	No	MP-5413	243	
	See Figure 12	120	18	No	MP-5410	240	
	on Page 339	208		No	MP-5412		
2-15 Vdc, System 8000, start 6 Vdc factory set.	V. Alexandra de la companya del companya del companya de la compan	240		No	MP-5411	241	
Adjustable 2-12 Vdc, 3 Vdc span, Positive positioning		24	36	No	MS-83013	351	
	See Figure 12	120	37	No	MS-83010	353	
	on Page 339	120	37	Yes	MS-83010-500		
		240	39	No	MS-83011		
	工程等 等等。	240	39	Yes	MS-83011-500		
		120	37	No	MS-84110	354	
Built-in System 8000 controller, Uses TS-8XXX sensor	See Figure 19	120	37	No	MS-84110-011*		
Sell of Sell o	on Page 343	120	37	Yes	MS-84110-500		

^{**}Certain models have built-in controller

2-WAY VALVES, SCREWED (1/2" TO 2") AND FLANGED (2-1/2" TO 4") WITH HYDRAULIC ACTUATORS

TABLE 4. Dimensions


	DIMENSIONS (Inches)								
		Valve E		Actuator	Series				
					200*	350			
Part Number	Size	A	8	C	E	E			
	1/2"	3		1	8-3/16				
VA-9213-2XX-4-P	3/4"	3-5/8		1-3/8	8-11/16				
VA-9253-2XX-4-P VA-9273-2XX-4-P	1.	4-5/8		1-1/2	9				
VS-9213-XXX-4-P	1-1/4"	4-5/8		1-5/8	9				
VS-9253-XXX-4-P	1-1/2"	6-1/8	1 5	2-1/2		19-1/8			
VS-9273-XXX-4-P	2	6-1/8		2-1/2		19-1/8			
	2-1/2"	8-1/2		3-1/2		19-13/16			
VS-9213-35X-5-P	3"	9-1/2		3-3/4		20-3/16			
	4'	11-1/2		4-1/2	and the series of the series	21-7/16			
Name to Add	1/2"	3		1-7/16	8-3/16				
VA-9223-2XX-4-P	3/4"	3-5/8		1-3/4	8-11/16				
VA-9263-2XX-4-P VA-9283-2XX-4-P	1°	4-5/8	448	2	9				
VS-9223-XXX-4-P	1-1/4"	4-5/8		2	9				
VS-9263-XXX-4-P	1-1/2"	6-1/8		3-3/16		18-5/8			
VS-9283-XXX-4-P	2"	6-1/8		3-3/16		18-5/8			
	2-1/2"	8-1/2	×	4-1/8		19-7/16			
V8-9223-35X-5-P	3"	9-1/2		4-1/8		19-13/16			
100	4'	11-1/2		5-1/16	21.7	20-7/16			

*Add 21/32" (52 mm) to the "E" dimension for a valve assembly using an AV-601 linkage extension that must be purchased separately.

Dimensions in inches (metric conversion 25.4 mm = 1 inch)


VS-9213-35X-5-P


NOTE: Allow 3 inches clearance above actuator for removal. Mount MA/MP-5XXX actuators above the valve body at 45° from vertical on steam applications.



See Flange Detail Table on following page

VS-9223-35X-5-P






(G1)

(H1)

300 & 400 Series &

PP-220 Series

MP-9810 ACTUATOR




Terminals 1, 5 & 6 are used for built-in auxiliary switch

- Rotates CW or Closes Valve


3 - Rotates CCW or Opens Valve

SYSTEM ROSD A. 2-15 VOC INPUT





Relay 1

32



Valve Assembly	Increasing Vdc Input Signal	Normal Position Decreasing Vdc	
VP-1112			
VS-9211	Closed		
VS-9212			
VS-9213		Open	
VS-9253			
VS-9273			
VS-9221			
VS-9222		Closed	
VS-9223	Open		
VS-9263			
VS-9283			
VS-9313	Flow "A" to "AB"	Flow "B" to "AB"	
VS-9323-XXX-4	Flow "B" to "A"	Flow "B" to "AB"	
VS-9323-XXX-5	Flow "C" to "U"	Flow "C" to "L"	







General Instructions

AT-602, 603, 607, 608 & 609-XXX Selector Switch Sub-Bases and Legend Plates


For use at the room thermostat to accommodate switching functions such as heating to cooling, day to night control, etc. **Device:** Rugged one piece molded beige plastic housing. One or two slide switches are double-pole, double throw (DPDT) or double pole-4 position (DP4T) allowing numerous control possibilities. DP4T can be used as two or three position by installing switch legend plates that limit switch travel. Coded screw terminals for the switch contacts are accessible for up to two No. 14 gauge wire connections. See Figure 2.


Installation

Use Class I wiring for all connections to switch subbases and to room thermostat unless all circuits are powered from a Class II source. Make all connections in accordance with national and local codes

Install subbases on a flush switch box, a surface switch box or directly on a wall (for 24V applications only).

- 1. Pull the required wires.
- If plastic conduit box is used, connect green wire from subbase to system ground, otherwise clip out the green wire.
- Mount the subbase (see Figure 1). Screws are provided for switch box mounting.
- Connect proper wires to subbase screw terminals. Push
 excess wire into conduit box, allowing field wires (if any) for
 room thermostat to project through opening in subbase.
- Make all electrical connections to thermostats and install any jumpers as required. Refer to job wiring diagram and/or General Instruction Sheet for thermostat.
- 6. Install thermostat on subbase (see Figure 1).
- To install switch legend plate on subbase strip the paper backing off and press plate into subbase. Note: Legend plates must be ordered separately.





Duplex Thermostat on Duplex Sub-Base

Figure 1

Single Thermostat on Single Sub-Base


			itch iption	
	Part Number	Upper Right	Lower Right	Used With
J	AT-602		DP4T	All Single Room Thermo- stats Except TK's, TA-115.
1	AT-603	DPDT	DP4T	TA-121, TA-133, TA-134, TC-114, and TC-142.
	AT-607	M	DP4T	TA-151, 115X, TC-154,
	AT-608	DPDT	DP4T	114X, 115X, 116X, 2-Stage and Duplex Thermostats.

	Inc	luctive		DII
Volts (AC)	Full Load Amps	Locked Rotor Amps	Non- Inductive Amps	Pilot Duty (VA)
24	5.8	34.8	6	125
120	5.8	34.8	6	125
240	2.9	17.4	3	125

^{*}The total load on both poles of a switch must not exceed the total electrical rating.


TYPICAL APPLICATIONS






ITEMS: TC-1101, AT-602, AT-609-302

THERMOSTAT PROVIDES SEQUENCED HEAT & COOL. ON-OFF SWITCH, OFF LOCKS OFF SYSTEM & FAN. LOW-MED-HIGH FAN SWITCH




ITEMS: TC-1191; AT-603; AT-609-353

THERMOSTAT PROVIDES SEQUENCED HEAT & COOL OFF-HEAT-AUTO-COOL SWITCH




ITEMS: TC-1191, AT-602, AT-609-402

THERMOSTAT CYCLES 2 STAGES HEAT AND 1 STAGE COOL, HEAT-COOL SWITCH, OFF-LOW-HIGH FAN SWITCH




ITEMS: TC-154, AT-608, AT-609-352

THERMOSTAT CYCLES HEAT & COOL, HEAT-COOL SWITCH, OFF-LOW-HIGH FAN SWITCH



ITEMS: TC-1101; AT-603; AT-609-352

THERMOSTAT CYCLES HEAT AND COOL, HEAT-COOL SYSTEM SWITCH



ITEMS: TC-1101, AT-602, AT-609-204




Figure 2


AT-609-XXX Legend Plates for Switch Sub-Bases

Various switch indicating plates are available and must be ordered separately. These have a brown simulated leather finish with bright letters and pressure sensitive backing for simplified field installation. Blank plate on left side of AT-602 & 603 is factory installed.

										AT-6	09-X	XX S	WIT	CH	LEG	EN	DPL	ATES								
Switch Position	Switch Action		81	ank	Plate	s*			Plates With Legends																	
Country	Macros	201	301	401	250	350	450	202	203	204	205	206	251	252	2531	362	303	305	306	307	351	352	353	480	403	452
A	DPDT												On Off	On Off	On Auto		cha tan				On Auto Fan	Heati Good	06 06			On Auto Fan
В	DP4T																							Off Heat Auto Cool	Off Low Med High	Off Heat Auto Cool
С	DP3T															Off Low High	Heat Off Cool	Occu Off Unoccu	Night Off Day	Off On Auto	Heat Off Cool	Off Low High	Low Med High			
ð	DPDT							On Off	Occu Unoccu	Heat Cool	Night Day	Auto On	Low High	High	High Low											

[&]quot;Special lettering can usually be provided by local nameplate engravers.
"*Legend Plate limits travel of DP4T Switch to provide DPDT or DP3T.

SWITCH POSITIONS



Barber-Colman Companu ENVIRONMENTAL CONTROLS DIVISION

1354 Clifford Avenue P.O. Box 2940 Loves Park. IL U.S.A. 61132-2940

^{†&}quot;Fan Operation" legend placed between switches.



General Instructions

OA. T'STAT

TC-4100 Series TC-4200 Series Bulb Thermostats Return Air Thermostats

For on-off control of media temperature in ducts, tanks, liquid lines, etc.

TC-4100 Series **one stage** units control one electrical circuit. Available in single or dual bulb configurations. (See Performance Table.)

TC-4200 Series **two stage** units control two electrical circuits in sequence. Available in single or dual bulb configurations. (See Performance Table.)

Dual bulb units are used to vary the control point of the controlled media as a function of outside air temperature. The ratio specified is outdoor to indoor. A unit with a 1 to 1-1/2 ratio will increase the water temperature 1-1/2°F for a 1°F decrease in outdoor temperature.

Air bulb units feature a coiled, fast responding air bulb. Used in return air control applications.

Device: Liquid filled thermal element actuates one snap acting SPDT switch per stage. Large color coded terminals. Setpoint adjustment dial plate is marked in °F on one side and °C on the other. The thermal differential is adjustable within the fimits shown in the performance table. The mechanism is enclosed in a metal case and the cover, and has 1/2-inch to 3/4-inch conduit opening in the bottom of the case. Remote bulbs are suitable for immersion, duct, or outside air mounting.

Dimensions


Bulb Units: 2-1/4" (57 mm) Wide × 4-5/8" (117 mm) High × 2" (51 mm) Deep.

Air Bulb Units: 2-1/4" (57 mm) Wide \times 9" (229 mm) High \times 2" (51 mm) Deep.

Electrical Rating: All Units Except TC-4115*

Switch Rating (50/60 Hz)	24V	120V	240V
Full Load Amps	9.8	9.8	8.0
Locked Rotor Amps	58.8	58.8	48.0
Pilot Duty VA	60	360	360
Non-Inductive Amps (Resistive)	-		_
Single Stage	22	22	22
Two Stage	16	16	8.0

^{*}TC-4115 for System 8000 and dry circuit switching Electrical Rating: 1.0 amp at 24 Vac; 25 amp at 24 Vdc.





Typical Air Bulb (Single or Two Stage)





Performance and Selection Table

		Setpoint	Dualt		Dimensions		Diffe	erential	Maximum	Case		
Туре	Part Number	Adjustment Range	Bulb Ratio	Capillary (Copper)			Factory Set	Adjustable	Safe Bulb Temperature	Ambient Temperature		
	TC-4111	-40 to 120°F		6′					170°F			
	TC-4111-020	-40 to 120 P	The state of	20′								
	TC-4112	100 to 260°F		6'	The second of				310°F			
Single Stage Single Bulb	TC-4115*	-40 to 120°F		3/8 × 4"		3 × 4"	3°F	3 to 16°F	170°F	-40 to 150°F		
	TC-4121	40101201		10'	10'							
	TC-4122	100 to 260°F	645	Armored		\$50 miles			310°F			
	TC-4123	190 to 350°F							400°F			
			100		Indoor	Outdoor			Total of indoor and outdoor	-40 to 150°F		
Single Stage Dual Bulb	TC-4151	70 to 120°F	1:1-1/2	Each Bulb	3/8 × 4"	3/8 × 5-1/2"	3°F	1.5 to 10°F	temperatures must not exceed			
	TC-4152		1:1		3/8 × 4"	3/8 × 4"		3 to 16°F	280°F			
One Stage Air Bulb	TC-4166	50 to 90°F		None		Coiled 2-1/2 × 2"				Fixed	-40 to 145°F Safe Bulb Range	-40 to 150°F
	TC-4211		tra German	6'				Per Stage	170°F			
Two Stage	TC-4221	-40 to 120°F			3/8×4"		3°F	Fixed Between	1701	-40 to 150°i		
Single Bulb	TC-4222	100 to 260°F		10' Armored	3/6	1.7	3 /	Stages	310°F	-40 to 150 F		
	TC-4223	190 to 350°F		741110100				2 to 10°F	400°F			
					Indoor	Outdoor	5-12-8	Per Stage Fixed	Total of indoor			
Two Stage Dual Bulb	TC-4251	70 to 120°F	1:1-1/2	30' Each Bulb	30' 3/8 × 5-1/2" 3/8 × 4" 3°F Stages tempera must not	3°F Between Stages	and outdoor temperatures must not exceed 280°F	-40 to 150°F				
	TC-4252		1:1		3/8×4"	3/8 × 4"	1.57	2 to 10°F				
Two Stage Air Bulb	TC-4266	50 to 90°F		None		biled 2 × 2"	3°F	Per Stage Fixed 2°F Between Stage Adj. 1 to 5°F	-40 to 145°F Safe Bulb Range	-40 to 150°F		

Ratio Selection Table

Outdoor Temperature	Ratto	Change in Water Temperature for Different Ratios as Outdoor Temperature Drops from 70°F to Design Temperature								
(°F)		Dial Set at 70°F	Dial Set at 80°F	Dial Set at 90°F	Dial Set at 100°F	Dial Set at 110°F	Dial Set at 120°F			
	1 to 1-1/2	70 to 220	80 to 230	90 to 240	100 to 250	110 to 260	120 to 270			
-30	1 to 1	70 to 170	80 to 180	90 to 190	100 to 200	110 to 210	120 to 220			
	1-1/2 to 1	70 to 137	80 to 147	90 to 157	100 to 167					
	1 to 1-1/2	70 to 205	80 to 215	90 to 225	100 to 235	110 to 245	120 to 255			
-20	1 to 1	70 to 160	80 to 170	90 to 180	100 to 190	110 to 200	120 to 210			
	1-1/2 to 1	70 to 130	80 to 140	90 to 150	100 to 160					
	1 to 1-1/2	70 to 190	80 to 200	90 to 210	100 to 220	110 to 230	120 to 240			
-10	1 to 1	70 to 150	80 to 160	90 to 170	100 to 180	110 to 190	120 to 200			
	1-1/2 to 1	70 to 123	80 to 133	90 to 143	100 to 153	_				
	1 to 1-1/2	70 to 175	80 to 185	90 to 195	100 to 205	110 to 215	120 to 225			
0	1 to 1	70 to 140	80 to 150	90 to 160	100 to 170	110 to 180	120 to 190			
	1-1/2 to 1	70 to 117	80 to 127	90 to 137	100 to 147	_				
	1 10 1-1/2	70 to 160	80 to 170	90 to 180	100 to 190	110 to 200	120 to 210			
+10	1 to 1	70 to 130	80 to 140	90 to 150	100 to 160	110 to 170	120 to 180			
	1-1/2 to 1	70 to 110	80 to 120	90 to 130	100 to 140	-				
and the state of the state of	1 to 1-1/2	70 to 145	80 to 155	90 to 165	100 to 175	110 to 185	120 to 195			
+20	1 to 1	70 to 120	80 to 130	90 to 140	100 to 150	110 to 160	120 to 170			
	1-1/2 to 1	70 to 103.	80 to 113	90 to 123	100 to 133	-	-			
	1 to 1-1/2	70 to 130	80 to 140	90 to 150	100 to 160	110 to 170	120 to 180			
+30	1 to 1	70 to 110	80 to 120	90 10 130	100 to 140	110 to 150	120 to 160			
	1-1/2 to 1	70 to 97	80 to 107	90 to 117	100 to 127	-	-			

^{*}TC-4115 for System 8000 and dry circuit switching. Electrical Rating: 1.0 amp at 24 Vac: .25 amp at 24 Vdc.
*TC-4151 and TC-4251 — For 1-1/2:1 ratio reverse bulbs and use extra dial supplied with unit.
†First number of reset ratio typically indicates outdoor air temperature change required to increase the setpoint by the second number.

Dual Bulb Selection

On the dual bulb units, indoor and outdoor bulbs are determined by the ratio selected. See Performance and Selection Table. Ratio refers to the outdoor air temperature change compared to the water temperature change. The dial setpoint is the water temperature setpoint when the outdoor temperature is 70°F.

To select ratio it is necessary to know only: (1) outdoor design temperature, (2) maximum water temperature at outdoor design temperature, and (3) desired water temperature at 70°F outdoors. Use the Ratio Selection Table to determine the required ratio based on this information and set the dial per item (3). NOTE If a 1-1/2:1 ratio is selected, the extra dial supplied with the unit must be used.

Options

Single bulb units are available with optional capillary lengths of 20' or 45'.


Accessories: (Order Separately)

Part No.		Description				
AT-201* AT-203* AT-206	Bulb Well	Copper, 3/4" MNPT 9-1/2" Stainless, 3/4" MNPT 9-1/2" Copper, 1/2" MNPT 4-1/2"				
AT-208	Duct Mounting Kit for Bulb					
AT-209	A Bulb Well	or Tank, Bulb Mounting Kit. is recommended vith AT-201 or AT-203.)				
AT-210	includes pla	Adjustment Kit. ate to conceal setpoint and lock cover screw.				
AT-211	Outside Bulb Shield					

^{*}Requires AT-209 Bulb Mounting Kif

Example: Select ratio for an installation with a -10°F design temperature and estimated supply water temperatures of 75°F at 70°F outdoors and 125°F at -10°F outdoors. From Ratio Selection Table, -10°F for 1-1/2:1 ratio, note by interpolation (70°F to 123°F with dial at 70°F, 80°F to 133°F with dial at 80°F) that water temperature varies from 75°F to 128°F as outdoor temperature drops from 70°F to -10°F.

For this application, the 1-1/2:1 ratio should be selected. The extra dial supplied with the unit would be used, and the dial set at 75°F.






Bulb Duct Mounting Kit AT-208





Liquid Line or Tank
Bulb Mounting Kit
AT-209
(Also Required with
AT-201 or AT-203 Well)



Pre-Installation

Refer to the INSTALLATION and Performance Data applicable to the part number of the device being installed. Make a visual inspection of the device for obvious signs of damage Avoid locations where excessive moisture, corrosive fumes, vibration or high ambient exists.

Installation

Location

Locate the decide allowing proper distance to the bulb location. The case can be mounted in any position. Refer to Figure 1 for case dimensions.

Procedure

Remote Bulb Mageis

Air Bulb Mode . - Mounting in Return Air Duct

- Remove outer and provide 2 holes for #10 round head screws using the housing as the template or by using the dimensions shown in Figure 1.
- Partially insertine mounting screws in the screw holes. Fit the housing four the screws, slide housing down on the screws and content the screws.




Figure 1. Case Dimensions

esign 75°F Ratio lation lial at °F as

I. The

1166 1266 nly ole in

" H for

1" 1-9/16"

Air Bulb Models

Mounting Outside of Return Air Duct

- Prepare duct for mounting by cutting hole and providing mounting screw holes per Figure 1.
- 2. Fabricate a cover as shown in Figure 2.
- Carefully roll bulbs toward back of unit and insert through 2-1/4" x 2-1/2" hole.
- Remove cover and attach unit to duct with #10 screws.
- Attach cover over 2-1/4" × 2-1/2" hole.

Remote Bulb Mounting — Duct and Outdoor

Maximum insertion length (6 inches). Maximum safe bulb temperature above scale range. For dual bulbs, total of indoor and outdoor bulb temperatures must not exceed (280°F).

Duct: Install bulb with AT-208 kit as shown in Figure 3.




Figure 2. Field Supplied Duct Hole Cover Plate




Figure 3. Duct Mounting with AT-208

Outdoor: Install with AT-211 kit as shown in Figure 4

- 1. Mount bulb to outside wall or surface with bulb clip.
- 2. Place shield over bulb and fasten to mounting surface




Figure 4. Outdoor Mounting with AT-211

Bulb Mounting — Liquid Line and Tank Straight Pipe Mounting FLOW NOTE: Angle Must Not Allow End of Well to Contact Side of Pipe

Installation Hardware and Application Limitations

Part		Mtg.	Insertion	Applications at 250 °F FI		Installation Per Figure	
No.	Description	Fitting	Size .	Max. Recommended Velocity (FPS)	Max. Recommended Static Press. (PSIG)		
AT-201	Copper Bulb Well**	3/4"	1/2" Dia. O.D.	11	250	5	
AT-203	Stainless Steel Bulb Well**	MNPT	9-1/2" Long	20	500		
AT-206	Copper Bulb Well	1/2" MNPT	1/2" Dia. O.D. 4-1/2" Long	11	250	5A	
AT-209†	Bulb Mounting Kit	3/4" MNPT	Length of Bulb	4	150	5	

^{*}Max. Recommended Fluid Temperature is 350°F

^{**}Requires AT-209

[†]Recommended Installation is with a Bulb Well




Figure 5. AT-201 or AT-203 Installation

Install bulb well or adaptor from AT-209 into 3/4" FNPT opening. Place packing nut, washers, and packing from AT-209 over bulb support section and insert bulb into well or AT-209 adaptor. Push interlocking washers and packing into well or adaptor and tighten packing nut until firmly seated.




Figure 5A. AT-206 Installation

Install AT-206 bulb well into 1/2" FNPT opening. Place packing (included with AT-206) over bulb support section and insert bulb into well. Push packing into nut on well using a screwdriver

Concealed Setpoint and Lock Cover Screw

Order AT-210 Concealed Adjustment Kit separately

- Peel off adhesive film from the concealed adjustment plate and place into the recess of cover.
- Remove screw from cover
- Install lock cover screw provided with AT-210. 3.

Wiring

The thermostat has one 1/2-inch to 3/4-inch conduit opening in bottom of housing. Make all electrical connections in accordance with the job wiring diagram and in compliance with national and local electrical codes. Terminal coding and switch action is shown in Figure 6, and Figure 7 shows two stage switching sequence




Figure 6. Terminal Coding and Switch Action





Figure 7. Two Stage Switch Sequence

Typical Applications


Figure 8 shows a typical heating or cooling application for single stage units. Figure 9 shows typical heating and cooling applications for two stage units.



N.C Cooling Valve Brn COOLING APPLICATION WIRING

NOTE. Some compressor unloaders must be de-

+ Loads N C Heating Valve or Contactors for Electric Heat STAGE Red First Stage (HI) Brn Second Stage (LO) Load Switch Terminals Add Jump



Two Compressor Packages May Be Sequenced With The Wiring Show

Checkout

After installing a thermostat, make an initial check of the switching action. Verify the switch action by listening to the switch contacts.

- Turn the setpoint dial to a temperature above ambient.
 This should cause the thermostat to switch, making orange to brown.
- Turn the setpoint dial setting down gradually. Orange to brown must break, making orange to red.
- Compare the differential of the device to the differential shown on the performance charts by turning the dial. The differential of the devices is the difference in dial reading between the make of orange to brown and the make of orange to red on single switch units.

Run/Adjust

Setpoint

Screwdriver adjustment. Scales dual marked °F on front and °C on back. To change scale, remove spring retaining ring, select scale and replace retaining ring.

Differential Adjustment

The differential is adjustable by turning the adjustor located on side of device (see Figure 10).

Single stage: Each line represents approximately 3°F change.



Calibration Nut (Turn with 1/2" open end wrench)

Differential Adjustment

Figure 10

Two stage: Each notch represents approximately 2°F change between stages. (Differential per switch is fixed)...

To adjust differential

- Disconnect power to unit.
- 2. Remove cover.
- 3. Turn adjustor to approximately desired position.
- Check out by turning dial and noting dial readings where switch contacts make.
- After changing differential, recalibrate. See Service and Repair.

Service and Repair

Calibration

- With all power disconnected, soak bulb(s) for 10 minutes at known temperature (must be 70°F for dual bulb).
- Turn dial and note where switch contacts make.
- 3. Turn dial midway between click points.
- Turn the calibration nut (located under dial) until the temperature of the bulb is indicated on the dial. (See Figure 10.)

NOTE .

On two-stage units follow above procedure. "LO" switch is first stage on cooling applications. "HI" switch is first stage on heating applications.

Repair

Field repair is not recommended. Replace defective device.

Barber-Colman Company ENVIRONMENTAL CONTROLS DIVISION

1354 Clifford Avenue P.O. Box 2940 Loves Park, IL U.S.A. 61132-2940

F-18895-1 BK



General Instructions

75- J, 75- Z
Solid State Sensing
Temperature and Humidity
Series TS-8000 and HS-8000


Temperature Sensing

GENERAL INFORMATION

Sensing is accomplished by the use of a temperature sensitive Balco resistance wire packaged in the form of room, duct, averaging and outdoor type configurations. The design of the entire system is around a $1000~\Omega$ sensing element at $70^{\circ}F$.


WIRING

Make all electrical connections to the element in accordance with the installation and wiring diagram for the job. Comply with national and local electrical codes. Do not use the element box as a junction box for other control circuits. It is generally advisable to use flexible conduit for connecting box to rigid conduit. Restrict element leads to shortest length practical. Barber-Colman twisted cable or factory approved cable should be used.



Average — TS-8400 Series

Part No.	Use	Location	Mounting	Terminal Code Wiring
TS-8101	Room Sensor w/o Setpoint	Wall	Mounting Screw Cover	①) Output
TS-8111	Room Sensor w/Setpoint	Wall	Printed Screw Circuit Mounting Board Screw	① } Terminals
TS-8201	Duct Immersion 7" Immersion Length	Duct or Well AT-215 3/4" NPT	AT-215 Thermowell Immersion Temperature	
TS-8201 -106	Immersion 4" Insertion Length	Well AT-225 1/2" NPT	3 -7	Pigtails: Black Black (C) Controlling
TS-8331	Lagged Sensor	Duct	(2) 1/8" Dia. Holes	Black (L)* Controlling Found only on the TS-8331
TS-8405	5' Average	Duct		
TS-8422	22' Average	Duct	Duct Mounting Dimensions	
TS-8241	Diffuser	Ceiling	Mount on Face of Ceiling Diffuser. See Instructions for B-C Models PB, PS or SFS, SFB. Pg. 2	Pigtails: Black Black
TS-8261	Light Fixture	Light Fixture	Mount in Return Grill of Light Fixture	Pigtails: Black Black
TS-8501	Outdoor Air	Outside of Building		Pigtails: Black Controlling
TS-8531	Solar	Outside of Building	Use Conduit Connectors	Orange Element Orange (Solar)
TS-8533	Econostat	Outside of Building		Red Heater Red (Econostat)





General Instructions

Solid State Sensing Temperature and Humidity Series TS-8000 and HS-8000


Temperature Sensing

GENERAL INFORMATION

Sensing is accomplished by the use of a temperature sensitive Balco resistance wire packaged in the form of room, duct, averaging and outdoor type configurations. The design of the entire system is around a $1000~\Omega$ sensing element at $70^{\circ}F$.

WIRING

Make all electrical connections to the element in accordance with the installation and wiring diagram for the job. Comply with national and local electrical codes. Do not use the element box as a junction box for other control circuits. It is generally advisable to use flexible conduit for connecting box to rigid conduit. Restrict element leads to shortest length practical. Barber-Colman twisted cable or factory approved cable should be used.



Part No.	Use	Location	Mounting	Terminal Code Wiring
TS-8101	Room Sensor w/o Setpoint	Wall	Mounting Screw Cover	①) Output
TS-8111	Room Sensor w/Setpoint	Wall	Printed Screw Circuit Mounting Board Screw	
TS-8201	Duct Immersion 7" Immersion Length	Duct or Well AT-215 3/4" NPT	AT-215 Thermowell Immersion Temperature	Pigtails:
TS-8201 -106	Immersion 4" Insertion Length	Well AT-225 1/2" NPT	2	Black Black (C) Controlling
TS-8331	Lagged Sensor	Duct	(2) 1/8" Dia 1" Dia. Holes	Black (L)* Controlling *Found only on the TS-8331
TS-8405	5' Average	Duct	- -	
TS-8422	22' Average	Duct	Duct Mounting Dimensions	
TS-8241	Diffuser	Ceiling	Mount on Face of Ceiling Diffuser. See Instructions for B-C Models PB, PS or SFS, SFB. Pg. 2	Pigtails: Black Black
TS-8261	Light Fixture	Light Fixture	Mount in Return Grill of Light Fixture	Pigtails: Black Black
TS-8501	Outdoor Air	Outside of Building		Pigtails: Black Controlling
TS-8531	Solar	Outside of Building	Use Conduit Connectors	Orange } Element (Solar)
TS-8533	Econostat	Outside of Building		Red } Heater (Econostat)

Solid State Humidity Sensing

Sensing is accomplished by the use of a nonorganic resistance type material which will be housed either in a room or duct type mounting base. Selection of the proper AH-100 series element will provide the capability of control over a 15% range. Elements are available through the span of 5% to 95% R.H.

The average resistance of each element at midrange is approximately 22,000 ohms; except the violet element, which is 50,000 ohms. A resistor of appropriate value may be substituted in the bridge circuit to verify the element resistance.

CAUTION

Do not measure resistance of element with an ohmmeter, as DC voltage across the element will cause polarization and a new element will be required. Basic element is not repairable. Order a replacement from the factory or local branch office.

CARE OF ELEMENT

The elements are wrapped with a moisture pervious cellophane, which actually is an air filter. On installations using duct elements, where air velocities are reasonably high **de not remove cellophane**. Always install element with wrapping so that perforations in cellophane are on downstream side of air currents. Punch more holes (only in gownstream side of cellophane) to increase element constitution.




TABLE 1.

*	Sensing Element Color	Relative Humidity Range
	Violet	85% to 95%
18	Blue	70% to 85%
	Green	* 50% to 70%
	Yellow	40% to 55%
251.00	Orange	30% to 45%
	Brown	10% to 30%
	*	Element Color Violet Blue Green Yellow Orange

WIRING


Make all electrical connections to the device in accordance with the installation wiring diagram for the job. Comply with national and local electrical codes. Restrict element leads to shortest length practical, using three conductor twisted cable, 18 gauge minimum.

CAUTION

Power wiring must never be installed in the same conduit

LOCATION


Locate the sensing element where it will be exposed to unrestricted natural air circulation and to the average conditions of the controlled space. Do not locate it near extreme sources of heat, cold, or moisture.



Duct — HS-8200 Series

Room — HS-8100 Series






CALIBRATION

- Place DC-VOM on output of CP-8102 controller, OP1 (+) and COM (-).
- 2. Read humidity at the sensor.
- 3. Place jumper on proper pin, per chart below
- 4. Adjust the controller (CAL A) to 7.5 Vdc output.
- Refer to CP-8102 literature if further details are required.

GENERAL INFORMATION



MOUNTING OF DIFFUSER SENSOR TS-8241

Sensor should be mounted to the face of the ceiling diffuser so that it projects downward into the room. See Figure 1. If the diffuser has an adjustable pattern, the discharge air direction must be adjusted to a horizontal pattern. This will insure a representative sample of room air over the element (Figure 2). The transmitter will not perform satisfactorily if the discharge is adjusted to a vertical pattern.



Figure 1.
Sensor Mounted in Perforated Face Ceiling Diffuser
Model PB or PS





Figure 2.
Room Air Induced over Sensor by Discharged Air


A 7/16-inch hole is required in the diffuser face for mounting.

The SFS and SFB louver faced diffusers are available in nine air patterns, both in the square and rectangular design. For peoper installation, use Table 2 which shows sensor location and the mounting figure referred to in the installation procedure. APNS-107 must be ordered separately.

SENSOR MOUNTING PROCEDURE ON SFS AND SFB USING APNS-107 KIT

- 1. Drill a 5/16" hole for sensor leads.
 - a. Fig. 3. Locate hole center on an angled surface about 5/16" from an edge of the 1/2" square so as to avoid drill contact with the welded center plate mounting brackets.
 - b. Fig. 4. Locate the hole center on one louver about 5/16" from junction of two center back to back louvers.
 - c. Fig. 5. Locate hole center on an end louver about 1/2" from the junction of the louver and the mounting flange.
- 2. Bring field leads through the 5/16" hole. If required, remove the louver assembly from the mounting flange.
- Center the APNS-107 bracket over the 5/16" hole (use as a template) and drill 1/8" holes for the mounting screws.
 - Fig. 3. Drill two holes near edges of square center plate.
 - Fig. 4. Drill two holes, one each on bottom edge of back to back louvers.
 - c. Fig. 5. Drill one hole on end louver.
- Assemble the sensor to APNS-107 bracket as shown in Figs. 3, 4, and 5.
 - Fig. 5. Cut off one side of APNS-107 as shown.
- Make field connections to sensor leads and push leads up through the 5/16" hole.
 - Wrap friction or electrical tape around the leads and fill the 5/16" hole, preventing direct primary air passage over the sensor.
- Attach APNS-107 as shown in Figs. 3, 4, and 5 using #6 screws
 - Fig. 5. Cover the crack between the end louver and mounting flange at least 12" on each side of the sensor. A 24" length of 3 / 4" tape stuck to mounting flange can be used.
- 7. The sensor installation is complete.









TABLE 2. SENSOR LOCATION AND FIGURE SHOWING MOUNTING DETAILS

	1		SEN	ISOR L	OCA	TION		
Air Pattern		ter of user	Side	ter of with Air	Opp	rner oosite Air row	Opp	nd oosite Air row
	Sq.	Rect.	Sq.	Rect.	Sq.	Rect.	Sq.	Rect.
0	Fig. 3	Fig. 4						
2			Fi	g. 4				4
3							Fig.	4
4	Fig	9. 4	# 1 # 16 0 10 m					
5	1				1		14.0	
6	-	190		- 1	Fig. 2	Fig E		
7					rig. 3	Fig. 5		
8				/			C:	g. 5
9				35- 85				y. 5

TS-8241 must not be located nearer than 18" from a wall or corner of a room when used on air patterns 2, 6, 7, 8, or 9. This allows space for induced air to pass over TS-8241.

AIR PATTERNS (As Viewed from Diffuser Face)

Number is air pattern designation when ordering.



	in i		Fr #4	Temperatu	re Sensors	-	Humidity	Sensors
da .	Spe	cifications	Room & Light Fixture Diffuser*	Duct/ Immersion	Averaging	Selective Ratio Discharge	ordered s Refer to Se	
		er.	Dinuser				Room	Duct
		Size**	4%×2%×1%	4%×3½×9%	4% × 3½ × +	4%×3½×9%	4%×2%×1%	4%×3½×9½
		Mounting	Wall	quet/ Immersion	Duct	Duct	Wall	Duct
Pac	kage	Mounting Position	Vertical *	Vertical	Vertical	Vertical	Vertical	Vertical
ja v	İ	Connection	Terminals	Pigtails	Pigtails	Terminals	Pigtails	Pigtails
roug #	-	Ambient Temp. Limits	-40 to 250°	-40 to 250°	-40 to 250°	-40 to 250°	35 to 135°	35 to 135°
V. Trans		Resistance	1000 Ω	-,1000 Ω	1000 Ω	1000 Ω		
Se	nsor	Sensitivity	2:2 Ω/°F	2.2Ω/°F	2.2 Ω/°F	2.2 Ω/°F		
		Length		* 6"	5' or 22'	6"		6"
		Control Range						
	7.7	Impedance					Euse S.	
Input		Setpoint Range	55 to 85°				Up to 20% R.H.	Up to 20% R.H.
		Calibration Range				*	±5%	±5%
	Adjust	Throttling Range						-
		Ratio				5 to 20/1		
16	10.	Impedance						
-014	Voltage	Range		-		47.72.53		
		Reference	me al resultation			Negative	Negative	Negative
Output		Voltage			1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1			
V	Power	Current			Geldi, - 49			
		Regulation						
	-	Voltage				-12 12 12 12 15 1		
L	ad	Current						
-		Voltage				6.2 Vdc ±.4	24Vac±10%	24Vac±10%
100	wer	Current		Territoria di		1 mA	25 mA	25 mA

Barber-Colman Company ENVIRONMENTAL CONTROLS DIVISION

1354 Clifford Avenue P.O. Box 2940 Loves Park, IL U.S.A. 61132-2940 Para. 2.2.2.9



CP-8102 Electronic Two Input Temperature or Humidity Controller



General Instructions


FUNCTIONS

Electronic controller receives temperature or humidity sensor inputs and sends a variable electronic signal, 1 to 15 Vdc, to up to six System 8000® actuators or relays (controlled devices). Additional devices can be controlled with the use of adapters. These actuators or relays operate heating, cooling, humidification or dehumidification equipment in HVAC systems.

FEATURES AND BENEFITS

The reliable, easy to install CP-8102 electronic controller incorporates an amplifier with inputs for 1000ohm Balco® temperature sensors, humidity sensors or remote setpoint adjustor. Two setpoint dials, ratio authority dials, throttling range dials and calibration potentiometers are visable and accessible without removing controller cover allow for easy field adjustment. Coded screw terminals make sensor, remote setpoint, power supply and output signal wiring easy to install and change. The CP-8102 controller is used with other System 8000 devices.

Table 1. Specifications



CP-8102

Wiring Connections: Coded screw terminals for all control inputs and outputs.

Safe Ambient Temperature Limits:

Operation: 40 to 135°F (4.4 to 57°C) Storage: -40 to 160°F (-40 to 71°C)

Dimensions: 4" (102 mm) high × 11" (279 mm) wide × 2-1/2" (64 mm) deep

Part Number	Control Dial Range Setpoint "A"	Control Dial Range Setpoint "B"	Throttling Range for 3 Vdc Output Change	Authority Ratio Adjustment Setpoint "A" Setpoint "B"	Control Output Voltage†	Power Required	Power Supply Available
CP-8102	20 to 120°F	20 to 120°F	Adjustable 2 to 10°F by Dial*	.5:1 to 25:1 Adjustable	1 to 15 Vdc 10 mA Max.	20 Vdc	6.2 Vdc
CP-8102-116	-6 to 48°C	-6 to 48°C	Adjustable 1 to 6°C by Dial*	by Dial	Factory Set for D.A.	23 mA	7 mA Max.

See	ADJUSTMENTS for	additional	throttling ranges.
	/ IDOOO ! III.E ! I ! O ! O!	additional	unouning ranges.

† Units factory calibrated for 7.5 Vdc output with sensor at setpoint temperature.

Options: None.

AT-8155

AT-8158

ACCESSORIES	
AD-8122	Signal adaptor for dual outputs (two direct acting)
AD-8123	Signal adaptor for dual outputs (one direct, one reverse acting)
AD-8124	Signal adaptor for dual outputs (one reverse, one direct acting)
AD-8912	12" enclosure
AD-8969-201	Off set resistor kit: 5, 10, 15 & 20°F
AD-8969-901	Extended throttling range jumper
ASP-301	Power supply required for HSP-6X81 humidity transmitter
ASP-581	Indication meter 20 to 80% RH
AT-8122	Remote setpoint adjuster, dual scale 20 to 120°F (-6 to 49°C)

	85°F (13 to 29°C)
AT-8222-101	Setpoint scale for humidity 20% to 100%
AT-8435	Remote setpoint adjuster, dual scale 50 to 450°F (10 to 232°C) for use with TS-8204 only
CN-8101	Multi nurnose bridge

250°F (10 to 121°C)

Remote setpoint adjuster, dual scale 50 to

Remote setpoint adjuster, dual scale 55 to

CIN-8101	Multi-purpose bridge
HS-8101	Room humidity sensor
HS-8201	Duct humidity sensor
TS-8101	Room sensor

LITHO IN U.S.A. 9-84

TS-8111	Room sensor with setpoint
TS-8131	Room button type sensor
TS-8201	Duct/immersion sensor
TS-8204	High temp. duct/immersion sensor requires AT-8435 remote setpoint for all applications except differential control
TS-8241	Diffuser sensor
TS-8261	Light fixture sensor
TS-8331	Lagged sensor (CN-8101 is required)
TS-8405	5' averaging sensor
TS-8422	22' averaging sensor
TS-8501	Outdoor sensor
TS-8531	Solar sensor (CN-8101 is required)
TS-8533	Econostat sensor
Tool-201	Calibration kit for system 8000

DEFINITIONS

Mode of Operation: Either direct-acting or reverse-acting.

Direct-acting (D.A.) means that an increase in temperature at the sensor(s) causes the voltage output (OP1) to increase.

Reverse-acting (R.A.) means that an increase in temperature at the sensor(s) causes the voltage output (OP1) to decrease.

Reset Control Action: The direction of reset determines whether input A setpoint is reset upward or downward on a temperature decrease at input B.

Direct reset: (D.R.) A temperature decrease on input B resets input A setpoint downward.

Reverse reset: (R.R.) A temperature decrease on input B resets input A setpoint upward.




Figure 1. CP-8102

CONTROL TERMINAL INPUTS (See Figure 1)

ISA: Any TS-8000 Temperature Sensor (1000 ohm Balco)

ISB: Any TS-8000 Temperature Sensor (1000 ohm Balco)

AB1, AB2, AB3: Auxiliary inputs; any remote setpoint adjuster AT-8000 series, HS-8X01 humidity sensor, CN-8101 multipurpose bridge

CONTROL TERMINAL OUTPUT (See Figure 1)

OP1: 1 to 15 Vdc (10 mA maximum). Units factory calibration for 7.5 Vdc output with sensor at setpoint temperature.

ADJUSTMENTS: (See figure 1)

Temperature Setpoint "A": By dial 20 to 120°F (-6 to 48°C), or by remote setpoint adjuster (See Accessories).

Temperature Setpoint "B": By dial 20 to 120°F (-6 to 48°C), or by remote setpoint adjuster (See Accessories).

Setpoint "A" Calibration: By potentiometer.

Setpoint "B" Calibration: By potentiometer. For reset control, set Setpoint "B" at value where Setopint "A" will be reset. Adjust Setpoint "A" at control point required with no reset from sensor "B".

THOTTLING RANGE: By dial 2 to 10°F, 1 to 6°C. By pin selection 15, 25, 40 and 60°F (8, 14, 22, 33°C). Remove J9 jumper from JC9 and attach to required throttling range pin. By extended throttling range adjuster, AD8969-901 (order separately), 55, 65, 75, 85, 100, 115, 125 and 140°F (31, 36, 42, 47, 56, 64, 69 and 78°C). The throttling range is the sum of the T.R. pins connected.

AUTHORITY RATIO

ADJUSTMENT: By dial .5 to 25:1. Ratio is the number of degrees change at Sensor "B" required to reset Setpoint "A" one (1) degree. Example: 25:1 means a 25°F (14°C) change at Sensor "B" will reset Setpoint "A" 1°F (.5°C).

Table 2


Controller Function	Jumper Connections Required			
	Bridge "A"	Bridge "B"		
Direct Acting*	J4 to JC6 J3 to JC5	J5 to JC5 J6 to JC6		
Reverse Acting	J4 to JC5 J3 to JC6	J5 to JC6 J6 to JC5		
Internal Setpoint Active*	J1 to JC1	J2 to JC3		
Internal Setpoint Inactive for Remote Setpoint	J1 to JC2	J2 to JC4		
Disable Bridge "B" for Single Sensor Input		Jumper 2 to AB3		

^{*} As supplied from factory.

To Obtain Reverse Reset: Both bridges should have the same action. Example: both direct acting, or both reverse acting.

To Obtain Direct Reset: Bridges should have different action. Example: one direct and one reverse acting.

Disable "A" Bridge Setpoint Disconnect Jumper J1 from JC1 Pin and reconnect to JC2 Pin.



Disable 'B" Bridge Setpoint if "B" Bridge is to be used. Disconect Jumper J2 from JC3 Pin and reconnect to JC4 Pin.

Figure 2. Disabling Setpoint "A" and/or Setpoint "B"




Figure 3. CP-8102 Controller Block Diagram

PRE-INSTALLATION: Open the carton and visually inspect the device for part number and obvious defects before proceeding with the installation.

NOTE .

Mounting screws are not provided.

INSTALLATION: Device may be mounted, in any position, in an inside location near the controlled equipment using the two slots in the track. AD-8912 enclosures can be ordered separately for remote installations.

CAUTION .

Avoid locations where excessive vibration, moisture, corrosive fumes or vapors are present, or where high radio frequency or electro-magnetic interference generating devices are near.

See Figure 4 for mounting dimensions.




Figure 4. Mounting Dimensions

GENERAL WIRING INFORMATION

Make all connections according to job wiring diagrams and in compliance with national and local codes.

Two separate No. 18 twisted pair wires (six turns per foot 1.3ml).

Class II, low voltage, are suitable for up to 1000 feet (300 m) for the sensor leads. See table 3 for longer runs.

Never run line voltage in the same conduit with unshielded sensing element leads. Use copper conductors only.

Shielded cable (Belden No. 8422 or equivalent) must be used when it is necessary to install the DC signal leads in the same conduit with power wiring, or when it is known that high RFI/EMI generating devices are near. Ground the shield at the controller only on the COM (-) terminal.

Table 3. Wiring Lengths

			LEN	IGTH OF RUN IN F	EET**		
Wire Gauge	"HS" Sensor To CP-8102	"TS" Sensor To CP-8102	CN-8101, AT-81X4 TS-8601 To CP-8102	"HSP" Transmitter To CP-8102	TSP-8101 To CP-8102	CP-8102 To Controlled Device	CP-8102 To Adaptor
22	125	_	_	_	Should be	_	_
18	300	1,000	1,000	250	in Same	1,000	1,000
16	_	2,250	_	_	Panel as	2,250	2,250
14		4,000	_	_	Controller	4,000	4,000

^{*} AD-8101, AD-812X, AD-8201, AD-8301, AD-8501

GENERAL RULES FOR WIRING CP-8102 TO CONTROLLED DEVICE(S)

- Never connect red lead (or +20 terminal) of any controlled device which has a regulated power supply to the red lead (or +20 terminal) of any other controlled device (see Figure 5).
- Controlled devices (MP-52XX) with unfiltered and unregulated power supplies must be filtered. CP-8102 will provide filtering for a maximum of two MP-52XX by connecting the two red leads together at the controller's +20 terminal (see Figure 6).
- Controlled devices with filtered and unregulated supplies: Up to six controlled devices with the red leads (+20 terminals) can be connected together. Number of units paralleled depends on the current (mADC) requirements of the controller or adaptor.

Table 4. Controlled Device Power Supply Characteristics

Filtered & Regulated	Filtered & Unregulated	Unfiltered & Unregulated
CC-8101 CC-8102 CC-8103 CC-8111 Series CC-8118 Series CC-8218 Series CP-8161 Series CP-8301 Series CP-8425 Series CP-8501 Series CP-8502 Series	MP-54XX MS-8XXX Actuators	MP-52XX Actuators

^{*} Except CP-8301-101 which does not have a power supply.




Figure 5. Controlled Devices All Filtered

FIELD CHECKOUT

Units are factory calibrated and tested and should not require field checkout. If required, proceed as follows (see Figure 1):

The following procedures can be used for either reverse or direct acting connected CP-8102 controllers.

- Initial Conditions for CP-8102
 - A. Jumper between AB2 and AB3 disconnected.
 - B. 20 Vdc +1 1.5 Vdc (23 mA) applied to the +20 and common terminals. This power is normally supplied by the controlled device.
- Connect a 20,000 ohm/volt DC VOM meter between the OP1 (+) terminal and COM (-) terminal of the CP-8102. Use a 20 Vdc or less range.
- Disconnect the temperature sensing element "A" from the ISA terminals of the CP-8102. Short ISA terminals together and VOM reading should be 1 Vdc or less if bridge "A" is direct acting and more than 15 Vdc if bridge A is reverse acting.
- Open ISA terminals and VOM reading should be greater than 15 Vdc if bridge "A" is direct acting and less than 1 Vdc if bridge "A" is reverse acting.
- 5. The CP-8102 is a good unit if it passes tests in steps 3 and 4. Replace the unit if tests 3 and 4 are not met.




Figure 6. At Least One of the Controlled Devices in MP-52XX (Unfiltered)

^{**1} Ft. approx. .3 meter

FIELD CALIBRATION PROCEDURES FOR CONTROLLERS WITH ONE AND TWO INPUTS

(See Figures 7 and 9):

The following procedures can be used for either reverse or direct acting connected CP-8102 controllers.

The CP-8102 is factory calibrated and shipped with both inputs connected for direct acting output.

Normally, the CP-8102 (connected for either direct or reverse acting) requires no field calibration but if a field calibration check or recalibration becomes necessary, then proceed as follows:

- 1. Initial Conditions for CP-8102:
 - A. Setpoint "A" set for: 70°F.
 - B. Setpoint "B" set for: 70°F.
 - C. Ratio adjustment set for: 1:1.
 - D. Throttling range adjustment set for: 3°F.
 - E. Jumper between AB2 and AB3 disconnected.
 - F. 20 Vdc (23 mA) applied to the +20 and common terminals. This power is normally supplied by the controlled device.
- Connect a 20,000 ohm/volt DC VOM meter between the OP1 (+) terminal and COM (-) terminal of the CP-8102.
 Use a 20 Vdc or less range.
- Calibration of "A" input. Use one of the following two methods.
 - A. Temperature measurement methods:

Accurately measure the temperature at the temperature sensing element "A". Adjust setpoint "A" until the dial reading agrees with the temperature measured. Rotate setpoint "A" calibration potentiometer (located just to the right of setpoint "A" dial) until a VOM reading of 7.5±.2 Vdc is obtained.

B. Sensing element substitution method:

Disconnect the temperature sensing element "A" from the ISA terminals of the CP-8102. Reconnect a 1000 ohm ±.1% wire wound resistor (TOOL-203) to the ISA terminals. Adjust setpoint "A" for 70°F. Rotate setpoint "A" calibration potentiometer (located just to the right of setpoint "A" dial) until a VOM reading of 7.5±.2 Vdc is obtained.

NOTE

Method B above does not calibrate out any errors due to sensing element tolerances or wire lead resistance.

- 4. Calibration of "A" input complete
 - If "B" input is not being used (jumper between AB2 and AB3 removed) then proceed to step 7 below
- 5. Reconnect jumper between AB2 and AB3.
- Calibration of "B" input. Use one of the following two methods.
 - A. Temperature measurement method

Accurately measure the temperature at the temperature sensing element "B". Adjust setpoint "B" until the dial reading agrees with the temperature measured. Rotate setpoint "B" calibration potentiometer (located just to the right of setpoint "B" dial) until a VOM reading of 7.5±.2 Vdc is obtained.

B. Sensing element substitution method:

Disconnect the temperature sensing element "B" from ISB terminals of the CP-8102. Reconnect a 1000 ohm ±.1%, wire wound resistor (TOOL-203) to the ISB terminals. Adjust setpoint "B" for 70°F. Rotate setpoint "B" calibration potentiometer (located just to the right of setpoint "A" dial) until a VOM reading of 7.5±.2 Vdc is obtained.

NOTE .

Method B above does not calibrate out any errors due to sensing element tolerances or wire lead resistance.

 CP-8102 calibration is complete. Remove all test meters, test resistor, etc. Reconnect all elements, place setpoints, throttling range and ratio adjustments as required for the application.




Figure 7. One or Two sensor Application

FIELD SERVICE

Units are factory calibrated and tested for direct acting control (D.A.) and reverse reset (R.R.) and should not require service. If required, proceed as follows (see Figure 8):

Power Supply

Apply ± 20 ; ± 1 , ± 1.5 Vdc (23 mA) to the ± 20 and common terminals. Proper power supply is always required for unit to function properly. The ± 6.2 ($\pm .3$) Vdc should be available from the controller, if required.

Test

Connect a 20,000 ohm/volt DC VOM meter between +20 and common terminals. Controller power supply +20, +1 -1.5 Vdc (indicated by M1 in Figure 8) should be measured. Power supply is normally supplied by controlled device. Check +6.2 (±.3) Vdc power supply of controller with VOM.

Service

If the +20 Vdc level is not measured, service the (lead) controlled device, power supply or installation wiring as necessary to insure proper power supply.

Controller Output

See Field Calibration Procedures on this page, for calibration of "A" setpoint using sensor element substitutes

Test

With signal output measured between OP1 and COM at $7.5 \pm .2$ Vdc, rotate setpoint "A" dial several degrees (in increments of 1°F) each way from 70° setting to vary the M2 reading from 1 to 15 Vdc. The number of degrees that setpoint dial "A" is changed to vary the reading on M2 3 Vdc should be approximately 3°F (if T.R. is set at 5°F, 3 Vdc will change over 5°F).

Service

See Field Calibration Procedures, on page 5, for calibration of "B" setpoint using sensor element substitutes. (Make certain that jumper is connected to AB2 and AB3.)

Adjusting setpoint "B" several degrees from 70°F setting will cause the M2 reading to vary from 1 to 15 Vdc.

If output voltage cannot be made to vary over a 1 to 15 Vdc range, then replace the CP-8102 as defective.




Figure 8.




Figure 9.

MAINTENANCE

This is a quality product. Regular maintenance of the total system is recommended to assure sustained optimum performance.

TYPICAL APPLICATIONS




Figure 10. One or Two Temperature Sensor Application

Hot water reset is typical application for a two sensor application of the CP-8102. For example, perimeter radiation temperature, with hot water as a heating medium, is increased as the temperature of the outside air decreases. This method of control is known as reverse reset. A reset schedule shown below in table requires the hot water temperature to increase from 100° to 170°F, a change of 60°F, as the outside air temperature decreases from 60° to 0°F. If the throttling range of the CP-8102 controller is 10°F the setting of the CP-8102 will be as follows:

Setpoint "A": 110° Setpoint "B": 60°

Ratio Adjustment: 1 (change in outside air temperature/

change in hot water temperature)

Throttling Range: 10°F

Note: Controller function is Direct Acting * (see table 2)

* Factory setting

Table 5. Reset Schedule

Outside Air Temp.	Water Temperature (°F)
60	110
0	170




Figure 11. Derivative (Lagged) Sensor




Figure 12. Three Temperature Sensor Application*





Figure 13. Solar and Outdoor Air Reset of Hot Water (Direct Acting Output)



NOTE: If the controller bridge is reverse acting, the red and blue wires at the AT-8XXX Series must be reversed (red to common, blue to +6.2).

Figure 14. Single Input with Remote Setpoint




Figure 15. Single Unit Winter-Summer Switching

- Cut both jumpers that are located between the terminal strip and cover on the left hand side of the device. (See Figure 15).
- Connect D.P.D.T. Switch (CYZP-11 or equivalent) according to Figure 15.

Switch contacts should have pilot duty ratings and main-
tain a 1 ohm or less contact rating over its normal life.

No recalibration of CP-8102 is required.

SINGLE UNIT SUMMER/WINTER SWITCHING (Continued):

Table 6. Bridge Connections for Summer/Winter (See Figure 15.)

			Service of the service of		JUMPER TO PIN CONNECTIONS				
BRIDGE "A" (MAIN SENSOR)		BRIDGE "B" (RESET SENSOR)		RESET OF SETPOINT "A"		J3	J4	J5	J6
Winter	Summer	Winter	Summer	Winter	Summer				
D.A.	R.A.	D	.A.	Reverse	Direct	JC5	JC6	COM	+6.2
R.A.	D.A.	D	.A.	Direct	Reverse	JC6	JC5	COM	+6.2
D.A.	R.A.	R	.A.	Direct	Reverse	JC5	JC6	+6.2	COM
R.A.	D.A.	R	.A.	Reverse	Direct	JC6	JC5	+6.2	COM
D).A.	D.A.	R.A.	Reverse	Direct	COM	+6.2	JC5	JC6
R.A. D.A		D.A.	R.A.	Direct	Reverse	+6.2	СОМ	JC5	JC6
D).A.	R.A.	D.A.	Direct	Reverse	COM	+6.2	JC6	JC5
F	I.A.	R.A.	D.A.	Reverse	Direct	+6.2	COM	JC6	JC5




Table 7. Typical Reset Schedule

Outside Air Temp. (°F)	Water Temperature(°F)
70°	110°
0.	140°
Above 70°	85°

Outside air temperature reset of supply water temperature with fixed temperature of 85°F with outside air temperature of 70°F.

Setpoint "A": 110°F


Setpoint "B": 70°F

Ratio Adjustment: 2.33

Throttling Range: 10°F

AT-8122: Set 45°F for S.P. of 85 where O.A. is above 70°F. Relay is energized with outside air temperature below 70°.

Figure 15. Outside Air Temperature Reset of Hot Water with Fixed Temperature with Outside Air Temperature Above Selected Value



Resistor (5, 10, 15, 20°F offset) use AD-8969-201 kit.

Offsetting setpoint for Direct Acting Controller:

Raise, connector resistor to +6.2 terminal.

Lower, connect resistor to COM terminal.

Offsetting setpoint for Reverse Acting Controller:

Raise, connect resistor to COM terminal.


Lower, connect resistor to +6.2 terminal.

NOTE _

Standard two conductor twisted wire should be used if remote switching is employed.

Resistor must always be located at stat.

Figure 16. Setpoint Offset




Install 1000 ohm 1% (TOOL-203) resistor in ISB. Install AE-178 7 day time clock. Set setpoint "B" as desired for night setback.

Table 8.

Setpoint "B"	Night Setback		
70°F (21.1°C)	No Setback		
65°F (18.3°C)	5°F (2.8°C) Setback		
60°F (15.6°C)	10°F (5.6°C)Setback		
55°F (12.8°C)	15°F (8.3°C) Setback		

Figure 17. Night Setback



Note: Settings of 2-6 throttling range result in 2-6% RH throttling range for 3 Vdc output change. 6 TR is maximum setting.

Figure 18. Humidity Control




Figure 19. Humidity Control & Indication

Barber-Colman Company ENVIRONMENTAL CONTROLS DIVISION

| 1354 Clifford Avenue | P.O. Box 2940 | Loves Park IL U.S.A 61132-2940