

# Interference: Defining the Source

## FCC Consumer Facts

### Background

Interference is any unwanted radio frequency signal that prevents you from watching television, listening to your radio/stereo or talking on your cordless telephone. Interference may prevent reception altogether, may cause only a temporary loss of a signal, or may affect the quality of the sound or picture produced by your equipment.

### Common Causes

Before you can resolve an interference problem you must isolate the actual interference source. Interference originates from many sources - the equipment itself, your residence or the neighborhood.

The two most common causes of interference are transmitters and electrical equipment. Communication systems that transmit signals (transmitters) are capable of generating interference; these include amateur radios, CBs and radio and television stations. Electrical interference may be caused by power lines or electrical equipment in your home.

### Transmitter Interference

Transmitter interference is normally caused by the actual design of the (interfered-with) equipment itself. Many manufacturers do not protect internal wiring with adequate shielding or sufficient filtering, so the interfered-with equipment is susceptible to receiving unwanted signals – interference.

The source may be as simple as a frayed wire that connects your speakers to an amplifier. A faulty wire can act as an antenna that will carry interfering signals. Check the incoming wire from your outside antenna for any damage or corrosion. Replace any twin-lead cable with a coaxial cable; a coaxial cable offers the best protection from all types of outside interference.

To determine whether the interference is coming from the equipment itself, unplug one component at a time on the equipment or on other equipment to see if you can isolate the source. Also, disconnect other electrical equipment (answering machines, telephones, fax machines, etc.) one by one. If the problem goes away when the device is disconnected, you have found the source – the device itself.

(More)



### Transmitter Interference (cont'd.)

If your equipment is reacting to transmitters such as an amateur radio or CB, you will have interference only when the radio operator is talking; you will be able to hear only half of the conversation. This type of interference is normally intermittent during specific times of the day. You will probably be able to verify your conclusion if you see an antenna mounted on a nearby house or car. Stereos, electronic organs, home intercom systems and other devices can react to nearby radio transmitters and will function as radio receivers. Cordless telephones use radio frequencies and have no protection from interference. If you are experiencing interference on your cordless phone, you should contact the manufacturer for assistance.

### Electrical Interference

Electrical interference appears on the audio and video portion of television programming. There are various patterns; the entire screen may be covered with rolling horizontal lines, bars on the TV screen or a series of diagonal dashed white lines. Short bursts of interference may be caused by hair dryers, sewing machines, electric drills, doorbell transformers and garage door openers. If the pattern is on continuously, it may be caused by equipment that is in use full time, such as aquarium heaters and fluorescent lighting. Interference caused by your power company's electrical equipment is normally continuous and your power company should be notified.

A simple method of determining the location of electrical interference is by using a portable AM radio tuned to a quiet frequency at the lower end of the dial. If you hear static or a buzzing sound, check to see if it corresponds with the interference to your equipment. The closer you get to the source of the interference, the more intense the static will be.

### Electrical Interference (cont'd.)

If you cannot locate the interference source in your own house, check with your neighbors to see if they also receive interference. The house that has the worst interference will often be the source of the interference.

If you can determine that the electrical interference is not caused by any device in your home or a neighbor's home served by the same transformer, contact the customer service department of your local power company. Most power companies will investigate the problem and take steps to correct it.

The manufacturer of your home electronics equipment is in the best position to offer assistance in resolving your interference problems. You can usually find information about the manufacturer of your equipment on the Internet. The dealer who sold you the equipment should also be able to provide contact information for the manufacturer.

### Filing a Complaint with the FCC

If you cannot locate the source of the interference and the problem continues, you can file a complaint with the Federal Communications Commission (FCC), which has established rules to reduce interference. There is no charge for filing a complaint. You can file your complaint using our online complaint form found at [www.fcc.gov/complaints](http://www.fcc.gov/complaints). You can also file your complaint with the FCC's Consumer Center by calling 1-888-CALL-FCC (1-888-225-5322) voice or 1-888-TELL-FCC (1-888-835-5322) TTY; faxing 1-866-418-0232; or writing to:

Federal Communications Commission  
Consumer & Governmental Affairs Bureau  
Consumer Inquiries and Complaints Division  
445 12th Street, SW  
Washington, D.C. 20554.

(More)  
→



## What to Include in Your Complaint

The best way to provide all the information the FCC needs to process your complaint is to thoroughly complete the online complaint form. When you open the online complaint form, you will be asked a series of questions that will take you to the particular section of the form you need to complete. If you do not use the online complaint form, your complaint should indicate the following:

- your name, address, email address and phone number where you can be reached;
- the type of company you are complaining about (telephone, wireless, Internet access provider, TV or radio station, cable or satellite provider); and
- any additional details of your complaint, including time, date and nature of the conduct or activity you are complaining about and identifying information for any companies, organizations or individuals involved.

## For More Information

For information about other telecommunications issues, visit the FCC's Consumer & Governmental Affairs Bureau website at [www.fcc.gov/consumer-governmental-affairs-bureau](http://www.fcc.gov/consumer-governmental-affairs-bureau), or contact the FCC's Consumer Center using the information provided for filing a complaint.

###

*For this or any other consumer publication in an alternative format (electronic ASCII text, Braille, large print or audio), please write or call us at the address or phone number below, or send an email to [FCC504@fcc.gov](mailto:FCC504@fcc.gov).*

*To receive information on this and other FCC consumer topics through the Commission's electronic subscriber service, visit [www.fcc.gov/cgb/contacts/](http://www.fcc.gov/cgb/contacts/).*

*This fact sheet is for consumer education purposes only and is not intended to affect any proceedings or cases involving this subject matter or related issues.*

